
FORM NO. 3321–802

TORO®

MODEL NO. 04482–90001 & UP
MODEL NO. 04483–90001 & UP

PARTS CATALOG

8 & 11 BLADE SPA CUTTING UNIT
GREENSMASTER® 3200



T–2189–6

ROLLERS & BEDBAR ASSSEMBLY


Ref. No.	Part No.	Description	No. Used
1	94–6389	Roller–Wiehle	1
2	93–2511	Bedbar	1
3	33113–012	Screw–HH	2
4	94–8170	Bracket–Front	2
5	95–1618	Bolt–Shoulder	1
6	93–7502	Bushing–Flanged	2
7	93–2512	Hub–Pivot LH	1
8	33024–00	Nut–Lock	8
9	93–7501	Bushing	2
11	94–3489	Screw–HHF	1
12	33124–025	Screw–Carriage	4
13	93–2518	Housing–Pivot	1
14	93–2545	Screw–Pivot	2
15	99–8168	Collar–Height–of–Cut	2
16	93–2891	Bushing–Plastic	2
17	94–8169	Decal–Bracket Position	2
18	33113–008	Screw–HH	2

Ref. No.	Part No.	Description	No. Used
19	93–2522	Arm–Spring	1
20	93–2550	Adjustor	1
21	95–1633	Adjuster–Height–of–Cut	2
22	33125–025	Screw–Carriage	4
23	33025–00	Nut–Lock	4
26	93–2513	Hub–Pivot. RH	1
27	3256–82	Washer–Flat	1
28	33104–020	Screw–HHF	1
29	93–7510	Ring–Quad	1
30	95–1617	Bolt–Eccentric	1
32	62–5510	Bushing–Rubber	2
33	52–2890	Bushing–Links, Steering	2
34	52–2920	Pivot–Bedbar	1
35	302–18	Fitting–Grease	1
36	77–0350	Washer–Thrust Nylon	2
37	257–5	Washer–Thrust	3

© The TORO Company – 1998
All Rights Reserved

TPS

Note: Quantity is for 1 Unit




ROLLERS & BEDBAR ASSEMBLY (Continued)

Ref. No.	Part No.	Description	No. Used
39	95–1638	Bracket–Height–of–Cut Adjustment	2
40	95–2913	Tube–Roller	1
41	33114–020	Screw–Hex. Hd.	2
43	93–2562	Spring–Compression	1
44	87–7510	Washer–Flat	2
45	3256–46	Washer–Flat	2
46	33004–00	Nut–Flange Lock	3
47	3296–5	Nut–Lock	2
48	32151–12	Ring–Retaining	2
49	94–2958	Stud–Ball (Used on old suspensions)	2
50	3254–6	Washer–Lock	2
51	93–2364	Bolt–Shoulder	2

Ref. No.	Part No.	Description	No. Used
52	93–4263	Bedknife–Tournament	1
*	93–4262	Bedknife–Microcut	1
*	93–4264	Bedknife–Low 1/8”	1
*	94–6392	Bedknife–High 3/16”	1
*	94–6393	Bedknife–Fairway	1
53	57–4910	Screw–Special	13
54	95–2912	Shaft	1
55	93–2559	Bearing	2
56	93–2525	Ring–Retaining	2
57	302–5	Fitting–Grease	4
58	93–2470	Shaft–Roller Wiehle	1
59	85–7190	Washer–Shield	2
60	85–9970	Bearing	2
*	94–8171	Asm–Wiehle Roller (Incl. Ref. #1 & 55–58)	1

*Not Illustrated

Note: Quantity is for 1 Cutting Unit.



REEL & SHIELDS ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	94–8039	Reel–8 Blade Standard	1
*	94–8037	Reel–11 Blade Standard	1
†*	98–2181	Reel–5 Blade Heavy Duty	1
†*	98–2182	Reel–8 Blade Heavy Duty	1
2	95–1634	Frame	1
3	33025–00	Nut–Lock	1
4	93–2463	Roller–Lift	1
5	93–2464	Spacer–Roller	1
6	33115–080	Screw–HH	1
7	94–8908	Seal–Grease	2
8	93–2489	Bearing	2
9	94–4543	Spring–Flat Wire	2
10	94–4545	Housing–Bearing	2
11	302–5	Fitting–Grease	2
12	93–2454	Nut–Taper	4
13	95–1642	Counterweight	1
14	3256–74	Washer–Flat	4
15	93–2569	Screw–HHF	4
16	95–0745	Screw–Tapered	4
17	33115–020	Screw–HHF	2

Ref. No.	Part No.	Description	No. Used
18	98–0645	Asm–Front Shield (Incl. Ref. #33–34)	1
19	33114–020	Screw–HH	2
20	99–4103	Asm–Rear Shield (Incl. Ref. #35)	1
21	33024–00	Nut–Lock	4
22	32121–123	Pin–Spring	2
25	98–2196	Rod–Shield	1
26	2410–30	Cap–Plastic	1
27	94–4544	Spacer–Bearing	1
28	32120–37	Ring–Retaining	1
29	94–4507	Coupler–Spline	1
30	3256–24	Washer	4
31	95–1636	Strip–Seal	1
33	94–1380	Clip–Spring Large	4
34	3269–33	Rivet–Pop	8
35	94–1392	Pad–Rubber	2
36	98–2167	Bolt–Shoulder	2
37	36–7260	Bar–Cut Off	1
38	32144–73	Screw–HWH	5

*Not Illustrated

†Optional

Note: Quantity is for 1 Cutting Unit.

3321–802

MAINTENANCE RECORD

Date								

Compliance with Radio Interference Regulations Certified.
Certifie Conforme au Reglement sur le Brouillage Radioelectrique.

Litho in U.S.A.