



Form No. 3423-466 Rev A

Count on it.

Parts Catalog

Water Seal Kit

**Workman® HDX and HDX-Auto Utility Vehicle
Cab Kit**

Model No. 137-1019



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.


For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Roof Top Console and Wiper Mount Assembly 4

Water Gutter, Inner Fender and Mount Assembly 6


Roof Top Console and Wiper Mount Assembly



Roof Top Console and Wiper Mount Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	136-2130	1	Seal-Mount, Wiper	10	32144-11	3	Screw-HWHTF
2	136-1973-03	1	Mount-Wiper	11	119-1065	8	Screw-HWH
3	137-1018-03	1	Mount-Console	12	3230-1	2	Bolt-CARR
4	126-3739	8	Nut-Retainer	13	104-8300	2	Nut-HF, NI
5	137-1313-03	1	Support-Roof	14	104-2408	4	Screw-HSBH
6	119-0872	8	Washer-Sealing, Bonded	15	32180-139	3	Mount-Tie Wrap, Magnetic
7	120-4654	8	Screw-HHF	16	3290-378	9	Tie-Cable
8	107-1013	4	Nut-Speed	17	104-7201	8	Nut-HF
9	136-1969	1	Console-Roof Top	18	137-1316	1	Seal-Trim

Water Gutter, Inner Fender and Mount Assembly



Water Gutter, Inner Fender and Mount Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	119-8615	2	Isolator-Rubber	19	137-1033	2	Seal-Cover
2	136-2151	2	Spacer-Mount	20	137-1031-03	1	Plate-Floor, RH
3	136-2146-03	1	Mount-RH	21	137-1032-03	1	Plate-Floor, LH
4	136-2147-03	1	Mount-LH	22	32104-95	8	Screw-HWH
5	3217-7	2	Nut-Hex	23	137-1314-03	1	Gutter
6	66-9302	2	Screw-HHF, Whiz	24	137-1315	1	Seal-Trim, Cam
7	137-1024-03	1	Plate-Adjust	25	138-2659	1	Fender-Inner
8	137-1021-03	1	Back-Plate	26	138-2660	2	Strap-Fender
9	3229-5	4	Screw-CARR	27	3234-4	6	Screw-HHF
10	104-7201	12	Nut-HF	28	138-2662	2	Bumper-Rubber
11	116-0559	1	Bolt-TAP	29	119-8952	2	Washer
12	32128-56	1	Nut-HF	30	3290-379	2	Tie-Cable
13	137-1023	1	Plate-Stop	31	3290-378	3	Tie-Cable
14	3234-46	2	Screw-HHF	32	138-2751	1	Fitting-Tee, Barb
15	114-0019	2	Washer-Plain	33	138-2704	1	Tube-Clear, 48 Inch
16	3296-25	2	Nut-Lock, NI	34	138-2705	1	Tube-Clear, 17 Inch
17	137-1025	1	Cover-Panel, Lower RH	35	138-2706	1	Tube-Clear, 13 Inch
18	137-1026	1	Cover-Panel, Lower LH	36	32180-139	3	Mount-Tie Wrap, Magnetic



Count on it.