




MODEL NO. 03857-90001 & UP
MODEL NO. 03858-90001 & UP
MODEL NO. 03859-90001 & UP

PARTS CATALOG


5/7/11 BLADE REELS REELMASTER® 6500D/6700D



T-1979-5

REEL & BEARING HOUSING ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	33105-060	Screw - HHF	2	7	93-9795	Housing - Bearing, LH (Incl. Ref. #27)	1
2	93-9794	Housing - Bearing, RH (Incl. Ref. #27)	1	8	93-9783	O-Ring (Shipped with Traction Unit)	10
3	93-2489	Bearing	2	9	32121-69	Pin - Roll	4
4	94-8908	Seal - Grease	2	10	95-2793	Nut - Bearing Adj.	1
5	94-2732	Insert - Threaded RH	1	11	94-4347	Weight - End (Shipped with Traction Unit)	3
*	94-2733	Insert - Threaded LH	1	12	93-7522	Screw - HH	2
6	94-4337	5 Blade Reel Assembly Model 03857 (Incl. Ref. #5)	1	13	93-3094	Plug - Cap	1
*	95-2770	7 Blade Reel Assembly Model 03858 (Incl. Ref. #5)	1	14	33105-030	Screw - HHF	4
*	94-4338	11 Blade Reel Assembly Model 03859 (Incl. Ref. #5)	1	15	302-5	Fitting - Grease, Straight	2
				16	33025-00	Nut - Lock	4
				17	93-3085	Asm. - Shaft, Magnet	1
				18	253-165	Seal - Outer	1
				19	93-2956	Bearing	1
				20	93-3080	Weight - Housing, End	1




T-1979-5

REEL & BEARING HOUSING ASSEMBLY (Continued)

Ref. No.	Part No.	Description	No. Used
21	3256-23	Washer - Flat	1
22	33024-00	Nut - Lock	1
23	93-3088	Clamp (Shipped with Traction Unit)	2
24	33103-020	Screw - HH (Shipped with Traction Unit)	2


Ref. No.	Part No.	Description	No. Used
25	94-6980	Sensor - Speed (Shipped with Traction Unit)	2
26	237-30	O-Ring (Shipped with Traction Unit)	2
27	93-2922	Ring - Bearing	2
28	93-8717	Plug	1
29	3245-42	Screw - Set	1



FRAME & BEDBAR ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	33104-020	Screw-HHF	3	27	98-3994	Bedknife-Standard	1
2	3256-82	Washer	1	*	93-9774	Bedknife	
3	93-7510	Ring-Quad	1			.5" (13 mm) Height of Cut (Optional)	1
4	33024-00	Nut-Lock	4	28	57-4910	Screw-Special	8
5	93-2513	Pivot Hub RH	1	29	32121-36	Pin-Roll	4
6	93-2981	Sideplate-RH	1	30	94-3489	Screw	1
7	98-7971	Reel Frame	1	31	33104-040	Screw-HHF	1
8	93-7501	Bushing Assembly	2	32	33004-00	Nut-Flange	3
9	93-7502	Bushing-Flange	2	33	93-2512	Pivot Hub LH	1
10	33094-00	Washer-Flat	4	34	33105-025	Screw-HHF	8
11	302-18	Fitting-Grease, Str.	1	35	93-2982	Sideplate-LH	1
14	52-2890	Bushing-Plastic	2	36	33025-00	Nut-Lock	8
15	57-5260	Pivot Screw Adj.	1	37	94-2738	Screw-Carriage	4
16	3296-62	Nut-Lock	1	39	99-5723	Rear Grass Shield	1
17	29-8910	Washer	2	40	98-7978	Asm.-Grass Shield (Incl. Ref. #42)	1
18	95-0772	Spring-Compression	1	41	93-9759	Deflector - Grass Shield	5
20	95-8752	Arm-Spring	1	42	93-6688	Decal-Danger	1
23	95-2762	Bedbar Adjuster Assy.	1	42	94-4584	Decal-Danger (Japanese)	1
24	93-2959	Spacer-Adjuster	1	43	700382	Rivet	18
25	93-2892	Pivot-Bedbar, Man. Adj.	1	45	99-5725	Flap-Side	2
26	95-3458	Bedbar	1	47	62-5510	Bushing	2
				48	99-8660	Bracket-Stop	1

*Not Illustrated




T-2840-4

ROLLERS & CARRIER FRAME ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	61-0910	Bracket - Angle	2
2	33025-00	Nut - Lock	6
3	32120-62	Snap Ring	4
4	93-2921	Spring - Compression HOC	2
5	93-2902	Support - HOC, Rear	2
6	94-4344	Spacer	2
7	93-2906	Pin - HOC	2
8	3290-467	Pin - Cotter, Hair	2
9	93-7500	Screw - HH	2
10	93-7509	Washer - Special	2
11	99-5722	Bracket - HOC, Rear	2
12	33125-030	Screw - Carriage	2
13	93-9757	Screw - HH	2
14	253-70	Seal - Oil	4
15	93-1252	Seal - Outer	4
16	93-1251	Seal - Inner	4
17	109966	Bearing - Ball	4
18	93-3007	Seal - Oil	4
19	302-5	Fitting - Grease, Straight	4
20	99-5718	Tube Assy. - Rear Roller	1
21	99-5717	Shaft - Rear Roller	1
24	33115-016	Screw - HH	4
26	93-2931	Washer - Roller	4
28	94-1291	Bushing - Special	2
29	98-7972	Carrier Frame Assembly	1

Ref. No.	Part No.	Description	No. Used
30	93-2877	Bushing	2
31	98-1885	Spacer - Frame	2
32	94-2701	Washer - Hardened	2
33	94-2702	Bolt	2
34	94-4336	Roller - Wiehle	1
35	94-4329	Shaft - Wiehle Roller	1
36	33105-025	Screw - HHF	4
37	94-4307	Nut - Lock	2
38	302-60	Fitting - Grease, 90°	1
40	33114-025	Screw - HH	2
41	95-2783	Support Rod Assembly	2
42	95-2789	Nut - Special	2
43	95-7733	Bracket - HOC	2
44	95-2790	Nut - Special, Long	2
45	99-8663	Bracket - Spring	1
46	99-8661	Rod - Spring	1
47	92-7768	Spring - Compression	1
48	65-6390	Washer - Hardened	2
49	3218-5	Nut - Hex.	3
50	3296-39	Nut - Lock NI	3
51	3234-19	Screw - HHF	1
52	99-8664	Screw - Special	1
53	3296-23	Nut - Lock NI	1
54	99-8662	Tube - Spring	1
55	33035-00	Nut - Hex. Jam	4




T-2840-4

ROLLERS & CARRIER FRAME ASSEMBLY (Continued)

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
*	99-5720	Rear Roller Assembly (Incl. Ref. #3, 14-21 & 26)	1	*	98-7973	Carrier Frame Assembly (Incl. Ref. #28, 30 & 38)	1
*	94-4330	Wiehle Roller Assembly (Incl. Ref. #3, 14-19, 26 & 34-35)	1	*	99-3503	Tool-Angle Locator	1

*Not Illustrated



T-3209-1

OPTIONAL FRONT ROLLER


Ref. No.	Part No.	Description	No. Used
1		Roller Tube Assembly	1
2	302-5	Fitting-Grease	2
3	93-2887	Shaft-Roller	1
4	93-3007	Seal-Oil	2
5	109966	Bearing-Ball	2
6	93-1251	Seal-Inner	2

Ref. No.	Part No.	Description	No. Used
7	93-1252	Seal-Outer	2
8	253-70	Seal-Oil	2
9	32120-62	Ring-Retaining	2
10	93-2931	Washer-Roller	2
*	93-3040	Roller Assembly (Incl. Ref. #1-10)	1

*Not Illustrated

SPECIAL TOOLS


GAUGE BAR ASSEMBLY NO. 98-1852



Ref. No.	Part No.	Description	No. Used
1	32122-54	Screw – Mach. Slot. Hd.	2
2	98-7976	Decal	1
3		Bar	1
4	32103-3	Nut – Wing	2

T-2933-1


BACKLAPPING BRUSH ASSEMBLY NO. *TOR299100



Ref. No.	Part No.	Description	No. Used
1	12-9140	Decal	1
2	2410-18	Plug	1
3	29-9080	Handle	1
4	29-9090	Hose – Handle	1
5	36-4310	Brush	1

T-0731-1


BEDKNIFE SCREW TOOL NO. *TOR510880



Ref. No.	Part No.	Description	No. Used
1		Tool – Bedknife Screw	1

T-0729-1

REEL DRIVE SHAFT NO. *TOR4074




Ref. No.	Part No.	Description	No. Used
1		Shaft – Reel Drive	1

T-2383-2

*Obtain these items directly from OTC 2013 4th St. Owatonna, MN. 55060 1-800-533-0492
(in Minnesota and Canada 1-507-455-7050) Fax. 507-455-7011.

SPECIAL TOOLS

CUTTING UNIT TOOL KIT NO. *TOR4070



T-2676

Ref. No.	Part No.	Description	No. Used
1	*TOR 4064	Spanner Wrench	1
	*TOR4065	Inner Oil Seal Installer	1
	*TOR4066	Bearing Installer	1
	*TOR4067	Shaft Support Tool	1
	*TOR4068	Inner Seal Installer	1
	*TOR4069	Outer Seal Installer	1
	*TOR4071	Outer Oil Seal Installer	1
	*TOR4072	Reel Motor Shaft Seal Protector	1
	*TOR4073	Handle	1
	*TOR4074	Spline Insert Tool	1

*Obtain these items directly from OTC 2013 4th St. Owatonna, MN. 55060 1-800-533-0492
(in Minnesota and Canada 1-507-455-7050) Fax. 507-455-7011.