



TORO®**MODEL NO. 53011-895001 & UP****PARTS
CATALOG****PROLINE STRING TRIMMER**
Commercial 26cc

C-2640

CLUTCH AND HANDLE ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	M214592	Bearing Case	1	14	M089738	Bolt	1
2	M214161	Bearing	2	16	M219032	Loop Handle	1
3	M054676	Snap Ring	1	17	M213171	Packing	1
4	M214162	Buffer	1	18	M092088	Screw	4
5	M214163	Washer	1	19	M081027	Nut	4
6	M092033	Screw	4	20	M817002	Bolt	4
7	M214593	Driveshaft Tube Adapter	1	21	M213444	Throttle Cable	1
8	M092561	Bolt	1	22	M213548	Plastic Tube	1
9	M054677	Clutch Drum	1	*	M215512	Clutch Case Assembly (Incl. Ref. #1-7)	1
10	M221434	Shaft Grip	1				
11	M221465	Throttle Trigger	1	*	95-6122	Safety Glasses	1
12	M214083	Outer Guide	1				
13	M054691	Hanging Bracket Assembly (Incl. Ref. #14)	1				

* Not Illustrated




C-2636

HEAD, SHAFT AND SHIELD ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	M219268	Driveshaft Assembly	1
2	M221753	Driveshaft Tube Assembly (Incl. Ref. # 14,15)	1
5	M221436	Safety Cover Assembly (Incl. Ref. # 6-13)	1
6	M221403	Safety Cover	1
8	M221438	String Cutter	1
9	M092560	Bolt	2
10	M012501	Spring Washer	2
11	M081027	Nut	2
12	M221469	Plate	1
13	M092579	Bolt	4

Ref. No.	Part No.	Description	No. Used
14	M221502	Decal - Caution	1
15	M221501	Decal - Caution	1
16	M221500	Decal - Toro	1
17	99-8504	Cap	1
18	99-8505	Spool with Line	1
19	99-8506	Stud-Mounting	1
20	99-8507	Base-Indexing	
*	99-8508	5" Head Assembly (Incl. Ref. #17-20)	1
*	M221437	String Cutter Assembly (Incl. Ref. #8-11)	1

* Not Illustrated




C-2637

GEARCASE ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
2	M219077	Gearcase	1	11	M140268	Bearing	1
3	M089884	Bolt	1	12	M140269	Snap Ring	1
4	M210554	Bearing	1	13	M140270	Snap Ring	1
5	M210555	Gear	1	14	M092561	Bolt	1
6	M215762	Blade Shaft	1	15	M221467	Boss Adapter	1
7	M212999	Bearing	1	16	M221998	Bolt	1
8	M055185	Snap Ring	1	17	M089737	Bolt	1
9	M215544	Pinion Gear	1	*	M221435	Gearcase Assembly	1
10	M210560	Bearing	1				

* Not Illustrated

ENGINE ASSEMBLY



C-2641


ENGINE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
2	M264989	Cylinder	1
3	M265001	Gasket	1
4	M261250	Cap Screw	10
5	M265802	Insulator	1
6	M265470	Air Duct	1
7	M261171	Gasket	2
8	M265924	Cap Screw	1
9	M264993	Muffler Assembly (Incl. Ref. #10-15)	1
10	M265063	Muffler	1
11	M264864	Plate	1
12	M264835	Screen	1
13	M264837	Gasket	1
14	M264836	Tail	1
15	M265107	Cap Screw	4
16	M265133	Gasket	1
17	M266491	Cylinder Cover	1
18	M265742	Knob	1
19	M265004	Muffler Cover	1
20	M264807	Cap Screw	3
21	M265006	Crankcase	1
22	M261491	Bearing	2
23	M261492	Oil Seal	1
24	M261386	Oil Seal	1
25	M055185	Snap Ring	1
26	M261612	Cap Screw	3
27	M265012	Piston	1
28	M261496	Piston Ring	2
29	M261497	Piston Pin	1
30	M261037	Bearing – Needle	1
31	M261576	Clip – Piston	2
32	M265197	Crankcase – Connector Rod Assembly	1
34	M264026	Clutch Shoe	2
35	M264028	Spring – Clutch	1
36	M264505	Bolt	2
37	M261189	Washer	2
38	M261777	Wave Washer	2

Ref. No.	Part No.	Description	No. Used
39	M266158	Fan Cover	1
41	M261356	Rotor – Fan	1
42	M261301	Ignition Coil Assembly (Incl. Ref. #43-49)	1
43	M261302	Coil	1
45	M261071	Spark Plug Wire	1
46	M261074	Plug Boot	1
47	M261075	Connector	1
48	M261072	Cap	1
49	M261073	Insulator	1
50	M261772	Wire – Coil Ground	2
51	M261076	Woodruff Key	1
52	M261417	Nut – Rotor	1
53	M261078	Spacer	2
54	M261256	Cap Screw	2
55	M261200	Spark Plug (NGK BPM6Y)	1
56	M261202	Grommet	1
57	M264588	Clamp	1
59	M265019	Recoil Assembly (Incl. Ref. #60-65)	1
61	M261725	Starter Grip	1
62	M261724	Starter Rope	1
63	M261721	Spiral Spring	1
64	M261720	Pulley	1
65	M262922	Screw	1
67	M263477	Pawl	1
68	M261728	Return Spring	1
69	M263476	Pawl Case	1
70	M264999	Plate	1
71	M266291	Decal – Warning	1
72	M266025	Stand	1
73	M266190	Screw	1
74	M266323	Decal – Toro	1
75	M266211	Decal – Toro (Round)	1
76	25-9150	Decal – Serial	1
*	M261910	Liquid Gasket	1
*	M266204	Engine Assembly	1

* Not Illustrated

CARBURETOR AND FUEL ASSEMBLY



CARBURETOR AND FUEL ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	M266150	Carburetor Assembly (Incl. Ref. # 2-19)	1
2	M261871	O-Ring	1
3	M266462	Main Jet	1
4	M262995	Gasket	1
5	M262994	Diaphragm	1
6	M264155	Pump Body	1
7	M262993	Gasket	1
8	M261873	Diaphragm	1
9	M262991	Purge Body	1
10	M261874	Primer Bulb	1
11	M262992	Cover Plate	1
12	M262996	Screw	4
13	M261876	E-Ring	1
14	M261658	Swivel	1
15	M261875	Screw	2
16	M264677	Bracket	1
17	M261878	Nut	1
18	M263994	Adapter	1
19	M261657	Packing	1
20	M261864	Gasket	1
22	M263005	Housing	1

Ref. No.	Part No.	Description	No. Used
23	M262998	Cover	1
24	M263006	Element	1
25	M263000	Washer	1
26	M263001	Sleeve	2
27	M266423	Choke Valve	1
28	M263003	Plate	1
29	M264016	Cap Screw	2
31	M265032	Fuel Tank	1
32	M264784	Fuel Tank Cap Assembly (Incl. Ref. # 34)	1
33	M261105	Gasket	1
34	M261696	Breather Assembly	1
36	M265867	Fuel Pipe Assembly (Incl. Ref. # 38-40)	1
37	M265869	Grommet	1
38	M261690	Fuel Pipe	1
39	M263038	Return Pipe	1
40	M261797	Fuel Filter Assembly	1
41	M261117	Clip	2
42	M264318	Pad	2
43	M263824	Pad	1

TORO PART NUMBER INDEX

Part No.	Description	Pg. No.	Ref. No.	Qty.	Part No.	Description	Pg. No.	Ref. No.	Qty.
M012501	Spring Washer	2	10	2	M261386	Oil Seal	5	24	1
M054676	Snap Ring	1	3	1	M261417	Nut – Rotor	5	52	1
M054677	Clutch Drum	1	9	1	M261491	Bearing	5	22	2
M054691	Hanging Bracket Assembly	1	13	1	M261492	Oil Seal	5	23	1
M055185	Snap Ring	3	8	1	M261496	Piston Ring	5	28	2
M055185	Snap Ring	5	25	1	M261497	Piston Pin	5	29	1
M081027	Nut	2	11	2	M261576	Clip – Piston	5	31	2
M081027	Nut	1	19	4	M261612	Cap Screw	5	26	3
M089737	Bolt	3	17	1	M261657	Packing	7	19	1
M089738	Bolt	1	14	1	M261658	Swivel	7	14	1
M089884	Bolt	3	3	1	M261690	Fuel Pipe	7	38	1
M092033	Screw	1	6	4	M261696	Breather Assembly	7	34	1
M092088	Screw	1	18	4	M261720	Pulley	5	64	1
M092560	Bolt	2	9	2	M261721	Spiral Spring	5	63	1
M092561	Bolt	1	8	1	M261724	Starter Rope	5	62	1
M092561	Bolt	3	14	1	M261725	Starter Grip	5	61	1
M092579	Bolt	2	13	4	M261728	Return Spring	5	68	1
M140268	Bearing	3	11	1	M261772	Wire – Coil Ground	5	50	2
M140269	Snap Ring	3	12	1	M261777	Wave Washer	5	38	2
M140270	Snap Ring	3	13	1	M261797	Fuel Filter Assembly	7	40	1
M210554	Bearing	3	4	1	M261864	Gasket	7	20	1
M210555	Gear	3	5	1	M261871	O–Ring	7	2	1
M210560	Bearing	3	10	1	M261873	Diaphragm	7	8	1
M212999	Bearing	3	7	1	M261874	Primer Bulb	7	10	1
M213171	Packing	1	17	1	M261875	Screw	7	15	2
M213444	Throttle Cable	1	21	1	M261876	E–Ring	7	13	1
M213548	Plastic Tube	1	22	1	M261878	Nut	7	17	1
M214083	Outer Guide	1	12	1	M261910	Liquid Gasket	5	*	1
M214161	Bearing	1	2	2	M262922	Screw	5	65	1
M214162	Buffer	1	4	1	M262991	Purge Body	7	9	1
M214163	Washer	1	5	1	M262992	Cover Plate	7	11	1
M214592	Bearing Case	1	1	1	M262993	Gasket	7	7	1
M214593	Driveshaft Tube Adapter	1	7	1	M262994	Diaphragm	7	5	1
M215512	Clutch Case Assembly	1	*	1	M262995	Gasket	7	4	1
M215544	Pinion Gear	3	9	1	M262996	Screw	7	12	4
M215762	Blade Shaft	3	6	1	M262998	Cover	7	23	1
M219032	Loop Handle	1	16	1	M263000	Washer	7	25	1
M219077	Gearcase	3	2	1	M263001	Sleeve	7	26	2
M219268	Driveshaft Assembly	2	1	1	M263003	Plate	7	28	1
M221403	Safety Cover	2	6	1	M263005	Housing	7	22	1
M221434	Shaft Grip	1	10	1	M263006	Element	7	24	1
M221435	Gearcase Assembly	3	*	1	M263038	Return Pipe	7	39	1
M221436	Safety Cover Assembly	2	5	1	M263476	Pawl Case	5	69	1
M221437	String Cutter Assembly	2	*	1	M263477	Pawl	5	67	1
M221438	String Cutter	2	8	1	M263824	Pad	7	43	1
M221465	Throttle Trigger	1	11	1	M263994	Adapter	7	18	1
M221467	Boss Adapter	3	15	1	M264016	Cap Screw	7	29	2
M221469	Plate	2	12	1	M264026	Clutch Shoe	5	34	2
M221500	Decal – Toro	2	16	1	M264028	Spring – Clutch	5	35	1
M221501	Decal – Caution	2	15	1	M264155	Pump Body	7	6	1
M221502	Decal – Caution	2	14	1	M264318	Pad	7	42	2
M221753	Driveshaft Tube Assembly	2	2	1	M264505	Bolt	5	36	2
M221998	Bolt	3	16	1	M264588	Clamp	5	57	1
M261037	Bearing – Needle	5	30	1	M264677	Bracket	7	16	1
M261071	Spark Plug Wire	5	45	1	M264784	Fuel Tank Cap Assembly	7	32	1
M261072	Cap	5	48	1	M264807	Cap Screw	5	20	3
M261073	Insulator	5	49	1	M264835	Screen	5	12	1
M261074	Plug Boot	5	46	1	M264836	Tail	5	14	1
M261075	Connector	5	47	1	M264837	Gasket	5	13	1
M261076	Woodruff Key	5	51	1	M264864	Plate	5	11	1
M261078	Spacer	5	53	2	M264989	Cylinder	5	2	1
M261105	Gasket	7	33	1	M264993	Muffler Assembly	5	9	1
M261117	Clip	7	41	2	M264999	Plate	5	70	1
M261171	Gasket	5	7	2	M265001	Gasket	5	3	1
M261189	Washer	5	37	2	M265004	Muffler Cover	5	19	1
M261200	Spark Plug (NGK BPM6Y)	5	55	1	M265006	Crankcase	5	21	1
M261202	Grommet	5	56	1	M265012	Piston	5	27	1
M261250	Cap Screw	5	4	10	M265019	Recoil Assembly	5	59	1
M261256	Cap Screw	5	54	2	M265032	Fuel Tank	7	31	1
M261301	Ignition Coil Assembly	5	42	1	M265063	Muffler	5	10	1
M261302	Coil	5	43	1	M265107	Cap Screw	5	15	4
M261356	Rotor – Fan	5	41	1	M265133	Gasket	5	16	1

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

3322-366

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
M265197	Crankcase – Connector	5 32 1	M266462	Main Jet	7 3 1
M265470	Air Duct	5 6 1	M266491	Cylinder Cover	5 17 1
M265742	Knob	5 18 1	M817002	Bolt	1 20 4
M265802	Insulator	5 5 1	25-9150	Decal – Serial	5 76 1
M265867	Fuel Pipe Assembly	7 36 1	95-6122	Safety Glasses	1 * 1
M265869	Grommet	7 37 1	99-8504	Cap	2 17 1
M265924	Cap Screw	5 8 1	99-8505	Spool with Line	2 18 1
M266025	Stand	5 72 1	99-8506	Stud–Mounting	2 19 1
M266150	Carburetor Assembly	7 1 1	99-8507	Base–Indexing	2 20
M266158	Fan Cover	5 39 1	99-8508	5" Head Assembly	2 * 1
M266190	Screw	5 73 1	OPTIONAL EQUIPMENT		
M266204	Engine Assembly	5 * 1			
M266211	Decal – Toro (Round)	5 75 1			
M266291	Decal – Warning	5 71 1			
M266323	Decal – Toro	5 74 1	Single Strap Harness	46-2951	
M266423	Choke Valve	7 27 1	Deluxe Strap Harness	46-2961	
			Original Strap Harness	M220952	

PRODUCT CHANGES

In an effort to make improvements available to TORO owners as quickly as possible, minor changes are incorporated into Toro’s products from time to time that do not become immediately shown in the Parts Catalog. If such a change has been made in your unit, which is not reflected in your manual, see your TORO Distributor or his Authorized TORO Service Dealer for information and part numbers.

IDENTIFICATION AND ORDERING

MODEL AND SERIAL NUMBERS

The Lawnmower has two identification numbers; a model number and a serial number. The two numbers are stamped on a decal which is located on the rear of the housing. In any correspondence concerning the lawnmower, supply model and serial numbers to assure that correct information and replacement parts are obtained.

To order replacement parts from an Authorized TORO Service Dealer, supply the following information:

- 1. Model and serial number of the lawnmower.
- 2. Part number, description, and the quantity of part(s) desired.

NOTE: Do not order by reference number if a parts catalog is being used; use the PART NUMBER.

COUNTRIES OTHER THAN THE UNITED STATES OR CANADA

Customers who have purchased TORO products exported from the United States or Canada should contact their Toro Distributor (Dealer) to obtain guarantee policies for your country, province or state. If for any

reason you are dissatisfied with your Distributor’s service or have difficulty obtaining guarantee information, contact the TORO importer. If all other remedies fail, you may contact us at The Toro Company.

MAINTENANCE RECORD

Date								

[illegible]

MAINTENANCE RECORD

[illegible]

Compliance with Radio Interference Regulations Certified.
Certifie Conforme au Reglement sur le Brouillage Radioelectrique.

Litho in U.S.A.