




MODEL NO. 53002-895001 & UP

PARTS CATALOG

PROLINE STRING TRIMMER Industrial 26cc




C-2640

CLUTCH AND HANDLE ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	M214592	Bearing Case	1	14	M089738	Bolt	1
2	M214161	Bearing	2	16	M219032	Loop Handle	1
3	M054676	Snap Ring	1	17	M213171	Packing	1
4	M214162	Buffer	1	18	M092088	Screw	4
5	M214163	Washer	1	19	M081027	Nut	4
6	M092033	Screw	4	20	M817002	Bolt	4
7	M214593	Driveshaft Tube Adapter	1	21	M213444	Throttle Cable	1
8	M092561	Bolt	1	22	M213548	Plastic Tube	1
9	M054677	Clutch Drum	1	*	M215512	Clutch Case Assembly (Incl. Ref. #1-7)	1
10	M221434	Shaft Grip	1	*	95-6122	Safety Glasses	1
11	M221465	Throttle Trigger	1				
12	M214083	Outer Guide	1				
13	M054691	Hanging Bracket Assembly (Incl. Ref. #14)	1				

* Not Illustrated




C-2636

HEAD, SHAFT AND SHIELD ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	M219268	Driveshaft Assembly	1
2	M221753	Driveshaft Tube Assembly (Incl. Ref. # 14,15)	1
5	M221436	Safety Cover Assembly (Incl. Ref. # 6-13)	1
6	M221403	Safety Cover	1
8	M221438	String Cutter	1
9	M092560	Bolt	2
10	M012501	Spring Washer	2
11	M081027	Nut	2
12	M221469	Plate	1
13	M092579	Bolt	4

Ref. No.	Part No.	Description	No. Used
14	M221502	Decal - Caution	1
15	M221501	Decal - Caution	1
16	M221500	Decal - Toro	1
17	99-8504	Cap	1
18	99-8505	Spool with Line	1
19	99-8506	Stud - Mounting	1
20	99-8507	Base - Indexing	
*	99-8508	5" Head Assembly (Incl. Ref. #17-20)	1
*	M221437	String Cutter Assembly (Incl. Ref. #8-11)	1

* Not Illustrated




C-2637

GEARCASE ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
2	M219077	Gearcase	1	11	M140268	Bearing	1
3	M089884	Bolt	1	12	M140269	Snap Ring	1
4	M210554	Bearing	1	13	M140270	Snap Ring	1
5	M210555	Gear	1	14	M092561	Bolt	1
6	M215762	Blade Shaft	1	15	M221467	Boss Adapter	1
7	M212999	Bearing	1	16	M221998	Bolt	1
8	M055185	Snap Ring	1	17	M089737	Bolt	1
9	M215544	Pinion Gear	1	*	M221435	Gearcase Assembly	1
10	M210560	Bearing	1				

* Not Illustrated

ENGINE ASSEMBLY




ENGINE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
2	M261472	Cylinder	1
3	M262200	Gasket	1
4	M261250	Cap Screw	11
5	M266317	Insulator	1
6	M266124	Air Duct	1
7	M261171	Gasket	2
8	M265924	Cap Screw	2
9	M262438	Muffler Body	1
10	M261986	Deflector Plate	1
11	M261368	Deflector	1
12	M261968	Gasket	1
13	M261246	Cap Screw	2
14	M261607	Cap Screw	3
15	M262440	Muffler Cover	1
16	M262442	Muffler Trail	1
17	M262443	Spark Arrestor	1
18	M262446	Gasket	1
19	M263743	Washer	2
21	M266068	Top Cover	1
22	M261018	Knob	1
23	M261020	Spacer	1
24	M261734	Snap Ring	1
25	M261486	Crankcase	1
26	M261491	Bearing	2
27	M261492	Oil Seal	1
28	M261386	Oil Seal	1
29	M055185	Snap Ring	1
30	M261612	Cap Screw	3
31	M265012	Piston	1
32	M261496	Piston Ring	2
33	M261497	Piston Pin	1
34	M261037	Bearing – Needle	1
35	M261576	Clip – Piston	2
36	M265197	Crankshaft – Connector Rod Assembly	1
38	M264504	Clutch Shoe	2
39	M263614	Spring – Clutch	1
40	M261189	Washer	2

Ref. No.	Part No.	Description	No. Used
41	M261777	Wave Washer	2
42	M264505	Bolt	2
43	M266319	Fan Cover	1
45	M261356	Rotor – Fan	1
46	M261301	Ignition Coil Assembly (Incl. Ref. #47–53)	1
47	M261302	Coil	1
49	M261071	Spark Plug Wire	1
50	M261074	Plug Boot	1
51	M261075	Connector	1
52	M261072	Cap	1
53	M261073	Insulator	1
54	M261076	Woodruff Key	1
55	M261417	Nut – Rotor	1
56	M261078	Spacer	2
57	M261256	Cap Screw	2
58	M261200	Spark Plug (NGK BPM6Y)	1
59	M261772	Wire – Coil Ground	2
60	M261202	Grommet	1
62	M262039	Recoil Assembly (Incl. Ref. #63–70)	1
64	M261725	Starter Grip	1
65	M261724	Starter Rope	1
68	M261721	Spiral Spring	1
69	M261720	Pulley	1
70	M262922	Screw	1
72	M263477	Pawl	1
73	M261728	Return Spring	1
74	M263476	Pawl Case	1
75	M261257	Cap Screw	4
76	M266099	Stand	1
79	M261999	Cap Screw	2
80	M266322	Decal – Toro	1
81	M266211	Decal – Toro (Round)	1
82	25–9150	Decal – Serial	1
*	M261910	Liquid Gasket	1
*	M266237	Engine Assembly	1

* Not Illustrated

CARBURETOR AND FUEL ASSEMBLY



CARBURETOR AND FUEL ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	M266153	Carburetor Assembly (Incl. Ref. # 2-19)	1	26	M263984	Washer	1
2	M261871	O-Ring	1	27	M261660	Nut	1
3	M262120	Main Jet	1	28	M262720	Cap Screw	2
4	M262995	Gasket	1	30	M261598	Foam Element	1
5	M262994	Diaphragm	1	31	M261734	Snap Ring	1
6	M263739	Pump Body	1	32	M266493	Air Filter Cover	1
7	M262993	Gasket	1	33	M263129	Knob	1
8	M261873	Diaphragm	1	34	M261993	Screen	1
9	M262991	Purge Body	1	35	M261352	Decal	1
10	M261874	Primer Bulb	1	37	M266071	Fuel Tank	1
11	M262992	Cover Plate	1	38	M264784	Fuel Tank Cap Assembly (Incl. Ref. # 39)	1
12	M262996	Screw	4	39	M261105	Gasket	1
13	M261876	E-Ring	1	40	M261696	Breather Assembly	1
14	M261658	Swivel	1	42	M264031	Fuel Pipe Assembly (Incl. Ref. # 43-45)	1
15	M261875	Screw	2	43	M261115	Grommet	1
16	M264677	Bracket	1	44	M261690	Fuel Pipe	1
17	M261878	Nut	1	45	M263038	Return Pipe	1
18	M263994	Adapter	1	46	M261797	Fuel Filter Assembly	1
19	M261657	Packing	1	47	M261117	Clip	2
20	M261864	Gasket	1	48	M261118	Pad	2
22	M261594	Bracket	1	49	M261119	Pad	1
23	M266330	Choke Valve	1	50	M266291	Decal	1
24	M263097	Packing	1				
25	M261597	Bolt	1				

TORO PART NUMBER INDEX

Part No.	Description	Pg. No.	Ref. No.	Qty.	Part No.	Description	Pg. No.	Ref. No.	Qty.
M012501	Spring Washer	2	10	2	M261246	Cap Screw	5	13	2
M054676	Snap Ring	1	3	1	M261250	Cap Screw	5	4	11
M054677	Clutch Drum	1	9	1	M261256	Cap Screw	5	57	2
M054691	Hanging Bracket Assembly	1	13	1	M261257	Cap Screw	5	75	4
M055185	Snap Ring	3	8	1	M261301	Ignition Coil Assembly	5	46	1
M055185	Snap Ring	5	29	1	M261302	Coil	5	47	1
M081027	Nut	2	11	2	M261352	Decal	7	35	1
M081027	Nut	1	19	4	M261356	Rotor – Fan	5	45	1
M089737	Bolt	3	17	1	M261368	Deflector	5	11	1
M089738	Bolt	1	14	1	M261386	Oil Seal	5	28	1
M089884	Bolt	3	3	1	M261417	Nut – Rotor	5	55	1
M092033	Screw	1	6	4	M261472	Cylinder	5	2	1
M092088	Screw	1	18	4	M261486	Crankcase	5	25	1
M092560	Bolt	2	9	2	M261491	Bearing	5	26	2
M092561	Bolt	1	8	1	M261492	Oil Seal	5	27	1
M092561	Bolt	3	14	1	M261496	Piston Ring	5	32	2
M092579	Bolt	2	13	4	M261497	Piston Pin	5	33	1
M140268	Bearing	3	11	1	M261576	Clip – Piston	5	35	2
M140269	Snap Ring	3	12	1	M261594	Bracket	7	22	1
M140270	Snap Ring	3	13	1	M261597	Bolt	7	25	1
M210554	Bearing	3	4	1	M261598	Foam Element	7	30	1
M210555	Gear	3	5	1	M261607	Cap Screw	5	14	3
M210560	Bearing	3	10	1	M261612	Cap Screw	5	30	3
M212999	Bearing	3	7	1	M261657	Packing	7	19	1
M213171	Packing	1	17	1	M261658	Swivel	7	14	1
M213444	Throttle Cable	1	21	1	M261660	Nut	7	27	1
M213548	Plastic Tube	1	22	1	M261690	Fuel Pipe	7	44	1
M214083	Outer Guide	1	12	1	M261696	Breather Assembly	7	40	1
M214161	Bearing	1	2	2	M261720	Pulley	5	69	1
M214162	Buffer	1	4	1	M261721	Spiral Spring	5	68	1
M214163	Washer	1	5	1	M261724	Starter Rope	5	65	1
M214592	Bearing Case	1	1	1	M261725	Starter Grip	5	64	1
M214593	Driveshaft Tube Adapter	1	7	1	M261728	Return Spring	5	73	1
M215512	Clutch Case Assembly	1	*	1	M261734	Snap Ring	5	24	1
M215544	Pinion Gear	3	9	1	M261734	Snap Ring	7	31	1
M215762	Blade Shaft	3	6	1	M261772	Wire – Coil Ground	5	59	2
M219032	Loop Handle	1	16	1	M261777	Wave Washer	5	41	2
M219077	Gearcase	3	2	1	M261797	Fuel Filter Assembly	7	46	1
M219268	Driveshaft Assembly	2	1	1	M261864	Gasket	7	20	1
M221403	Safety Cover	2	6	1	M261871	O–Ring	7	2	1
M221434	Shaft Grip	1	10	1	M261873	Diaphragm	7	8	1
M221435	Gearcase Assembly	3	*	1	M261874	Primer Bulb	7	10	1
M221436	Safety Cover Assembly	2	5	1	M261875	Screw	7	15	2
M221437	String Cutter Assembly	2	*	1	M261876	E–Ring	7	13	1
M221438	String Cutter	2	8	1	M261878	Nut	7	17	1
M221465	Throttle Trigger	1	11	1	M261910	Liquid Gasket	5	*	1
M221467	Boss Adapter	3	15	1	M261968	Gasket	5	12	1
M221469	Plate	2	12	1	M261986	Deflector Plate	5	10	1
M221500	Decal – Toro	2	16	1	M261993	Screen	7	34	1
M221501	Decal – Caution	2	15	1	M261999	Cap Screw	5	79	2
M221502	Decal – Caution	2	14	1	M262039	Recoil Assembly	5	62	1
M221753	Driveshaft Tube Assembly	2	2	1	M262120	Main Jet	7	3	1
M221998	Bolt	3	16	1	M262200	Gasket	5	3	1
M261018	Knob	5	22	1	M262438	Muffler Body	5	9	1
M261020	Spacer	5	23	1	M262440	Muffler Cover	5	15	1
M261037	Bearing – Needle	5	34	1	M262442	Muffler Trail	5	16	1
M261071	Spark Plug Wire	5	49	1	M262443	Spark Arrestor	5	17	1
M261072	Cap	5	52	1	M262446	Gasket	5	18	1
M261073	Insulator	5	53	1	M262720	Cap Screw	7	28	2
M261074	Plug Boot	5	50	1	M262922	Screw	5	70	1
M261075	Connector	5	51	1	M262991	Purge Body	7	9	1
M261076	Woodruff Key	5	54	1	M262992	Cover Plate	7	11	1
M261078	Spacer	5	56	2	M262993	Gasket	7	7	1
M261105	Gasket	7	39	1	M262994	Diaphragm	7	5	1
M261115	Grommet	7	43	1	M262995	Gasket	7	4	1
M261117	Clip	7	47	2	M262996	Screw	7	12	4
M261118	Pad	7	48	2	M263038	Return Pipe	7	45	1
M261119	Pad	7	49	1	M263097	Packing	7	24	1
M261171	Gasket	5	7	2	M263129	Knob	7	33	1
M261189	Washer	5	40	2	M263476	Pawl Case	5	74	1
M261200	Spark Plug (NGK BPM6Y)	5	58	1	M263477	Pawl	5	72	1
M261202	Grommet	5	60	1	M263614	Spring – Clutch	5	39	1

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

3322-367

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
M263739	Pump Body	7 6 1	M266317	Insulator	5 5 1
M263743	Washer	5 19 2	M266319	Fan Cover	5 43 1
M263984	Washer	7 26 1	M266322	Decal – Toro	5 80 1
M263994	Adapter	7 18 1	M266330	Choke Valve	7 23 1
M264031	Fuel Pipe Assembly	7 42 1	M266493	Air Filter Cover	7 32 1
M264504	Clutch Shoe	5 38 2	M817002	Bolt	1 20 4
M264505	Bolt	5 42 2	25-9150	Decal – Serial	5 82 1
M264677	Bracket	7 16 1	95-6122	Safety Glasses	1 * 1
M264784	Fuel Tank Cap Assembly	7 38 1	99-8504	Cap	2 17 1
M265012	Piston	5 31 1	99-8505	Spool with Line	2 18 1
M265197	Crankshaft – Connector	5 36 1	99-8506	Stud–Mounting	2 19 1
M265924	Cap Screw	5 8 2	99-8507	Base–Indexing	2 20
M266068	Top Cover	5 21 1	99-8508	5" Head Assembly	2 * 1
M266071	Fuel Tank	7 37 1			
M266099	Stand	5 76 1			
M266124	Air Duct	5 6 1			
M266153	Carburetor Assembly	7 1 1			
M266211	Decal – Toro (Round)	5 81 1			
M266237	Engine Assembly	5 * 1			
M266291	Decal	7 50 1			

OPTIONAL EQUIPMENT

Brushcutter Accessory Kit	53050
Single Strap Harness	46-2951
Deluxe Strap Harness	46-2961
Original Strap Harness	M220952

PRODUCT CHANGES

In an effort to make improvements available to TORO owners as quickly as possible, minor changes are incorporated into Toro's products from time to time that do not become immediately shown in the Parts Catalog. If such a change has been made in your unit, which is not reflected in your manual, see your TORO Distributor or his Authorized TORO Service Dealer for information and part numbers.

IDENTIFICATION AND ORDERING

MODEL AND SERIAL NUMBERS

The Lawnmower has two identification numbers; a model number and a serial number. The two numbers are stamped on a decal which is located on the rear of the housing. In any correspondence concerning the lawnmower, supply model and serial numbers to assure that correct information and replacement parts are obtained.

To order replacement parts from an Authorized TORO Service Dealer, supply the following information:

1. Model and serial number of the lawnmower.
2. Part number, description, and the quantity of part(s) desired.

NOTE: Do not order by reference number if a parts catalog is being used; use the PART NUMBER.

COUNTRIES OTHER THAN THE UNITED STATES OR CANADA

Customers who have purchased TORO products exported from the United States or Canada should contact their Toro Distributor (Dealer) to obtain guarantee policies for your country, province or state. If for any

reason you are dissatisfied with your Distributor's service or have difficulty obtaining guarantee information, contact the TORO importer. If all other remedies fail, you may contact us at The Toro Company.

MAINTENANCE RECORD

[illegible]

[illegible]

MAINTENANCE RECORD

[illegible]

Compliance with Radio Interference Regulations Certified.
Certifie Conforme au Reglement sur le Brouillage Radioelectrique.

Litho in U.S.A.