



**Count on it.**

# Parts Catalog

## **Z Master® Professional 5000 Series Riding Mower with 60in TURBO FORCE® Side Discharge Mower**

**Model No. 75951—Serial No. 403319953 and Up**



# Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

## Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

## Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

## Reference Numbers Indicating Quantity


In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

# Contents

|                                                             |    |
|-------------------------------------------------------------|----|
| Frame Assembly . . . . .                                    | 4  |
| Subframe Assembly . . . . .                                 | 6  |
| Roll-Over Protection System Assembly No. 116-0231 . . . . . | 8  |
| Caster Fork and Wheel Assembly . . . . .                    | 10 |
| Hydraulic Drive Assembly . . . . .                          | 12 |
| Pump Idler Assembly No. 116-1255 . . . . .                  | 14 |
| LH Hydro Assembly No. 126-1323 . . . . .                    | 16 |
| RH Hydro Assembly No. 126-1324 . . . . .                    | 18 |
| Rear Wheel Assembly . . . . .                               | 20 |
| Park Brake Assembly . . . . .                               | 22 |
| Fuel System Assembly . . . . .                              | 24 |
| Fuel Tank Assembly No. 135-0643 . . . . .                   | 26 |
| Seat Mounting Assembly . . . . .                            | 28 |
| Seat Assembly No. 116-0035 . . . . .                        | 30 |
| Motion Control Assembly . . . . .                           | 32 |
| Console and Control Panel Assembly . . . . .                | 34 |
| Electrical Assembly . . . . .                               | 36 |
| Wire Harness Assembly No. 135-5753 . . . . .                | 38 |
| Deck Lift Assembly . . . . .                                | 40 |
| Height-of-Cut Assembly No. 109-7438 . . . . .               | 42 |
| Engine, Clutch and Muffler Assembly . . . . .               | 44 |
| Deck Assembly . . . . .                                     | 46 |
| Deck Decal Assembly No. 136-8639 . . . . .                  | 48 |
| Idler Arm Assembly . . . . .                                | 50 |
| Spindle Assembly No. 127-0560 . . . . .                     | 52 |
| Rubber Deflector Assembly No. 108-2792 . . . . .            | 54 |
| Frame Decal Assembly . . . . .                              | 56 |
| Attachments and Accessories . . . . .                       | 58 |


# Frame Assembly



## Frame Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>           | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>          |
|-------------|--------------------|-------------|------------------------------|-------------|--------------------|-------------|-----------------------------|
| 1           | 116-5902           | 1           | Mainframe ASM                | 11:2        | 99-8936            | 1           | Decal-Control, Motion       |
| 1:2         | 132-0871           | 1           | Decal-Danger                 | 11:3        | 136-8967           | 1           | Flap-Rubber                 |
| 1:3         | 106-5517           | 2           | Decal-Warning                | 12          | 131-4610           | 1           | LH Motion Control Cover ASM |
| 1:4         | 106-2655           | 2           | Decal-Hazard, Pinched Finger | 12:2        | 99-8936            | 1           | Decal-Control, Motion       |
| 1:5         | 133-8062           | 1           | Decal-Arrestor, Spark        | 12:3        | 136-8967           | 1           | Flap-Rubber                 |
| 2           | 115-7410           | 1           | Rear Guard ASM               | 13          | 126-2067-03        | 1           | Guard-Muffler               |
| 2:2         | 67-7320            | 1           | Decal                        | 14          | 136-5520           | 1           | Decal                       |
| 3           | 131-8834           | 2           | Bumper                       | 15          | 32144-10           | 4           | Screw-HWH                   |
| 4           | 104-7201           | 2           | Nut-HF                       | 16          | 136-1674-01        | 2           | Plate-Mount, Shock          |
| 5           | 1-811010           | 2           | Plug                         | 17          | 131-6327-01        | 1           | Mount-Lower                 |
| 6           | 116-0180           | 1           | LH Bumper ASM                | 18          | 104-8300           | 7           | Nut-HF, NI                  |
| 6:2         | 106-5517           | 1           | Decal-Warning                | 20          | 107-3154           | 2           | Nut-Push                    |
| 7           | 116-0057-03        | 1           | Bumper-RH                    | 21          | 322-3              | 3           | Screw-HH                    |
| 8           | 104-8301           | 11          | Nut-HF, NI                   | 22          | 1-543508           | 4           | Cup-Bearing                 |
| 9           | 3231-22            | 7           | Screw-CARR                   | 23          | 3230-23            | 2           | Screw-CARR                  |
| 10          | 3231-21            | 4           | Screw-CARR                   | 24          | 127-6766           | 1           | LH Plate ASM (W/Studs)      |
| 11          | 131-4615           | 1           | RH Motion Control Cover ASM  | 25          | 127-6765           | 1           | RH Plate ASM (W/Studs)      |
|             |                    |             |                              | 26          | 3230-3             | 2           | Screw-CARR                  |


# Subframe Assembly



## Subframe Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       |
|-------------|--------------------|-------------|-------------------------|-------------|--------------------|-------------|--------------------------|
| 1           | 127-6759-03        | 2           | Bracket-Bearing         | 15          | 131-4647           | 2           | Knob-Front               |
| 2           | 127-6743           | 4           | Housing-Bearing, Flange | 16          | 136-8956           | 1           | Shock/Spring ASM         |
| 3           | 1-653346           | 2           | Bearing                 | 16          | 136-8993           | 1           | Shock/Spring ASM         |
| 4           | 127-6754-03        | 1           | Arm-Trailing            | 17          | 3231-22            | 3           | Screw-CARR               |
| 5           | 132-5057           | 1           | Subframe ASM            | 18          | 47-7270            | 2           | Bearing-Needle           |
| 5:2         | 132-0871           | 1           | Decal-Danger            | 19          | 132-5058           | 1           | Bumper-Rubber            |
| 5:3         | 115-9625           | 1           | Decal-Brake, Parking    | 20          | 132-5089-01        | 1           | Floorpan                 |
| 5:4         | 127-6745           | 2           | Bushing-Flange          | 21          | 325-19             | 1           | Screw-HH                 |
| 6           | 133-1808           | 1           | Bracket-Mounting        | 22          | 105-3048           | 2           | Washer-Flat              |
| 6:2         | 132-5067           | 1           | Decal-Adjustment, Ride  | 23          | 116-0648           | 2           | Screw-HH, Thread Locking |
| 6:3         | 132-5063           | 1           | Decal-Lock, Cam         | 24          | 1-513658           | 2           | Bumper                   |
| 7           | 127-6768           | 3           | Screw-CARR              | 25          | 86-1990            | 2           | Washer-Thrust            |
| 8           | 127-6751           | 2           | Spacer-Aluminum         | 26          | 132-5068           | 1           | Cover-Shock              |
| 9           | 99-5107            | 8           | Nut-Lock                | 27          | 125-9383           | 1           | Decal-Service Aid        |
| 10          | 131-8801           | 2           | Spacer                  | 28          | 3256-6             | 2           | Washer-Flat              |
| 11          | 131-6348           | 2           | Bolt-Shoulder           | 31          | 133-1810           | 1           | Mat-Floor                |
| 12          | 133-1815           | 2           | Shock/Spring ASM        | 32          | 117-2382           | 2           | Plug-Plastic             |
| 13          | 131-8843           | 2           | Cam Lock ASM            | 33          | 130-0733           | 4           | Pad-Rubber               |
| 13:2        | 107-1644           | 1           | Cap-Lock                | 34          | 104-8301           | 5           | Nut-HF, NI               |
| 13:4        | 119-4038           | 1           | Nut-Hex                 | 35          | 104-8300           | 9           | Nut-HF, NI               |
| 14          | 131-4646           | 2           | Plate-Stop              | 36          | 3230-10            | 4           | Bolt-CARR                |

# Roll-Over Protection System Assembly No. 116-0231




# Roll-Over Protection System Assembly No. 116-0231 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           |                    | 1           | Leg-ROPS, LH ●     |
| 2           |                    | 1           | Leg-ROPS, RH ●     |
| 3           | 109-6653           | 2           | Spacer             |
| 4           |                    | 1           | Upper ROPS ASM ●   |
| 4:2         | 107-3069           | 1           | Decal-Warning      |
| 5           | 109-5337           | 2           | Bumper-ROPS        |
| 6           | 116-0104           | 2           | Pin-Spring         |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       |
|-------------|--------------------|-------------|--------------------------|
| 7           | 99-5107            | 6           | Nut-Lock                 |
| 8           | 3233-10            | 2           | Screw-CARR               |
| 9           | 325-35             | 4           | Screw-HH                 |
| 10          | 109-9505           | 4           | Washer-Spring            |
| 11          | 109-9233           | 1           | Bumper-Push-In, Rubber   |
| 12          | 117-0346           | 1           | Decal-Caution, Fuel Vent |
| 14          | 116-0960           | 2           | Spacer                   |

● Not serviced separately

# Caster Fork and Wheel Assembly



## Caster Fork and Wheel Assembly (continued)


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|-------------------------|
| 1           | 1-543509           | 2           | Bearing-Roller, Tapered |
| 2           | 116-5647           | 1           | Seal-Grease             |
| 3           | 1-633508           | 3           | Washer-Bellville        |
| 4           | 116-6707-01        | 1           | Caster                  |
| 5           | 127-9528           | 1           | Wheel And Axle ASM      |
| 5:1         | 103-2768           | 2           | Guard-Seal              |
| 5:2         |                    | 1           | Wheel And Bearing ASM ● |
| 5:2:1       | 1-633585           | 2           | Bearing-Cone, Taper     |
| 5:2:2       | 103-0063           | 2           | Seal-Caster             |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   |
|-------------|--------------------|-------------|----------------------|
| 5:2:3       | 103-3051           | 1           | Spacer-Nut ■         |
| 5:2:4       | 126-5361           | 1           | Axle Caster ASM      |
| 5:2:5       |                    | 1           | Wheel And Tire ASM ● |
| 5:2:5:1     | 1-633584           | 2           | Bearing-Cup          |
| 5:3         | 325-39             | 1           | Screw-HH             |
| 5:4         | 3296-23            | 1           | Nut-Lock, NI         |
| 6           | 103-4882           | 1           | Cap-Grease           |
| 7           | 3296-51            | 1           | Nut-Lock, NI         |

● Not serviced separately

■ Use Pro-Lock, Nut Type (P/N 1-840022, .5ml tube) on threads.

# Hydraulic Drive Assembly




## Hydraulic Drive Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>              | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>          |
|-------------|--------------------|-------------|---------------------------------|-------------|--------------------|-------------|-----------------------------|
| 1           | 116-1255           | 1           | Pump Idler ASM                  | 12:2        | 116-8726           | 1           | Decal-Oil, Hydro            |
| 2           | 109-6658           | 1           | Nut-Flange, NI                  | 13          | 116-0171           | 1           | RH Hydro Guard ASM          |
| 3           | 126-1323           | 1           | LH Hydro ASM (12Cc W/<br>Shock) | 13:2        | 116-8726           | 1           | Decal-Oil, Hydro            |
| 4           | 109-3388           | 1           | Belt                            | 14          | 109-9057           | 1           | Guard-Hydro, Rear (LH)      |
| 5           | 116-6317           | 1           | Spring-Extension                | 15          | 109-9058           | 1           | Guard-Hydro, Rear (RH)      |
| 6           | 116-7558           | 1           | Cradle-Hydro                    | 16          | 1-803035           | 2           | Rivet-Pop                   |
| 7           | 116-1502           | 1           | Bolt-Shoulder, Carriage         | 17          | 116-2362           | 1           | Deflector-Air Flow          |
| 8           | 126-0095           | 6           | Screw-CARR                      | 18          | 109-9905           | 1           | Sheave                      |
| 9           | 99-5107            | 6           | Nut-Lock                        | 19          | 1-807259           | 1           | Key                         |
| 10          | 325-8              | 4           | Screw-HH                        | 99          | 114-4713           | 1           | Hypr-Oil 500 (Quart) ●      |
| 11          | 126-1324           | 1           | RH Hydro ASM (12Cc W/<br>Shock) | 99          | 114-4714           | 1           | Hypr-Oil 500 (Gallon) ●     |
| 12          | 116-0170           | 1           | LH Hydro Guard ASM              | 99          | 114-4715           | 1           | Hypr-Oil 500-5 (5 Gallon) ● |
|             |                    |             |                                 | 99          | 117-0390           | 1           | Filter-Hydro ●              |

● Not illustrated


Pump Idler Assembly No. 116-1255



## Pump Idler Assembly No. 116-1255 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|--------------------|
| 2           | 43-0940            | 1           | Spacer             | 8           | 323-8              | 1           | Screw-HH           |
| 3           | 103-3504           | 2           | Bearing-Spherical  | 9           | 32120-10           | 2           | Ring-Snap          |
| 4           | 103-3505           | 1           | Seal-Lip, Double   | 10          | 302-19             | 1           | Fitting-Grease     |
| 5           | 103-3506           | 1           | Seal-Lip, Single   | 11          | 109-8076           | 1           | Pulley-Idler       |
| 6           | 109-6658           | 1           | Nut-Flange, NI     | 12          | 132-4724           | 1           | Pin-Anchor, Spring |
| 7           | 106-7159           | 2           | O-Ring             |             |                    |             |                    |

# LH Hydro Assembly No. 126-1323




## LH Hydro Assembly No. 126-1323 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>            | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         |
|-------------|--------------------|-------------|-------------------------------|-------------|--------------------|-------------|----------------------------|
| 2           | 116-0233           | 1           | Fan Kit                       | 15          | 116-3287           | 1           | Housing-LH                 |
| 3           | 116-0234           | 1           | Pulley Kit                    | 16          | 116-8915           | 1           | Motor-Hydraulic LH 240Cc   |
| 4           | 116-0235           | 1           | Handle-Bypass Valve,<br>Hydro | 17          | 116-7901           | 1           | Magnetic Plugs Service Kit |
| 5           | 116-0236           | 1           | Dipstick-Hydro W/Gasket       | 18          | 76-1900            | 2           | O-Ring                     |
| 6           | 116-0237           | 1           | Gasket-Dipstick, Hydro        | 19          | 116-8662           | 2           | O-Ring-Check Valve         |
| 7           | 116-1367           | 1           | Swash Block Kit               | 20          | 116-8974           | 4           | Screw HH                   |
| 8           | 116-1368           | 1           | Pump Seal Kit                 | 21          | 116-8975           | 2           | Screw-HSH                  |
| 9           | 116-1369           | 1           | Motor Seal Kit                | 22          | 116-9922           | 2           | Hydraulic Tube Kit         |
| 10          | 116-1370           | 1           | Tube Seal Kit                 | 23          | 126-7466           | 2           | Shock Valve, 12Cc Hydro    |
| 11          | 116-1371           | 1           | Output Shaft Seal Kit         | 24          | 126-7711           | 1           | Seal-Fan Drive             |
| 12          | 116-5469           | 1           | Nose Cup-Uht                  | 99          | 116-4245           | 1           | Puller-Pulley ●            |
| 13          | 3257-42            | 1           | Key-Woodruff                  | 99          | 116-1373           | 1           | Flow Test Kit ●            |

● Not illustrated

# RH Hydro Assembly No. 126-1324




## RH Hydro Assembly No. 126-1324 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>            | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         |
|-------------|--------------------|-------------|-------------------------------|-------------|--------------------|-------------|----------------------------|
| 1           | 116-9063           | 1           | Mount-Shoe, Horse             | 13          | 3257-42            | 1           | Key-Woodruff               |
| 2           | 116-0233           | 1           | Fan Kit                       | 15          | 116-3288           | 1           | Housing-RH                 |
| 3           | 116-0234           | 1           | Pulley Kit                    | 16          | 116-8916           | 1           | Motor-Hydraulic RH 240Cc   |
| 4           | 116-0235           | 1           | Handle-Bypass Valve,<br>Hydro | 17          | 116-7901           | 1           | Magnetic Plugs Service Kit |
| 5           | 116-0236           | 1           | Dipstick-Hydro W/Gasket       | 18          | 76-1900            | 2           | O-Ring                     |
| 6           | 116-0237           | 1           | Gasket-Dipstick, Hydro        | 19          | 116-8662           | 2           | O-Ring-Check Valve         |
| 7           | 116-1367           | 1           | Swash Block Kit               | 20          | 116-8974           | 4           | Screw HH                   |
| 8           | 116-1368           | 1           | Pump Seal Kit                 | 21          | 116-8975           | 2           | Screw-HSH                  |
| 9           | 116-1369           | 1           | Motor Seal Kit                | 22          | 116-9922           | 2           | Hydraulic Tube Kit         |
| 10          | 116-1370           | 1           | Tube Seal Kit                 | 23          | 126-7466           | 2           | Shock Valve, 12Cc Hydro    |
| 11          | 116-1371           | 1           | Output Shaft Seal Kit         | 24          | 126-7711           | 1           | Seal-Fan Drive             |
| 12          | 116-5469           | 1           | Nose Cup-Uht                  | 99          | 116-4245           | 1           | Puller-Pulley ●            |
|             |                    |             |                               | 99          | 116-1373           | 1           | Flow Test Kit ●            |

● Not illustrated


# Rear Wheel Assembly



## Rear Wheel Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|-------------------------|
| 1           | 127-9520           | 2           | Wheel And Tire ASM | 2           | 242-50             | 8           | Nut-Lug                 |
| 1:1         | 127-9517           | 1           | Wheel              | 3           | 126-2055           | 2           | Decal-Torque, Wheel Hub |
| 1:2         | 1-633993           | 1           | Tire               |             |                    |             | Lug                     |
| 1:3         | 232-27             | 1           | Stem-Valve         |             |                    |             |                         |


# Park Brake Assembly



## Park Brake Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|-------------------------|-------------|--------------------|-------------|---------------------|
| 1           | 126-4248           | 1           | Mount-Bellcrank, LH     | 25          | 126-3693           | 2           | Yoke-Offset         |
| 2           | 126-4249           | 1           | Mount-Bellcrank, RH     | 26          | 116-9085           | 2           | Spring-Compression  |
| 3           | 116-9681           | 1           | Mount-Pivot, LH         | 27          | 3220-2             | 2           | Nut-Jam             |
| 4           | 116-9682           | 1           | Mount-Pivot, RH         | 28          | 104-8300           | 4           | Nut-HF, NI          |
| 5           | 32144-70           | 4           | Screw-HWHTF             | 29          | 1-808280           | 2           | Pin-Clevis          |
| 6           | 109-8054           | 2           | Bushing-Flange          | 30          | 3256-23            | 4           | Washer-Plain        |
| 7           | 116-9096-01        | 1           | Bracket-Mount           | 31          | 116-6639           | 2           | Pin-Cotter, Locking |
| 8           | 131-4623           | 1           | Brake Lever ASM W/ Grip | 32          | 116-9102           | 1           | Front Linkage ASM   |
| 8:2         | 109-8054           | 2           | Bushing-Flange          | 32:2        | 94-7572            | 1           | End-Tie Rod, RH     |
| 8:3         | 132-4749           | 1           | Grip-Lever              | 32:3        | 3220-3             | 1           | Nut-HJ              |
| 9           | 116-9117           | 1           | Handle-Pivot, Brake     | 33          | 119-1415           | 2           | Pin-Cotter, Locking |
| 10          | 323-11             | 1           | Screw-HH                | 34          | 3296-6             | 1           | Nut-Lock            |
| 11          | 104-8301           | 1           | Nut-HF, NI              | 35          | 126-7587           | 2           | Rear Linkage ASM    |
| 12          | 126-6199           | 4           | Bushing                 | 35:1        | 126-7588           | 2           | Yoke                |
| 13          | 3256-24            | 2           | Washer-Flat             | 35:2        | 116-9069           | 1           | Linkage, Rear       |
| 14          | 109-0958           | 2           | Plate-Mount, Brake      | 35:3        | 3220-1             | 1           | Nut-Jam             |
| 15          | 109-2889           | 1           | Caliper-Brake           | 36          | 32120-19           | 2           | E-Ring              |
| 16          | 116-9103           | 1           | Caliper-Brake, RH       | 37          | 3230-2             | 2           | Bolt-CARR           |
| 17          | 126-4251           | 2           | Bellcrank               | 38          | 323-6              | 2           | Screw-HH            |
| 18          | 126-3715           | 1           | Arm-Inner, LH           | 39          | 3296-39            | 2           | Nut-Lock, NI        |
| 19          | 126-3716           | 1           | Arm-Inner, RH           | 40          | 116-1746           | 2           | Wheel Hub ASM       |
| 20          | 116-9080           | 1           | Shaft-Cross             | 40:2        | 116-1696           | 4           | Stud-Wheel          |
| 21          | 115-7109           | 2           | Washer-Flat             | 41          | 116-1399           | 2           | Locknut             |
| 22          | 98-9940            | 4           | Screw-HHF               | 42          | 126-6395           | 4           | Pin-Clevis, Spring  |
| 23          | 116-9609           | 2           | Bracket-L               | 43          | 92-5727            | 2           | Screw-Lock, Patch   |
| 24          | 116-9086           | 2           | Linkage-Mid             | 44          | 126-6200           | 2           | Spacer              |


# Fuel System Assembly



## Fuel System Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   |
|-------------|--------------------|-------------|-------------------------|-------------|--------------------|-------------|----------------------|
| 1           | 135-0643           | 1           | Fuel Tank ASM           | 10          | 119-4235           | 1           | Hose-Vent, Formed    |
| 2           | 3218-1             | 2           | Nut-Jam                 | 11          | 116-1433-03        | 1           | Mount-Canister       |
| 3           | 1-523420           | 2           | Bumper                  | 12          | 116-2228           | 1           | Clamp, T-Bolt        |
| 4           | 127-0583           | 1           | Fuel Manifold Vent ASM  | 13          | 32144-70           | 2           | Screw-HWHTF          |
| 4:2         | 109-0302           | 3           | Hose-Fuel               | 14          | 3231-22            | 1           | Screw-CARR           |
| 4:3         | 108-5376           | 1           | Hose-Fuel               | 15          | 104-8301           | 1           | Nut-HF, NI           |
| 5           | 105-1853           | 1           | Clamp-Hose              | 16          | 116-4464           | 1           | Plug-Port            |
| 7           | 116-1442           | 1           | Canister-Carbon, 1200Cc | 17          | 116-6005           | 1           | Retainer-Line, Vapor |
| 8           | 116-2963           | 1           | Hose-Vent, Formed       | 19          | 125-8067           | 1           | Plug-Plastic         |
| 9           | 133-8499           | 1           | Valve-Check, Vacuum     | 20          | 121-7560           | 1           | Decal-EFI            |


# Fuel Tank Assembly No. 135-0643



## Fuel Tank Assembly No. 135-0643 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>              | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>                |
|-------------|--------------------|-------------|---------------------------------|-------------|--------------------|-------------|-----------------------------------|
| 3           | 116-2459           | 1           | Fuel Line Kit (With Grommet)    | 8:1         | 46-6560            | 1           | Bushing                           |
| 3:1         | 46-6560            | 1           | Bushing                         | 9           | 116-2461           | 1           | LH Vent Line Kit (With Grommet)   |
| 4           | 3290-500           | 5           | Screw-PPH                       | 9:1         | 46-6560            | 1           | Bushing                           |
| 5           | 3253-17            | 5           | Washer-Lock                     | 10          | 116-2462           | 1           | Rear Vent Line Kit (With Grommet) |
| 6           | 126-3913           | 1           | Float-Sender, Fuel              | 10:1        | 46-6560            | 1           | Bushing                           |
| 6:1         | 126-3950           | 1           | Gasket-Sender                   | 11          | 1-603770           | 1           | Valve-Fuel                        |
| 7           | 126-1789           | 1           | Cap-Fuel, Ratcheting            | 12          | 2412-98            | 2           | Clamp-Hose                        |
| 8           | 116-2460           | 1           | RH Vent Line Kit (With Grommet) | 13          | 109-0650           | 1           | Hose-Fuel                         |


# Seat Mounting Assembly



## Seat Mounting Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|-------------------------|-------------|--------------------|-------------|--------------------|
| 1           | 116-2130-03        | 1           | Panel-Front, Seat Mount | 9           | 116-3859-03        | 1           | Plate-Frame, Seat  |
| 2           | 3230-23            | 3           | Screw-CARR              | 10          | 116-1297           | 2           | Screw-Shoulder     |
| 3           | 9266934            | 2           | Screw                   | 11          | 116-0035           | 1           | Seat-Standard      |
| 4           | 109-9034           | 4           | Isolator-Seat           | 12          | 116-0070           | 1           | Rod-Prop           |
| 5           | 3230-10            | 8           | Bolt-CARR               | 13          | 132-5088-03        | 1           | Plate-Latch, Seat  |
| 6           | 104-8300           | 18          | Nut-HF, NI              | 14          | 3256-23            | 1           | Washer-Plain       |
| 7           | 131-6324-03        | 1           | Plate-Support, ISO Seat | 15          | 107-3017           | 1           | Spring-Compression |
| 8           | 104-8301           | 4           | Nut-HF, NI              | 16          | 3230-4             | 1           | Bolt-CARR          |

# Seat Assembly No. 116-0035




## Seat Assembly No. 116-0035 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 2           | 109-9801           | 1           | Seat Track Set     |
| 3           | 109-9802           | 1           | Arm Rest Pad Set   |
| 4           | 109-9803           | 1           | Arm Rest Set       |
| 5           | 109-9805           | 1           | Seat Belt Kit      |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 6           | 109-9806           | 1           | Cover-Cushion      |
| 7           | 109-9808           | 1           | Cover-Back         |
| 8           | 82-2190            | 1           | Switch-Bail        |

# Motion Control Assembly




## Motion Control Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>                | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     |
|-------------|--------------------|-------------|-----------------------------------|-------------|--------------------|-------------|------------------------|
| 1           | 116-0880           | 1           | RH Motion Control And Bushing ASM | 14          | 133-1839           | 1           | RH Steering Handle ASM |
| 1:2         | 109-8054           | 4           | Bushing-Flange                    | 14:2        | 109-5668           | 1           | Grip-Control, Lever    |
| 2           | 116-0881           | 1           | LH Motion Control And Bushing ASM | 15          | 133-1841           | 1           | LH Steering Handle ASM |
| 2:2         | 109-8054           | 4           | Bushing-Flange                    | 15:2        | 109-5668           | 1           | Grip-Control, Lever    |
| 3           | 116-0648           | 2           | Screw-HH, Thread Locking ●        | 16          | 104-8301           | 4           | Nut-HF, NI             |
| 4           | 109-4581           | 2           | Arm-Control, Pump                 | 17          | 323-7              | 4           | Screw-HH               |
| 5           | 9080046            | 2           | Screw-HH ●                        | 18          | 109-5575           | 2           | Spring-Leaf            |
| 6           | 1-303435           | 2           | Washer-Spring                     | 19          | 109-8106           | 2           | Front Pump Linkage ASM |
| 7           | 116-0027           | 2           | Damper-Control, Motion            | 19:2        | 3219-2             | 2           | Nut-Hex                |
| 8           | 104-8300           | 8           | Nut-HF, NI                        | 19:3        | 1-323245           | 2           | Spring-Compression     |
| 9           | 3230-2             | 2           | Bolt-CARR                         | 19:4        | 1-633152           | 1           | Balljoint-LH           |
| 10          | 109-5891           | 2           | Hub-Threaded                      | 19:5        | 1-543017           | 1           | Balljoint-RH           |
| 11          | 325-12             | 2           | Screw-HH                          | 20          | 109-9505           | 4           | Washer-Spring          |
| 12          | 116-0039           | 1           | Lever-Control Motion, RH          | 21          | 3256-6             | 2           | Washer-Flat            |
| 13          | 116-0040           | 1           | Lever-Control Motion, LH          | 22          | 32128-56           | 2           | Nut-HF                 |
|             |                    |             |                                   | 23          | 3256-23            | 2           | Washer-Plain           |
|             |                    |             |                                   | 24          | 3218-5             | 2           | Nut-Jam                |
|             |                    |             |                                   | 25          | 115-1794           | 2           | Screw-HHF              |

● Use Pro-Lock, Nut Type (P/N 1-840022, .5ml tube) on threads.


# Console and Control Panel Assembly



## Console and Control Panel Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|----------------------|-------------|--------------------|-------------|--------------------|
| 1           | 135-3644           | 1           | Control Panel ASM    | 3:2         | 107069             | 4           | Clip               |
| 1:2         | 137-9208           | 1           | Decal-Panel, Control | 4           | 119-2602           | 1           | Console-LH         |
| 2           | 32105-15           | 4           | Screw-HWH            | 5           | 116-1875           | 1           | Plug-Plastic       |
| 3           | 119-2603           | 1           | RH Console ASM       |             |                    |             |                    |

# Electrical Assembly




## Electrical Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|---------------------|-------------|--------------------|-------------|-------------------------|
| 1           | 104-8162           | 1           | Battery-Dry         | 7           | 116-0042-03        | 1           | Strap-Tie Down, Battery |
| 2           | 135-5753           | 1           | Harness-Wire ASM    | 8           | 1-633651           | 2           | Bolt-Holddown           |
| 3           | 135-2471           | 1           | Meter-Hour          | 9           | 1-543792           | 2           | Wingnut                 |
| 4           | 126-6187           | 1           | Switch-PTO, Sealed  | 10          | 3234-5             | 2           | Screw-HHF               |
| 5           | 126-6285           | 1           | Ignition Switch ASM | 11          | 104-8300           | 2           | Nut-HF, NI              |
| 5:1         |                    | 1           | Switch-Ignition ●   | 12          | 82-2190            | 1           | Switch-Bail             |
| 5:2         | 108-8660           | 1           | Nut-Mounting        | 13          | 117-2382           | 1           | Plug-Plastic            |
| 5:3         | 106-5270           | 1           | Ignition Key Set    | 14          | 1-303335           | 1           | Tie-Plastic             |
| 5:4         | 108-8659           | 1           | Washer-Backup       | 16          | 1-303287           | 3           | Tie-Cable               |
| 6           | 110-6765           | 2           | Switch              | 17          | 131-8846           | 1           | Cover-Hose              |

● Not serviced separately


Wire Harness Assembly No. 135-5753



## Wire Harness Assembly No. 135-5753 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|-------------------------|-------------|--------------------|-------------|-------------------------|
| 6           | 32180-037          | 2           | Clip-Harness            | 12          | 121-8867           | 1           | Fuse-Mini Blade, 15 Amp |
| 7           | 32180-030          | 6           | Clip-Tie                | 13          | 126-8876           | 1           | Insulator-Battery       |
| 8           | 32180-197          | 1           | Cap-Plug                | 14          | 1-543393           | 1           | Insulator-Solenoid      |
| 9           | 121-8868           | 1           | Fuse-Mini Blade, 20 Amp | 15          | 32180-176          | 1           | Cover-Block, Fuse       |
| 10          | 126-3991           | 1           | Relay-Micro             | 16          | 32180-177          | 1           | Clip-Mounting           |
| 11          | 32180-156          | 1           | Cap-Plug, 6 Way         | 17          | 126-7875           | 1           | Decal-Fuse              |


# Deck Lift Assembly



## Deck Lift Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>                   | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|--------------------------------------|-------------|--------------------|-------------|---------------------|
| 1           | 109-7952           | 2           | Deck Strut ASM                       | 17          | 109-7438           | 1           | HOC ASM             |
| 1:2         | 109-5009           | 2           | Bushing-Suspension,<br>Rubber        | 18          | 109-9065           | 1           | Screw-HH            |
| 1:3         | 109-5010           | 2           | Spacer                               | 19          | 3296-23            | 1           | Nut-Lock, NI        |
| 3           | 109-5013           | 1           | Panhard Rod ASM                      | 20          | 3231-2             | 2           | Bolt-CARR           |
| 3:2         | 109-5009           | 2           | Bushing-Suspension,<br>Rubber        | 21          | 126-2475-03        | 1           | Decklift-Front      |
| 3:3         | 109-5010           | 2           | Spacer                               | 22          | 116-0756           | 4           | Deck Lift Chain ASM |
| 4           | 86-1990            | 6           | Washer-Thrust                        | 22:1        | 1-633447           | 1           | Chain-Lift, Deck    |
| 5           | 99-5107            | 12          | Nut-Lock                             | 22:2        | 109-9065           | 1           | Screw-HH            |
| 6           | 325-12             | 2           | Screw-HH                             | 22:3        | 32128-37           | 1           | Nut-HF              |
| 7           | 325-17             | 1           | Screw-HH                             | 23          | 116-0559           | 1           | Bolt-TAP            |
| 8           | 3233-34            | 3           | Screw-CARR                           | 24          | 32128-37           | 6           | Nut-HF              |
| 9           | 127-0553           | 2           | Support-Cross Shaft,<br>Bearing Rear | 25          | 109-9066           | 4           | Yoke-Adjust, Deck   |
| 10          | 109-7173           | 2           | Bearing-Cross Shaft, Rear            | 26          | 322-47             | 4           | Screw-HH            |
| 11          | 3231-4             | 2           | Screw-CARR                           | 27          | 3218-2             | 8           | Nut-Jam             |
| 12          | 104-8301           | 12          | Nut-HF, NI                           | 28          | 116-0459-03        | 1           | Lift-Deck, Rear     |
| 13          | 109-9409           | 2           | Support-Cross Shaft,<br>Bearing      | 29          | 116-0780           | 2           | Screw-Shoulder, HHF |
| 14          | 109-9410           | 2           | Bearing-Cross Shaft, Front           | 30          | 116-0797-03        | 1           | Link-Lift, Deck     |
| 15          | 116-1700           | 4           | Bolt-CARR                            | 31          | 116-0000           | 1           | Spring-Extension    |
| 16          | 109-9840           | 4           | Screw-Shoulder, HHF                  | 32          | 116-5584           | 1           | Pin-HOC             |
|             |                    |             |                                      | 33          | 131-8812-01        | 1           | Lever-Foot          |
|             |                    |             |                                      | 34          | 3256-28            | 2           | Washer-Flat         |
|             |                    |             |                                      | 35          | 92-7674            | 1           | Bolt-Shoulder       |
|             |                    |             |                                      | 36          | 3231-7             | 4           | Screw-CARR          |

Height-of-Cut Assembly No. 109-7438




## Height-of-Cut Assembly No. 109-7438 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|---------------------|
| 1           | 62-1330            | 1           | Bolt-Shoulder       |
| 2           | 109-7130           | 1           | Grommet             |
| 3           | 104-8301           | 1           | Nut-HF, NI          |
| 4           | 109-7124           | 1           | Spring-Extension    |
| 5           | 109-7128           | 1           | Rod-Lock, Transport |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|---------------------|
| 6           | 116-0118           | 1           | Pawl-Transport, HOC |
| 7           | 109-7335           | 1           | HOC Plate ASM       |
| 7:2         | 126-4398           | 1           | Decal-HOC           |
| 8           | 109-8250           | 1           | Grip-Lever          |

# Engine, Clutch and Muffler Assembly



## Engine, Clutch and Muffler Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>                         |
|-------------|--------------------|-------------|--------------------------------------------|
| 1           |                    | 1           | Engine-Kohler Ecv740-3063<br>▲◆            |
| 1:1         |                    | 1           | Kohler 52 050 02-S Engine<br>Oil Filter ▲◆ |
| 1:2         |                    | 1           | Kohler 25 083 01-S Engine<br>Air Filter ▲◆ |
| 1:3         |                    | 1           | Kohler 25 083 04-S Safety<br>Filter ▲◆     |
| 1:4         | 135-2483           | 1           | Kohler 25 050 42-S Fuel<br>Filter          |
| 3           | 116-1620           | 1           | Clutch Kit                                 |
| 4           | 109-6919           | 1           | Washer-Clutch                              |
| 5           | 1-603610           | 2           | Washer-Spring                              |
| 6           | 109-9761           | 1           | Screw-HH □                                 |
| 7           | 3231-22            | 1           | Screw-CARR                                 |
| 8           | 116-4297           | 1           | Muffler Bracket Kit                        |
| 9           | 135-2127           | 1           | Muffler Kit                                |
| 10          | 32144-102          | 4           | Screw-HWH                                  |
| 11          | 98-5975            | 4           | Washer-Belleville                          |
| 12          | 116-5316           | 1           | Oil Drain Hose ASM ■                       |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   |
|-------------|--------------------|-------------|----------------------|
| 12:2        | 353-508            | 1           | Plug-HH ●            |
| 12:2:1      | 237-42             | 1           | O-Ring               |
| 13          | 3234-5             | 2           | Screw-HHF            |
| 15          | 104-8301           | 1           | Nut-HF, NI           |
| 16          | 116-2612-01        | 1           | Clutch-Anchor        |
| 17          | 94-2413            | 2           | Nut-U                |
| 18          | 117-3893           | 1           | Fuel Line ASM        |
| 18:1        | 109-0273           | 1           | Hose-Fuel            |
| 18:2        | 117-3892           | 1           | Sleeve-Thermal       |
| 18:3        | 2412-98            | 2           | Clamp-Hose           |
| 19          | 116-4295           | 2           | Screw-HH             |
| 20          | 1-303435           | 2           | Washer-Spring        |
| 21          | 105-1853           | 1           | Clamp-Hose           |
| 22          | 115-2752           | 1           | Throttle Control ASM |
| 22:1        | 112-2334           | 1           | Lever-Throttle       |
| 22:2        | 115-3868           | 1           | Cable-Throttle       |
| 23          | 1-807513           | 2           | Bolt-CARR            |
| 24          | 3296-2             | 2           | Nut-Lock, NI         |
| 25          | 1-603175           | 1           | Knob-Ball            |

● Torque to 24-26 ft-lb


▲ Not serviced separately

□ Use Pro-Lock, Nut Type (P/N 1-840022, .5ml tube) on threads.

■ Torque to 17-23 ft-lb

◆ Obtain parts from [www.kohlerplus.com](http://www.kohlerplus.com)

# Deck Assembly




## Deck Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   |
|-------------|--------------------|-------------|--------------------------|-------------|--------------------|-------------|----------------------|
| 1           | 136-8639           | 1           | Deck Decal ASM           | 24          | 92-1624            | 3           | Screw-HWH            |
| 2           | 114-5858           | 1           | Belt-V                   | 25          | 106-3216-01        | 1           | Baffle-Discharge     |
| 3           | 104-8301           | 42          | Nut-HF, NI               | 26          | 98-7913            | 2           | Tube-Spacer          |
| 4           | 105-7734           | 3           | Pulley                   | 27          | 1-603299           | 4           | Roller-Scalp, Anti   |
| 5           | 109-6938           | 1           | Cover-Belt, LH           | 28          | 98-7912            | 2           | Tube-Spanner         |
| 6           |                    | 1           | Idler Arm ASM ●          | 29          | 322-50             | 1           | Screw-HH             |
| 7           | 127-0560           | 3           | Spindle ASM              | 30          | 108-2792           | 1           | Rubber Deflector ASM |
| 8           | 109-6982           | 2           | Wireform-Cover           | 31          | 108-4052           | 1           | Spring-Torsion       |
| 9           | 121-8031-01        | 1           | Plate-Skid               | 32          | 105-4622           | 1           | Spacer               |
| 10          | 3231-27            | 9           | Screw-CARR               | 35          | 3296-47            | 1           | Nut-Lock, NI         |
| 11          | 1-373034           | 4           | Washer                   | 36          | 114-5867           | 1           | Anchor-Spring, Tall  |
| 12          | 3290-357           | 6           | Nut-HHF, Whiz            | 37          | 116-6317           | 1           | Spring-Extension     |
| 13          | 108-5387           | 3           | Screw-CARR               | 38          | 109-9416           | 1           | Spacer-Idler         |
| 14          | 323-23             | 2           | Screw-HH                 | 39          | 109-2872           | 1           | Spacer-Pulley        |
| 15          | 105-7718-03        | 3           | Blade-Hi Flow            | 40          | 136-5404           | 1           | Pulley-Idler, Flat   |
| 16          | 103-0865           | 3           | Washer-Blade Bolt, Heavy | 41          | 116-0094           | 1           | Cover-Belt, RH       |
| 17          | 51-4060            | 3           | Screw-Blade              | 42          | 132-4734           | 1           | Pulley-Idler, Flat   |
| 18          | 114-5842-01        | 1           | Baffle                   | 43          | 109-6658           | 4           | Nut-Flange, NI       |
| 19          | 3231-40            | 1           | Bolt-CARR, Short Neck    | 44          | 126-4781-03        | 1           | Step-Deck            |
| 20          | 3231-42            | 1           | Screw-CARR               | 45          | 3230-3             | 1           | Screw-CARR           |
| 21          | 108-5388           | 1           | Screw-HH                 | 46          | 104-8300           | 1           | Nut-HF, NI           |
| 22          | 98-5967            | 1           | Spacer-Wheel             |             |                    |             |                      |
| 23          | 115-7465-01        | 1           | Baffle                   |             |                    |             |                      |

● Not serviced separately

Deck Decal Assembly No. 136-8639




## Deck Decal Assembly No. 136-8639 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       |
|-------------|--------------------|-------------|--------------------------|-------------|--------------------|-------------|--------------------------|
| 1           |                    | 1           | Deck Decal ASM ●         | 7           | 127-0326           | 1           | Decal-Scalp, Anti        |
| 2           | 112-9028           | 3           | Decal-Cover, Missing     | 8           | 107-1619           | 1           | Decal                    |
| 3           | 136-5508           | 1           | Decal-Routing, Deck Belt | 10          | 58-6520            | 1           | Decal-Grease             |
| 4           | 93-7818            | 1           | Decal-Torque, Blade Bolt | 11          | 110-2068           | 1           | Decal-Adjustment, Baffle |
| 5           | 117-3848           | 2           | Decal-Danger             | 12          | 110-2067           | 1           | Decal-Setting, Baffle    |

● Not serviced separately


# Idler Arm Assembly



## Idler Arm Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|----------------------|
| 1           | 114-5870           | 1           | Idler Arm ASM      | 5           | 98-5961            | 1           | Screw-HH             |
| 1:2         | 1-303514           | 2           | Bearing-Flanged    | 6           | 132-9425           | 1           | Pulley-Idler, Flat   |
| 1:3         | 1481               | 1           | Fitting-Grease     | 7           | 112-4212           | 1           | Mount-Pulley         |
| 2           | 109-6658           | 4           | Nut-Flange, NI     | 8           | 323-11             | 2           | Screw-HH             |
| 3           | 1-213069           | 3           | Washer             | 9           | 132-4729           | 1           | Anchor-Spring, Short |
| 4           | 114-5848           | 1           | Spacer-Plain       | 10          | 104-0151           | 1           | Spacer               |

# Spindle Assembly No. 127-0560




## Spindle Assembly No. 127-0560 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>               |
|-------------|--------------------|-------------|----------------------------------|
| 1           |                    | 1           | Spindle Housing ASM<br>W/Studs ● |
| 1:2         | 114-8195           | 6           | Bolt-Neck, Ribbed                |
| 2           | 116-0720           | 2           | Bearing-Ball                     |
| 3           | 127-0554           | 1           | Spacer-Bearing                   |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>          |
|-------------|--------------------|-------------|-----------------------------|
| 4           | 127-0556           | 1           | Shaft-Spindle, Ball Bearing |
| 5           | 127-0557           | 1           | Hub-Spindle (W/Studs)       |
| 6           | 92-5836            | 1           | Washer                      |
| 7           | 3296-67            | 1           | Nut-Lock, NI                |

● Not serviced separately

# Rubber Deflector Assembly No. 108-2792




## Rubber Deflector Assembly No. 108-2792 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 3231-4             | 4           | Screw-CARR         |
| 2           | 106-3246-01        | 1           | Deflector          |
| 3           | 106-3248-03        | 1           | Strap-Discharge    |
| 4           | 108-5029           | 1           | Deflector-Rubber   |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 5           | 108-4059-01        | 1           | Plate-Hinge, Rear  |
| 6           | 106-3253-01        | 1           | Plate-Hinge, Front |
| 7           | 104-8301           | 4           | Nut-HF, NI         |

# Frame Decal Assembly



## Frame Decal Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 120-5894           | 2           | Decal              |

# Attachments and Accessories

## For 75951 Z Master Professional 5000 Series Riding Mower with 60in TURBO FORCE Side Discharge Mower

| Product Name                                 | Model/Part  |
|----------------------------------------------|-------------|
| Blower and Drive Kit .....                   | 78553       |
| E-Z Vac Triple Bagging System .....          | 78563       |
| Recycler Kit .....                           | 115-7468    |
| E-Z Vac DFS Collection System .....          | 78567       |
| Turbo Baffle Kit .....                       | 107-1634    |
| Operator Controlled Discharge Chute Kit..... | 117-3600    |
| 6 Pack-Blade, 20.5in Lo Flow .....           | 108-1128    |
| Seat Cover W/arm rest .....                  | 117-0095    |
| Blade-Lo Flow, 20.5in .....                  | 105-7716-03 |
| Hypr-Oil 500 (quart) .....                   | 114-4713    |
| Bimini Folding Shade Assembly .....          | 115-4510    |
| Light Kit.....                               | 116-1154    |
| 6 Pack Blade, 20.5in Mid-Flow .....          | 108-1123    |
| Hitch Kit .....                              | 109-9487    |
| Hypr-Oil 500 (gallon).....                   | 114-4714    |
| Filter Minder Gauge .....                    | 99-4664     |
| Blade-Mid Flow, 20.5in .....                 | 105-7715-03 |
| Hypr-Oil 500-5 (5 gallon).....               | 114-4715    |
| Trash Holder Kit.....                        | TC26        |
| 6 Pack Blade, 20.5in Hi-Flow .....           | 108-1114    |
| Blade-Hi Flow, 20.5in .....                  | 105-7718-03 |
| 6 Pack-Blade, 20.5in Recycler.....           | 110-0405    |
| Blade-Recycler, 20.5in.....                  | 105-7777-03 |
| 6 Pack-Blade, 20.5in Atomic.....             | 108-1115    |
| Blade-Atomic, 20.5in .....                   | 105-8777-03 |
| Roller Striper Kit.....                      | 115-7470    |
| Toro Deluxe Rider Cover.....                 | 490-7319    |
| Spark Arrestor Screen .....                  | 75-6880     |
| Anti-Scalp Kit (Trim Side).....              | 108-4140    |
| MVP Belt and Blade Kit.....                  | 127-1639    |
| Toro Rider Over Seat Bag .....               | 490-7317    |
| Toro Rider Arm Rest Bag .....                | 490-7320    |
| Toro Rops Lock Kit.....                      | 126-4064    |
| Jack Mount Kit .....                         | 127-6665    |
| Jack Kit .....                               | 127-6666    |
| Shock/Spring Asm .....                       | 136-8993    |
| Trimmer Mount .....                          | 137-9769    |

**Notes:**



**Count on it.**