



HAYTER

MAKERS OF THE FINEST MOWERS

Parts Catalogue

46cm Lawn Mower

Code CODE611A

Serial No.318000001

Manual Part No. 3409-859 Rev D

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents


Deck and Grass Bag Assembly 4

Engine and Blade Assembly 6

Suspension, Traction and HOC Assembly 8

Handle Bar and Controls Assembly 10


Deck and Grass Bag Assembly



Deck and Grass Bag Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	134-0117	2	Nut-Lock, Flange	15	134-0131	2	Screw-Self Driving
2	134-0118	4	Nut-Lock, Flange	16	134-0132	1	Deflector-Rear
3	134-0119	2	Screw-Tooth	17	134-0133	1	Pressing Board-Lock Button, Mulch
4	134-0120	1	Bumper-Front	18	134-0134	1	Spring-Button, Mulch
5	134-0121	2	Nut-Lock	19	134-0135	1	Lock-Button, Mulch
6	134-2000	1	Deck	20	134-0136	1	Plug-Mulch
7	134-0123	1	Spring-Twist, RH	21	134-0137	1	Bag-Grass
8	134-0124	1	Rod-Spring, Rear Deflector	22	134-0138	1	Frame-Bag, Grass
9	134-0125	1	Spring-Twist, LH	32	134-0148	1	Sheath-Cable, Protective
10	134-0126	1	O-Ring	39	134-0084	1	Decal-Safety
11	134-2001	1	Port-Wash	40	134-0051	1	Logo-Hayter
12	134-0128	4	Bolt-HH, Flange	43	111-9937	1	Decal-Easy Wash
13	134-0129	1	Bracket-Handle, RH				
14	134-0130	1	Bracket-Handle, LH				


Engine and Blade Assembly



Engine and Blade Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	134-0150	1	Bolt-Blade	11	134-0118	3	Nut-Lock, Flange
2	134-0151	1	Washer-Dished	13	134-0158	3	Washer-Square
3	134-0073	1	Blade-Mulch	14	134-2010	3	Bolt-Blade
4	134-0152	1	Support-Blade	16	134-0161	1	Screw-Grub
5	134-0153	1	Sheath-Blade	17	134-0162	1	Pulley-Drive
6	134-0154	1	Key-Flat	18	134-0163	1	Belt-Triangle
7	134-0155	2	Screw-Self Driving	19	134-0115	1	Engine-Briggs & Stratton, 500E
8	134-0156	1	Screw-Tooth	33	111-9993	1	Decal-Engine
9	134-0157	1	Cover-Pulley, Belt				
10	134-0117	1	Nut-Lock, Flange				


Suspension, Traction and HOC Assembly



Suspension, Traction and HOC Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	134-0156	2	Screw-Tooth	23	134-0190	4	Nut-Lock
2	134-0117	6	Nut-Lock, Flange	25	134-0191	2	Ring-Fixed
3	134-2002	2	Cap-Hub (7)	26	134-0192	1	Handle-Lever, HOC
4	134-0118	4	Nut-Lock, Flange	27	134-0197	4	Washer-Spring
5	134-0176	8	Bearing	28	134-0198	1	Gear Output ASM-RH
6	134-0177	2	Wheel ASM (7)	29	134-0199	2	Washer-Flat
7	134-0178	2	Cover-Wheel, Dustproof	30	134-0200	2	Bearing
8	134-0179	4	Washer-Wave	31	134-0201	2	Sheath-Bearing
9	134-0180	2	Clamp-Axle, Fixed	32	134-0202	2	Pin-Cylindrical
10	134-0181	4	Screw-Tooth	33	134-0203	1	Gearbox
11	134-0182	1	Front Wheel Axis ASM	34	134-0204	1	Gear Output ASM-LH
12	134-0183	2	Ring-Fixed	35	134-0205	1	Bracket-Location
13	134-0184	1	Spring-Tension	36	134-0206	2	Bolt-HH, Flange
14	134-0185	1	Bracket-Connecting, HOC	37	134-0207	1	Rear Axle Shaft ASM
15	134-0186	1	Board-Adjuster, HOC	38	134-0208	1	Handle ASM
16	134-2003	2	Cap-Hub (8)	39	134-0209	2	Washer-Spring
17	134-0188	2	Wheel ASM (8)	40	134-0210	1	Washer
19	134-0131	6	Screw-Self Driving	41	134-0211	2	Gear Ring
20	134-0189	2	Screw-Pan, Cross	42	134-0212	2	Cover-Wheel, Dustproof

Handle Bar and Controls Assembly



Handle Bar and Controls Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	134-0219	4	Bolt
2	09475	4	Washer
3	03469	4	Washer-Spring
4	134-0222	4	Nut-Lid
5	134-0223	2	Handlebar-Lower
6	134-0224	2	Nut-Hex
7	134-0225	2	Knob-Rotary
8	134-0226	2	Bolt-Flat Head
9	134-0227	2	Washer-Curve
10	134-0228	1	Cable Clamp
11	134-0229	1	Handlebar-Upper
12	134-0230	1	Bolt-HH, Flange

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
13	134-0231	1	Hook-Cable
14	09472	2	Washer-Plain
15	09474	1	Washer-Spring
16	134-0234	2	Nut-Lid
17	134-0235	2	Plug-Tube
18	134-2148	1	Cable-Brake, Engine
19	134-0237	1	Cable-Block, Fixed
20	134-0238	2	Grip-Handle
21	134-0239	1	Lever-Engine
22	134-0240	1	Cable-Clutch
23	134-0241	1	Lever-Clutch, Gearbox
24	H295159	1	Decal-Stop

