

Count on it.

Parts Catalog

Rear Roller Brush Kit

Reelmaster® 5010-H Series Cutting Unit with 7in Reel

Model No. 03408



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1,6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.


Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.


Contents

rive Assembly	4
oller Brush Assembly	5
late Assembly	6



Drive Assembly

R	ef.	Part Number	Qty.	Description
	1	112-6967	5	O-Ring
	2	108-4203	5	Housing-Bearing, Drive
	3	240-7	5	Grommet-Rubber
	4	3274-7	10	Screw-HSH
	6	125-2788	3	Shaft-Drive, LH
	7	125-2787	2	Shaft-Drive, RH
	8	127-7122	5	Bolt-Shoulder, Flange Hex Socket
	9	104-1843	5	Fitting-Grease, 90 DEG



Roller Brush Assembly

Ref.	Part Number	Qty.	Description	Ref.	Part Number	Qty.	Description		
1	127-7134	5	Non Driven Bearing Housing ASM	4:6	137-0842	1	HD Brush-Rear Roller, 22In ●		
1:2	95-0707	1	Bearing-Aligning, Self	5	104-8300	20	Nut-HF, NI		
1:3	106-8530	1	Seal-Grease	6	108-4480	10	Bracket-Mounting		
1:4	302-5	1	Fitting-Grease	7	108-4172	10	Seal-Excluder		
2	127-7138	5	Driven Bearing Housing	8	94-6936	20	Washer-Hardened		
			ASM	9	322-16	20	Screw-HH		
2:2	95-0707	1	Bearing-Aligning, Self	10	127-7139	5	Spacer-Pulley, Driven		
2:3	106-8530	2	Seal-Grease	11	112-6957	10	Washer-Hardened		
2:4	302-5	1	Fitting-Grease	12	115-0821	5	Pulley-Driven, RRB (5-Rib)		
3	107-8844	5	O-Ring	13	104-8301	5	Nut-HF, NI		
4	127-7146	5	22 Inch Roller Brush ASM	14	48-9220	1	Washer-Plain		
4:2	108-4193	1	Brush-Roller	50	131-3233	1	Groomer/RRB Seal Kit ●		
4:3	110-1740	1	Brush-Roller, High HOC ●	50:1	95-0707	2	Bearing-Aligning, Self		
4:4	105-9632	2	Bolt-J	50:2	106-8530	3	Seal-Grease		
4:5	3296-2	2	Nut-Lock, NI	50:3	108-4172	2	Seal-Excluder		

Optional Equipment




Plate Assembly

Ref.	Part Number	Qty.	Description	Ref.	Part Number	Qty.	Description
1	3230-23	10	Screw-CARR	12	114-9397	5	Idler Pulley ASM
2	112-6950	15	Screw-CARR	12:2	110-1701	1	Bearing
3	115-0814-03	5	Plate-Brush, 7 Inch	12:3	32151-60	1	Ring-Snap
4	322-1	10	Screw-HH	13	115-0831-03	5	Plate-Cover, 7 Inch (RRB)
5	3256-45	20	Washer-Flat	14	104-8300	10	Nut-HF, NI
6	3296-47	30	Nut-Lock, NI	15	27-0411	5	Screw-Shoulder
7	115-0834	5	Idler Arm ASM	16	66-9302	5	Screw-HHF, Whiz
7:2	125-8775	1	Bushing-Flange	17	115-0832	5	Pulley-Driver
8	115-0826	5	Spacer-Idler	18	108-4477	5	Spacer
9	115-0839	5	Spring-Idler	19	108-0989	5	Screw-Set
10	5-4460	5	Washer-Pivot	50	114-5446	1	Tool-Alignment ●
11	115-0833	5	Belt-Brush, 7 Inch				-



