



**Count on it.**

**Parts Catalog**

**Power Shovel™**

Model No. 38361—Serial No. 319000001 and Up



# Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

## Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

## Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.


## Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.


# Contents

Shroud and Auger Assembly ..... 4  
Handle Assembly ..... 5  
Pulley and Drive Assembly ..... 6




## Shroud and Auger Assembly

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
5	114-8987	1	Decal-Danger
11	106-9786	1	Scraper-Snow
12	112-1588	1	Rotor
13	32153-11	1	Nut-Lock
14	38-8211	1	Pin-Rotor
15	3256-80	1	Washer-Plain



## Handle Assembly

<b>Ref.</b>	<b>Part Number</b>	<b>Qty.</b>	<b>Description</b>
3	94-4496	38	Screw-PPH
5	119-9784	1	Screw-CARR
6	125-0519	1	Screw-Self Tapping
7	33-5790	1	Bolt-CARR
9	106-4161	2	Knob-Handle
11	117-8799	1	Handle-Assist
19	114-8985	1	Decal-Control



## Pulley and Drive Assembly

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	61-8880	1	Spring
2	106-9796	1	Arm-Idler
3	38-7820	1	Bearing-Ball
4	106-9797	1	Retainer-Pulley, Idler Arm
6	36-4780	1	Washer-Plain
8	106-9781	1	Pulley Bracket ASM
9	107-9986	1	Pulley ASM
10	106-9767	1	Belt-Drive

**Notes:**



**Count on it.**