Form No. 3424-702 Rev A

TORO®

Count on it.

Parts Catalog

Power Shovel™

Model No. 38361—Serial No. 319000001 and Up

Register at www.Toro.com.
Original Instructions (EN)

3424-702 A

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1,6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.


For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Shroud and Auger Assembly 4
Handle Assembly 5
Pulley and Drive Assembly 6


© 2018—The Toro® Company
8111 Lyndale Avenue South
Bloomington, MN 55420

Contact us at www.Toro.com.
Printed in the USA.
All Rights Reserved




Shroud and Auger Assembly

Ref.	*Part Number*	*Qty.*	*Description*
5	114-8987	1	Decal-Danger
11	106-9786	1	Scraper-Snow
12	112-1588	1	Rotor
13	32153-11	1	Nut-Lock
14	38-8211	1	Pin-Rotor
15	3256-80	1	Washer-Plain



Handle Assembly

Ref.	*Part Number*	*Qty.*	*Description*
3	94-4496	38	Screw-PPH
5	119-9784	1	Screw-CARR
6	125-0519	1	Screw-Self Tapping
7	33-5790	1	Bolt-CARR
9	106-4161	2	Knob-Handle
11	117-8799	1	Handle-Assist
19	114-8985	1	Decal-Control



Pulley and Drive Assembly

Ref.	*Part Number*	*Qty.*	*Description*
1	61-8880	1	Spring
2	106-9796	1	Arm-Idler
3	38-7820	1	Bearing-Ball
4	106-9797	1	Retainer-Pulley, Idler Arm
6	36-4780	1	Washer-Plain
8	106-9781	1	Pulley Bracket ASM
9	107-9986	1	Pulley ASM
10	106-9767	1	Belt-Drive

Notes:



Count on it.