



**Count on it.**

# Parts Catalog

## **Groundsmaster® 5900N/5910N Rotary Mower**

Model No. 31598N—Serial No. 314000001 and Up

Model No. 31599N—Serial No. 314000001 and Up



# Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

## Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

## Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

## Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

# Contents

|                                                              |    |
|--------------------------------------------------------------|----|
| Frame and Rear Axle Assembly .....                           | 6  |
| RH PTO Valve Assembly .....                                  | 7  |
| Hydraulic PTO Manifold Assembly No. 117-1112 .....           | 8  |
| LH PTO Valve Assembly .....                                  | 9  |
| Hydraulic PTO Manifold Assembly No. 117-1111 .....           | 10 |
| Filter Manifold Assembly .....                               | 11 |
| Hydraulic Filter Manifold Assembly No. 119-7703 .....        | 12 |
| Axle Assembly No. 114-5982-01 .....                          | 13 |
| Rear Axle Assembly .....                                     | 14 |
| Left Rear Wheel Hydraulic Motor Assembly No. 114-5593 .....  | 16 |
| Tie Rod Assembly No. 110-6049-03 .....                       | 17 |
| Right Rear Wheel Hydraulic Motor Assembly No. 114-5594 ..... | 18 |
| Hydraulic Steering Cylinder Assembly No. 98-0661 .....       | 19 |
| Front Axle and Brake Assembly .....                          | 20 |
| Planetary Assembly No. 105-4500 .....                        | 22 |
| Brake Assembly No. 119-8258 .....                            | 23 |
| Brake Assembly No. 119-8259 .....                            | 24 |
| Front PTO Valve Assembly .....                               | 25 |
| Hydraulic PTO Manifold Assembly No. 117-1110 .....           | 26 |
| Traction Valve Assembly .....                                | 27 |
| Hydraulic Traction Manifold Assembly No. 110-6062 .....      | 28 |
| Hydraulic Motor Assembly No. 114-4849 .....                  | 29 |
| Seat and Platform Assembly .....                             | 30 |
| Air Ride Seat Suspension Assembly No. 108-1488 .....         | 32 |
| Head Light Assembly No. 114-5928 .....                       | 34 |
| Steering Column Assembly .....                               | 35 |
| Steering Tower Assembly No. 117-5492 .....                   | 37 |
| Steering Valve Assembly No. 114-4900 .....                   | 38 |
| Traction Pedal Assembly .....                                | 39 |
| Brake Pedal Assembly .....                                   | 40 |
| Control Console Assembly .....                               | 41 |
| Electrical Component Assembly .....                          | 42 |
| Battery and Lift Manifold Assembly .....                     | 44 |
| Hydraulic Lift Manifold Assembly .....                       | 46 |
| Hydraulic Lift Manifold Assembly No. 119-7731 .....          | 47 |
| Front Deck Lift Arm and Cylinder Assembly .....              | 48 |
| Hydraulic Gear Motor Assembly No. 114-4940 .....             | 50 |
| Hydraulic Cylinder Assembly No. 114-4830 .....               | 51 |
| Hydraulic Cylinder Assembly No. 114-4831 .....               | 52 |
| Wing Lift Arm Assembly .....                                 | 53 |
| Hydraulic Cylinder Assembly No. 114-5685 .....               | 55 |
| Wing Connection and Impact Arm Assembly .....                | 56 |
| Hood and Bumper Assembly .....                               | 57 |
| Air Cleaner and Muffler Assembly .....                       | 59 |
| Air Cleaner Assembly No. 112-7329 .....                      | 60 |
| Radiator and Fan Shroud Assembly .....                       | 61 |
| Radiator Assembly .....                                      | 63 |
| Engine and Mount Assembly .....                              | 64 |
| 4 Wheel Drive Hydraulic Manifold Assembly .....              | 65 |
| 4 Wheel Drive Hydraulic Manifold Assembly No. 110-6063 ..... | 66 |
| Flush Manifold Assembly .....                                | 67 |
| Flush Valve Assembly No. 120-9869 .....                      | 68 |
| Fan and Coupling Assembly .....                              | 69 |
| Hydraulic Fan Motor Assembly No. 112-7400 .....              | 70 |

## Contents (continued)

|                                                         |     |
|---------------------------------------------------------|-----|
| Steer/Fan Manifold Assembly .....                       | 71  |
| Hydraulic Manifold Assembly No. 110-6065 .....          | 72  |
| Hydraulic Tank Assembly .....                           | 73  |
| Hydraulic Pump Assembly .....                           | 74  |
| Triple Pump Assembly No. 114-4840 .....                 | 75  |
| Piston Pump Assembly No. 121-3900 .....                 | 76  |
| Traction Hydraulic Plumbing Assembly.....               | 78  |
| Power-Take-Off Hydraulic Plumbing Assembly .....        | 80  |
| Lift Arms Hydraulic Plumbing Assembly .....             | 81  |
| Steering Hydraulic Plumbing Assembly .....              | 82  |
| Hydraulic Tank Plumbing Assembly .....                  | 83  |
| Acoustic Foam Assembly .....                            | 84  |
| Battery Cable Routing and Assembly .....                | 85  |
| Fuel Tank Assembly.....                                 | 86  |
| Engine Breather Assembly .....                          | 87  |
| Roll-Over Protection System Assembly .....              | 88  |
| Right Hand Tail Light Assembly No. 108-8007 .....       | 89  |
| Left Hand Tail Light Assembly No. 108-8008.....         | 90  |
| Vinyl Premium Seat Assembly No. 117-5676 .....          | 91  |
| Cab Mounting Assembly .....                             | 92  |
| Compressor Mount and Screen Assembly .....              | 93  |
| Cab Seat Assembly .....                                 | 94  |
| Cloth Premium Seat Assembly No. 117-9429 .....          | 95  |
| Right Door Cab Assembly.....                            | 96  |
| Left Door Cab Assembly .....                            | 98  |
| Front and Rear Window Cab Assembly .....                | 100 |
| Window Wiper and Washer Bottle Cab Assembly .....       | 101 |
| Shielding Component Cab Assembly .....                  | 102 |
| Headliner Cab Assembly.....                             | 103 |
| Roof, Condenser and Evaporator Cab Assembly .....       | 104 |
| Switchplate and Fuse Block Cover Cab Assembly .....     | 105 |
| A/C Heater and Evaporator Cab Assembly .....            | 106 |
| Condenser Cab Assembly .....                            | 107 |
| Center Deck and Winglet Assembly .....                  | 108 |
| Center Front Deck and Decal Assembly No. 110-5911 ..... | 109 |
| Right Front Deck and Decal Assembly No. 110-5914.....   | 110 |
| Left Front Deck and Decal Assembly No. 110-5917 .....   | 111 |
| Center Deck Belt and Pulley Assembly.....               | 112 |
| Driving Spindle Assembly No. 119-4547 .....             | 113 |
| Double Driven Spindle Assembly No. 119-4548 .....       | 114 |
| High Driven Spindle Assembly No. 119-4549 .....         | 115 |
| Center Deck Roller, Skid and Caster Wheel Assembly..... | 116 |
| 10 Inch Wheel Assembly No. 93-4240 .....                | 117 |
| Center Deck Spindle and Blade Assembly .....            | 118 |
| Center Deck Belt Cover Assembly.....                    | 119 |
| Center Deck Chamber Assembly.....                       | 120 |
| Center Deck Transport Damper Assembly.....              | 121 |
| Right Deck Belt and Pulley Assembly .....               | 122 |
| Right Deck Decal Assembly No. 110-5921 .....            | 123 |
| Right Deck Roller, Skid and Caster Wheel Assembly ..... | 124 |
| Right Deck Spindle and Blade Assembly .....             | 125 |
| Right Deck Belt Cover Assembly .....                    | 126 |
| Right Deck Chamber Assembly .....                       | 127 |
| Right Deck Stop and Hose Guide Assembly .....           | 128 |

# Contents (continued)

Left Deck Belt and Pulley Assembly ..... 129

Left Deck Decal Assembly No. 110-5931 ..... 130

Left Deck Roller, Skid and Caster Wheel Assembly ..... 131

Left Deck Spindle and Blade Assembly ..... 132

Left Deck Belt Cover Assembly ..... 133

Left Deck Chamber Assembly ..... 134

Engine Alternator Assembly ..... 135

Engine Starter Assembly..... 136

Engine Gear Case Front Cover Assembly ..... 137

Engine Water Pump and Thermostat Assembly ..... 138


Engine Exhaust Manifold Assembly ..... 139

Engine Valve Cover Assembly ..... 140

Engine Oil Filter and Dipstick Assembly ..... 141

Engine Fuel Filter Assembly ..... 142

Attachments and Accessories ..... 143




## Frame and Rear Axle Assembly

| Ref. | Part Number | Qty. | Description             |
|------|-------------|------|-------------------------|
| 2    |             | 1    | RH PTO Valve ASM ●      |
| 3    |             | 1    | LH PTO Valve ASM ●      |
| 4    |             | 1    | Filter Manifold ASM ●   |
| 5    | 322-19      | 4    | Screw-HH                |
| 6    | 2811-7      | 1    | Elbow                   |
| 7    | 114-5586    | 1    | Hose ASM (With Fitting) |
| 8    | 114-5587    | 1    | Nut                     |
| 9    | 302-5       | 1    | Fitting-Grease          |
| 10   | 104-8300    | 6    | Nut-HF, NI              |
| 11   | 3234-1      | 4    | Screw-HHF               |
| 12   | 3296-68     | 1    | Nut-Lock, NI            |
| 13   | 114-5970    | 1    | Shaft-Pivot             |
| 14   | 32121-110   | 1    | Pin-Roll, Slotted       |
| 15   | 110-6033-01 | 1    | Support-Axle            |
| 16   | 3256-26     | 10   | Washer-Flat             |
| 17   | 100-6116    | 10   | Screw-HHF               |
| 18   | 114-5982-01 | 1    | Axle ASM                |
| 19   | 98-1452     | 3    | Washer-Thrust           |
| 20   | 119-8275-01 | 1    | Pad-Transport, LH       |

| Ref. | Part Number | Qty. | Description       |
|------|-------------|------|-------------------|
| 21   | 86-6110     | 1    | Filter-Hydraulic  |
| 22   | 114-5990    | 2    | Plate-Tapped      |
| 23   | 114-5969-01 | 1    | Crossmember       |
| 24   | 110-6767    | 4    | Washer-Thrust     |
| 25   | 110-6006    | 2    | Pin-Clevis        |
| 26   | 3272-30     | 4    | Pin-Cotter        |
| 27   | 119-8270-01 | 1    | Pad-Transport, RH |
| 28   | 87-3470     | 2    | Bumper            |
| 29   | 33025-00    | 2    | Nut-Lock, NI      |
| 30   | 323-14      | 2    | Screw-HH          |
| 31   | 323-6       | 4    | Screw-HH          |
| 32   | 104-8301    | 6    | Nut-HF, NI        |
| 33   | 115-5465    | 1    | Seal-Trim         |
| 34   | 115-8826    | 2    | Shim-Bumper       |
| 35   | 3234-17     | 2    | Screw-HHF         |
| 36   | 117-5476    | 2    | Pad-Roller        |
| 37   | 1-807512    | 8    | Bolt-CARR         |
| 38   | 104-7201    | 8    | Nut-HF            |



● Not serviced separately



## RH PTO Valve Assembly

| Ref. | Part Number | Qty. | Description      |
|------|-------------|------|------------------|
| 1    | 117-1112    | 1    | Manifold-PTO, RH |
| 2    | 354-77      | 1    | Fitting-Quick    |
| 2:1  | 237-78      | 1    | O-Ring           |
| 3    | 354-79      | 1    | Cap-Dust         |
| 4    | 340-142     | 1    | Fitting-Elbow-90 |
| 4:1  | 237-58      | 1    | O-Ring           |
| 4:2  | 237-81      | 1    | O-Ring           |
| 5    | 104-3795    | 1    | Fitting-Tee      |

| Ref. | Part Number | Qty. | Description         |
|------|-------------|------|---------------------|
| 5:1  | 340-65      | 2    | O-Ring              |
| 5:2  | 237-146     | 1    | O-Ring              |
| 6    | 340-99      | 1    | Fitting-HYD, 90 DEG |
| 6:1  | 237-30      | 1    | O-Ring              |
| 6:2  | 237-42      | 1    | O-Ring              |
| 7    | 340-9       | 2    | Fitting-STR         |
| 7:1  | 237-58      | 1    | O-Ring              |
| 7:2  | 237-81      | 1    | O-Ring              |




## Hydraulic PTO Manifold Assembly No. 117-1112

| Ref. | Part Number | Qty. | Description            |
|------|-------------|------|------------------------|
| 1    | 114-5511    | 2    | Cartridge-Logic        |
| 1:1  | 119-8048    | 1    | Seal Kit               |
| 2    | 105-9333    | 1    | Coil-12Vdc             |
| 3    | 110-0494    | 1    | Valve-Solenoid         |
| 3:1  | 110-8773    | 1    | Seal Kit               |
| 3:2  | 110-2634    | 1    | Nut-Coil               |
| 4    | 114-5514    | 1    | Valve-Relief, 2000 PSI |
| 4:1  | 105-9156    | 1    | Seal Kit               |

| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 5    | 114-5512    | 1    | Valve-Relief, 600 PSI |
| 5:1  | 105-9156    | 1    | Seal Kit              |
| 6    | 106-1027    | 1    | Plug-HYD              |
| 6:1  | 237-79      | 1    | O-Ring                |
| 7    | 353-990     | 1    | Plug ASM              |
| 7:1  | 237-78      | 1    | O-Ring                |
| 8    | 112-6538    | 1    | Orifice (.063)        |
| 9    | 117-2791    | 1    | Disc-Orifice (.050)   |







## LH PTO Valve Assembly

| Ref. | Part Number | Qty. | Description      |
|------|-------------|------|------------------|
| 1    | 117-1111    | 1    | Manifold-PTO, LH |
| 2    | 354-77      | 1    | Fitting-Quick    |
| 2:1  | 237-78      | 1    | O-Ring           |
| 3    | 354-79      | 1    | Cap-Dust         |
| 4    | 340-142     | 1    | Fitting-Elbow-90 |
| 4:1  | 237-58      | 1    | O-Ring           |
| 4:2  | 237-81      | 1    | O-Ring           |
| 5    | 340-15      | 1    | Fitting-Elbow 90 |


| Ref. | Part Number | Qty. | Description         |
|------|-------------|------|---------------------|
| 5:1  | 237-58      | 1    | O-Ring              |
| 5:2  | 237-146     | 1    | O-Ring              |
| 6    | 340-99      | 1    | Fitting-HYD, 90 DEG |
| 6:1  | 237-30      | 1    | O-Ring              |
| 6:2  | 237-42      | 1    | O-Ring              |
| 7    | 340-9       | 2    | Fitting-STR         |
| 7:1  | 237-58      | 1    | O-Ring              |
| 7:2  | 237-81      | 1    | O-Ring              |



## Hydraulic PTO Manifold Assembly No. 117-1111

| Ref. | Part Number | Qty. | Description            |
|------|-------------|------|------------------------|
| 1    | 114-5511    | 2    | Cartridge-Logic        |
| 1:1  | 119-8048    | 1    | Seal Kit               |
| 2    | 105-9333    | 1    | Coil-12Vdc             |
| 3    | 110-0494    | 1    | Valve-Solenoid         |
| 3:1  | 110-8773    | 1    | Seal Kit               |
| 3:2  | 110-2634    | 1    | Nut-Coil               |
| 4    | 114-5510    | 1    | Valve-Relief, 3000 PSI |
| 4:1  | 105-9156    | 1    | Seal Kit               |

| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 5    | 114-5512    | 1    | Valve-Relief, 600 PSI |
| 5:1  | 105-9156    | 1    | Seal Kit              |
| 6    | 106-1027    | 1    | Plug-HYD              |
| 6:1  | 237-79      | 1    | O-Ring                |
| 7    | 353-990     | 1    | Plug ASM              |
| 7:1  | 237-78      | 1    | O-Ring                |
| 8    | 112-6538    | 1    | Orifice (.063)        |
| 9    | 117-2791    | 1    | Disc-Orifice (.050)   |




## Filter Manifold Assembly

| Ref. | Part Number | Qty. | Description         |
|------|-------------|------|---------------------|
| 1    | 119-7703    | 1    | Manifold-Filter     |
| 2    | 112-7374    | 1    | Fitting             |
| 3    | 114-0090    | 1    | Flange Kit          |
| 3:1  | 115-5420    | 1    | O-Ring              |
| 3:2  | 324-6       | 4    | Screw-HH            |
| 3:3  | 3253-6      | 4    | Washer-Lock         |
| 3:4  |             | 2    | Halve-Flange ●      |
| 4    | 340-79      | 1    | Fitting-Elbow 90    |
| 4:1  | 237-101     | 1    | O-Ring              |
| 4:2  | 340-65      | 1    | O-Ring              |
| 5    | 340-14      | 1    | Fitting-HYD, 45 DEG |


| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 5:1  | 237-65      | 1    | O-Ring                |
| 5:2  | 237-80      | 1    | O-Ring                |
| 6    | 340-105     | 1    | Fitting-Elbow, 90 DEG |
| 6:1  | 237-80      | 1    | O-Ring                |
| 6:2  | 237-30      | 1    | O-Ring                |
| 7    | 340-6       | 1    | Fitting-Straight      |
| 7:1  | 237-30      | 1    | O-Ring                |
| 7:2  | 237-80      | 1    | O-Ring                |
| 8    | 340-7       | 1    | Fitting-Straight      |
| 8:1  | 237-65      | 1    | O-Ring                |
| 8:2  | 237-80      | 1    | O-Ring                |

● Not serviced separately




## Hydraulic Filter Manifold Assembly No. 119-7703

| Ref. | Part Number | Qty. | Description         |
|------|-------------|------|---------------------|
| 1    | 115-5411    | 1    | Valve-Check, 43 PSI |
| 1:1  | 115-5416    | 1    | Seal Kit            |
| 2    | 106-1026    | 1    | Plug-HYD            |
| 2:1  | 237-42      | 1    | O-Ring              |



## Axle Assembly No. 114-5982-01

| Ref. | Part Number | Qty. | Description    |
|------|-------------|------|----------------|
| 1    | 69-6470     | 2    | Bushing-Castor |
| 2    | 100-2506    | 4    | Bushing-Castor |
| 3    | 302-5       | 2    | Fitting-Grease |




## Rear Axle Assembly

| Ref. | Part Number | Qty. | Description         |
|------|-------------|------|---------------------|
| 1    | 120-9886    | 2    | Wheel And Tire ASM  |
| 1:1  | 120-9884    | 1    | Rim-Wheel           |
| 1:2  | 117-2901    | 1    | Tire                |
| 1:3  | 5108        | 1    | Valve               |
| 2    | 92-7483     | 12   | Nut-Lug             |
| 3    | 325-11      | 8    | Screw-HH            |
| 4    | 3253-7      | 8    | Washer-Lock         |
| 5    | 114-5593    | 1    | HYD Motor ASM       |
| 6    | 3272-12     | 6    | Pin-Cotter          |
| 7    | 110-6049-03 | 1    | Tie Rod ASM         |
| 8    | 110-6015-01 | 1    | Spindle-Steer, RH   |
| 9    | 114-5594    | 1    | HYD Motor ASM       |
| 10   | 340-103     | 2    | Fitting-HYD, 45 DEG |
| 10:1 | 237-78      | 1    | O-Ring              |
| 10:2 | 237-21      | 1    | O-Ring              |
| 11   | 98-0661     | 2    | HYD Cylinder ASM    |
| 13   | 106-6895-03 | 2    | Ball Joint ASM      |
| 13:1 |             | 1    | Joint-Ball ●        |

| Ref.   | Part Number | Qty. | Description           |
|--------|-------------|------|-----------------------|
| 13:1:1 | 32136-13    | 1    | Nut-SHH               |
| 13:1:2 | 106-6896    | 1    | Seal                  |
| 13:1:3 | 302-5       | 1    | Fitting-Grease        |
| 13:1:4 | 3210-7      | 1    | Screw-HH              |
| 13:1:5 | 32152-5     | 1    | Nut-Hex               |
| 14     | 3234-12     | 2    | Screw-HHF             |
| 15     | 100-3362    | 2    | Cap-Spindle           |
| 16     | 100-4196    | 2    | Ring-Retaining        |
| 17     | 340-132     | 2    | Fitting-Elbow, 90 DEG |
| 17:1   | 237-78      | 1    | O-Ring                |
| 17:2   | 237-21      | 1    | O-Ring                |
| 18     | 32136-13    | 2    | Nut-SHH               |
| 20     | 100-2508    | 2    | Washer-Thrust         |
| 21     | 110-6013-01 | 1    | Spindle-Steer, LH     |
| 22     | 340-7       | 4    | Fitting-Straight      |
| 22:1   | 237-65      | 1    | O-Ring                |
| 22:2   | 237-80      | 1    | O-Ring                |
| 23     | 117-1102-03 | 2    | Hub-7.50 Inch, 6 Bolt |

● Not serviced separately




## Rear Axle Assembly (continued)

| Ref. | Part Number | Qty. | Description      |
|------|-------------|------|------------------|
| 24   | 10-6830     | 12   | Stud-Type, Drive |
| 25   | 117-5198    | 2    | Key-Square       |
| 26   | 325-6       | 2    | Screw-HH         |

| Ref. | Part Number | Qty. | Description |
|------|-------------|------|-------------|
| 27   | 99-5107     | 2    | Nut-Lock    |
| 28   | 30-8770     | 2    | Washer      |

● Not serviced separately




## Left Rear Wheel Hydraulic Motor Assembly No. 114-5593

| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 1    | 100-6131    | 1    | Seal Kit              |
| 1:1  |             | 1    | Ring-Back Up ●        |
| 1:2  |             | 1    | Washer-Back Up ●      |
| 1:3  |             | 1    | Seal-Shaft ●          |
| 1:4  |             | 5    | Seal-Ring ●           |
| 1:5  |             | 1    | Seal-Commutator ●     |
| 1:6  |             | 1    | Seal-Dirt And Water ● |
| 2    | 107-9319    | 1    | Nut-Hex               |

● Not serviced separately






## Tie Rod Assembly No. 110-6049-03

| Ref.  | Part Number | Qty. | Description        |
|-------|-------------|------|--------------------|
| 1     | 110-6141-03 | 1    | RH Tie Rod End ASM |
| 1:1   |             | 1    | Rod End-Tie, RH ●  |
| 1:1:1 | 302-5       | 1    | Fitting-Grease     |
| 1:1:2 | 32136-2     | 1    | Nut-SHH            |
| 2     | 110-6142-03 | 1    | LH Tie Rod End ASM |
| 2:1   |             | 1    | Rod End-Tie, LH ●  |
| 2:1:1 | 302-5       | 1    | Fitting-Grease     |
| 2:1:2 | 32136-2     | 1    | Nut-SHH            |
| 3     | 44-2200     | 1    | Screw-Blade        |
| 4     | 32153-7     | 1    | Nut-Lock           |


● Not serviced separately



## Right Rear Wheel Hydraulic Motor Assembly No. 114-5594

| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 1    | 100-6131    | 1    | Seal Kit              |
| 1:1  |             | 1    | Ring-Back Up ●        |
| 1:2  |             | 1    | Washer-Back Up ●      |
| 1:3  |             | 1    | Seal-Shaft ●          |
| 1:4  |             | 5    | Seal-Ring ●           |
| 1:5  |             | 1    | Seal-Commutator ●     |
| 1:6  |             | 1    | Seal-Dirt And Water ● |
| 2    | 107-9319    | 1    | Nut-Hex               |

● Not serviced separately




## Hydraulic Steering Cylinder Assembly No. 98-0661

| Ref. | Part Number | Qty. | Description      |
|------|-------------|------|------------------|
| 2    | 98-0667     | 1    | Repair Kit       |
| 2:1  |             | 1    | Ring-Retaining ● |
| 2:2  |             | 1    | Wiper-Rod ●      |
| 2:3  |             | 1    | Seal-U Cup ●     |
| 2:4  |             | 1    | Ring-Back Up ●   |
| 2:5  |             | 1    | O-Ring ●         |
| 2:6  |             | 1    | O-Ring ●         |
| 2:7  |             | 1    | Ring-Piston ●    |
| 2:8  |             | 1    | O-Ring ●         |
| 3    |             | 1    | Rod-Piston ●     |

| Ref. | Part Number | Qty. | Description      |
|------|-------------|------|------------------|
| 4    |             | 1    | Ring-Head ●      |
| 5    |             | 1    | Piston ●         |
| 6    |             | 1    | Nut-Lock ●       |
| 7    | 69-1980     | 1    | Nut-Jam          |
| 8    | 82-5730     | 1    | Tie Rod End ASM  |
| 8:1  | 105-7941    | 1    | Nut-Hex, Slotted |
| 8:2  | 105-7835    | 1    | Seal             |
| 8:3  | 302-5       | 1    | Fitting-Grease   |
| 9    | 32121-34    | 1    | Pin-Roll         |


● Not serviced separately



## Front Axle and Brake Assembly

| Ref. | Part Number | Qty. | Description              | Ref. | Part Number | Qty. | Description        |
|------|-------------|------|--------------------------|------|-------------|------|--------------------|
| 1    | 110-5974-01 | 1    | Frame-Axle, Front        | 16   | 105-6814    | 4    | Washer-Plain       |
| 2    | 100-3046    | 2    | Shaft-Brake, Splined     | 17   | 283-52      | 2    | Pin-Clevis         |
| 3    | 93-7972     | 4    | Ring-Retaining, Internal | 18   | 3232-17     | 2    | Screw-CARR         |
| 4    | 105-4500    | 2    | Planetary ASM            | 19   | 99-5107     | 10   | Nut-Lock           |
| 5    | 92-7483     | 16   | Nut-Lug                  | 20   | 3218-4      | 6    | Nut-Jam            |
| 6    | 114-4860    | 2    | Wheel And Tire ASM       | 21   | 94-3050     | 6    | Plate-Spring       |
| 6:1  | 114-4861    | 1    | Tire                     | 22   | 94-3088     | 2    | Spring-Compression |
| 6:2  | 114-4862    | 1    | Wheel                    | 23   | 114-0161    | 2    | Spacer-Plain       |
| 6:3  | 232-24      | 1    | Stem-Valve               | 24   | 110-5053    | 4    | Screw-HHF          |
| 7    | 119-8258    | 1    | Brake ASM                | 25   | 104-8300    | 2    | Nut-HF, NI         |
| 8    | 119-8259    | 1    | Brake ASM                | 26   | 114-0159    | 1    | Cable-Brake, RH    |
| 9    | 237-166     | 2    | O-Ring                   | 27   | 104-3797    | 4    | Fitting-Straight   |
| 10   | 33106-090   | 8    | Screw-HHF                | 27:1 | 237-146     | 1    | O-Ring             |
| 11   |             | 1    | Front PTO Valve ASM ●    | 27:2 | 340-65      | 1    | O-Ring             |
| 12   |             | 1    | Traction Valve ASM ●     | 28   | 94-2628     | 2    | Fitting-STR        |
| 13   | 3272-6      | 2    | Pin-Cotter               | 28:1 | 237-79      | 1    | O-Ring             |
| 14   | 114-0160-03 | 2    | Lever-Brake              | 28:2 | 237-30      | 1    | O-Ring             |
| 15   | 322-19      | 2    | Screw-HH                 | 29   | 33116-120   | 4    | Screw-HH           |

● Not serviced separately




## Front Axle and Brake Assembly (continued)

| Ref. | Part Number | Qty. | Description      |
|------|-------------|------|------------------|
| 30   | 3256-26     | 12   | Washer-Flat      |
| 31   | 114-4849    | 2    | Piston Motor ASM |
| 32   | 33106-030   | 12   | Screw-HHF        |

| Ref. | Part Number | Qty. | Description     |
|------|-------------|------|-----------------|
| 33   | 100-6116    | 8    | Screw-HHF       |
| 34   | 325-12      | 2    | Screw-HH        |
| 35   | 114-0158    | 1    | Cable-Brake, LH |

● Not serviced separately




## Planetary Assembly No. 105-4500

| Ref. | Part Number | Qty. | Description       |
|------|-------------|------|-------------------|
| 1    |             | 1    | Spindle ■         |
| 2    | 105-8122    | 1    | Seal-Boot         |
| 4    | 105-8120    | 1    | Bearing-Cone      |
| 5    | 105-8119    | 1    | Bearing-Cup       |
| 6    | 105-8124    | 8    | Stud-Wheel        |
| 7    | 105-8125    | 16   | Bolt-Head, Socket |
| 8    | 3253-18     | 16   | Washer-Lock       |
| 9    |             | 1    | Housing ■         |
| 10   | 105-8121    | 1    | Pin-Dowel         |
| 11   | 105-8117    | 1    | Bearing-Cup       |
| 12   | 105-8118    | 1    | Bearing-Cone      |
| 16   | 105-8113    | 1    | Gear-Ring         |
| 17   | 105-8132    | 1    | Ring-Retaining    |
| 18   | 353-990     | 2    | Plug ASM          |
| 18:1 | 237-78      | 1    | O-Ring            |
| 19   | 105-8138    | 1    | Cap-End           |
| 21   | 105-8133    | 1    | Plug-Thrust       |
| 22   | 105-8123    | 1    | Washer-Thrust     |
| 23   | 105-8131    | 1    | Ring-Retaining    |

| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 24   | 105-8114    | 1    | Gear-Primary          |
| 25   | 105-8115    | 1    | Shaft-Drive           |
| 26   | 105-8129    | 1    | Carrier-Primary       |
| 27   | 105-8139    | 1    | Gear-Secondary        |
| 28   | 105-8130    | 1    | Carrier-Secondary     |
| 29   | 105-8136    | 1    | Shim Kit              |
| 29:1 |             | 1    | Ring-Snap ■           |
| 29:2 |             | 1    | Shim-Bearing, 2.9Mm ■ |
| 29:3 |             | 1    | Shim-Bearing, 2.8Mm ■ |
| 29:4 |             | 1    | Shim-Bearing, 2.7Mm ■ |
| 29:5 |             | 1    | Shim-Bearing, 2.6Mm ■ |
| 29:6 |             | 1    | Shim-Bearing, 2.5Mm ■ |
| 29:7 |             | 1    | Shim-Bearing, 2.4Mm ■ |
| 30   | 105-8137    | 1    | Seal Kit ●            |
| 30:1 |             | 1    | O Ring-Flange Cap ■   |
| 30:2 |             | 1    | Seal-Oil ■            |
| 30:3 |             | 2    | O Ring-End Cap ■      |
| 30:4 | 237-78      | 2    | O-Ring                |


● Not illustrated

■ Not serviced separately



## Brake Assembly No. 119-8258


| Ref. | Part Number | Qty. | Description             |
|------|-------------|------|-------------------------|
| 2    | 93-7977     | 1    | Seal                    |
| 3    | 93-7978     | 1    | Rod-Pull                |
| 4    | 93-7983     | 2    | Pin-Clevis              |
| 5    | 93-7980     | 2    | Link                    |
| 6    | 93-7979     | 2    | Pin-Hitch               |
| 7    | 93-7986     | 4    | Disc-Stationary         |
| 8    | 119-8257    | 3    | Disc-Rotating, Metallic |
| 9    | 93-7976     | 1    | Ring-Retaining          |
| 10   | 93-7984     | 1    | Gasket                  |
| 11   | 104-4280    | 1    | Actuator-Rotating       |
| 12   | 93-7987     | 3    | Spring-Extension        |
| 13   | 93-7985     | 3    | Ball                    |
| 14   | 353-990     | 2    | Plug ASM                |
| 14:1 | 237-78      | 1    | O-Ring                  |



## Brake Assembly No. 119-8259

| Ref. | Part Number | Qty. | Description             |
|------|-------------|------|-------------------------|
| 2    | 93-7977     | 1    | Seal                    |
| 3    | 93-7978     | 1    | Rod-Pull                |
| 4    | 93-7983     | 2    | Pin-Clevis              |
| 5    | 93-7980     | 2    | Link                    |
| 6    | 93-7979     | 2    | Pin-Hitch               |
| 7    | 93-7986     | 4    | Disc-Stationary         |
| 8    | 119-8257    | 3    | Disc-Rotating, Metallic |
| 9    | 93-7976     | 1    | Ring-Retaining          |
| 10   | 93-7984     | 1    | Gasket                  |
| 11   | 104-4279    | 1    | Actuator-Rotating       |
| 12   | 93-7987     | 3    | Spring-Extension        |
| 13   | 93-7985     | 3    | Ball                    |
| 14   | 353-990     | 2    | Plug ASM                |
| 14:1 | 237-78      | 1    | O-Ring                  |







## Front PTO Valve Assembly


| Ref. | Part Number | Qty. | Description         |
|------|-------------|------|---------------------|
| 1    | 117-1110    | 1    | Manifold-PTO, Front |
| 2    | 354-77      | 1    | Fitting-Quick       |
| 2:1  | 237-78      | 1    | O-Ring              |
| 3    | 354-79      | 1    | Cap-Dust            |
| 4    | 100-5530    | 1    | Fitting-45 DEG      |
| 4:1  | 237-58      | 1    | O-Ring              |
| 4:2  | 237-81      | 1    | O-Ring              |
| 5    | 104-3509    | 1    | Fitting-HYD, 45 DEG |

| Ref. | Part Number | Qty. | Description      |
|------|-------------|------|------------------|
| 5:1  | 237-146     | 1    | O-Ring           |
| 5:2  | 340-65      | 1    | O-Ring           |
| 6    | 340-86      | 1    | Fitting-Tee      |
| 6:1  | 237-22      | 2    | O-Ring           |
| 6:2  | 237-42      | 1    | O-Ring           |
| 7    | 340-142     | 2    | Fitting-Elbow-90 |
| 7:1  | 237-58      | 1    | O-Ring           |
| 7:2  | 237-81      | 1    | O-Ring           |



## Hydraulic PTO Manifold Assembly No. 117-1110


| Ref. | Part Number | Qty. | Description            |
|------|-------------|------|------------------------|
| 1    | 114-5511    | 2    | Cartridge-Logic        |
| 1:1  | 119-8048    | 1    | Seal Kit               |
| 2    | 105-9333    | 1    | Coil-12Vdc             |
| 3    | 110-0494    | 1    | Valve-Solenoid         |
| 3:1  | 110-8773    | 1    | Seal Kit               |
| 3:2  | 110-2634    | 1    | Nut-Coil               |
| 4    | 114-5510    | 1    | Valve-Relief, 3000 PSI |
| 4:1  | 105-9156    | 1    | Seal Kit               |
| 5    | 114-5512    | 1    | Valve-Relief, 600 PSI  |
| 5:1  | 105-9156    | 1    | Seal Kit               |
| 6    | 106-1027    | 1    | Plug-HYD               |
| 6:1  | 237-79      | 1    | O-Ring                 |
| 7    | 117-2791    | 1    | Disc-Orifice (.050)    |



## Traction Valve Assembly

| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 1    | 110-6062    | 1    | Manifold-Traction     |
| 2    | 104-3795    | 1    | Fitting-Tee           |
| 2:1  | 340-65      | 2    | O-Ring                |
| 2:2  | 237-146     | 1    | O-Ring                |
| 3    | 340-129     | 1    | Fitting-Elbow, 90 DEG |
| 3:1  | 237-146     | 1    | O-Ring                |
| 3:2  | 340-65      | 1    | O-Ring                |
| 4    | 340-9       | 1    | Fitting-STR           |
| 4:1  | 237-58      | 1    | O-Ring                |
| 4:2  | 237-81      | 1    | O-Ring                |


| Ref. | Part Number | Qty. | Description      |
|------|-------------|------|------------------|
| 5    | 340-3       | 1    | Fitting-Straight |
| 5:1  | 237-22      | 1    | O-Ring           |
| 5:2  | 237-79      | 1    | O-Ring           |
| 6    | 354-77      | 1    | Fitting-Quick    |
| 6:1  | 237-78      | 1    | O-Ring           |
| 7    | 354-79      | 1    | Cap-Dust         |
| 8    | 340-2       | 1    | Fitting-Straight |
| 8:1  | 237-22      | 1    | O-Ring           |
| 8:2  | 237-42      | 1    | O-Ring           |



## Hydraulic Traction Manifold Assembly No. 110-6062

| Ref. | Part Number | Qty. | Description               |
|------|-------------|------|---------------------------|
| 1    | 115-5407    | 1    | Divider-Flow, 50/50 Split |
| 1:1  | 115-5414    | 1    | Seal Kit                  |
| 2    | 105-9333    | 1    | Coil-12Vdc                |
| 3    | 110-0494    | 1    | Valve-Solenoid            |
| 3:1  | 110-8773    | 1    | Seal Kit                  |
| 3:2  | 110-2634    | 1    | Nut-Coil                  |
| 4    | 106-1029    | 1    | Plug-Leak, Zero           |
| 4:1  | 237-81      | 1    | O-Ring                    |


| Ref. | Part Number | Qty. | Description              |
|------|-------------|------|--------------------------|
| 5    | 353-990     | 3    | Plug ASM                 |
| 5:1  | 237-78      | 1    | O-Ring                   |
| 6    | 106-1027    | 2    | Plug-HYD                 |
| 6:1  | 237-79      | 1    | O-Ring                   |
| 7    | 105-9321    | 1    | Check Valve ASM          |
| 7:1  | 105-9156    | 1    | Seal Kit                 |
| 8    | 115-5408    | 1    | Valve-Directional, Pilot |
| 8:1  | 115-5415    | 1    | Seal Kit                 |



## Hydraulic Motor Assembly No. 114-4849

| Ref. | Part Number | Qty. | Description          |
|------|-------------|------|----------------------|
| 1    | 94-3004     | 1    | Shaft-Drive, Splined |
| 2    |             | 1    | Backplate ASM ●      |
| 3    |             | 1    | Housing ASM ●        |
| 4    | 76-6910     | 1    | Rotating Kit         |
| 5    | 76-6970     | 1    | Insert-Plate, Cam    |
| 6    | 94-3002     | 6    | Screw-Cap            |
| 7    | 106-6876    | 1    | Seal Kit             |
| 7:1  |             | 1    | O-Ring ●             |
| 7:2  | 76-7010     | 1    | Ring-Retaining       |
| 7:3  | 76-7000     | 2    | Ring-Retaining       |
| 7:4  |             | 1    | Seal-Shaft ●         |
| 8    | 76-6950     | 2    | Race-Thrust          |
| 9    | 94-3003     | 1    | Plate-Valve          |
| 10   | 60-6240     | 1    | Washer               |
| 11   | 76-6960     | 1    | Bearing-Thrust       |

● Not serviced separately




## Seat and Platform Assembly

| Ref. | Part Number | Qty. | Description                   |
|------|-------------|------|-------------------------------|
| 1    |             | 1    | Seat And Suspension ASM       |
| 1:1  | 108-1488    | 1    | Seat Suspension ASM           |
| 2    | 112-7264    | 2    | Screw-HH                      |
| 3    | 92-2651     | 6    | Washer                        |
| 4    | 3256-25     | 4    | Washer-Flat                   |
| 5    | 110-0413    | 1    | Seatbelt-Retractable          |
| 6    | 3212-4      | 1    | Screw-HH                      |
| 7    | 117-9400    | 1    | Platform ASM                  |
| 7:1  | 114-0849    | 1    | Decal-Pedal, Traction         |
| 7:2  | 114-0846    | 1    | Decal-Instructions, Operating |
| 7:3  | 117-2718    | 1    | Decal-Arrester, Spark         |
| 8    | 104-8301    | 6    | Nut-HF, NI                    |
| 9    | 3231-22     | 4    | Screw-CARR                    |
| 10   | 125-5305-01 | 2    | Bracket-Headlight             |
| 11   | 114-5928    | 2    | Headlight ASM                 |
| 13   | 69-9290     | 2    | Pad-Bumper                    |

| Ref. | Part Number | Qty. | Description          |
|------|-------------|------|----------------------|
| 14   | 32108-103   | 4    | Screw-FH             |
| 15   | 104-8300    | 11   | Nut-HF, NI           |
| 16   | 99-5107     | 4    | Nut-Lock             |
| 17   | 115-5519    | 4    | Washer-Plain         |
| 18   | 110-5954    | 4    | Mount-Center, Bonded |
| 19   | 322-3       | 2    | Screw-HH             |
| 20   | 116749      | 1    | Horn                 |
| 21   | 702093      | 2    | Screw-HH             |
| 22   | 112-7449-03 | 1    | Bracket-Support      |
| 23   | 17-7190     | 1    | Spacer-Finger        |
| 24   | 112-7437-03 | 1    | Channel-Support      |
| 25   | 3230-1      | 5    | Bolt-CARR            |
| 26   | 3212-8      | 1    | Screw-HH             |
| 27   | 112-7446-03 | 1    | Support-Arm          |
| 28   | 33114-010   | 1    | Screw-HH             |
| 29   | 3253-4      | 1    | Washer-Lock          |
| 30   | 112-7405    | 1    | Nut-Hex, Coupling    |
| 31   | 104-7048    | 1    | Cap-Housing          |

● Not serviced separately




## Seat and Platform Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|------|-------------|------|-------------|
| 32   | 104-7050    | 1    | Tube-Manual |
| 33   | 107-1865    | 2    | R-Clamp     |
| 34   | 114-5553    | 4    | Shim-Pad    |
| 35   | 104-7201    | 2    | Nut-HF      |

| Ref. | Part Number | Qty. | Description |
|------|-------------|------|-------------|
| 36   | 32105-15    | 2    | Screw-HWH   |
| 37   | 107-3154    | 4    | Nut-Push    |
| 38   | 3256-45     | 2    | Washer-Flat |
| 39   | 323-10      | 2    | Screw-HH    |

● Not serviced separately

# Air Ride Seat Suspension Assembly No. 108-1488






# Air Ride Seat Suspension Assembly No. 108-1488 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|----------------------|-------------|--------------------|-------------|--------------------|
| 1           | 108-8026           | 1           | Cover ASM            | 9:1         |                    | 1           | Nut ■              |
| 1:1         | 39-5710            | 2           | Plug-Plastic         | 9:2         |                    | 5           | Tie-Wire ■         |
| 2           | 108-8027           | 1           | Cover                | 9:3         |                    | 4           | Tie-Wire ■         |
| 2:1         |                    | 2           | Rivet ■              | 9:4         |                    | 1           | Screw ■            |
| 3           | 108-8028           | 1           | Level Indicator Kit  | 9:5         |                    | 1           | Compressor ■       |
| 3:1         |                    | 2           | Rivet ■              | 9:6         |                    | 1           | Plate-Mounting ■   |
| 3:2         |                    | 2           | Washer ■             | 9:7         |                    | 1           | Nipple-Hose ■      |
| 4           | 108-8029           | 1           | Valve-Control, Air   | 9:8         |                    | 2           | Clamp ■            |
| 4:1         |                    | 1           | Handle ■             | 10          | 108-8035           | 1           | Bellows ASM        |
| 4:2         |                    | 3           | Screw ■              | 10:1        | 39-5710            | 23          | Plug-Plastic       |
| 5           | 108-8030           | 1           | Shock Absorber Kit   | 11          | 108-8036           | 1           | Stop Kit           |
| 5:1         |                    | 4           | Washer ■             | 11:1        |                    | 2           | Screw ■            |
| 5:2         |                    | 4           | C-Clip ■             | 12          | 107-1213           | 2           | Bumper Set         |
| 5:3         |                    | 2           | Pin ■                | 13          | 108-8037           | 4           | Roller             |
| 6           | 108-8031           | 1           | Air Spring Kit       | 14          | 108-8038           | 1           | Wear Parts Kit ●   |
| 6:1         |                    | 1           | Air Spring ■         | 14:1        |                    | 4           | Spacer ■           |
| 6:3         |                    | 2           | Cable Tie ■          | 14:2        | 39-5710            | 2           | Plug-Plastic       |
| 6:6         |                    | 2           | Screw ■              | 14:3        |                    | 1           | Bumper ■           |
| 6:7         |                    | 1           | Washer ■             | 14:4        |                    | 4           | Support-Housing ■  |
| 6:8         |                    | 1           | Nipple-Hose ■        | 14:5        |                    | 2           | Roller ■           |
| 7           | 108-8032           | 1           | Air Tube ASM         | 14:6        | 107-1213           | 2           | Bumper Set         |
| 7:1         |                    | 1           | Nipple-Hose ■        | 14:7        |                    | 2           | Screw ■            |
| 7:2         |                    | 7           | Tie-Wire ■           | 14:8        | 108-8037           | 4           | Roller             |
| 7:3         |                    | 4           | Tie-Wire ■           | 14:9        |                    | 9           | Tie-Wire ■         |
| 7:4         |                    | 1           | Nipple-Hose ■        | 14:10       |                    | 4           | Tie-Wire ■         |
| 8           | 108-8033           | 1           | Connecting Cable ASM | 14:11       |                    | 1           | Nipple-Hose ■      |
| 8:1         |                    | 8           | Tie-Wire ■           | 14:12       |                    | 1           | Screw ■            |
| 8:2         |                    | 4           | Tie-Wire ■           | 15          | 119-2161           | 1           | Tether Kit         |
| 9           | 108-8034           | 1           | Compressor Kit       |             |                    |             |                    |


● Not illustrated

■ Not serviced separately



## Head Light Assembly No. 114-5928


| Ref. | Part Number | Qty. | Description            |
|------|-------------|------|------------------------|
| 1    | 3217-6      | 1    | Nut-Hex                |
| 2    | 3217-9      | 1    | Nut-HH                 |
| 3    | 322-12      | 1    | Screw-HH               |
| 4    | 3253-4      | 1    | Washer-Lock            |
| 5    | 3253-7      | 1    | Washer-Lock            |
| 6    | 92-6595     | 1    | Lamp-Beam, Sealed      |
| 7    | 92-6596     | 1    | Bezel                  |
| 8    | 92-6597     | 1    | Bracket-Mounting       |
| 9    | 92-6598     | 1    | Bolt-Carriage, Drilled |
| 10   | 92-6599     | 4    | Screw                  |



## Steering Column Assembly

| Ref. | Part Number | Qty. | Description                 |
|------|-------------|------|-----------------------------|
| 1    | 117-5493-01 | 1    | Cover-Steering Tower, Front |
| 2    | 3234-33     | 12   | Screw-HHF                   |
| 3    | 323-7       | 2    | Screw-HH                    |
| 4    | 93-5988     | 3    | Hub-Pivot                   |
| 5    | 114-0167    | 1    | Steering Column ASM         |
| 5:1  | 256-132     | 2    | Bushing-Flange              |
| 6    | 9547        | 4    | Washer-Thrust               |
| 7    | 117-5492    | 1    | Steering Tower ASM          |
| 8    | 115-5447-01 | 1    | Guard-Visor                 |
| 9    | 112-3324    | 1    | Switch-Horn                 |
| 10   | 112-3313    | 1    | Nut-Weatherproof            |
| 11   | 125-5320    | 1    | Infocenter                  |
| 11:1 | 115-8884    | 4    | Nut-Thumb                   |
| 11:2 | 115-8885    | 4    | Stud                        |
| 12   | 107-8034    | 1    | Switch-Rocker, On-Off-On    |
| 13   | 100-1535    | 2    | Switch                      |
| 14   | 112-3530    | 1    | Switch-Rocker, On-On-On     |
| 15   | 99-7420     | 3    | Plug-Hole                   |
| 16   | 233-17      | 1    | Knob                        |
| 17   | 98-1459     | 1    | Decal                       |
| 18   | 108-9342    | 1    | Nut-Hex                     |


| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 19   | 3256-27     | 1    | Washer-Flat           |
| 20   | 98-1471     | 1    | Wheel-Steering        |
| 20:1 | 98-1468     | 1    | Cover-Wheel, Steering |
| 21   | 93-5429     | 1    | Collar-Foam           |
| 22   | 93-5439     | 1    | Seal-Steering         |
| 23   | 32151-29    | 2    | Ring-Retaining        |
| 24   | 93-5428     | 1    | Shaft-Steering        |
| 25   | 104-8301    | 3    | Nut-HF, NI            |
| 26   | 33115-016   | 4    | Screw-HH              |
| 27   | 3272-10     | 1    | Pin-Cotter            |
| 28   | 114-0190-03 | 1    | Pivot-Parking, Brake  |
| 29   | 3296-2      | 1    | Nut-Lock, NI          |
| 30   | 100-1270    | 1    | Switch-Proximity      |
| 31   | 100-4872    | 1    | Plate-Switch, Neutral |
| 32   | 3229-34     | 1    | Screw-CARR            |
| 33   | 95-1821-03  | 1    | Spring-Compression    |
| 34   | 114-0195    | 1    | Rod-Parking, Brake    |
| 35   | 63-7900-03  | 1    | Rack                  |
| 36   | 3256-22     | 2    | Washer-Flat           |
| 37   | 3272-5      | 1    | Pin-Cotter            |
| 38   | 3256-26     | 2    | Washer-Flat           |



## Steering Column Assembly (continued)


| Ref. | Part Number | Qty. | Description      |
|------|-------------|------|------------------|
| 39   | 93-5446     | 1    | Cap-Vinyl        |
| 40   | 323-8       | 1    | Screw-HH         |
| 41   | 114-5907-03 | 1    | Lever-Tilt       |
| 42   | 114-4854    | 1    | Spacer-Cup       |
| 43   | 13-0480     | 1    | Spring           |
| 44   | 107069      | 2    | Clip             |
| 45   | 340-2       | 5    | Fitting-Straight |
| 45:1 | 237-22      | 1    | O-Ring           |
| 45:2 | 237-42      | 1    | O-Ring           |

| Ref. | Part Number | Qty. | Description         |
|------|-------------|------|---------------------|
| 46   | 114-4900    | 1    | Steering Valve ASM  |
| 47   | 114-5554    | 1    | Decal-Center, Info  |
| 48   | 115-5417    | 2    | Strip-Foam          |
| 49   | 104-7201    | 1    | Nut-HF              |
| 50   | 117-5499    | 1    | Spacer-Deflector    |
| 51   | 55-9620     | 1    | Spacer-Plate, Pivot |
| 52   | 3274-9      | 1    | Screw-HSH           |
| 53   | 62-5550     | 1    | Decal               |




## Steering Tower Assembly No. 117-5492

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>          |
|-------------|--------------------|-------------|-----------------------------|
| 1           | 32148-6            | 10          | Nut-Clinch                  |
| 2           | 114-0844           | 1           | Decal-Column, Steering (LH) |
| 3           | 114-0845           | 1           | Decal-Column, Steering      |
| 4           | 114-0848           | 1           | Decal-Column, Steering (RH) |
| 5           | 114-0906           | 1           | Decal-Attachment            |




## Steering Valve Assembly No. 114-4900

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 115-5480           | 1           | Seal Kit           |



## Traction Pedal Assembly

| Ref. | Part Number | Qty. | Description           | Ref. | Part Number | Qty. | Description      |
|------|-------------|------|-----------------------|------|-------------|------|------------------|
| 1    | 3230-1      | 6    | Bolt-CARR             | 21   | 117-5451-01 | 1    | Bracket-Sensor   |
| 2    | 110-5986-01 | 1    | Pedal-Traction        | 22   | 117-5445    | 1    | Bushing Hub ASM  |
| 3    | 93-5368     | 1    | Abrasive-Pedal        | 22:1 | 95-7497     | 1    | Bushing-Wheel    |
| 4    | 93-5347     | 1    | Abrasive-Pedal        | 23   | 114-5609    | 1    | Sensor-Position  |
| 5    | 117-5450    | 1    | Shaft-Pedal, Traction | 24   | 114-5608    | 2    | Spacer-Standoff  |
| 6    | 104-7201    | 2    | Nut-HF                | 25   | 114-5595    | 1    | Plate-Capture    |
| 7    | 117-5459    | 2    | Block-Clamp           | 26   | 32105-25    | 2    | Screw-SHH        |
| 8    | 104-8300    | 10   | Nut-HF, NI            | 27   | 117-5452-01 | 1    | Bracket-Spring   |
| 9    | 256-236     | 1    | Bearing-Mount, Flange | 28   | 3256-24     | 1    | Washer-Flat      |
| 10   | 117-5455    | 1    | Plate-Cover           | 29   | 3296-6      | 1    | Nut-Lock         |
| 11   | 117-5454    | 1    | Plate-Butterfly       | 30   | 92-7610     | 1    | Retainer-Spring  |
| 12   | 322-14      | 1    | Screw-HH              | 31   | 84-9100     | 1    | Spring           |
| 13   | 3253-4      | 1    | Washer-Lock           | 32   | 3256-5      | 1    | Washer-Flat      |
| 14   | 32121-78    | 1    | Pin-Roll              | 33   | 117-5446    | 1    | Shaft-Spring     |
| 15   | 117-5453-01 | 1    | Bracket-Butterfly     | 34   | 3219-3      | 1    | Nut-Hex          |
| 16   | 93-7960     | 1    | Spacer                | 35   | 2411-36     | 1    | Bearing-End, Rod |
| 17   | 322-5       | 1    | Screw-HH              | 36   | 321-37      | 2    | Screw-HH         |
| 18   | 114-7728    | 2    | Screw-Threadlock      | 37   | 3296-59     | 1    | Nut-Lock, NI     |
| 19   | 322-3       | 3    | Screw-HH              | 38   | 323-7       | 1    | Screw-HH         |
| 20   | 3296-9      | 2    | Nut-Hex               |      |             |      |                  |




## Brake Pedal Assembly

| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 1    | 256-236     | 2    | Bearing-Mount, Flange |
| 2    | 32121-16    | 1    | Pin-Spring            |
| 3    | 75-1470     | 1    | Pin-Pivot, Brake      |
| 4    | 283-61      | 2    | Pin-Yoke              |
| 5    | 100-5540    | 2    | Strap-Brake           |
| 6    | 75-1440-03  | 1    | Pedal-Brake, LH       |
| 7    | 3256-69     | 5    | Washer-Flat           |
| 8    | 75-1430     | 1    | RH Brake Pedal ASM    |
| 8:2  | 256-42      | 2    | Bushing               |
| 8:3  | 302-5       | 1    | Fitting-Grease        |
| 9    | 93-8742     | 2    | Footpad-Brake         |
| 10   | 32121-50    | 1    | Pin-Spring            |

| Ref. | Part Number | Qty. | Description      |
|------|-------------|------|------------------|
| 11   | 63-7880     | 1    | Pin-Latch, Brake |
| 12   | 93-5262     | 2    | Spring-Extension |
| 13   | 3272-6      | 2    | Pin-Cotter       |
| 14   | 322-3       | 2    | Screw-HH         |
| 15   | 104-8300    | 4    | Nut-HF, NI       |
| 16   | 108-9824    | 2    | Nut-Switch       |
| 17   | 99-3410     | 2    | Switch           |
| 18   | 114-0740-01 | 1    | Bracket-Switch   |
| 19   | 117-5458    | 4    | Screw-HHF        |
| 20   | 3234-33     | 3    | Screw-HHF        |
| 21   | 107069      | 3    | Clip             |
| 22   | 322-2       | 2    | Screw-HH         |






## Control Console Assembly

| Ref. | Part Number | Qty. | Description         |
|------|-------------|------|---------------------|
| 1    | 95-8999     | 1    | Switch              |
| 2    | 3296-12     | 1    | Nut-Lock, NI        |
| 3    | 108-7604    | 1    | Cover-LH            |
| 4    | 121-3876-03 | 1    | Panel               |
| 5    | 121-5159    | 1    | Ignition Switch ASM |
| 5:2  | 121-5160    | 1    | Nut-Hex             |
| 5:3  | 121-5161    | 1    | Nut-Face            |
| 5:4  | 121-5162    | 1    | Set-Key, Ignition   |
| 6    | 108-7605    | 1    | Cover-RH            |
| 7    | 3250-22     | 1    | Screw-PPH           |
| 8    | 3234-21     | 2    | Screw-HHF           |
| 9    | 115-8849-03 | 1    | Plate-Cover         |
| 10   | 117-2382    | 2    | Plug-Plastic        |
| 11   | 114-3329    | 1    | Switch-Rocker       |
| 12   | 106-2027    | 1    | Switch-Intermittent |
| 13   | 100-1535    | 3    | Switch              |
| 14   | 114-0135    | 1    | Decal-Console, Lift |


| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 15   | 108-7602    | 1    | Rest-Arm              |
| 16   | 127-3531-03 | 1    | Panel-Control         |
| 17   | 104-8300    | 3    | Nut-HF, NI            |
| 19   | 94-2413     | 4    | Nut-U                 |
| 21   | 93-9999     | 1    | Switch-PTO            |
| 22   | 3234-5      | 5    | Screw-HHF             |
| 23   | 104-8301    | 2    | Nut-HF, NI            |
| 24   | 3234-42     | 2    | Screw-HHF             |
| 25   | 32144-112   | 10   | Screw-HWH             |
| 27   | 107069      | 2    | Clip                  |
| 30   | 110-0542    | 2    | Spacer-Flange         |
| 32   | 3290-378    | 1    | Tie-Cable             |
| 33   | 121-3889    | 1    | Step-Elevated, Switch |
| 34   | 3269-17     | 2    | Rivet-Pop             |
| 35   | 114-0133    | 1    | Decal-Console, Lower  |
| 36   | 121-3883    | 1    | Decal-Console, PTO    |
| 37   | 121-3884    | 1    | Decal-Console, Upper  |

# Electrical Component Assembly



## Electrical Component Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    |
|-------------|--------------------|-------------|----------------------------|-------------|--------------------|-------------|-----------------------|
| 1           | 112-7316           | 1           | Cover-Storage, Center      | 25          | 321-44             | 4           | Screw-HHF             |
| 2           | 3296-27            | 4           | Nut-Lock, NI               | 26          | 32105-15           | 1           | Screw-HWH             |
| 3           | 3290-357           | 4           | Nut-HHF, Whiz              | 27          | 114-5502           | 1           | Clip-Fuse             |
| 4           | 104-7201           | 9           | Nut-HF                     | 28          | 122-0274           | 1           | Harness-Wire          |
| 5           | 99-7435            | 4           | Relay                      | 28:17       | 104-9055           | 1           | Fuse-Blade, 1 Amp     |
| 6           | 3296-2             | 11          | Nut-Lock, NI               | 28:18       | 94-6710            | 2           | Fuse-2 Amp            |
| 7           | 3229-11            | 4           | Screw-CARR                 | 28:19       | 110928             | 1           | Fuse-Blade, 5 Amp     |
| 8           | 3273-26            | 4           | Screw-HSH                  | 28:20       | 114241             | 6           | Fuse-Blade, 7.5 Amp   |
| 9           | 110-8822           | 1           | Block-Junction             | 28:21       | 218-578            | 4           | Fuse-Blade, 10 Amp    |
| 11          | 32105-13           | 11          | Screw-HWH                  | 28:22       | 109355             | 1           | Fuse-Blade, 15 Amp    |
| 12          | 112-7315           | 1           | Cover-Power, Center        | 28:23       | 109103             | 2           | Fuse-Blade, 30 Amp    |
| 13          | 94-5583            | 1           | Knob                       | 28:24       | 114-3342           | 1           | Fuse-Maxi, 60 Amp     |
| 14          | 125-5319           | 1           | Lid-Center, Storage        | 29          | 114-5508           | 1           | Rod-Hinge             |
| 14:2        | 117-2754           | 1           | Decal-Warning              | 30          | 115-5417           | 2           | Strip-Foam            |
| 14:3        | 130-2449           | 1           | Decal-Service              | 31          | 121-3874           | 1           | Wrench ASM            |
| 15          | 3218-2             | 1           | Nut-Jam                    | 31:2        | 119-1846           | 1           | Grip                  |
| 16          | 115-1900           | 1           | Controller                 | 32          | 125-5263           | 1           | Decal-Fuse            |
| 17          | 125-5265           | 1           | Power Center Bracket ASM   | 33          | 42863              | 1           | Strip-Jumper          |
| 17:2        | 115-5459           | 1           | Decal-Warning              | 35          | 3254-6             | 1           | Washer-Lock, Internal |
| 18          | 322-5              | 1           | Screw-HH                   | 36          | 110-8823           | 1           | Block-Junction        |
| 19          | 42862              | 1           | Block-Terminal, Ground     | 38          | 115-5592           | 1           | Mount-Post, Positive  |
| 20          | 80-9330            | 1           | Audio Alarm ASM            | 39          | 3290-409           | 2           | Rivet                 |
| 20:1        | 104-5107           | 1           | Nut-Plastic, Knurled       | 40          | 113690             | 1           | Nut-Coupling          |
| 21          | 114-3321           | 1           | Controller-Tec             | 42          | 3256-55            | 8           | Washer-Flat           |
| 22          | 125-5262-01        | 1           | Bracket-Power Center, Rear | 43          | 117-2382           | 8           | Plug-Plastic          |
| 23          | 99-7411            | 1           | Point-Power                | 44          | 99-7430            | 2           | Relay-Mini 280        |
| 24          | 99-7416            | 1           | Cap                        |             |                    |             |                       |




## Battery and Lift Manifold Assembly

| Ref. | Part Number | Qty. | Description             |
|------|-------------|------|-------------------------|
| 1    |             | 2    | Battery-12 Volt, Wet ●■ |
| 2    | 121-3886-01 | 1    | Panel-Access, Rear      |
| 3    | 3234-42     | 5    | Screw-HHF               |
| 4    | 114-5681-03 | 1    | Support-Fuse            |
| 5    | 110-8820    | 1    | Fuse-Mega, 300A         |
| 6    | 114-5682    | 2    | Strap-Jumper            |
| 7    | 3255-8      | 6    | Washer-Lock             |
| 8    | 32149-8     | 2    | Nut-Keps                |
| 9    | 3234-1      | 8    | Screw-HHF               |
| 10   |             | 1    | Lift Manifold ASM ■     |
| 11   | 354-93      | 2    | Fitting-Elbow, 90       |
| 12   | 114-0832    | 1    | Hose-Fuel               |
| 13   | 2412-108    | 2    | Clamp-Worm              |
| 14   | 114-5585    | 2    | Shim-Support, Hood      |
| 15   | 122-0275    | 1    | Harness-Wire, Rear      |
| 15:1 | 117-5461    | 1    | Harness-Wire, Starter   |
| 16   | 104-8301    | 7    | Nut-HF, NI              |

| Ref. | Part Number | Qty. | Description                     |
|------|-------------|------|---------------------------------|
| 17   | 114-0149    | 1    | Fuel/Water Separator Filter ASM |
| 17:1 | 115-5470    | 1    | Gasket-Beveled                  |
| 17:2 | 115-5471    | 1    | Element-Separator, Fuel/Water   |
| 17:3 | 115-5472    | 1    | O Ring-Bowl                     |
| 18   | 114-0881    | 2    | Strap-Battery                   |
| 19   | 114-0170    | 1    | Sensor-Wif                      |
| 20   | 104-7201    | 2    | Nut-HF                          |
| 21   | 121-3885-01 | 1    | Cover-Battery                   |
| 22   | 700806      | 2    | Knob                            |
| 23   | 323-7       | 2    | Screw-HH                        |
| 24   | 119-7732-03 | 1    | Plate-Mount, Filter             |
| 25   | 340-148     | 1    | Fitting-Tee                     |
| 25:1 | 237-81      | 1    | O-Ring                          |
| 25:2 | 237-58      | 2    | O-Ring                          |
| 26   | 96-0864     | 1    | Fitting-Straight                |
| 26:1 | 237-81      | 1    | O-Ring                          |

● Obtain locally.

■ Not serviced separately




## Battery and Lift Manifold Assembly (continued)

| Ref. | Part Number | Qty. | Description       |
|------|-------------|------|-------------------|
| 27   | 340-157     | 1    | Fitting-HYD, Tee  |
| 27:1 | 237-79      | 1    | O-Ring            |
| 27:2 | 237-30      | 2    | O-Ring            |
| 28   | 3220-2      | 2    | Nut-Jam           |
| 29   | 114-3315    | 1    | Solenoid          |
| 30   | 33004-00    | 4    | Nut-HF            |
| 31   | 110-8818    | 1    | Fuse-Mega, 125A   |
| 32   | 114-3318    | 2    | Holder-Fuse, Mega |

| Ref. | Part Number | Qty. | Description        |
|------|-------------|------|--------------------|
| 33   | 104-8300    | 4    | Nut-HF, NI         |
| 34   | 94-2413     | 2    | Nut-U              |
| 35   | 119-8252-03 | 1    | Support-Hood       |
| 36   | 321-11      | 2    | Screw-HH           |
| 37   | 32180-008   | 1    | Insulator-Lug, Red |
| 38   | 3234-47     | 4    | Screw-HHF          |
| 39   | 108-9683    | 1    | Strip-Foam         |

● Obtain locally.


■ Not serviced separately



## Hydraulic Lift Manifold Assembly

| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 1    | 119-7731    | 1    | HYD Lift Manifold ASM |
| 2    | 340-77      | 4    | Fitting-Elbow, 90 DEG |
| 2:1  | 237-22      | 1    | O-Ring                |
| 2:2  | 237-42      | 1    | O-Ring                |
| 3    | 340-4       | 2    | Fitting-Straight      |
| 3:1  | 237-30      | 1    | O-Ring                |
| 3:2  | 237-79      | 1    | O-Ring                |
| 4    | 340-9       | 1    | Fitting-STR           |
| 4:1  | 237-58      | 1    | O-Ring                |
| 4:2  | 237-81      | 1    | O-Ring                |

| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 5    | 340-17      | 1    | Fitting-Elbow, 90 DEG |
| 5:1  | 237-65      | 1    | O-Ring                |
| 5:2  | 237-80      | 1    | O-Ring                |
| 6    | 354-77      | 1    | Fitting-Quick         |
| 6:1  | 237-78      | 1    | O-Ring                |
| 7    | 354-79      | 2    | Cap-Dust              |
| 8    | 340-86      | 1    | Fitting-Tee           |
| 8:1  | 237-22      | 2    | O-Ring                |
| 8:2  | 237-42      | 1    | O-Ring                |
| 9    | 86-5480     | 1    | Nipple-Test           |




## Hydraulic Lift Manifold Assembly No. 119-7731

| Ref. | Part Number | Qty. | Description        |
|------|-------------|------|--------------------|
| 1    | 106-1027    | 1    | Plug-HYD           |
| 1:1  | 237-79      | 1    | O-Ring             |
| 2    | 115-5400    | 4    | Solenoid Valve ASM |
| 2:1  | 107-7813    | 1    | Seal Kit           |
| 2:2  | 110-2634    | 1    | Nut-Coil           |
| 3    | 115-5405    | 1    | Solenoid Valve ASM |
| 3:1  | 115-5413    | 1    | Seal Kit           |
| 3:2  | 110-2634    | 1    | Nut-Coil           |
| 4    | 115-5404    | 1    | Valve-Solenoid     |
| 4:1  | 105-9159    | 1    | Seal Kit           |
| 4:2  | 110-2634    | 1    | Nut-Coil           |
| 5    | 119-7706    | 2    | Valve-Solenoid     |
| 5:1  | 119-7716    | 1    | Seal Kit           |
| 5:2  | 110-2634    | 1    | Nut-Coil           |
| 6    | 107-7517    | 1    | Valve-Solenoid     |
| 6:1  | 105-9156    | 1    | Seal Kit           |

| Ref. | Part Number | Qty. | Description         |
|------|-------------|------|---------------------|
| 6:2  | 107-7812    | 1    | Nut-Solenoid        |
| 7    | 105-9333    | 4    | Coil-12Vdc          |
| 8    | 110-2630    | 5    | Coil-12Vdc          |
| 9    | 115-5499    | 1    | Valve-Relief        |
| 9:1  | 105-9156    | 1    | Seal Kit            |
| 10   | 106-1026    | 2    | Plug-HYD            |
| 10:1 | 237-42      | 1    | O-Ring              |
| 11   | 353-990     | 7    | Plug ASM            |
| 11:1 | 237-78      | 1    | O-Ring              |
| 12   |             | 6    | Plug-Expander ●     |
| 13   | 119-7721    | 1    | Valve-Logic, Vented |
| 13:1 | 119-2159    | 1    | Seal Kit            |
| 14   | 115-5406    | 1    | Divider-Flow        |
| 14:1 | 110-6111    | 1    | Seal Kit            |
| 15   |             | 1    | Manifold Block ●    |

● Not serviced separately



## Front Deck Lift Arm and Cylinder Assembly


| Ref. | Part Number | Qty. | Description      |
|------|-------------|------|------------------|
| 1    |             | 1    | Front Deck ASM ■ |
| 2    | 99-5107     | 4    | Nut-Lock         |
| 3    | 3256-26     | 12   | Washer-Flat      |
| 4    | 104-3542    | 3    | Spider           |
| 5    | 110-8815    | 3    | Nut-Hex          |
| 6    | 112-6957    | 3    | Washer-Hardened  |
| 7    | 104-3541    | 3    | Hub-Spider       |
| 8    | 340-142     | 5    | Fitting-Elbow-90 |
| 8:1  | 237-58      | 1    | O-Ring           |
| 8:2  | 237-81      | 1    | O-Ring           |
| 9    | 3234-42     | 6    | Screw-HHF        |
| 10   | 114-4940    | 3    | Gear Motor ASM   |
| 11   | 340-2       | 3    | Fitting-Straight |
| 11:1 | 237-22      | 1    | O-Ring           |
| 11:2 | 237-42      | 1    | O-Ring           |
| 13   | 114-5671    | 1    | Bracket-Sensor   |
| 14   | 321-4       | 2    | Screw-HH         |
| 15   | 3256-22     | 2    | Washer-Flat      |

| Ref. | Part Number | Qty. | Description               |
|------|-------------|------|---------------------------|
| 16   | 106-9288    | 1    | Sensor-Proximity, Ferrous |
| 17   | 3229-34     | 1    | Screw-CARR                |
| 18   | 100-4872    | 1    | Plate-Switch, Neutral     |
| 19   | 3234-29     | 2    | Screw-HHF                 |
| 20   | 1-811010    | 2    | Plug                      |
| 21   | 125-1912    | 2    | Pin-Pivot                 |
| 22   | 3296-25     | 4    | Nut-Lock, NI              |
| 23   | 110-5962    | 1    | LH Front Lift Arm ASM     |
| 23:1 | 104-0015    | 2    | Bushing-Flange            |
| 23:2 | 302-11      | 2    | Fitting-Lube, 45 DEG      |
| 23:3 | 105-7468    | 1    | Stud-Tapered              |
| 23:4 | 105-7441    | 1    | Bearing-Spherical         |
| 23:5 | 32128-42    | 1    | Nut-HF                    |
| 23:6 | 32151-34    | 1    | Ring-Retaining            |
| 24   | 110-5966    | 1    | RH Front Lift Arm ASM     |
| 24:1 | 104-0015    | 2    | Bushing-Flange ●          |
| 24:2 | 302-11      | 2    | Fitting-Lube, 45 DEG ●    |
| 24:3 | 105-7468    | 1    | Stud-Tapered ●            |

● Not illustrated

■ Not serviced separately






## Front Deck Lift Arm and Cylinder Assembly (continued)

| Ref. | Part Number | Qty. | Description            |
|------|-------------|------|------------------------|
| 24:4 | 105-7441    | 1    | Bearing-Spherical ●    |
| 24:5 | 32128-42    | 1    | Nut-HF ●               |
| 24:6 | 32151-34    | 1    | Ring-Retaining ●       |
| 25   | 325-17      | 4    | Screw-HH               |
| 26   | 92-2743     | 2    | Pin-Clevis             |
| 27   | 3290-467    | 2    | Pin-Hair               |
| 28   | 3296-41     | 2    | Nut-Lock NI            |
| 29   | 86-1440     | 2    | Washer-Flat            |
| 30   | 115-5442-01 | 2    | Support-Hub            |
| 31   | 95-6231     | 2    | Chain-HOC              |
| 32   | 104-0108    | 2    | U-Bolt                 |
| 33   | 3218-5      | 4    | Nut-Jam                |
| 34   | 302-5       | 4    | Fitting-Grease         |
| 35   | 114-4831    | 1    | LH Lift Cylinder ASM   |
| 36   | 114-4830    | 1    | RH Lift Cylinder ASM ● |
| 37   | 340-77      | 4    | Fitting-Elbow, 90 DEG  |

| Ref. | Part Number | Qty. | Description        |
|------|-------------|------|--------------------|
| 37:1 | 237-22      | 1    | O-Ring             |
| 37:2 | 237-42      | 1    | O-Ring             |
| 38   | 104-8300    | 3    | Nut-HF, NI         |
| 39   | 32121-110   | 2    | Pin-Roll, Slotted  |
| 40   | 3296-49     | 2    | Nut-Lock, NI       |
| 41   | 100-3017    | 2    | Pin-Arm, Lift      |
| 42   | 3296-2      | 1    | Nut-Lock, NI       |
| 43   | 3272-30     | 4    | Pin-Cotter         |
| 44   | 110-6006    | 2    | Pin-Clevis         |
| 45   | 104-7201    | 2    | Nut-HF             |
| 46   | 3230-4      | 1    | Bolt-CARR          |
| 47   | 114-0738-01 | 1    | Sensor Trigger ASM |
| 48   | 3257-3      | 3    | Key-Woodruff       |
| 49   | 69-8790-01  | 2    | Plate-Reinforcing  |
| 50   | 75-7730     | 2    | Washer-Thrust      |
| 51   | 3256-29     | 8    | Washer-Flat        |

● Not illustrated


■ Not serviced separately



## Hydraulic Gear Motor Assembly No. 114-4940

| Ref. | Part Number | Qty. | Description             |
|------|-------------|------|-------------------------|
| 1    | 114-5620    | 1    | Seal Kit                |
| 1:1  |             | 1    | Seal-Shaft ●            |
| 1:2  |             | 1    | Seal-Shaft ●            |
| 1:3  |             | 2    | Seal-Anti Extrusion ●   |
| 1:4  |             | 2    | Seal-Plate, Balancing ● |
| 1:5  |             | 2    | O Ring-Housing ●        |


● Not serviced separately



## Hydraulic Cylinder Assembly No. 114-4830

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 114-5611           | 1           | Seal Kit           |
| 1:1         |                    | 1           | O-Ring ●           |
| 1:2         |                    | 1           | Backup ●           |
| 1:3         |                    | 1           | Seal-Bp ●          |
| 1:4         |                    | 1           | Seal-Bs ●          |
| 1:5         |                    | 1           | Ring-Wear ●        |
| 1:6         |                    | 1           | Seal-Dust ●        |
| 1:7         |                    | 1           | O-Ring ●           |


● Not serviced separately



## Hydraulic Cylinder Assembly No. 114-4831

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 114-5611           | 1           | Seal Kit           |
| 1:1         |                    | 1           | O-Ring ●           |
| 1:2         |                    | 1           | Backup ●           |
| 1:3         |                    | 1           | Seal-Bp ●          |
| 1:4         |                    | 1           | Seal-Bs ●          |
| 1:5         |                    | 1           | Ring-Wear ●        |
| 1:6         |                    | 1           | Seal-Dust ●        |
| 1:7         |                    | 1           | O-Ring ●           |

● Not serviced separately




## Wing Lift Arm Assembly

| Ref.  | Part Number | Qty. | Description        |
|-------|-------------|------|--------------------|
| 1     | 114-5650-01 | 1    | RH Lift Arm ASM ●  |
| 1:1   |             | 1    | Arm-Lift, RH ●■    |
| 1:1:1 | 69-6470     | 2    | Bushing-Castor ●   |
| 1:1:2 | 114-5596    | 2    | Bushing-Straight ● |
| 1:1:3 | 302-60      | 1    | Fitting-Grease ●   |
| 1:1:4 | 302-5       | 1    | Fitting-Grease ●   |
| 2     | 114-5660-01 | 1    | LH Lift Arm ASM    |
| 2:1   |             | 1    | Arm-Lift, LH ■     |
| 2:1:1 | 69-6470     | 2    | Bushing-Castor     |
| 2:1:2 | 114-5596    | 2    | Bushing-Straight   |
| 2:1:3 | 302-60      | 1    | Fitting-Grease     |
| 2:1:4 | 302-5       | 1    | Fitting-Grease     |
| 3     | 302-5       | 2    | Fitting-Grease     |
| 4     | 104-8300    | 6    | Nut-HF, NI         |
| 5     | 125-1912    | 2    | Pin-Pivot          |
| 6     | 322-5       | 2    | Screw-HH           |
| 7     | 340-2       | 2    | Fitting-Straight   |
| 7:1   | 237-22      | 1    | O-Ring             |

| Ref. | Part Number | Qty. | Description                   |
|------|-------------|------|-------------------------------|
| 7:2  | 237-42      | 1    | O-Ring                        |
| 8    | 114-5685    | 2    | HYD Cylinder ASM              |
| 9    | 104-8300    | 4    | Nut-HF, NI                    |
| 10   | 119-7707    | 2    | Fitting-HYD, Straight (Check) |
| 10:1 | 237-22      | 1    | O-Ring                        |
| 10:2 | 237-42      | 1    | O-Ring                        |
| 11   | 112-7339    | 2    | Plate-Sensing                 |
| 12   | 3229-34     | 2    | Screw-CARR                    |
| 13   | 112-7338    | 2    | Plate-Aluminum                |
| 14   | 3290-412    | 6    | Rivet-Blind                   |
| 15   | 106-9288    | 2    | Sensor-Proximity, Ferrous     |
| 16   | 100-4872    | 2    | Plate-Switch, Neutral         |
| 17   | 3296-2      | 2    | Nut-Lock, NI                  |
| 18   | 3234-46     | 2    | Screw-HHF                     |
| 19   | 3256-26     | 2    | Washer-Flat                   |
| 20   | 104-3577    | 4    | Washer                        |
| 21   | 104-8301    | 4    | Nut-HF, NI                    |

● Not illustrated

■ Not serviced separately




## Wing Lift Arm Assembly (continued)

| Ref. | Part Number | Qty. | Description    |
|------|-------------|------|----------------|
| 22   | 119-7723-03 | 2    | Latch-Wing     |
| 23   | 114-5659-03 | 2    | Handle-Latch   |
| 24   | 48-7081     | 2    | Grip-Plastic   |
| 25   | 3231-25     | 4    | Bolt-CARR      |
| 26   | 3230-16     | 4    | Screw-CARR     |
| 27   | 99-5107     | 2    | Nut-Lock       |
| 28   | 115-5468    | 2    | Pivot Hub ASM  |
| 28:1 | 115-5469    | 2    | Bushing-Flange |
| 28:2 | 114-5680    | 2    | Bushing-Flange |
| 28:3 | 302-60      | 1    | Fitting-Grease |

| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 29   | 98-1452     | 4    | Washer-Thrust         |
| 30   | 114-5675    | 2    | Shim-Pad              |
| 31   | 69-9300     | 4    | Pad-Bumper            |
| 32   | 3289-22     | 4    | Screw-FH              |
| 33   | 121-3882    | 2    | Shaft-Pivot, Lift Arm |
| 34   | 106-2008    | 2    | Washer-Thrust         |
| 35   | 325-5       | 2    | Screw-HH              |
| 36   | 117-5479    | 4    | Pin-Spring            |
| 37   | 302-60      | 2    | Fitting-Grease        |

● Not illustrated


■ Not serviced separately



## Hydraulic Cylinder Assembly No. 114-5685

| Ref. | Part Number | Qty. | Description    |
|------|-------------|------|----------------|
| 1    | 114-5612    | 1    | Seal Kit       |
| 1:1  |             | 1    | O-Ring ●       |
| 1:2  |             | 1    | Backup ●       |
| 1:3  |             | 1    | Seal-Bp ●      |
| 1:4  |             | 1    | Ring-Wear ●    |
| 1:5  |             | 1    | Seal-Bs ●      |
| 1:6  |             | 1    | Ring-Wear ●    |
| 1:7  |             | 1    | Seal-Dust ●    |
| 1:8  |             | 1    | O-Ring ●       |
| 2    | 117-9407    | 1    | Bushing-Connex |

● Not serviced separately



## Wing Connection and Impact Arm Assembly


| Ref.  | Part Number | Qty. | Description           |
|-------|-------------|------|-----------------------|
| 1     |             | 1    | Right Deck ASM ● ■    |
| 2     |             | 1    | Left Deck ASM ■       |
| 3     | 323-7       | 8    | Screw-HH              |
| 4     | 117-9419    | 2    | Plate-Spacer          |
| 5     | 3296-51     | 2    | Nut-Lock, NI          |
| 6     | 328-5       | 2    | Screw-HH              |
| 7     | 104-0731    | 4    | Shim                  |
| 8     | 115-8870-03 | 4    | Mount-Base            |
| 9     | 114-5640-03 | 2    | Joint Yoke ASM        |
| 9:1   |             | 1    | Yoke-Joint ■          |
| 9:1:1 | 104-4299    | 1    | Cross And Bearing Kit |
| 10    | 104-0720    | 2    | Spacer                |
| 11    | 104-0721    | 4    | Washer-Thrust         |
| 12    | 104-2281    | 2    | Shaft-Pivot           |
| 13    | 114-5641    | 2    | Washer-Thrust         |
| 14    | 104-0719    | 2    | Washer-Hardened       |
| 15    | 3296-53     | 2    | Nut-Lock, NI          |
| 16    | 3253-8      | 2    | Washer-Lock           |
| 17    | 112-7330-03 | 2    | Arm-Impact, Rear      |
| 18    | 104-8301    | 8    | Nut-HF, NI            |
| 19    | 3220-9      | 4    | Nut-Jam               |
| 20    | 3256-62     | 2    | Washer-Flat           |
| 21    | 114-5986    | 6    | Washer-Plain          |
| 22    | 114-5992    | 2    | Bearing-Plastic       |

| Ref. | Part Number | Qty. | Description          |
|------|-------------|------|----------------------|
| 23   | 114-5993    | 2    | Spring-Compression   |
| 24   | 117-9404    | 2    | Shaft-Spring         |
| 25   | 114-5989    | 2    | Bushing-Plain        |
| 26   | 114-5677-03 | 2    | Housing              |
| 27   | 3220-7      | 2    | Nut-Jam              |
| 28   | 105-2806    | 2    | End-Rod              |
| 29   | 74-3730     | 4    | Spacer-Spindle, Rear |
| 30   | 114-0925-01 | 1    | Connection-Deck, LH  |
| 31   | 114-0926-01 | 1    | Connection-Deck, RH  |
| 32   | 104-8300    | 4    | Nut-HF, NI           |
| 33   | 32108-103   | 4    | Screw-FH             |
| 34   | 69-9290     | 4    | Pad-Bumper           |
| 35   | 99-3139     | 2    | Nut                  |
| 36   | 3272-25     | 2    | Pin-Cotter           |
| 37   | 3234-38     | 16   | Screw-HHF            |
| 38   | 99-5107     | 16   | Nut-Lock             |
| 39   | 119-4525-01 | 2    | Stop                 |
| 40   | 285-17      | 2    | Plug-Pipe            |
| 41   | 323-43      | 16   | Screw-HH             |
| 42   | 100-4852    | 16   | Washer-Hardened      |
| 43   | 119-4522    | 4    | Shim-Stop            |
| 44   | 119-4521    | 2    | Pad-Stop             |
| 45   | 3269-35     | 8    | Rivet-Blind          |

● Not illustrated

■ Not serviced separately






## Hood and Bumper Assembly

| Ref.   | Part Number | Qty. | Description       | Ref. | Part Number | Qty. | Description          |
|--------|-------------|------|-------------------|------|-------------|------|----------------------|
| 1      | 117-9405    | 1    | Hood ASM          | 14   | 114-0186    | 1    | Foam-Hood, Air Box   |
| 1:1    | 114-0990    | 2    | Decal             | 15   | 114-0184    | 2    | Foam-Hood, Side      |
| 1:2    | 106-6754    | 2    | Decal-Danger      | 16   | 114-5532    | 2    | Cylinder-Gas         |
| 1:3    |             | 1    | Hood ASM ●        | 17   | 103-5752    | 4    | Stud-Ball            |
| 1:3:11 | 114-5527    | 1    | Tape-Heat Shield  | 18   | 32153-3     | 4    | Nut-Hex, Side Deform |
| 1:4    | 117-2382    | 38   | Plug-Plastic      | 19   | 104-7201    | 12   | Nut-HF               |
| 2      | 114-0076-03 | 1    | Screen-Hood, Top  | 21   | 321-10      | 8    | Screw-HH             |
| 3      | 117-2382    | 48   | Plug-Plastic      | 22   | 114-4890-03 | 1    | Panel-Side           |
| 4      | 114-0077-03 | 1    | Screen-Hood, Back | 23   | 117-5456    | 1    | Shroud-Front, LH     |
| 5      | 46-8091     | 4    | Screw-HWH         | 24   | 3234-29     | 8    | Screw-HHF            |
| 6      | 87-6630     | 12   | Washer-Plain      | 25   | 115-5498-03 | 1    | Shield-Heat          |
| 7      | 65-5100     | 2    | Handle-Door       | 26   | 92-2762     | 2    | Pin-Hair             |
| 8      | 3274-39     | 4    | Screw-HSBH        | 27   | 283-55      | 2    | Pin-Clevis           |
| 9      | 103-2897    | 2    | Latch-Catch       | 28   | 117-5457    | 1    | Shroud-Front, RH     |
| 10     | 114-0187    | 1    | Foam-Rear, RH     | 29   | 114-5619    | 4    | Plate-Grommet        |
| 11     | 3256-14     | 4    | Washer-Flat       | 30   | 114-4869    | 4    | Grommet              |
| 12     | 3296-12     | 4    | Nut-Lock, NI      | 32   | 3234-42     | 6    | Screw-HHF            |
| 13     | 114-0185    | 1    | Foam-Hood, Top    | 33   | 99-5107     | 8    | Nut-Lock             |

● Not serviced separately




## Hood and Bumper Assembly (continued)

| Ref. | Part Number | Qty. | Description                 |
|------|-------------|------|-----------------------------|
| 34   | 100-6116    | 8    | Screw-HHF                   |
| 35   | 115-5457-03 | 1    | Bumper                      |
| 36   | 3290-506    | 4    | Palnut                      |
| 37   | 3234-4      | 2    | Screw-HHF                   |
| 38   | 103-2898    | 2    | Latch-Rubber                |
| 39   | 119-8251    | 1    | Shroud ASM-Lower, Rear      |
| 40   | 114-0188    | 1    | Foam-Rear, LH               |
| 41   | 104-6662    | 2    | Stop And Tail Lamp ASM      |
| 41:1 | 32144-93    | 4    | Screw-PPHTF                 |
| 41:2 | 87-6300     | 2    | Lens-Light, Tail            |
| 41:3 | 87-6310     | 2    | Gasket-Light, Tail          |
| 42   | 114-8410    | 2    | Screw-HHF                   |
| 43   | 92-7760     | 1    | Emblem-Vehicle, Slow Moving |
| 44   | 114-4897-03 | 1    | Screen-Shroud, Lower        |
| 45   | 114-5592-03 | 1    | Panel-Side, LH              |

| Ref. | Part Number | Qty. | Description     |
|------|-------------|------|-----------------|
| 46   | 114-0183    | 1    | Foam-Hood, Rear |
| 47   | 92-9674     | 4    | Knob            |
| 48   | 114-5548-03 | 1    | Frame-Hood      |
| 49   | 1-803035    | 8    | Rivet-Pop       |
| 50   | 115-5458-03 | 1    | Shim-Bumper     |
| 51   | 3234-4      | 3    | Screw-HHF       |
| 52   | 107069      | 3    | Clip            |
| 53   | 3256-23     | 4    | Washer-Plain    |
| 54   | 32180-030   | 2    | Clip-Tie        |
| 55   | 115-5497-03 | 1    | Plate-Support   |
| 56   | 99-7335     | 2    | Screw           |
| 57   | 3256-1      | 2    | Washer-Flat     |
| 58   | 115-5522-03 | 1    | Strap-Hood      |
| 61   | 107-8676    | 2    | Seal-Foam       |
| 62   | 104-1453    | 1    | Grommet         |


● Not serviced separately



## Air Cleaner and Muffler Assembly


| Ref. | Part Number | Qty. | Description                |
|------|-------------|------|----------------------------|
| 1    | 117-9417-03 | 1    | Shield-Heat                |
| 2    | 112-7310    | 1    | Clamp-Muffler              |
| 3    | 114-5589    | 1    | Muffler                    |
| 4    | 114-5588    | 1    | Tube-Exhaust               |
| 5    | 112-7323    | 1    | Clamp-Exhaust              |
| 6    | 114-4938    | 2    | Clamp-Worm                 |
| 7    | 69-1940     | 1    | Indicator-Electrical       |
| 8    | 112-7329    | 1    | Air Cleaner ASM            |
| 9    | 112-7340    | 2    | Band-Mounting, Air Cleaner |
| 10   | 104-8300    | 8    | Nut-HF, NI                 |

| Ref. | Part Number | Qty. | Description        |
|------|-------------|------|--------------------|
| 11   | 3234-29     | 4    | Screw-HHF          |
| 12   | 2412-46     | 2    | Clamp              |
| 13   | 112-7371    | 1    | Hose-Air           |
| 14   | 112-7348-03 | 1    | Mount-Cleaner, Air |
| 15   | 125-5323    | 1    | Hose-Intake, Air   |
| 16   | 3230-2      | 4    | Bolt-CARR          |
| 17   | 33104-016   | 4    | Screw-HHF          |
| 18   | 117-9448-03 | 1    | Shield-Heat        |
| 19   | 32180-030   | 2    | Clip-Tie           |



## Air Cleaner Assembly No. 112-7329

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>           |
|-------------|--------------------|-------------|------------------------------|
| 4           | 115-8877           | 1           | Filter-Air, Engine (Safety)  |
| 5           | 115-8887           | 1           | Filter-Air, Engine (Primary) |
| 6           | 114-5624           | 1           | Valve-Vacuator               |
| 7           | 114-5625           | 1           | Cover ASM                    |




## Radiator and Fan Shroud Assembly

| Ref. | Part Number | Qty. | Description            |
|------|-------------|------|------------------------|
| 1    |             | 1    | Radiator ASM ●         |
| 2    | 32128-49    | 4    | Nut-HHF                |
| 3    | 115-5433-01 | 2    | Plate-Support, Cooler  |
| 4    | 104-8301    | 8    | Nut-HF, NI             |
| 5    | 52-5260     | 4    | Pad-Rubber             |
| 6    | 2412-130    | 3    | Clamp-Hose             |
| 7    | 112-7285    | 1    | Hose-Upper, Radiator   |
| 8    | 94-5625     | 1    | Hose                   |
| 9    | 2412-111    | 1    | Clamp                  |
| 10   | 2412-108    | 5    | Clamp-Worm             |
| 11   | 354-94      | 1    | Fitting-Female, Barbed |
| 12   | 93-5528     | 1    | Fitting-Cock, Drain    |
| 13   | 121-3870    | 1    | Shroud-Fan             |
| 14   | 112-7283    | 4    | Tube-Cac, Flexible     |
| 15   | 114-0031    | 8    | Clamp, T-Bolt          |
| 16   | 112-7281    | 1    | Tube-Cac, Hot (Rigid)  |
| 17   | 120-5571    | 1    | Coolant Reservoir ASM  |
| 17:1 | 87-7050     | 1    | Cap-Reservoir          |

| Ref. | Part Number | Qty. | Description             |
|------|-------------|------|-------------------------|
| 18   | 3256-23     | 2    | Washer-Plain            |
| 19   | 3296-29     | 2    | Nut-Lock, NI            |
| 20   | 115-5438    | 1    | LH Radiator Support ASM |
| 20:2 | 106-6754    | 1    | Decal-Danger            |
| 21   | 323-6       | 4    | Screw-HH                |
| 22   | 106-1126    | 1    | Hose-Fuel               |
| 23   | 105-0778    | 2    | Strip-Foam              |
| 24   | 104-2287-03 | 1    | Cover-Frame             |
| 25   | 3256-3      | 10   | Washer-Flat             |
| 26   | 95-9648     | 2    | Knob                    |
| 27   | 32151-72    | 2    | Ring-Retaining          |
| 28   | 105-0777    | 2    | Strip-Foam              |
| 29   | 112-7282    | 1    | Tube-Cac, Cold (Rigid)  |
| 30   | 117-5468    | 1    | Air Box ASM             |
| 30:2 | 93-7275     | 1    | Decal-Fluid, Starting   |
| 31   | 104-8300    | 14   | Nut-HF, NI              |
| 32   | 104-5429    | 2    | Clamp-Form, Wire        |
| 33   | 3230-2      | 14   | Bolt-CARR               |

● Not serviced separately




## Radiator and Fan Shroud Assembly (continued)

| Ref. | Part Number | Qty. | Description             |
|------|-------------|------|-------------------------|
| 34   | 112-7284    | 1    | Hose-Lower, Radiator    |
| 35   | 125-5255-03 | 1    | Bracket-Motor, Fan      |
| 36   | 108-0342    | 1    | Fitting-Straight        |
| 37   | 110-8828    | 1    | Sensor-Level, Coolant   |
| 38   | 114-0155-03 | 1    | Support-Radiator, Top   |
| 40   | 323-14      | 2    | Screw-HH                |
| 41   | 322-38      | 2    | Screw-HH                |
| 42   | 115-5437    | 1    | RH Radiator Support ASM |
| 42:2 | 106-6754    | 1    | Decal-Danger            |
| 43   | 41-8440     | 4    | Washer                  |
| 44   | 325-17      | 2    | Screw-HH                |
| 45   | 108-3723    | 2    | Grommet                 |


| Ref. | Part Number | Qty. | Description          |
|------|-------------|------|----------------------|
| 46   | 323-11      | 2    | Screw-HH             |
| 47   | 114-5530    | 1    | Sleeve-Hose          |
| 48   | 109-0309    | 1    | Hose-Fuel            |
| 49   | 115-5440    | 1    | Radiator Cap ASM     |
| 49:2 | 106-6755    | 1    | Decal-Cap, Radiator  |
| 50   | 1-543610    | 4    | Washer-Clutch        |
| 51   | 115-5496    | 1    | Rod-Support          |
| 52   | 32128-20    | 4    | Nut-HF               |
| 54   | 119-8254-01 | 1    | Bracket-Diffuser, RH |
| 55   | 119-8255-01 | 1    | Bracket-Diffuser, LH |
| 56   | 32180-030   | 1    | Clip-Tie             |

● Not serviced separately



## Radiator Assembly

| Ref. | Part Number | Qty. | Description        |
|------|-------------|------|--------------------|
| 1    | 114-5542    | 1    | Radiator           |
| 1:1  | 93-5957     | 1    | Cap-Radiator       |
| 2    | 114-5540    | 1    | Bracket-Cooler, RH |
| 3    | 114-5541    | 1    | Bracket-Cooler, LH |
| 4    | 114-5543    | 1    | Cooler-Charge, Air |
| 5    | 114-5544    | 1    | Cooler-Oil         |
| 5:1  | 115-5495    | 2    | Bumper-Rubber      |
| 5:2  | 340-65      | 2    | O-Ring             |
| 6    | 114-5545    | 8    | Pin                |
| 7    | 114-5546    | 8    | Clip-Pin           |




## Engine and Mount Assembly

| Ref. | Part Number | Qty. | Description                       |
|------|-------------|------|-----------------------------------|
| 1    |             | 1    | Engine-Cummins ●                  |
| 2    | 114-5591-03 | 1    | Shield-Heat                       |
| 3    | 323-5       | 7    | Screw-HH                          |
| 4    | 324-11      | 4    | Screw-HH                          |
| 5    | 110-6018-03 | 2    | Mount-Engine, Rear                |
| 6    | 3253-6      | 8    | Washer-Lock                       |
| 7    | 33115-025   | 8    | Screw-HH                          |
| 8    | 53-9681     | 4    | Mount-Engine                      |
| 9    | 87-5100     | 4    | Washer-Snubbing                   |
| 10   | 3296-48     | 4    | Nut-Lock, NI                      |
| 11   | 33116-030   | 8    | Screw-HH                          |
| 12   | 3253-7      | 8    | Washer-Lock                       |
| 13   | 110-6029-03 | 1    | Mount-Front, LH (Engine Isolator) |
| 14   | 323-14      | 3    | Screw-HH                          |
| 15   | 104-8301    | 11   | Nut-HF, NI                        |
| 16   | 112-7422-03 | 1    | Plate-Mount, 4Wd Valve            |
| 17   | 3234-1      | 4    | Screw-HHF                         |

| Ref. | Part Number | Qty. | Description                       |
|------|-------------|------|-----------------------------------|
| 18   |             | 1    | 4Wd Manifold ASM ●                |
| 19   | 110-6028-03 | 1    | Mount-Front, RH (Engine Isolator) |
| 20   | 114-5560    | 1    | Plate-Mount, Bulkhead             |
| 21   | 114-0878    | 1    | Fitting-Special                   |
| 21:1 | 237-146     | 1    | O-Ring                            |
| 21:2 | 237-58      | 2    | O-Ring                            |
| 22   | 114-0877    | 1    | Fitting-Special                   |
| 22:1 | 237-146     | 1    | O-Ring                            |
| 22:2 | 237-58      | 2    | O-Ring                            |
| 23   | 3256-23     | 2    | Washer-Plain                      |
| 24   |             | 1    | Flush Manifold ASM ●              |
| 25   | 321-14      | 2    | Screw-HH                          |
| 26   | 104-7201    | 2    | Nut-HF                            |
| 27   | 110-8829    | 1    | Sender-Temperature                |
| 27:1 | 237-42      | 1    | O-Ring                            |
| 28   | 3256-24     | 3    | Washer-Flat                       |


● Not serviced separately





## 4 Wheel Drive Hydraulic Manifold Assembly


| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 1    | 110-6063    | 1    | Manifold-4Wd          |
| 2    | 340-142     | 2    | Fitting-Elbow-90      |
| 2:1  | 237-58      | 1    | O-Ring                |
| 2:2  | 237-81      | 1    | O-Ring                |
| 3    | 340-77      | 2    | Fitting-Elbow, 90 DEG |
| 3:1  | 237-22      | 1    | O-Ring                |
| 3:2  | 237-42      | 1    | O-Ring                |
| 4    | 340-98      | 1    | Fitting-Elbow, 90 DEG |
| 4:1  | 237-79      | 1    | O-Ring                |
| 4:2  | 237-30      | 1    | O-Ring                |
| 5    | 354-79      | 2    | Cap-Dust              |
| 6    | 354-77      | 2    | Fitting-Quick         |
| 6:1  | 237-78      | 1    | O-Ring                |



## 4 Wheel Drive Hydraulic Manifold Assembly No. 110-6063


| Ref. | Part Number | Qty. | Description        |
|------|-------------|------|--------------------|
| 1    | 106-1027    | 2    | Plug-HYD           |
| 1:1  | 237-79      | 1    | O-Ring             |
| 2    | 106-1025    | 2    | Plug-HYD           |
| 2:1  | 237-78      | 1    | O-Ring             |
| 3    | 110-0468    | 1    | Valve-Check, 5 PSI |
| 3:1  | 110-0470    | 1    | Seal Kit           |
| 4    | 105-9333    | 1    | Coil-12Vdc         |
| 5    | 106-1995    | 1    | Valve-3 Way        |
| 5:1  | 110-8773    | 1    | Seal Kit           |
| 6    | 106-1026    | 2    | Plug-HYD           |
| 6:1  | 237-42      | 1    | O-Ring             |
| 7    | 353-990     | 2    | Plug ASM           |

| Ref. | Part Number | Qty. | Description             |
|------|-------------|------|-------------------------|
| 7:1  | 237-78      | 1    | O-Ring                  |
| 8    | 110-6069    | 1    | Valve-Pressure, Red/Rel |
| 8:1  | 110-6068    | 1    | Seal Kit                |
| 9    | 112-7394    | 1    | Directional-Pilot       |
| 9:1  | 115-5415    | 1    | Seal Kit                |
| 10   | 110-0491    | 1    | Valve-Directional       |
| 10:1 | 106-6775    | 1    | Seal Kit                |
| 11   | 119-7724    | 1    | Valve-Relief, Free Rev  |
| 11:1 | 110-6316    | 1    | Seal Kit                |
| 12   | 107-1987    | 1    | Orifice-0.040           |
| 13   | 110-5973    | 1    | Orifice-0.030           |
| 14   | 110-2634    | 1    | Nut-Coil                |




## Flush Manifold Assembly

| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 1    | 120-9869    | 1    | Manifold-Flush        |
| 2    | 340-4       | 1    | Fitting-Straight      |
| 2:1  | 237-30      | 1    | O-Ring                |
| 2:2  | 237-79      | 1    | O-Ring                |
| 3    | 340-132     | 1    | Fitting-Elbow, 90 DEG |
| 3:1  | 237-78      | 1    | O-Ring                |
| 3:2  | 237-21      | 1    | O-Ring                |
| 4    | 340-157     | 1    | Fitting-HYD, Tee      |
| 4:1  | 237-79      | 1    | O-Ring                |
| 4:2  | 237-30      | 2    | O-Ring                |



## Flush Valve Assembly No. 120-9869

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     |
|-------------|--------------------|-------------|------------------------|
| 1           | 110-0469           | 1           | Valve-Check, 180 PSI   |
| 1:1         | 105-9159           | 1           | Seal Kit               |
| 2           | 106-1026           | 1           | Plug-HYD               |
| 2:1         | 237-42             | 1           | O-Ring                 |
| 3           | 120-9868           | 1           | Valve-Shuttle, Hot Oil |
| 3:1         | 120-7597           | 1           | Seal Kit               |




## Fan and Coupling Assembly

| Ref. | Part Number | Qty. | Description                  |
|------|-------------|------|------------------------------|
| 1    | 3274-49     | 2    | Screw-HSH                    |
| 2    | 112-7400    | 1    | Fan Motor ASM                |
| 4    | 114-4848-03 | 1    | Hub-Fan                      |
| 7    |             | 1    | Steer/Fan Manifold ASM ●     |
| 8    | 3257-3      | 1    | Key-Woodruff                 |
| 9    | 114-5560    | 1    | Plate-Mount, Bulkhead        |
| 10   | 104-8301    | 3    | Nut-HF, NI                   |
| 11   | 3296-48     | 2    | Nut-Lock, NI                 |
| 12   | 110-5980    | 1    | Fan                          |
| 13   | 110-5053    | 7    | Screw-HHF                    |
| 14   | 3234-47     | 6    | Screw-HHF                    |
| 15   | 110-6046    | 1    | Flywheel Coupling ASM        |
| 16   | 112-7423-03 | 1    | Plate-Mount, Fan/Steer Valve |
| 17   | 107-1413    | 8    | Washer-Hardened              |

| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 18   | 323-14      | 3    | Screw-HH              |
| 19   | 33115-035   | 12   | Screw-HH              |
| 20   | 100-4852    | 12   | Washer-Hardened       |
| 21   | 125-5260-03 | 1    | Plate-Cover, Flywheel |
| 22   | 33115-025   | 8    | Screw-HH              |
| 23   | 340-4       | 2    | Fitting-Straight      |
| 23:1 | 237-30      | 1    | O-Ring                |
| 23:2 | 237-79      | 1    | O-Ring                |
| 24   | 340-2       | 1    | Fitting-Straight      |
| 24:1 | 237-22      | 1    | O-Ring                |
| 24:2 | 237-42      | 1    | O-Ring                |
| 25   | 112-6957    | 1    | Washer-Hardened       |
| 26   | 3256-24     | 3    | Washer-Flat           |
| 27   | 110-8815    | 1    | Nut-Hex               |


● Not serviced separately



## Hydraulic Fan Motor Assembly No. 112-7400

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|-------------------------|
| 1           | 115-4110           | 1           | Seal Kit                |
| 1:1         |                    | 2           | Seal-Shaft ●            |
| 1:2         |                    | 2           | Seal-Plate, Balancing ● |
| 1:3         |                    | 2           | Seal-Anti Extrusion ●   |
| 1:4         |                    | 2           | O-Ring (Housing) ●      |


● Not serviced separately



## Steer/Fan Manifold Assembly

| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 1    | 110-6065    | 1    | Manifold-Steer / Fan  |
| 2    | 340-98      | 1    | Fitting-Elbow, 90 DEG |
| 2:1  | 237-79      | 1    | O-Ring                |
| 2:2  | 237-30      | 1    | O-Ring                |
| 3    | 340-2       | 2    | Fitting-Straight      |
| 3:1  | 237-22      | 1    | O-Ring                |
| 3:2  | 237-42      | 1    | O-Ring                |
| 4    | 340-4       | 1    | Fitting-Straight      |
| 4:1  | 237-30      | 1    | O-Ring                |
| 4:2  | 237-79      | 1    | O-Ring                |

| Ref. | Part Number | Qty. | Description      |
|------|-------------|------|------------------|
| 5    | 340-86      | 1    | Fitting-Tee      |
| 5:1  | 237-22      | 2    | O-Ring           |
| 5:2  | 237-42      | 1    | O-Ring           |
| 6    | 354-77      | 1    | Fitting-Quick    |
| 6:1  | 237-78      | 1    | O-Ring           |
| 7    | 354-79      | 1    | Cap-Dust         |
| 8    | 340-7       | 2    | Fitting-Straight |
| 8:1  | 237-65      | 1    | O-Ring           |
| 8:2  | 237-80      | 1    | O-Ring           |




## Hydraulic Manifold Assembly No. 110-6065

| Ref. | Part Number | Qty. | Description            |
|------|-------------|------|------------------------|
| 1    | 106-1026    | 1    | Plug-HYD               |
| 1:1  | 237-42      | 1    | O-Ring                 |
| 2    | 115-5409    | 1    | Compensator ASM        |
| 2:1  | 110-8908    | 1    | Spool Valve Seal Kit   |
| 3    | 114-5514    | 1    | Valve-Relief, 2000 PSI |
| 3:1  | 105-9156    | 1    | Seal Kit               |
| 4    | 110-2630    | 1    | Coil-12Vdc             |
| 5    | 115-3022    | 1    | Relief-Proportional    |
| 5:1  | 110-6316    | 1    | Seal Kit               |
| 5:2  | 119-7715    | 1    | Nut-Coil               |

| Ref. | Part Number | Qty. | Description     |
|------|-------------|------|-----------------|
| 6    | 353-990     | 2    | Plug ASM        |
| 6:1  | 237-78      | 1    | O-Ring          |
| 7    | 105-9321    | 1    | Check Valve ASM |
| 7:1  | 105-9156    | 1    | Seal Kit        |
| 8    | 114-5084    | 1    | Coil-Solenoid   |
| 9    | 115-5410    | 1    | Valve-Solenoid  |
| 9:1  | 110-6111    | 1    | Seal Kit        |
| 9:2  | 114-5085    | 1    | Nut-E Coil      |
| 10   | 106-1027    | 1    | Plug-HYD        |
| 10:1 | 237-79      | 1    | O-Ring          |






## Hydraulic Tank Assembly

| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 1    | 46-6560     | 1    | Bushing               |
| 2    | 46-6550     | 1    | Fitting-Elbow, 90 DEG |
| 3    | 114-0941    | 1    | Plate-Latch           |
| 4    | 3274-47     | 2    | Screw-HSFH            |
| 5    | 58-4250     | 1    | Catch-Magnetic        |
| 6    | 114-0940    | 2    | Bracket-Hinge         |
| 7    | 108-3629    | 2    | Nut-Push              |
| 8    | 3274-31     | 2    | Screw-HSBH            |
| 9    | 114-0939-03 | 1    | Cover-Tank, HYD       |
| 10   | 114-0904    | 1    | Rod                   |
| 11   | 93-6686     | 1    | Decal-Oil, HYD        |
| 12   | 93-7498     | 1    | Plug-Plastic          |
| 13   | 94-8166     | 1    | O-Ring                |
| 14   | 114-0002    | 4    | Pipe-Stand            |
| 15   | 105-2812    | 1    | Dipstick              |


| Ref. | Part Number | Qty. | Description        |
|------|-------------|------|--------------------|
| 16   | 104-0790    | 4    | Bushing            |
| 17   | 92-1705     | 1    | Filter-Screen      |
| 18   | 119-7726    | 1    | Hydraulic Tank ASM |
| 19   | 323-12      | 1    | Screw-HH           |
| 20   | 63-8410     | 1    | Washer             |
| 21   | 95-6448     | 1    | Spacer             |
| 22   | 353-508     | 1    | Plug-HH            |
| 22:1 | 237-42      | 1    | O-Ring             |
| 23   | 105-0131    | 1    | Strainer-Tank, Oil |
| 23:1 | 340-136     | 1    | O-Ring             |
| 24   | 104-8301    | 2    | Nut-HF, NI         |
| 25   | 114-0094    | 1    | Hold Down-Tank     |
| 26   | 3234-42     | 2    | Screw-HHF          |
| 27   | 2412-108    | 1    | Clamp-Worm         |



## Hydraulic Pump Assembly

| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 1    | 114-4840    | 1    | Triple Gear Pump ASM  |
| 2    | 340-142     | 2    | Fitting-Elbow-90      |
| 2:1  | 237-58      | 1    | O-Ring                |
| 2:2  | 237-81      | 1    | O-Ring                |
| 3    | 121-3900    | 1    | Piston Pump ASM       |
| 5    | 354-79      | 3    | Cap-Dust              |
| 6    | 325-6       | 4    | Screw-HH              |
| 7    | 340-8       | 1    | Fitting-Straight      |
| 7:1  | 237-65      | 1    | O-Ring                |
| 7:2  | 237-81      | 1    | O-Ring                |
| 9    | 340-77      | 1    | Fitting-Elbow, 90 DEG |
| 9:1  | 237-22      | 1    | O-Ring                |
| 9:2  | 237-42      | 1    | O-Ring                |
| 10   | 2412-111    | 2    | Clamp                 |
| 11   | 114-5506    | 1    | Hose-Formed           |
| 12   | 121-1525    | 2    | Screw-HH              |


| Ref. | Part Number | Qty. | Description        |
|------|-------------|------|--------------------|
| 13   | 93-6810     | 1    | Fitting-Tee        |
| 13:1 | 237-30      | 2    | O-Ring             |
| 14   | 107-3395    | 6    | Washer-Hardened    |
| 15   | 59-7410     | 2    | Fitting-Diagnostic |
| 15:1 | 237-42      | 1    | O-Ring             |
| 16   | 86-5480     | 1    | Nipple-Test        |
| 18   | 340-6       | 1    | Fitting-Straight   |
| 18:1 | 237-30      | 1    | O-Ring             |
| 18:2 | 237-80      | 1    | O-Ring             |
| 19   | 340-9       | 1    | Fitting-STR        |
| 19:1 | 237-58      | 1    | O-Ring             |
| 19:2 | 237-81      | 1    | O-Ring             |
| 20   | 107-9447    | 1    | O-Ring             |
| 21   | 100-4240    | 1    | Fitting-STR        |
| 21:1 | 237-30      | 1    | O-Ring             |
| 21:2 | 237-81      | 1    | O-Ring             |



## Triple Pump Assembly No. 114-4840


| Ref. | Part Number | Qty. | Description            |
|------|-------------|------|------------------------|
| 1    | 117-1109    | 1    | Seal Kit               |
| 2    | 127-3620    | 8    | Screw-Cap, Socket Head |

# Piston Pump Assembly No. 121-3900



## Piston Pump Assembly No. 121-3900 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>          |
|-------------|--------------------|-------------|-----------------------|-------------|--------------------|-------------|-----------------------------|
| 1           | 125-5266           | 2           | Screen                | 20          | 125-5281           | 4           | Screw                       |
| 2           | 75-0170            | 2           | Plug-Thread, Straight | 21          | 125-5282           | 4           | Screw                       |
| 2:1         | 92-8777            | 1           | O-Ring                | 22          | 125-5287           | 1           | Plate-Thrust                |
| 3           | 107-4352           | 2           | Plug                  | 23          | 125-5290           | 1           | Valve-Relief, High Pressure |
| 4           | 125-5267           | 1           | Cylinder Block Kit    | 24          | 125-5291           | 1           | Valve-Relief, High Pressure |
| 5           | 125-5268           | 1           | Valve Plate, CW       | 25          | 125-5292           | 2           | Pressure Limiter Plug ASM   |
| 6           | 125-5271           | 1           | Servo Piston ASM      | 26          | 125-5293           | 1           | Swashplate Bearing Kit      |
| 7           | 125-5270           | 6           | Screw                 | 27          | 125-5295           | 1           | Control Kit (12 Volt)       |
| 8           | 125-5276           | 2           | Orifice (0.8)         | 27:1        | 125-5272           | 6           | Screw                       |
| 9           | 125-5277           | 4           | Screw                 | 27:2        | 125-5273           | 1           | Nut-Seal                    |
| 10          | 125-5300           | 4           | Plug ASM              | 27:3        | 125-5302           | 1           | Plug                        |
| 11          | 125-5275           | 2           | Screw                 | 27:4        | 125-5266           | 1           | Screen                      |
| 12          | 125-5301           | 1           | Plug                  | 27:5        | 125-5269           | 1           | Ring-Locking                |
| 13          | 125-5278           | 1           | Shaft                 | 27:6        | 125-5274           | 6           | Screw                       |
| 14          | 125-5279           | 1           | Bearing-Roller        | 27:7        | 125-5294           | 2           | Coil Kit                    |
| 15          | 125-5280           | 1           | Ring-Retaining        | 27:8        | 125-5283           | 1           | Gasket-Control              |
| 16          | 125-5296           | 1           | Shaft Seal Kit        | 27:9        | 125-5288           | 2           | O-Ring                      |
| 17          | 125-5284           | 1           | Adapter               | 28          | 125-5303           | 2           | Plug ASM                    |
| 18          | 125-5285           | 1           | Seal-Adapter          | 29          | 125-5297           | 1           | Charge Relief Kit           |
| 19          | 125-5286           | 1           | Coupling              | 30          | 125-5299           | 1           | Overhaul Seal Kit           |




## Traction Hydraulic Plumbing Assembly

| Ref. | Part Number | Qty. | Description        |
|------|-------------|------|--------------------|
| 1    | 120-9878    | 2    | Hose-Hydraulic, HP |
| 2    | 321-11      | 6    | Screw-HH           |
| 3    | 114-0989    | 3    | Plate-Cover        |
| 4    | 99-3641     | 6    | Clamp-Tube         |
| 5    | 98-5055     | 3    | Pin-Weld           |
| 6    | 104-7201    | 8    | Nut-HF             |
| 7    | 94-4714     | 1    | Hose-Hydraulic     |
| 8    | 121-3903    | 2    | Flange Kit         |
| 8:1  | 121-3904    | 1    | O-Ring             |
| 8:2  | 33116-045   | 4    | Screw-HH           |
| 8:3  | 48-8070     | 4    | Washer-Lock        |
| 9    | 121-3902    | 1    | Hose-Hydraulic, HP |
| 10   | 114-4843    | 1    | Tube-Hydraulic     |
| 11   | 117-5460    | 1    | Tube-Hydraulic     |
| 12   | 114-4819    | 1    | Tube-Hydraulic     |
| 13   | 114-4844    | 1    | Tube-Hydraulic     |
| 14   | 114-4847    | 1    | Tube-Hydraulic     |
| 14:1 | 237-58      | 1    | O-Ring ●           |

| Ref. | Part Number | Qty. | Description        |
|------|-------------|------|--------------------|
| 15   | 114-4842    | 1    | Tube-Hydraulic     |
| 15:1 | 237-22      | 1    | O-Ring ●           |
| 15:2 | 237-30      | 1    | O-Ring ●           |
| 16   | 114-4834    | 1    | Tube-Hydraulic     |
| 17   | 114-4845    | 1    | Tube-Hydraulic     |
| 18   | 114-4846    | 1    | Tube-Hydraulic     |
| 18:1 | 340-65      | 1    | O-Ring ●           |
| 18:2 | 237-58      | 1    | O-Ring ●           |
| 19   | 104-8300    | 1    | Nut-HF, NI         |
| 20   | 56-7978     | 2    | Clamp-Tube         |
| 21   | 121-3901    | 1    | Hose-Hydraulic, HP |
| 22   | 3256-23     | 1    | Washer-Plain       |
| 23   | 322-10      | 1    | Screw-HH           |
| 24   | 108-6514    | 1    | Hose-Hydraulic     |
| 25   | 121-3914    | 1    | Tube-Hydraulic     |
| 26   | 114-4918    | 1    | Tube-Hydraulic     |
| 27   | 121-3869    | 1    | Tube-Hydraulic     |
| 27:1 | 237-21      | 1    | O-Ring ●           |

● Not illustrated




## Traction Hydraulic Plumbing Assembly (continued)

| Ref. | Part Number | Qty. | Description    |
|------|-------------|------|----------------|
| 28   | 114-4905    | 1    | Tube-Hydraulic |
| 29   | 92-9258     | 1    | Adapter-Check  |
| 29:1 | 237-22      | 1    | O-Ring         |
| 29:2 | 237-42      | 1    | O-Ring         |
| 30   | 114-0025    | 1    | Tube-Hydraulic |
| 30:1 | 237-58      | 1    | O-Ring ●       |

| Ref. | Part Number | Qty. | Description        |
|------|-------------|------|--------------------|
| 31   | 114-0026    | 1    | Tube-Hydraulic     |
| 31:1 | 237-58      | 1    | O-Ring ●           |
| 32   | 120-9879    | 2    | Hose-Hydraulic, HP |
| 33   | 340-70      | 1    | Nut-Lock           |
| 34   | 115-8875    | 1    | Tube-Hydraulic     |
| 35   | 121-3859    | 1    | Tube-Hydraulic     |

● Not illustrated




## Power-Take-Off Hydraulic Plumbing Assembly

| Ref. | Part Number | Qty. | Description        |
|------|-------------|------|--------------------|
| 1    | 114-4904    | 2    | Hose-Hydraulic, HP |
| 2    | 114-0016    | 1    | Tube-Hydraulic     |
| 2:1  | 340-65      | 1    | O-Ring ●           |
| 3    | 114-0173    | 2    | Tube-Hydraulic     |
| 3:1  | 237-22      | 1    | O-Ring ●           |
| 4    | 115-8869    | 1    | Hose-Hydraulic     |
| 5    | 120-9865    | 1    | Hose-Hydraulic     |
| 6    | 115-5518    | 1    | Hose-Hydraulic, HP |
| 7    | 115-5517    | 1    | Hose-Hydraulic, HP |
| 8    | 114-5500    | 1    | Hose-Hydraulic     |
| 9    | 114-4820    | 1    | Tube-Hydraulic     |
| 10   | 114-4839    | 1    | Tube-Hydraulic     |
| 11   | 114-5501    | 1    | Hose-Hydraulic     |
| 12   | 93-2242     | 1    | Filter-Oil         |
| 12:1 | 75-1310     | 1    | Filter-HYD         |
| 13   | 114-0985    | 4    | Hose-Hydraulic     |

| Ref. | Part Number | Qty. | Description      |
|------|-------------|------|------------------|
| 14   | 114-0945    | 2    | Hose-Hydraulic   |
| 15   | 119-7725    | 1    | Tube-Hydraulic   |
| 16   | 104-7201    | 4    | Nut-HF           |
| 17   | 114-4901    | 2    | Clamp            |
| 18   | 114-4902    | 2    | Plate-Cover      |
| 19   | 321-18      | 4    | Screw-HH         |
| 20   | 110-6067    | 1    | Tube-Hydraulic   |
| 21   | 99-4217     | 1    | Hose-Hydraulic   |
| 22   | 3290-379    | 2    | Tie-Cable        |
| 23   | 98-4735     | 1    | Valve-Check, HYD |
| 23:1 | 237-30      | 1    | O-Ring           |
| 23:2 | 237-79      | 1    | O-Ring           |
| 24   | 120-9864    | 1    | Hose-Hydraulic   |
| 25   | 2412-104    | 1    | Clamp-R          |
| 26   | 322-4       | 1    | Screw-HH         |
| 27   | 104-8300    | 1    | Nut-HF, NI       |

● Not illustrated






## Lift Arms Hydraulic Plumbing Assembly

| Ref. | Part Number | Qty. | Description        |
|------|-------------|------|--------------------|
| 1    | 121-3908    | 1    | Tube-Hydraulic     |
| 2    | 114-4817    | 3    | Hose-Hydraulic, HP |
| 3    | 114-4818    | 1    | Hose-Hydraulic, HP |
| 4    | 322-22      | 1    | Screw-HH           |
| 5    | 92-5694     | 4    | Hose-Hydraulic     |
| 6    | 56-7976     | 2    | Clamp-Tube         |
| 7    | 104-8300    | 1    | Nut-HF, NI         |
| 8    | 114-4824    | 1    | Tube-Hydraulic     |
| 8:1  | 237-22      | 2    | O-Ring ●           |
| 9    | 117-9408    | 1    | Tube-Hydraulic     |
| 9:1  | 237-22      | 2    | O-Ring ●           |
| 10   | 117-9411    | 1    | Hose-Hydraulic, HP |

● Not illustrated




## Steering Hydraulic Plumbing Assembly

| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 1    | 125-5315    | 1    | Hydraulic Tube ASM    |
| 2    | 125-5314    | 1    | Hydraulic Tube ASM    |
| 3    | 125-5313    | 1    | Hydraulic Tube ASM    |
| 4    | 114-0063    | 2    | Shim-Support          |
| 5    | 340-127     | 4    | Nut-Bulkhead          |
| 6    | 340-70      | 4    | Nut-Lock              |
| 7    | 340-68      | 2    | Fitting-Tee, Bulkhead |
| 7:1  | 237-22      | 3    | O-Ring                |
| 8    | 114-4922    | 3    | HYD Hose ASM          |
| 9    | 114-0910    | 1    | HYD Tube ASM          |
| 10   | 114-0911    | 1    | HYD Tube ASM          |
| 11   | 114-0909    | 1    | HYD Tube ASM          |
| 12   | 104-8300    | 8    | Nut-HF, NI            |
| 13   | 56-7973     | 16   | Clamp-Tube            |
| 14   | 114-4915    | 1    | HYD Tube ASM          |
| 15   | 322-10      | 1    | Screw-HH              |
| 16   | 3256-23     | 7    | Washer-Plain          |
| 17   | 121-3911    | 1    | Hydraulic Tube ASM    |
| 18   | 115-5435    | 1    | HYD Tube ASM          |

| Ref. | Part Number | Qty. | Description        |
|------|-------------|------|--------------------|
| 20   | 114-0145    | 1    | HYD Tube ASM       |
| 20:1 | 237-22      | 1    | O-Ring ●           |
| 21   | 114-0071    | 1    | HYD Tube ASM       |
| 21:1 | 237-22      | 1    | O-Ring ●           |
| 22   | 322-8       | 7    | Screw-HH           |
| 23   | 114-0144    | 1    | HYD Tube ASM       |
| 23:1 | 237-22      | 1    | O-Ring ●           |
| 24   | 114-0070    | 1    | HYD Tube ASM       |
| 24:1 | 237-22      | 1    | O-Ring ●           |
| 25   | 114-0147    | 1    | HYD Tube ASM       |
| 26   | 121-3907    | 1    | Hydraulic Tube ASM |
| 27   | 114-4916    | 1    | HYD Tube ASM       |
| 28   | 121-3910    | 1    | Hydraulic Tube ASM |
| 29   | 114-0066-03 | 1    | Plate-Mount, Tube  |
| 30   | 114-4934    | 1    | HYD Hose ASM       |
| 34   | 56-7971     | 2    | Clamp-Tube         |
| 35   | 354-77      | 1    | Fitting-Quick      |
| 35:1 | 237-78      | 1    | O-Ring             |
| 36   | 354-79      | 1    | Cap-Dust           |


● Not illustrated



## Hydraulic Tank Plumbing Assembly

| Ref. | Part Number | Qty. | Description    |
|------|-------------|------|----------------|
| 1    | 340-127     | 2    | Nut-Bulkhead   |
| 2    | 114-4821    | 1    | Tube-Hydraulic |
| 2:1  | 237-30      | 1    | O-Ring         |
| 3    | 114-4822    | 1    | Tube-Hydraulic |
| 3:1  | 237-22      | 1    | O-Ring         |
| 4    | 114-5507    | 1    | Hose-Formed    |
| 5    | 104-8300    | 4    | Nut-HF, NI     |
| 6    | 2412-111    | 2    | Clamp          |
| 7    | 322-8       | 2    | Screw-HH       |
| 8    | 2412-36     | 8    | Clamp-Hose     |
| 9    | 114-4920    | 4    | Hose           |


| Ref. | Part Number | Qty. | Description       |
|------|-------------|------|-------------------|
| 10   | 114-4919-03 | 1    | Plate-Mount, Tube |
| 11   | 322-5       | 2    | Screw-HH          |
| 12   | 114-0172    | 1    | Tube-Hydraulic    |
| 13   | 117-9409    | 1    | Tube-Hydraulic    |
| 14   | 56-7977     | 4    | Clamp-Tube        |
| 15   | 121-3909    | 1    | Tube-Hydraulic    |
| 15:1 | 237-30      | 2    | O-Ring            |
| 15:2 | 237-22      | 1    | O-Ring            |
| 15:3 | 237-65      | 1    | O-Ring            |
| 16   | 115-5523    | 1    | Guard-Hose        |
| 17   | 3290-379    | 2    | Tie-Cable         |



## Acoustic Foam Assembly

| Ref. | Part Number | Qty. | Description            |
|------|-------------|------|------------------------|
| 1    | 121-3925    | 1    | Foam-Battery, Cover    |
| 2    | 115-8801    | 1    | Foam-Battery, Plug     |
| 3    | 115-8802    | 1    | Foam-Plug, Round       |
| 4    | 115-8803    | 1    | Foam-Plug, Rectangular |
| 5    | 115-8804    | 1    | Foam-Brake, LH         |
| 6    | 115-8805    | 1    | Foam-Brake, Center     |
| 7    | 115-8806    | 1    | Foam-Brake, RH         |
| 8    | 115-8807    | 2    | Foam-Plug, Brake       |
| 9    | 115-8808    | 1    | Foam-Strip, Front      |
| 10   | 115-8809    | 1    | Foam-Plug, RH          |


| Ref. | Part Number | Qty. | Description          |
|------|-------------|------|----------------------|
| 11   | 115-8810    | 1    | Foam-Steering, Rear  |
| 12   | 115-8811    | 1    | Foam-Steering, Front |
| 13   | 115-8812    | 1    | Foam-Column, Front   |
| 14   | 115-8813    | 1    | Foam-Column, Rear    |
| 15   | 115-8841-01 | 1    | Bracket-Foam, Pawl   |
| 16   | 115-8814    | 1    | Foam-Pawl, Brake     |
| 17   | 115-8815    | 1    | Foam-Plug, Brake     |
| 18   | 3234-33     | 2    | Screw-HHF            |
| 19   | 104-7201    | 2    | Nut-HF               |



## Battery Cable Routing and Assembly

| Ref. | Part Number | Qty. | Description             |
|------|-------------|------|-------------------------|
| 1    | 114-3304    | 1    | Cable-Battery, Positive |
| 2    | 114-3305    | 1    | Cable-Battery, Positive |
| 3    | 3254-6      | 2    | Washer-Lock, Internal   |
| 4    | 323-6       | 1    | Screw-HH                |
| 5    | 114-3308    | 1    | Cable-Battery, Positive |
| 6    | 114-3309    | 1    | Cable-Battery, Positive |
| 7    | 114-3310    | 1    | Cable-Battery, Positive |
| 8    | 114-3311    | 1    | Cable-Battery, Negative |

| Ref. | Part Number | Qty. | Description             |
|------|-------------|------|-------------------------|
| 9    | 114-3312    | 1    | Cable-Battery, Negative |
| 10   | 114-3313    | 1    | Cable-Battery, Negative |
| 11   | 33115-025   | 1    | Screw-HH                |
| 12   | 3255-8      | 1    | Washer-Lock             |
| 13   | 98-5845     | 1    | Nut-Hex                 |
| 14   | 33014-00    | 1    | Nut-Hex                 |
| 15   | 3334-945    | 2    | Tie-Cable               |
| 16   | 3290-378    | 1    | Tie-Cable               |




## Fuel Tank Assembly

| Ref. | Part Number | Qty. | Description               |
|------|-------------|------|---------------------------|
| 1    | 114-4939-03 | 1    | Cover-Fitting, Fuel       |
| 2    | 3274-31     | 3    | Screw-HSBH                |
| 3    | 119-7748    | 1    | Pipe-Stand, Fuel          |
| 4    | 114-0943    | 1    | Pipe-Stand, Return        |
| 5    | 104-0790    | 2    | Bushing                   |
| 6    | 46-6550     | 1    | Fitting-Elbow, 90 DEG     |
| 7    | 46-6560     | 1    | Bushing                   |
| 8    | 119-7745    | 1    | Fuel Tank ASM             |
| 9    | 110-6086    | 1    | Harness-Wire, Fuel Tank ● |
| 10   | 104-8301    | 2    | Nut-HF, NI                |
| 11   | 114-0094    | 1    | Hold Down-Tank            |
| 12   | 3234-42     | 2    | Screw-HHF                 |

| Ref. | Part Number | Qty. | Description          |
|------|-------------|------|----------------------|
| 13   | 94-6821     | 2    | Clamp-Wire           |
| 14   | 119-8266    | 1    | Cap-Fuel (Biodiesel) |
| 15   | 117-2382    | 4    | Plug-Plastic         |
| 16   | 62-7650     | 1    | Gasket               |
| 17   | 114-0942    | 1    | Sender-Fuel          |
| 18   | 3253-15     | 5    | Washer-Lock          |
| 19   | 32122-24    | 5    | Screw-PTH            |
| 20   | 114-9600    | 1    | Decal-Low Sulfur     |
| 21   | 2412-108    | 3    | Clamp-Worm           |
| 23   | 114-5916    | 2    | Hose-Fuel            |
| 24   | 110-4110    | 2    | Hose-LP              |


● Not illustrated



## Engine Breather Assembly

| Ref. | Part Number | Qty. | Description                 |
|------|-------------|------|-----------------------------|
| 1    | 117-2789    | 1    | Fitting-Barb                |
| 2    | 115-3392    | 2    | Hose-Fuel                   |
| 3    | 115-3397    | 1    | Valve-Check                 |
| 4    | 115-3398    | 1    | Adapter-Straight, Hose Barb |
| 5    | 87-3740     | 1    | Hose-Breather               |
| 6    | 115-3399    | 1    | Breather-Cyclone            |
| 7    | 2412-34     | 2    | Clamp-Hose                  |
| 8    | 2412-129    | 1    | Clamp-Hose                  |
| 9    | 115-3395    | 1    | Hose-Formed, Breather Inlet |

| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 10   | 115-8879    | 1    | Plate-Latch           |
| 11   | 3290-378    | 3    | Tie-Cable             |
| 12   | 117-9406    | 1    | Hose-Formed, Breather |
| 13   | 115-3393-03 | 1    | Plate-Mount, Breather |
| 14   | 2412-36     | 2    | Clamp-Hose            |
| 15   | 2412-108    | 6    | Clamp-Worm            |
| 16   | 121-1759    | 3    | Spacer                |
| 17   | 114-4947    | 1    | Plate-Mount, Pad      |
| 18   | 33104-030   | 3    | Screw-HHF             |




## Roll-Over Protection System Assembly

| Ref. | Part Number | Qty. | Description            |
|------|-------------|------|------------------------|
| 1    | 114-5505    | 1    | ROPS ASM               |
| 2    | 33114-020   | 4    | Screw-HH               |
| 3    | 104-8301    | 8    | Nut-HF, NI             |
| 4    | 114-5601-03 | 2    | Bracket-Flasher        |
| 5    | 108-8007    | 1    | Tail Light Flasher ASM |
| 6    | 100-7067    | 4    | U-Bolt (4 Inch)        |
| 7    | 114-0938    | 1    | Tube-Vent              |
| 8    | 114-0937    | 1    | Tube-Vent              |
| 9    | 3290-412    | 4    | Rivet-Blind            |
| 10   | 120-6305    | 1    | Harness-Wire, Flashers |
| 11   | 2412-72     | 4    | Clip-Closed, Insulated |


| Ref. | Part Number | Qty. | Description            |
|------|-------------|------|------------------------|
| 12   | 2412-108    | 2    | Clamp-Worm             |
| 13   | 108-8008    | 1    | Tail Light Flasher ASM |
| 14   | 2412-134    | 2    | Clamp-R                |
| 15   | 49-2040     | 2    | Screw-HWHTF            |
| 16   | 3256-27     | 4    | Washer-Flat            |
| 17   | 327-3       | 4    | Screw-HH               |
| 21   | 114-0835    | 1    | Tread-Foot, Abrasive   |
| 22   | 108-1488    | 1    | Seat Suspension ASM    |
| 23   | 117-5676    | 1    | Premium Seat ASM       |
| 24   | 3290-379    | 7    | Tie-Cable              |
| 25   | 110-6008    | 2    | Decal-Hood             |






## Right Hand Tail Light Assembly No. 108-8007

| Ref. | Part Number | Qty. | Description        |
|------|-------------|------|--------------------|
| 3    | 108-8056    | 1    | Lens-Amber, Base   |
| 4    | 7228        | 1    | Bulb               |
| 5    | 108-8054    | 1    | Bulb               |
| 7    | 108-8053    | 4    | Screw              |
| 10   | 108-8057    | 1    | Lens-Amber, Cover  |
| 11   | 108-8055    | 1    | Lens-Amber, Window |
| 17   | 108-8060    | 1    | Lens-Red, Base     |
| 18   | 108-8059    | 1    | Lens-Black, Cover  |



## Left Hand Tail Light Assembly No. 108-8008

| Ref. | Part Number | Qty. | Description        |
|------|-------------|------|--------------------|
| 3    | 108-8056    | 1    | Lens-Amber, Base   |
| 4    | 7228        | 1    | Bulb               |
| 5    | 108-8054    | 1    | Bulb               |
| 7    | 108-8053    | 4    | Screw              |
| 10   | 108-8057    | 1    | Lens-Amber, Cover  |
| 11   | 108-8055    | 1    | Lens-Amber, Window |
| 17   | 108-8061    | 1    | Lens-Red, Cover    |
| 18   | 108-8058    | 1    | Lens-Black, Base   |




## Vinyl Premium Seat Assembly No. 117-5676

| Ref. | Part Number | Qty. | Description             |
|------|-------------|------|-------------------------|
| 1    | 108-8016    | 1    | Backrest Cushion ASM    |
| 1:1  | 119-7742    | 4    | Screw-Cushion           |
| 2    | 108-8017    | 1    | Seat Cushion ASM        |
| 2:1  | 119-7742    | 3    | Screw-Cushion           |
| 3    | 108-8018    | 1    | Cover-Armrest           |
| 4    | 108-8019    | 1    | LH Armrest ASM          |
| 4:1  | 82-9650     | 1    | Nut                     |
| 4:2  | 107-1198    | 1    | Washer                  |
| 6    | 108-8021    | 1    | Cover-Armrest           |
| 7    | 108-8022    | 2    | Cover-Black             |
| 8    | 108-8024    | 1    | Switch Kit              |
| 8:1  |             | 3    | Wire Tie ●              |
| 8:2  |             | 4    | Rivet ●                 |
| 8:3  |             | 1    | Sensor-Seat Switch ●    |
| 8:4  |             | 2    | Spring-Compression ●    |
| 8:5  |             | 2    | Bumper-Pressure Plate ● |

| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 8:6  |             | 1    | Spring-Extension ●    |
| 8:7  |             | 1    | Plate-Mounting ●      |
| 8:8  |             | 1    | Magnet ●              |
| 9    | 108-8025    | 1    | Adjustment Rail Set   |
| 9:1  |             | 1    | Rail-Adjustment, RH ● |
| 9:2  |             | 1    | Rail-Adjustment, LH ● |
| 9:3  |             | 1    | Stop-Rail ●           |
| 9:4  |             | 1    | Handle ●              |
| 9:5  |             | 3    | Screw ●               |
| 9:6  |             | 3    | Washer ●              |
| 9:7  |             | 1    | Screw ●               |
| 10   | 110-6189    | 1    | Switch Kit            |
| 10:1 |             | 1    | Switch ●              |
| 10:2 |             | 3    | Wire Tie ●            |
| 10:3 |             | 2    | Rivet ●               |

● Not serviced separately




## Cab Mounting Assembly

| Ref. | Part Number | Qty. | Description         |
|------|-------------|------|---------------------|
| 1    |             | 1    | Cab ASM ●           |
| 2    | 115-5489    | 2    | Decal-Warning       |
| 3    | 117-2767    | 1    | Mat-Floor, Cab      |
| 4    | 115-8827    | 3    | Foam-Strip          |
| 5    | 115-5460    | 2    | Seal-Bulb           |
| 6    | 3230-1      | 6    | Bolt-CARR           |
| 7    | 110-6042-01 | 2    | Plate-Sealing, Side |
| 8    | 104-8300    | 10   | Nut-HF, NI          |
| 9    | 115-5461    | 2    | Seal-Bulb           |

| Ref. | Part Number | Qty. | Description            |
|------|-------------|------|------------------------|
| 10   | 2410-64     | 2    | Plug-Button            |
| 11   | 115-5465    | 2    | Seal-Trim              |
| 12   | 110-6036-01 | 1    | Panel-Transition, Rear |
| 13   | 115-5462    | 2    | Seal-Bulb              |
| 14   | 115-5463    | 1    | Seal-Bulb              |
| 15   | 115-5464    | 1    | Seal-Trim              |
| 16   | 3230-23     | 4    | Screw-CARR             |
| 18   | 115-5448    | 2    | Decal-Hood             |


● Not serviced separately



## Compressor Mount and Screen Assembly


| Ref. | Part Number | Qty. | Description               |
|------|-------------|------|---------------------------|
| 7    | 104-7201    | 6    | Nut-HF                    |
| 8    | 104-8300    | 3    | Nut-HF, NI                |
| 9    | 3256-23     | 1    | Washer-Plain              |
| 10   | 56-7974     | 2    | Clamp-Tube                |
| 11   | 114-5616    | 1    | Plate-Mount, Heater Hoses |
| 12   | 114-0004    | 1    | U-Bolt                    |
| 13   | 322-11      | 1    | Screw-HH                  |
| 14   | 33115-130   | 1    | Screw-HH                  |
| 15   | 3290-379    | 4    | Tie-Cable                 |
| 18   | 3234-4      | 6    | Screw-HHF                 |
| 19   | 114-5910-03 | 1    | Plate-Mounting            |
| 20   | 84-5330     | 1    | Bracket-Prop, Hood        |
| 21   | 115-8882    | 1    | Conduit-Convolved         |

| Ref. | Part Number | Qty. | Description             |
|------|-------------|------|-------------------------|
| 22   | 104-8301    | 4    | Nut-HF, NI              |
| 23   | 114-4937    | 1    | Compressor-AC           |
| 23:1 | 115-5418    | 1    | Clutch-Compressor       |
| 24   | 105-3693    | 1    | Belt-Fan                |
| 25   | 3231-22     | 2    | Screw-CARR              |
| 26   | 114-4948    | 1    | Plate-Mount, Compressor |
| 27   | 114-4949-03 | 1    | Arm-Tensioner           |
| 28   | 95-3857     | 2    | Screw-HSBH              |
| 29   | 33025-00    | 1    | Nut-Lock, NI            |
| 30   | 119-7734    | 2    | Shim                    |
| 31   | 114-4944-03 | 1    | Pivot Plate ASM         |
| 32   | 33105-030   | 4    | Screw-HHF               |



## Cab Seat Assembly

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    |
|-------------|--------------------|-------------|-----------------------|
| 6           | 108-1488           | 1           | Seat Suspension ASM   |
| 7           | 117-9429           | 1           | Matrix Cloth Seat ASM |




## Cloth Premium Seat Assembly No. 117-9429

| Ref. | Part Number | Qty. | Description             |
|------|-------------|------|-------------------------|
| 1    | 117-9415    | 1    | Backrest Cushion ASM    |
| 1:1  | 119-7742    | 4    | Screw-Cushion           |
| 2    | 117-9416    | 1    | Seat Cushion ASM        |
| 2:1  | 119-7742    | 3    | Screw-Cushion           |
| 3    | 108-8018    | 1    | Cover-Armrest           |
| 4    | 108-8019    | 1    | LH Armrest ASM          |
| 4:1  | 82-9650     | 1    | Nut                     |
| 4:2  | 107-1198    | 1    | Washer                  |
| 5    | 108-8021    | 1    | Cover-Armrest           |
| 6    | 108-8022    | 2    | Cover-Black             |
| 7    | 108-8024    | 1    | Switch Kit              |
| 7:1  |             | 3    | Wire Tie ●              |
| 7:2  |             | 4    | Rivet ●                 |
| 7:3  |             | 1    | Sensor-Seat Switch ●    |
| 7:4  |             | 2    | Spring-Compression ●    |
| 7:5  |             | 2    | Bumper-Pressure Plate ● |

| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 7:6  |             | 1    | Spring-Extension ●    |
| 7:7  |             | 1    | Plate-Mounting ●      |
| 7:8  |             | 1    | Magnet ●              |
| 8    | 108-8025    | 1    | Adjustment Rail Set   |
| 8:1  |             | 1    | Rail-Adjustment, RH ● |
| 8:2  |             | 1    | Rail-Adjustment, LH ● |
| 8:3  |             | 1    | Stop-Rail ●           |
| 8:4  |             | 1    | Handle ●              |
| 8:5  |             | 3    | Screw ●               |
| 8:6  |             | 3    | Washer ●              |
| 8:7  |             | 1    | Screw ●               |
| 9    | 110-6189    | 1    | Switch Kit            |
| 9:1  |             | 1    | Switch ●              |
| 9:2  |             | 3    | Wire Tie ●            |
| 9:3  |             | 2    | Rivet ●               |

● Not serviced separately




## Right Door Cab Assembly

| Ref. | Part Number | Qty. | Description         |
|------|-------------|------|---------------------|
| 1    | 33103-025   | 2    | Screw-HHF           |
| 2    | 33103-035   | 1    | Screw-HHF           |
| 3    | 117-9446    | 1    | RH Door Glass Kit   |
| 3:1  | 115-5571    | 3    | Bolt-Step           |
| 3:2  | 115-5570    | 6    | Bushing-Thin        |
| 3:3  | 115-5572    | 3    | Nut-Flange          |
| 3:4  | 115-5573    | 6    | Washer-Sealing      |
| 3:5  | 115-5567    | 1    | Trim-Seal, Bulb     |
| 3:6  |             | 1    | Glass-Door ●        |
| 4    | 115-5540    | 1    | RH Door Handle ASM  |
| 5    | 115-5542    | 1    | RH Door Latch ASM   |
| 6    | 115-5544    | 1    | Handle-Button, Push |
| 6:1  | 119-4514    | 1    | Gasket-Large        |
| 6:2  | 119-4515    | 1    | Gasket-Small        |
| 7    | 115-5591    | 2    | Clip-Shock, Gas     |
| 8    | 115-5590    | 1    | Shock-Gas, Long     |
| 9    | 98-3104     | 2    | Stud-Ball           |

| Ref. | Part Number | Qty. | Description         |
|------|-------------|------|---------------------|
| 10   | 115-5546    | 1    | Gasket-Handle       |
| 11   | 115-5532    | 1    | RH Lower Hinge ASM  |
| 12   | 115-5530    | 1    | RH Upper Hinge ASM  |
| 14   | 117-4996    | 1    | RH Rotary Latch ASM |
| 15   | 115-5545    | 1    | Key-Cab             |
| 16   | 32128-26    | 2    | Nut-Flange          |
| 17   | 104-3082    | 4    | Nut-Lock, HHF       |
| 18   | 81-0130     | 2    | Nut-Flange, NI      |
| 19   | 3274-96     | 3    | Screw-HSBH          |
| 20   | 115-5534    | 1    | Washer              |
| 21   | 115-5528    | 3    | Washer              |
| 22   | 117-2777    | 1    | Plate-Striker       |
| 23   | 115-5581    | 2    | Washer-Flat         |
| 24   | 3234-13     | 2    | Screw-HHF           |
| 25   | 115-5577    | 1    | Guard-Striker       |
| 26   | 115-5576    | 1    | Striker             |

● Not serviced separately






## Right Door Cab Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|------|-------------|------|-------------|
| 27   | 115-5579    | 1    | Nut-HH      |
| 28   | 3256-26     | 1    | Washer-Flat |

● Not serviced separately




## Left Door Cab Assembly

| Ref. | Part Number | Qty. | Description         |
|------|-------------|------|---------------------|
| 1    | 33103-025   | 2    | Screw-HHF           |
| 2    | 33103-035   | 1    | Screw-HHF           |
| 3    | 117-9445    | 1    | LH Door Glass Kit   |
| 3:1  | 115-5571    | 3    | Bolt-Step           |
| 3:2  | 115-5570    | 6    | Bushing-Thin        |
| 3:3  | 115-5572    | 3    | Nut-Flange          |
| 3:4  | 115-5573    | 6    | Washer-Sealing      |
| 3:5  | 115-5567    | 1    | Trim-Seal, Bulb     |
| 3:6  |             | 1    | Glass-Door ●        |
| 4    | 115-5541    | 1    | LH Door Handle ASM  |
| 5    | 115-5543    | 1    | LH Door Latch ASM   |
| 6    | 115-5544    | 1    | Handle-Button, Push |
| 6:1  | 119-4514    | 1    | Gasket-Large        |
| 6:2  | 119-4515    | 1    | Gasket-Small        |
| 7    | 115-5591    | 2    | Clip-Shock, Gas     |
| 8    | 115-5590    | 1    | Shock-Gas, Long     |
| 9    | 98-3104     | 2    | Stud-Ball           |

| Ref. | Part Number | Qty. | Description         |
|------|-------------|------|---------------------|
| 10   | 115-5546    | 1    | Gasket-Handle       |
| 11   | 115-5533    | 1    | LH Lower Hinge ASM  |
| 12   | 115-5531    | 1    | LH Upper Hinge ASM  |
| 14   | 117-4997    | 1    | LH Rotary Latch ASM |
| 15   | 115-5545    | 1    | Key-Cab             |
| 16   | 32128-26    | 2    | Nut-Flange          |
| 17   | 104-3082    | 4    | Nut-Lock, HHF       |
| 18   | 81-0130     | 2    | Nut-Flange, NI      |
| 19   | 3274-96     | 3    | Screw-HSBH          |
| 20   | 115-5534    | 1    | Washer              |
| 21   | 115-5528    | 3    | Washer              |
| 22   | 117-2777    | 1    | Plate-Striker       |
| 23   | 115-5581    | 2    | Washer-Flat         |
| 24   | 3234-13     | 2    | Screw-HHF           |
| 25   | 115-5577    | 1    | Guard-Striker       |
| 26   | 115-5576    | 1    | Striker             |


● Not serviced separately



## Left Door Cab Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|------|-------------|------|-------------|
| 27   | 115-5579    | 1    | Nut-HH      |
| 28   | 3256-26     | 1    | Washer-Flat |

● Not serviced separately




## Front and Rear Window Cab Assembly

| Ref. | Part Number | Qty. | Description                |
|------|-------------|------|----------------------------|
| 1    | 115-5566    | 2    | Window Glass Kit           |
| 1:1  | 115-5568    | 1    | Trim-Seal, Bulb            |
| 1:2  |             | 1    | Glass-Window ●             |
| 2    | 115-5563    | 6    | Hinge ASM                  |
| 3    | 115-5597    | 4    | Handle-Latch               |
| 4    | 32128-26    | 6    | Nut-Flange                 |
| 5    | 115-5548    | 6    | Screw-HSFH                 |
| 6    | 115-5549    | 12   | Screw-HSFH                 |
| 7    | 115-5599    | 4    | Pin-Split                  |
| 8    | 115-5598    | 6    | Washer-Rubber              |
| 9    | 115-5565    | 1    | Lower Windshield Glass Kit |


| Ref. | Part Number | Qty. | Description            |
|------|-------------|------|------------------------|
| 9:1  | 115-5571    | 4    | Bolt-Step              |
| 9:2  | 115-5569    | 1    | Trim-Seal, Bulb        |
| 9:3  | 115-5570    | 4    | Bushing-Thin           |
| 9:4  | 115-5574    | 4    | Bushing-Thick          |
| 9:5  | 115-5572    | 4    | Nut-Flange             |
| 9:6  |             | 1    | Glass-Front, Lower ●   |
| 10   | 115-5584    | 1    | Arm-Mount, Mirror (LH) |
| 11   | 115-5583    | 1    | Arm-Mount, Mirror (RH) |
| 12   | 115-5585    | 2    | Mirror-Convex          |
| 13   | 115-5582    | 2    | Nut-Flange, Crimplock  |

● Not serviced separately




## Window Wiper and Washer Bottle Cab Assembly

| Ref. | Part Number | Qty. | Description            |
|------|-------------|------|------------------------|
| 1    | 115-8831    | 1    | Motor-Wiper            |
| 1:1  | 119-7735    | 1    | Wiper Seal Kit         |
| 2    | 115-8834    | 1    | Blade-Wiper, 22 Inch   |
| 3    | 115-8832    | 1    | Adaptor ASM (W/Gasket) |
| 4    | 115-8833    | 1    | Arm-Wiper, 22 Inch     |
| 5    | 119-8366    | 1    | Line-Washer            |
| 6    | 119-8367    | 2    | Grommet                |
| 7    | 119-8368    | 1    | Connector-Barb         |
| 8    | 119-8369    | 1    | Washer Nozzle Kit      |
| 10   | 115-8848    | 1    | Tank-Fluid, Washer     |



## Shielding Component Cab Assembly


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|---------------------|
| 1           | 115-5589           | 1           | Cover-Composite, LH |
| 2           | 115-5588           | 1           | Cover-Composite, RH |
| 3           | 3274-65            | 4           | Screw-HSBH          |
| 4           | 115-5586           | 4           | Nut-Panel, Deep     |
| 5           | 115-5595           | 1           | Hook-Coat           |
| 6           | 115-5594           | 1           | Screw-HSBH          |
| 7           | 115-5596           | 2           | Seal-Bulb           |



## Headliner Cab Assembly

| Ref. | Part Number | Qty. | Description                |
|------|-------------|------|----------------------------|
| 1    | 121-3892    | 1    | Filter-Air, Cab Exterior   |
| 2    | 121-3891    | 1    | Filter-Air, Cab Interior   |
| 3    | 115-5559    | 1    | Louver-Ball                |
| 4    | 73-5380     | 4    | Nut-Hex                    |
| 5    | 117-2763    | 2    | Fastener-Mount, Rear Roof  |
| 6    | 117-2764    | 2    | Fastener-Mount, Front Roof |
| 7    | 115-5570    | 10   | Bushing-Thin               |
| 8    | 115-5515    | 1    | Light-Dome, LED            |
| 9    | 115-5554    | 1    | Cover-Filter, Rear         |
| 10   | 115-5557    | 1    | Cover-Filter, Front        |
| 11   | 115-5513    | 2    | Spacer-Roof, Front         |
| 14   | 115-5550    | 1    | Headliner                  |
| 15   | 115-5558    | 3    | Louver                     |
| 16   | 115-5524    | 1    | Mirror-Rear View           |
| 17   | 32128-26    | 4    | Nut-Flange                 |
| 18   | 32128-17    | 5    | Nut-Lock, Flange           |

| Ref. | Part Number | Qty. | Description          |
|------|-------------|------|----------------------|
| 19   | 115-5572    | 2    | Nut-Flange           |
| 20   | 115-5586    | 5    | Nut-Panel, Deep      |
| 21   | 115-5521    | 2    | Grommet-Light        |
| 22   | 115-5520    | 2    | Light-Warning, Front |
| 23   | 115-5526    | 1    | Mount-Roof           |
| 24   | 115-5514    | 2    | Spacer-Roof, Rear    |
| 25   | 119-4504    | 1    | Roof                 |
| 26   | 3274-65     | 2    | Screw-HSBH           |
| 27   | 108-3153    | 5    | Screw-HSBH           |
| 28   | 115-5594    | 2    | Screw-HSBH           |
| 31   | 115-5525    | 2    | Light-Warning, Rear  |
| 32   | 115-5555    | 4    | Screw-Thumb          |
| 33   | 115-5581    | 6    | Washer-Flat          |
| 34   | 99-2932     | 1    | Screw-HSBH           |
| 35   | 115-5598    | 1    | Washer-Rubber        |
| 36   | 121-3872    | 1    | Seal-Bulb, Roof      |



## Roof, Condenser and Evaporator Cab Assembly


| Ref. | Part Number | Qty. | Description              |
|------|-------------|------|--------------------------|
| 1    | 115-8835    | 1    | Hose-Air Duct            |
| 2    | 117-2785    | 1    | Hose ASM                 |
| 2:1  | 117-2779    | 2    | O-Ring                   |
| 2:2  | 117-2783    | 1    | Cap-Side, High ●         |
| 2:3  | 117-2781    | 1    | Grommet                  |
| 3    | 115-8837    | 1    | Hose ASM                 |
| 3:1  | 117-2778    | 2    | O-Ring                   |
| 3:2  | 117-2782    | 1    | Grommet                  |
| 4    | 115-8838    | 1    | Hose ASM                 |
| 4:1  | 117-2778    | 2    | O-Ring                   |
| 5    | 117-2786    | 1    | Hose ASM                 |
| 5:1  | 117-2780    | 2    | O-Ring                   |
| 5:2  | 117-2784    | 1    | Cap-Side, Low ●          |
| 6    |             | 1    | Condenser ASM ■          |
| 7    | 119-4503    | 1    | Cover-Condenser          |
| 8    | 115-8845    | 2    | Hose-Drain, Condensation |
| 9    | 3296-42     | 4    | Nut-Lock, NI             |

| Ref. | Part Number | Qty. | Description             |
|------|-------------|------|-------------------------|
| 10   | 67-1300     | 1    | Decal                   |
| 11   |             | 1    | Heater Evaporator ASM ■ |
| 12   | 115-8842    | 1    | Hose                    |
| 13   | 115-8843    | 1    | Hose                    |
| 14   | 115-8844    | 1    | Hose                    |
| 15   | 115-8840    | 1    | Valve-Heater            |
| 16   | 2412-141    | 4    | Clamp-Drive, Worm       |
| 17   | 3229-4      | 2    | Screw-CARR              |
| 18   | 115-5581    | 8    | Washer-Flat             |
| 19   | 3290-379    | 2    | Tie-Cable               |
| 20   | 115-5570    | 4    | Bushing-Thin            |
| 21   | 117-9410    | 2    | Fitting-Straight        |
| 22   | 119-4505    | 1    | Strap-Mounting          |
| 23   | 104-2408    | 2    | Screw-HSBH              |
| 24   | 3256-14     | 2    | Washer-Flat             |
| 25   | 119-4517    | 2    | Clamp-Hose              |
| 26   | 32128-17    | 2    | Nut-Lock, Flange        |

● Not illustrated

■ Not serviced separately






## Switchplate and Fuse Block Cover Cab Assembly

| Ref. | Part Number | Qty. | Description          |
|------|-------------|------|----------------------|
| 1    | 115-5502    | 1    | Switch-Fan, 3-Speed  |
| 2    | 115-8820    | 1    | Switch-Control, Heat |
| 3    | 115-5503    | 1    | Nut                  |
| 4    | 107-1013    | 5    | Nut-Speed            |
| 5    | 104-2408    | 9    | Screw-HSBH           |
| 6    | 115-5504    | 2    | Knob-Control         |
| 7    | 115-5500    | 1    | Plate-Switch         |
| 8    | 115-5501    | 1    | Label-Switch         |
| 9    | 114-3329    | 1    | Switch-Rocker        |
| 10   | 95-8999     | 1    | Switch               |
| 11   | 115-5510    | 1    | Cover-Access, Fuse   |

| Ref. | Part Number | Qty. | Description             |
|------|-------------|------|-------------------------|
| 12   | 117-2787    | 1    | Label-Information, Fuse |
| 13   | 115-5508    | 1    | Label-Block, Fuse       |
| 14   | 32128-17    | 2    | Nut-Lock, Flange        |
| 15   | 115-5506    | 1    | Knob                    |
| 16   | 119-1343    | 1    | Harness-Wire, Cab       |
| 16:2 | 109355      | 3    | Fuse-Blade, 15 Amp      |
| 16:3 | 109103      | 1    | Fuse-Blade, 30 Amp      |
| 17   | 115-5547    | 2    | Pad-Fastener            |
| 18   | 115-5511    | 1    | Mount-Block, Fuse       |
| 19   | 115-5505    | 3    | Nut-Panel, Spring       |




## A/C Heater and Evaporator Cab Assembly

| Ref.  | Part Number | Qty. | Description               |
|-------|-------------|------|---------------------------|
| 1     | 121-3860    | 1    | A/C Heater ASM            |
| 1:1   | 121-3861    | 1    | Fan-Blower                |
| 1:1:1 | 121-3862    | 1    | Resistor-Fan              |
| 1:1:2 |             | 1    | Fan And Motor ASM ●       |
| 1:2   | 115-5587    | 1    | Valve-Expansion           |
| 1:3   | 115-5593    | 1    | Thermostat-Switch, Freeze |
| 2     | 115-8829    | 1    | Cover-Top                 |
| 3     | 33103-025   | 2    | Screw-HHF                 |
| 4     | 115-8824    | 1    | Mount-Drier               |

| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 5    | 115-8828    | 1    | Evaporator-Bottom     |
| 6    | 2412-125    | 2    | Clamp-Hose            |
| 7    | 107-1013    | 8    | Nut-Speed             |
| 8    | 115-5586    | 4    | Nut-Panel, Deep       |
| 9    | 119-4502    | 1    | Drier-Receiver        |
| 10   | 104-2408    | 8    | Screw-HSBH            |
| 11   | 3274-65     | 5    | Screw-HSBH            |
| 12   | 119-4501    | 1    | Switch-Function, Dual |


● Not serviced separately



## Condenser Cab Assembly


| Ref. | Part Number | Qty. | Description    |
|------|-------------|------|----------------|
| 1    | 115-5570    | 4    | Bushing-Thin   |
| 2    | 115-8816    | 1    | Coil-Condenser |
| 3    | 119-4511    | 1    | Shroud-Fan     |
| 4    | 119-4500    | 1    | Fan-12 Inch    |
| 5    | 115-8822    | 4    | Mount-Isolator |
| 6    | 115-8823    | 4    | Coupler-Nut    |
| 8    | 3274-65     | 8    | Screw-HSBH     |
| 9    | 115-8819    | 4    | Screw-HSBH     |
| 10   | 115-5581    | 4    | Washer-Flat    |
| 11   | 107069      | 4    | Clip           |

| Ref. | Part Number | Qty. | Description     |
|------|-------------|------|-----------------|
| 12   | 119-4527    | 1    | Foam-Tray       |
| 13   | 119-4513    | 1    | Frame-Screen    |
| 14   | 119-4544    | 2    | Foam-End        |
| 15   | 119-4512    | 1    | Tray-Screen     |
| 16   | 119-4516    | 2    | Foam-Side       |
| 17   | 3296-42     | 1    | Nut-Lock, NI    |
| 18   | 119-4507    | 1    | Plate-Latch     |
| 19   | 66-2921     | 2    | Washer-Friction |
| 20   | 119-4506    | 1    | Spacer-Latch    |
| 21   | 3229-4      | 1    | Screw-CARR      |




## Center Deck and Winglet Assembly

| Ref. | Part Number | Qty. | Description                     |
|------|-------------|------|---------------------------------|
| 1    | 110-5911    | 1    | Center Front Deck And Decal ASM |
| 2    | 110-5914    | 1    | Right Front Deck And Decal ASM  |
| 3    | 110-5917    | 1    | Left Front Deck And Decal ASM   |
| 5    | 69-9300     | 2    | Pad-Bumper                      |
| 6    | 32108-103   | 4    | Screw-FH                        |
| 7    | 104-8300    | 4    | Nut-HF, NI                      |
| 10   | 325-35      | 4    | Screw-HH                        |
| 11   | 99-5107     | 4    | Nut-Lock                        |
| 12   | 114-0714    | 4    | Hinge Pin ASM                   |
| 13   | 115-3367    | 4    | Eccentric                       |
| 14   | 302-5       | 4    | Fitting-Grease                  |




## Center Front Deck and Decal Assembly No. 110-5911

| Ref. | Part Number | Qty. | Description              |
|------|-------------|------|--------------------------|
| 2    | 117-4979    | 3    | Decal-Warning            |
| 3    | 93-7818     | 1    | Decal-Torque, Blade Bolt |
| 4    | 114-0922    | 1    | Decal-Belt Routing       |
| 5    | 114-0975    | 1    | Decal-HOC                |
| 6    | 114-0864    | 1    | Decal-Rear HOC, RH       |
| 7    | 114-0865    | 1    | Decal-Rear HOC, LH       |
| 12   | 110-3510    | 1    | Nut-Retainer             |




## Right Front Deck and Decal Assembly No. 110-5914

| Ref. | Part Number | Qty. | Description              |
|------|-------------|------|--------------------------|
| 2    | 117-4979    | 1    | Decal-Warning            |
| 3    | 120-6604    | 1    | Decal-Danger             |
| 4    | 93-7818     | 1    | Decal-Torque, Blade Bolt |
| 5    | 93-6674     | 1    | Decal-Warning            |
| 6    | 93-6687     | 1    | Decal-No Step            |
| 7    | 110-3510    | 1    | Nut-Retainer             |
| 8    | 92-3162     | 4    | Bushing                  |



## Left Front Deck and Decal Assembly No. 110-5917

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       |
|-------------|--------------------|-------------|--------------------------|
| 2           | 117-4979           | 1           | Decal-Warning            |
| 3           | 120-6604           | 1           | Decal-Danger             |
| 4           | 93-7818            | 1           | Decal-Torque, Blade Bolt |
| 5           | 93-6674            | 1           | Decal-Warning            |
| 6           | 110-3510           | 1           | Nut-Retainer             |
| 7           | 92-3162            | 4           | Bushing                  |




## Center Deck Belt and Pulley Assembly

| Ref. | Part Number | Qty. | Description               |
|------|-------------|------|---------------------------|
| 1    | 119-4547    | 1    | Driving Spindle ASM       |
| 2    | 119-4548    | 2    | Double Driven Spindle ASM |
| 3    | 119-4549    | 2    | High-Driven Spindle ASM   |
| 4    | 110-9596    | 3    | Pulley-Idler              |
| 6    | 100-3102    | 2    | Washer-Flat               |
| 7    | 108-1924    | 3    | Spacer-Idler              |
| 8    | 108-1993    | 3    | Screw-HSBH                |
| 9    | 3296-45     | 3    | Nut-Hex                   |
| 10   | 108-1921    | 1    | Spring-Torsion            |
| 11   | 112-7395    | 2    | Spring-Torsion            |
| 12   | 108-1926    | 3    | Washer                    |
| 13   | 32120-84    | 3    | Ring-Snap, External       |
| 14   | 302-5       | 3    | Fitting-Grease            |

| Ref. | Part Number | Qty. | Description        |
|------|-------------|------|--------------------|
| 15   | 117-9176    | 2    | Idler Arm ASM      |
| 15:2 | 93-4510     | 2    | Bushing-Caster     |
| 16   | 112-7376    | 1    | Belt-V, B          |
| 17   | 112-7377    | 2    | Belt-V, B          |
| 18   | 114-0100    | 1    | High Idler Arm ASM |
| 18:2 | 93-4510     | 2    | Bushing-Caster     |
| 20   | 01-182-0816 | 1    | Bolt-HH            |
| 21   | 3218-5      | 2    | Nut-Jam            |
| 22   | 114-0997    | 3    | Pivot-Idler        |
| 23   | 3231-2      | 9    | Bolt-CARR          |
| 24   | 3296-59     | 9    | Nut-Lock, NI       |
| 25   | 3256-26     | 2    | Washer-Flat        |






## Driving Spindle Assembly No. 119-4547

| Ref.  | Part Number | Qty. | Description           |
|-------|-------------|------|-----------------------|
| 1     | 104-3554    | 1    | Shaft-Spindle         |
| 2     | 69-6950     | 1    | Spacer-Shaft, Spindle |
| 3     | 119-4546    | 1    | Spindle Housing ASM   |
| 3:1   | 104-3549    | 1    | Bearing Spacer Set    |
| 3:2   | 110-8297    | 1    | Bearing ASM           |
| 3:3   | 253-154     | 2    | Seal-Oil              |
| 3:4   | 302-60      | 1    | Fitting-Grease        |
| 3:5   |             | 1    | Spindle ASM ●         |
| 3:5:2 | 114-8195    | 4    | Bolt-Ribbed Neck      |
| 4     | 106-7159    | 1    | O-Ring                |
| 5     | 104-3545    | 1    | Pulley-Driving        |
| 6     | 104-8322    | 1    | Washer-Hardened       |
| 7     | 3296-60     | 1    | Nut-Lock, NI          |
| 8     | 104-3544    | 1    | Mount-Motor, Drive    |


● Not serviced separately



## Double Driven Spindle Assembly No. 119-4548

| Ref.  | Part Number | Qty. | Description           |
|-------|-------------|------|-----------------------|
| 1     | 104-3554    | 1    | Shaft-Spindle         |
| 2     | 69-6950     | 1    | Spacer-Shaft, Spindle |
| 3     | 119-4775    | 1    | Spindle Housing ASM   |
| 3:1   |             | 1    | Spindle ASM ●         |
| 3:1:2 | 114-8195    | 8    | Bolt-Ribbed Neck      |
| 3:2   | 104-3549    | 1    | Bearing Spacer Set    |
| 3:3   | 110-8297    | 1    | Bearing ASM           |
| 3:4   | 253-154     | 2    | Seal-Oil              |
| 3:5   | 302-60      | 1    | Fitting-Grease        |
| 4     | 106-7159    | 1    | O-Ring                |
| 5     | 104-3547    | 1    | Pulley-Driven, Double |
| 6     | 104-8322    | 1    | Washer-Hardened       |
| 7     | 3296-60     | 1    | Nut-Lock, NI          |


● Not serviced separately



## High Driven Spindle Assembly No. 119-4549

| Ref.  | Part Number | Qty. | Description           |
|-------|-------------|------|-----------------------|
| 1     | 104-3554    | 1    | Shaft-Spindle         |
| 2     | 69-6950     | 1    | Spacer-Shaft, Spindle |
| 3     | 119-4775    | 1    | Spindle Housing ASM   |
| 3:1   |             | 1    | Spindle ASM ●         |
| 3:1:2 | 114-8195    | 8    | Bolt-Ribbed Neck      |
| 3:2   | 104-3549    | 1    | Bearing Spacer Set    |
| 3:3   | 110-8297    | 1    | Bearing ASM           |
| 3:4   | 253-154     | 2    | Seal-Oil              |
| 3:5   | 302-60      | 1    | Fitting-Grease        |
| 4     | 106-7159    | 1    | O-Ring                |
| 5     | 104-3548    | 1    | Pulley-Driven, High   |
| 6     | 104-8322    | 1    | Washer-Hardened       |
| 7     | 3296-60     | 1    | Nut-Lock, NI          |


● Not serviced separately



## Center Deck Roller, Skid and Caster Wheel Assembly


| Ref. | Part Number | Qty. | Description          |
|------|-------------|------|----------------------|
| 1    | 93-4240     | 2    | 10 Inch Wheel ASM    |
| 2    | 114-4885    | 2    | Front Castor Arm ASM |
| 2:2  | 302-5       | 1    | Fitting-Grease       |
| 2:3  | 69-6470     | 2    | Bushing-Castor       |
| 3    | 323-42      | 12   | Screw-HH             |
| 4    | 3256-24     | 12   | Washer-Flat          |
| 5    | 92-9727     | 2    | HOC Cap ASM          |
| 5:1  | 92-5581     | 1    | Ring-Retaining       |
| 5:2  | 92-5583     | 1    | Washer-Cap           |
| 5:3  | 92-9726     | 1    | Spring-Compression   |
| 5:4  | 92-8861     | 1    | Cap-HOC              |
| 7    | 69-6860     | 8    | Washer-Thrust        |
| 8    | 69-1510     | 8    | Spacer               |
| 9    | 29-4820     | 2    | Roller               |

| Ref. | Part Number | Qty. | Description       |
|------|-------------|------|-------------------|
| 10   | 325-17      | 2    | Screw-HH          |
| 11   | 3296-45     | 2    | Nut-Hex           |
| 12   | 68-6710     | 1    | Roller            |
| 13   | 68-6840     | 1    | Shaft-Roller      |
| 14   | 3231-21     | 1    | Screw-CARR        |
| 15   | 110-5999-01 | 2    | Castor Fork ASM   |
| 16   | 327-24      | 2    | Screw-HH          |
| 17   | 3296-53     | 2    | Nut-Lock, NI      |
| 18   | 112-1479    | 2    | Skid-Bumper, Deck |
| 19   | 9136144     | 2    | Screw-HWHTF       |
| 20   | 3231-33     | 4    | Screw-CARR        |
| 21   | 104-8301    | 16   | Nut-HF, NI        |
| 22   | 3296-59     | 1    | Nut-Lock, NI      |



## 10 Inch Wheel Assembly No. 93-4240


| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 1    | 93-4243     | 1    | Tire                  |
| 2    | 93-4244     | 1    | Tube-Inner (W/Valve)  |
| 3    | 93-4241     | 1    | Spacer-Bearing, Inner |
| 4    | 120-3366    | 2    | Bearing               |
| 5    | 32128-16    | 4    | Nut-HHF               |
| 7    | 93-4242     | 1    | Plate                 |
| 8    | 93-4239     | 1    | Rim-Wheel, Half       |
| 9    | 93-5980     | 1    | Hub                   |
| 10   | 95-2741     | 1    | Rim-Wheel, Half       |



## Center Deck Spindle and Blade Assembly


| Ref. | Part Number | Qty. | Description            |
|------|-------------|------|------------------------|
| 1    | 110-5946-03 | 5    | Blade-Rotary           |
| 1    | 110-5948-03 | 5    | Blade-Rotary, Atomic ● |
| 2    | 72-9361     | 5    | Cup-Scalp, Anti        |
| 3    | 92-5816     | 5    | Bolt-Blade             |
| 5    | 104-8301    | 36   | Nut-HF, NI             |
| 6    | 323-6       | 4    | Screw-HH               |
| 7    | 3256-24     | 4    | Washer-Flat            |

● Not illustrated



## Center Deck Belt Cover Assembly

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>              |
|-------------|--------------------|-------------|---------------------------------|
| 1           | 114-5630           | 1           | Cover-Center, Front Deck        |
| 3           | 114-5632           | 1           | Cover-Front Deck, RH Transition |
| 4           | 114-5629           | 1           | Cover-Front Deck, LH            |
| 5           | 114-5631           | 1           | Cover-Front Deck, LH Transition |
| 6           | 114-5628           | 1           | Cover-Front Deck, RH            |
| 7           | 115-5424           | 2           | Shield-Deck, Flexible           |
| 8           | 117-2382           | 6           | Plug-Plastic                    |
| 10          | 110-3510           | 3           | Nut-Retainer                    |
| 11          | 3234-29            | 3           | Screw-HHF                       |
| 13          | 103-4080           | 4           | Latch-Rubber                    |
| 14          | 3274-39            | 8           | Screw-HSBH                      |




## Center Deck Chamber Assembly

| Ref. | Part Number | Qty. | Description       |
|------|-------------|------|-------------------|
| 1    | 115-2100-01 | 1    | Chamber-Outer, LH |
| 2    | 115-2101-01 | 1    | Chamber-Inner, LH |
| 3    | 115-2102-01 | 1    | Chamber-Center    |
| 4    | 115-2103-01 | 1    | Chamber-Inner, RH |
| 5    | 115-2104-01 | 1    | Chamber-Outer, RH |
| 6    | 3230-10     | 43   | Bolt-CARR         |
| 7    | 104-8300    | 43   | Nut-HF, NI        |
| 8    | 115-2147-01 | 1    | Baffle-Deflector  |


| Ref. | Part Number | Qty. | Description                |
|------|-------------|------|----------------------------|
| 9    | 104-7658    | 1    | Spacer                     |
| 13   | 114-0891    | 1    | Flap-Rubber, Right Winglet |
| 14   | 114-0890    | 1    | Flap-Rubber, Center        |
| 15   | 115-3389    | 1    | Flap-Rubber, Left Winglet  |
| 16   | 114-0884-03 | 1    | Bar-Flap Holddown, Center  |
| 17   | 115-3390-03 | 1    | Bar-Flap Holddown, Center  |
| 18   | 114-0885-03 | 2    | Bar-Flap Holddown, Outer   |
| 21   | 115-5444-03 | 1    | Strap-Deflector            |





## Center Deck Transport Damper Assembly


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 105-3249           | 1           | Damper             |
| 2           | 104-8331           | 1           | End-Rod, Spherical |
| 3           | 115-5455           | 1           | End-Rod, Clevis    |
| 4           | 115-5454           | 1           | Pin-Spring         |
| 5           | 322-17             | 1           | Screw-HH           |
| 6           | 115-2142           | 1           | Spacer             |
| 8           | 115-5452-01        | 1           | Mount-Damper       |
| 16          | 3230-10            | 2           | Bolt-CARR          |
| 17          | 104-8300           | 3           | Nut-HF, NI         |



## Right Deck Belt and Pulley Assembly


| Ref. | Part Number | Qty. | Description               |
|------|-------------|------|---------------------------|
| 1    | 110-5921    | 1    | Right Deck And Decal ASM  |
| 2    | 119-4547    | 1    | Driving Spindle ASM       |
| 3    | 119-4548    | 1    | Double Driven Spindle ASM |
| 4    | 119-4549    | 1    | High-Driven Spindle ASM   |
| 5    | 112-7377    | 2    | Belt-V, B                 |
| 6    | 01-268-0160 | 2    | Pulley-Idler              |
| 7    | 117-9176    | 1    | Idler Arm ASM             |
| 7:2  | 93-4510     | 2    | Bushing-Caster            |
| 8    | 108-1926    | 2    | Washer                    |
| 9    | 100-3102    | 1    | Washer-Flat               |
| 10   | 3274-5      | 2    | Screw-HSH                 |

| Ref. | Part Number | Qty. | Description         |
|------|-------------|------|---------------------|
| 11   | 108-1924    | 2    | Spacer-Idler        |
| 12   | 3296-45     | 2    | Nut-Hex             |
| 13   | 108-1921    | 2    | Spring-Torsion      |
| 14   | 32120-84    | 2    | Ring-Snap, External |
| 15   | 302-5       | 2    | Fitting-Grease      |
| 16   | 108-1930    | 1    | Idler Arm ASM       |
| 16:2 | 93-4510     | 2    | Bushing-Caster      |
| 17   | 114-0997    | 2    | Pivot-Idler         |
| 18   | 3231-2      | 6    | Bolt-CARR           |
| 19   | 3296-59     | 6    | Nut-Lock, NI        |
| 20   | 3256-26     | 4    | Washer-Flat         |



## Right Deck Decal Assembly No. 110-5921


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>            |
|-------------|--------------------|-------------|-------------------------------|
| 2           | 117-4979           | 3           | Decal-Warning                 |
| 3           | 120-6604           | 1           | Decal-Danger                  |
| 4           | 93-7818            | 1           | Decal-Torque, Blade Bolt      |
| 5           | 114-0974           | 1           | Decal-Belt Routing, Deck (RH) |
| 6           | 110-3510           | 4           | Nut-Retainer                  |
| 7           | 114-0975           | 1           | Decal-HOC                     |



## Right Deck Roller, Skid and Caster Wheel Assembly

| Ref. | Part Number | Qty. | Description       |
|------|-------------|------|-------------------|
| 1    | 112-1479    | 2    | Skid-Bumper, Deck |
| 2    | 3231-33     | 4    | Screw-CARR        |
| 3    | 104-8301    | 16   | Nut-HF, NI        |
| 4    | 9136144     | 2    | Screw-HWHTF       |
| 5    | 323-42      | 12   | Screw-HH          |
| 6    | 93-4240     | 4    | 10 Inch Wheel ASM |
| 7    | 110-6040    | 2    | Castor Arm ASM    |
| 7:2  | 302-5       | 1    | Fitting-Grease    |
| 7:3  | 69-6470     | 2    | Bushing-Castor    |
| 8    | 69-6860     | 16   | Washer-Thrust     |
| 9    | 110-5999-01 | 4    | Castor Fork ASM   |
| 10   | 29-4820     | 2    | Roller            |
| 11   | 325-17      | 2    | Screw-HH          |
| 12   | 3296-45     | 2    | Nut-Hex           |
| 13   | 327-24      | 4    | Screw-HH          |


| Ref. | Part Number | Qty. | Description        |
|------|-------------|------|--------------------|
| 14   | 3296-53     | 4    | Nut-Lock, NI       |
| 15   | 92-9727     | 4    | HOC Cap ASM        |
| 15:1 | 92-5581     | 1    | Ring-Retaining     |
| 15:2 | 92-5583     | 1    | Washer-Cap         |
| 15:3 | 92-9726     | 1    | Spring-Compression |
| 15:4 | 92-8861     | 1    | Cap-HOC            |
| 16   | 114-0953    | 1    | HOC Castor Arm ASM |
| 16:2 | 302-5       | 2    | Fitting-Grease     |
| 16:3 | 69-6470     | 4    | Bushing-Castor     |
| 17   | 69-1510     | 16   | Spacer             |
| 18   | 3256-24     | 12   | Washer-Flat        |
| 22   | 117-2768    | 1    | Flap-Rubber        |
| 23   | 104-0858    | 2    | Bolt-Shoulder      |
| 24   | 103995      | 2    | Washer             |
| 25   | 104-7201    | 2    | Nut-HF             |



## Right Deck Spindle and Blade Assembly


| Ref. | Part Number | Qty. | Description            |
|------|-------------|------|------------------------|
| 1    | 110-5946-03 | 3    | Blade-Rotary           |
| 1    | 110-5948-03 | 3    | Blade-Rotary, Atomic ● |
| 2    | 72-9361     | 3    | Cup-Scalp, Anti        |
| 3    | 92-5816     | 3    | Bolt-Blade             |
| 4    | 104-8301    | 20   | Nut-HF, NI             |
| 6    | 323-6       | 4    | Screw-HH               |
| 7    | 3256-24     | 4    | Washer-Flat            |

● Not illustrated




## Right Deck Belt Cover Assembly

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>            |
|-------------|--------------------|-------------|-------------------------------|
| 1           | 114-5635           | 1           | Cover-Deck, RH Wing (Inside)  |
| 2           | 114-5636           | 1           | Cover-Deck, RH Wing (Outside) |
| 3           | 114-5638           | 1           | Cover-Deck, RH Wing (Fixed)   |
| 4           | 110-3510           | 4           | Nut-Retainer                  |
| 5           | 115-3363           | 1           | Deflector-Debris, Side Deck   |
| 6           | 321-5              | 2           | Screw-HH                      |
| 7           | 104-7201           | 2           | Nut-HF                        |
| 8           | 3234-29            | 4           | Screw-HHF                     |
| 10          | 115-3362           | 1           | Guide-Hose                    |
| 11          | 3230-10            | 2           | Bolt-CARR                     |
| 12          | 104-8300           | 2           | Nut-HF, NI                    |
| 13          | 103-4080           | 4           | Latch-Rubber                  |
| 14          | 3274-39            | 8           | Screw-HSBH                    |



## Right Deck Chamber Assembly


| <b>Ref.</b> | <b>Part Number</b> | <b>Qty.</b> | <b>Description</b>         |
|-------------|--------------------|-------------|----------------------------|
| 1           | 115-2125-01        | 1           | Chamber-Inner, Right Deck  |
| 2           | 115-2126-01        | 1           | Chamber-Center, Right Deck |
| 3           | 115-2127-01        | 1           | Chamber-Outer, Right Deck  |
| 4           | 3230-10            | 16          | Bolt-CARR                  |
| 5           | 104-8300           | 16          | Nut-HF, NI                 |
| 6           | 115-2146-01        | 1           | Baffle-Deflector           |



## Right Deck Stop and Hose Guide Assembly

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 48-9520            | 1           | Nut                |
| 2           | 87-3470            | 1           | Bumper             |
| 3           | 325-17             | 2           | Screw-HH           |
| 4           | 115-2144           | 2           | Tube-Spacer        |
| 5           | 115-3366           | 2           | Roller             |
| 6           | 3296-45            | 2           | Nut-Hex            |
| 7           | 321-5              | 4           | Screw-HH           |
| 8           | 114-5918           | 2           | Support-Hose       |
| 9           | 104-7201           | 4           | Nut-HF             |






## Left Deck Belt and Pulley Assembly


| Ref. | Part Number | Qty. | Description               |
|------|-------------|------|---------------------------|
| 1    | 110-5931    | 1    | Left Deck And Decal ASM   |
| 2    | 119-4547    | 1    | Driving Spindle ASM       |
| 3    | 119-4548    | 1    | Double Driven Spindle ASM |
| 4    | 119-4549    | 1    | High-Driven Spindle ASM   |
| 5    | 110-9596    | 2    | Pulley-Idler              |
| 6    | 100-3102    | 1    | Washer-Flat               |
| 7    | 108-1993    | 2    | Screw-HSBH                |
| 8    | 108-1924    | 2    | Spacer-Idler              |
| 9    | 3296-45     | 2    | Nut-Hex                   |
| 10   | 117-9176    | 1    | Idler Arm ASM             |
| 10:2 | 93-4510     | 2    | Bushing-Caster            |

| Ref. | Part Number | Qty. | Description         |
|------|-------------|------|---------------------|
| 11   | 108-1926    | 2    | Washer              |
| 12   | 32120-84    | 2    | Ring-Snap, External |
| 13   | 302-5       | 2    | Fitting-Grease      |
| 14   | 108-1930    | 1    | Idler Arm ASM       |
| 14:2 | 93-4510     | 2    | Bushing-Caster      |
| 15   | 108-1921    | 2    | Spring-Torsion      |
| 16   | 112-7377    | 2    | Belt-V, B           |
| 17   | 114-0997    | 2    | Pivot-Idler         |
| 18   | 3231-2      | 6    | Bolt-CARR           |
| 19   | 3296-59     | 6    | Nut-Lock, NI        |
| 20   | 3256-26     | 1    | Washer-Flat         |



## Left Deck Decal Assembly No. 110-5931


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>            |
|-------------|--------------------|-------------|-------------------------------|
| 2           | 117-4979           | 3           | Decal-Warning                 |
| 3           | 120-6604           | 1           | Decal-Danger                  |
| 4           | 93-7818            | 1           | Decal-Torque, Blade Bolt      |
| 5           | 114-4883           | 1           | Decal-Belt Routing, Deck (LH) |
| 6           | 110-3510           | 4           | Nut-Retainer                  |
| 7           | 114-0975           | 1           | Decal-HOC                     |



## Left Deck Roller, Skid and Caster Wheel Assembly

| Ref. | Part Number | Qty. | Description       |
|------|-------------|------|-------------------|
| 1    | 112-1479    | 2    | Skid-Bumper, Deck |
| 2    | 3231-33     | 4    | Screw-CARR        |
| 3    | 104-8301    | 16   | Nut-HF, NI        |
| 4    | 9136144     | 2    | Screw-HWHTF       |
| 5    | 323-42      | 12   | Screw-HH          |
| 6    | 93-4240     | 4    | 10 Inch Wheel ASM |
| 7    | 110-6040    | 2    | Castor Arm ASM    |
| 7:2  | 302-5       | 1    | Fitting-Grease    |
| 7:3  | 69-6470     | 2    | Bushing-Castor    |
| 8    | 69-6860     | 16   | Washer-Thrust     |
| 9    | 110-5999-01 | 4    | Castor Fork ASM   |
| 10   | 327-24      | 4    | Screw-HH          |
| 11   | 3296-53     | 4    | Nut-Lock, NI      |
| 12   | 29-4820     | 2    | Roller            |
| 13   | 325-17      | 2    | Screw-HH          |


| Ref. | Part Number | Qty. | Description        |
|------|-------------|------|--------------------|
| 14   | 3296-45     | 2    | Nut-Hex            |
| 15   | 92-9727     | 4    | HOC Cap ASM        |
| 15:1 | 92-5581     | 1    | Ring-Retaining     |
| 15:2 | 92-5583     | 1    | Washer-Cap         |
| 15:3 | 92-9726     | 1    | Spring-Compression |
| 15:4 | 92-8861     | 1    | Cap-HOC            |
| 16   | 114-0953    | 1    | HOC Castor Arm ASM |
| 16:2 | 302-5       | 2    | Fitting-Grease     |
| 16:3 | 69-6470     | 4    | Bushing-Castor     |
| 17   | 69-1510     | 16   | Spacer             |
| 18   | 3256-24     | 12   | Washer-Flat        |
| 22   | 117-2768    | 1    | Flap-Rubber        |
| 23   | 104-0858    | 2    | Bolt-Shoulder      |
| 24   | 103995      | 2    | Washer             |
| 25   | 104-7201    | 2    | Nut-HF             |



## Left Deck Spindle and Blade Assembly


| Ref. | Part Number | Qty. | Description            |
|------|-------------|------|------------------------|
| 1    | 92-5816     | 3    | Bolt-Blade             |
| 2    | 72-9361     | 3    | Cup-Scalp, Anti        |
| 3    | 110-5946-03 | 3    | Blade-Rotary           |
| 3    | 110-5948-03 | 3    | Blade-Rotary, Atomic ● |
| 4    | 323-6       | 4    | Screw-HH               |
| 5    | 3256-24     | 4    | Washer-Flat            |
| 7    | 104-8301    | 20   | Nut-HF, NI             |

● Not illustrated




## Left Deck Belt Cover Assembly

| Ref. | Part Number | Qty. | Description                   |
|------|-------------|------|-------------------------------|
| 1    | 114-5633    | 1    | Cover-Deck, LH Wing (Inside)  |
| 2    | 114-5634    | 1    | Cover-Deck, LH Wing (Outside) |
| 3    | 114-5637    | 1    | Cover-Deck, LH Wing (Fixed)   |
| 4    | 110-3510    | 4    | Nut-Retainer                  |
| 5    | 115-3363    | 1    | Deflector-Debris, Side Deck   |
| 6    | 321-5       | 2    | Screw-HH                      |
| 7    | 104-7201    | 2    | Nut-HF                        |
| 8    | 3234-29     | 4    | Screw-HHF                     |
| 10   | 115-3362    | 1    | Guide-Hose                    |
| 11   | 3230-10     | 2    | Bolt-CARR                     |
| 12   | 104-8300    | 2    | Nut-HF, NI                    |
| 13   | 103-4080    | 4    | Latch-Rubber                  |
| 14   | 3274-39     | 8    | Screw-HSBH                    |




## Left Deck Chamber Assembly

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>        |
|-------------|--------------------|-------------|---------------------------|
| 1           | 115-2107-01        | 1           | Chamber-Inner, Left Deck  |
| 2           | 115-2106-01        | 1           | Chamber-Center, Left Deck |
| 3           | 115-2105-01        | 1           | Chamber-Outer, Left Deck  |
| 4           | 3230-10            | 12          | Bolt-CARR                 |
| 5           | 104-8300           | 12          | Nut-HF, NI                |



## Engine Alternator Assembly


| Ref. | Part Number | Qty. | Description        |
|------|-------------|------|--------------------|
| 1    | 117-5419    | 1    | Alternator         |
| 2    | 115-8851    | 1    | Bracket-Alternator |
| 3    | 117-5401    | 2    | Screw-Flange, HH   |
| 4    | 117-5400    | 1    | Screw-Flange, HH   |
| 5    | 117-5403    | 2    | Washer-Bevel       |
| 6    | 117-5402    | 1    | Nut-HH             |



## Engine Starter Assembly


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|-------------------------|
| 1           | 115-8861           | 1           | Starter                 |
| 2           | 117-5404           | 2           | Screw-Mounting, Starter |





## Engine Gear Case Front Cover Assembly


| Ref. | Part Number | Qty. | Description         |
|------|-------------|------|---------------------|
| 1    | 117-5405    | 2    | Screw-Flange, HH    |
| 2    | 117-5406    | 2    | Screw-Flange, HH    |
| 3    | 117-5407    | 6    | Screw-Flange, HH    |
| 4    | 117-5408    | 8    | Screw-Flange, HH    |
| 5    | 117-5423    | 1    | Gasket-Cover, Front |
| 6    | 117-5421    | 1    | Cover-Front         |
| 7    | 117-5409    | 2    | Screw-Flange, HH    |



## Engine Water Pump and Thermostat Assembly


| Ref. | Part Number | Qty. | Description        |
|------|-------------|------|--------------------|
| 1    | 117-5412    | 1    | Screw-Flange, HH   |
| 2    | 117-5407    | 3    | Screw-Flange, HH   |
| 3    | 117-5426    | 1    | Water Pump Kit     |
| 3:1  | 115-8857    | 1    | Gasket-Pump, Water |
| 3:2  | 117-5411    | 1    | O Ring-Seal        |
| 3:3  |             | 1    | Water Pump ●       |
| 4    | 117-5420    | 1    | Belt-V, Ribbed     |
| 5    | 115-8860    | 1    | Thermostat Kit     |
| 5:1  | 117-5414    | 1    | Gasket-Connection  |
| 5:2  |             | 1    | Thermostat ●       |
| 6    | 117-5406    | 2    | Screw-Flange, HH   |

● Not serviced separately




## Engine Exhaust Manifold Assembly

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       |
|-------------|--------------------|-------------|--------------------------|
| 1           | 117-5425           | 1           | Manifold-Exhaust         |
| 2           | 115-8855           | 1           | Gasket-Manifold, Exhaust |
| 3           | 117-5410           | 8           | Screw-Flange, HH         |




## Engine Valve Cover Assembly

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 117-5427           | 1           | Cover-Valve        |
| 2           | 117-5428           | 1           | O Ring-Seal        |
| 3           | 117-5417           | 3           | Nut-Lock           |
| 4           | 117-5415           | 3           | Washer-Plain       |
| 5           | 117-5416           | 3           | Isolator-Noise     |
| 6           | 117-5429           | 1           | Cap-Filler         |



## Engine Oil Filter and Dipstick Assembly

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 115-8868           | 1           | Filter-Oil, Engine |
| 2           | 117-5424           | 1           | Tube-Dipstick      |
| 3           | 117-5422           | 1           | Dipstick           |



## Engine Fuel Filter Assembly

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 117-2792           | 1           | Filter-Fuel        |

# Attachments and Accessories

## For 31598N Groundsmaster 5900N/5910N Rotary Mower

| Product Name                                              | Model/Part |
|-----------------------------------------------------------|------------|
| 12 Volt Battery .....                                     | 106-5190   |
| Premium All Season Hydraulic Fluid (55 Gallon Drum) ..... | 108-1177   |
| Premium All Season Hydraulic Fluid (5 Gallon Pail) .....  | 108-1178   |
| Premium Heavy Duty All Season Gear Lube (Pail) .....      | 108-1188   |
| Premium All Purpose Grease (Tube) .....                   | 108-1190   |
| Premium Heavy Duty All Season Gear Lube (Quart) .....     | 108-1591   |
| Atomic Blade Kit .....                                    | 114-0897   |
| Fuel/Water Separator Element .....                        | 115-5471   |
| Engine Oil Filter .....                                   | 115-8868   |
| Filter-Engine, Air Safety .....                           | 115-8877   |
| Filter-Engine, Air Primary .....                          | 115-8887   |
| Standard Blade Kit .....                                  | 115-8896   |
| Blade and Belt Kit .....                                  | 115-8898   |
| Fuel Filter .....                                         | 117-2792   |
| Tall Grass Kit .....                                      | 117-2795   |
| Extension Kit for 2-Post ROPS .....                       | 117-9430   |
| Windscreen Kit .....                                      | 117-9440   |
| CE Kit (For 2010 models and Up) .....                     | 117-9449   |
| Vinyl Backrest Extension Kit .....                        | 119-7718   |
| Beacon Kit .....                                          | 119-8256   |
| Flat Blade Kit .....                                      | 119-8268   |
| Registration Plate and Light Kit .....                    | 120-7570   |
| Breather Kit .....                                        | 120-9895   |
| Cab Interior Air Filter .....                             | 121-3891   |
| Cab Exterior Air Filter .....                             | 121-3892   |
| Premium Engine Oil 15w40 (55 Gallon Drum) .....           | 121-6394   |
| Premium Engine Oil 15w40 (5 Gallon Pail) .....            | 121-6395   |
| MVP Filter Kit .....                                      | 30041      |
| Universal Sunshade .....                                  | 30349      |
| Leaf Mulching Kit .....                                   | 31581      |
| Light Kit .....                                           | 31582      |
| Center Replacement Deck .....                             | 31591      |
| Right Replacement Deck .....                              | 31592      |
| Left Replacement Deck .....                               | 31593      |
| Hydraulic Filter .....                                    | 75-1310    |
| Hydraulic Filter .....                                    | 86-6110    |
| Fuse Block .....                                          | 92-2641    |
| 10in Foam Filled Castor Wheel .....                       | 93-5973    |

## For 31599N Groundsmaster 5900N/5910N Rotary Mower

| Product Name                                              | Model/Part |
|-----------------------------------------------------------|------------|
| 12 Volt Battery .....                                     | 106-5190   |
| Premium All Season Hydraulic Fluid (55 Gallon Drum) ..... | 108-1177   |
| Premium All Season Hydraulic Fluid (5 Gallon Pail) .....  | 108-1178   |

## Attachments and Accessories (continued)

|                                                       |          |
|-------------------------------------------------------|----------|
| Premium Heavy Duty All Season Gear Lube (Pail) .....  | 108-1188 |
| Premium All Purpose Grease (Tube) .....               | 108-1190 |
| Premium Heavy Duty All Season Gear Lube (Quart) ..... | 108-1591 |
| Atomic Blade Kit .....                                | 114-0897 |
| Work Light Kit .....                                  | 114-5610 |
| Fuel/Water Separator Element .....                    | 115-5471 |
| Engine Oil Filter .....                               | 115-8868 |
| Filter-Engine, Air Safety .....                       | 115-8877 |
| Filter-Engine, Air Primary .....                      | 115-8887 |
| Standard Blade Kit .....                              | 115-8896 |
| Blade and Belt Kit .....                              | 115-8898 |
| Fuel Filter .....                                     | 117-2792 |
| Tall Grass Kit .....                                  | 117-2795 |
| CE Kit (For 2010 models and Up) .....                 | 117-9449 |
| Backrest Extension Kit .....                          | 119-7719 |
| Beacon Kit .....                                      | 119-8256 |
| Flat Blade Kit .....                                  | 119-8268 |
| Registration Plate and Light Kit .....                | 120-7570 |
| Breather Kit .....                                    | 120-9895 |
| Cab Interior Air Filter .....                         | 121-3891 |
| Cab Exterior Air Filter .....                         | 121-3892 |
| Premium Engine Oil 15w40 (55 Gallon Drum) .....       | 121-6394 |
| Premium Engine Oil 15w40 (5 Gallon Pail) .....        | 121-6395 |
| MVP Filter Kit .....                                  | 30041    |
| Leaf Mulching Kit .....                               | 31581    |
| Light Kit .....                                       | 31582    |
| Center Replacement Deck .....                         | 31591    |
| Right Replacement Deck .....                          | 31592    |
| Left Replacement Deck .....                           | 31593    |
| Hydraulic Filter .....                                | 75-1310  |
| Hydraulic Filter .....                                | 86-6110  |
| Fuse Block .....                                      | 92-2641  |
| 10in Foam Filled Castor Wheel .....                   | 93-5973  |



**Notes:**

**Notes:**

**Notes:**



**Count on it.**