Form No. 3322–672

TORO®

Anti–Scalp Roller Kit

Model No. 03447

Parts Catalog

PROTOTYPE

Ordering Replacement Parts

To order replacement parts, please supply: the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form **a:b.** The **a** represents the reference number of the entire service assembly and the **b** represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number **6**, the tire by **6:1**, the valve by **6:2**, and the wheel by **6:3**. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually.


Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form **nX y.** The **n** represents the quantity of the part, the **X** is the multiplication symbol, and the **y** represents the reference number.

For example, in an illustration, the reference number **2X 37** means that two of the parts identified by reference number 37 are indicated.

© The TORO Company — 2000
All Rights Reserved



Sheet No.:0

T–2799–2

Anti–Scalp Roller Assembly

Ref. No.	Part No.	Qty.	Description
1	63–5090	3	Anti–Scalp Roller ASM
1:1	62–4990	1	Shaft–Roller
1:2	71–3590	2	Nut–Adjustment
1:3	3–6498	4	Washer–Thrust
1:4	63–5060	2	Roller
1:5	256–117	4	Bushing
2	61–0420–01	6	Support–HOC
3	14–4489	6	Front HOC Bracket ASM
3:2	56–9510	1	Bushing ASM
4	56–9520	3	Bushing–Flanged
5	61–0790	6	Screw–HH
6	3296–39	20	Nut–Lock, NI
7	71–3690	6	Spade–Bent
8	3290–467	6	Pin–Hair
9	61–0910	6	Bracket–Angle
10	3231–2	6	Screw–CARR
11	3256–3	8	Washer–Flat
12	323–6	8	Screw–HH

Ref. No.	Part No.	Qty.	Description

PROTOTYPE