




AIR RAKE™



BLOWER ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	93-8733	Motor	1
2	100-2457	Housing - LH	1
3	100-2456	Housing - RH	1
4	98-3179	Harness - Blower	1
5	95-3286	Switch - Interlock	1
6	93-0564	Impeller	1
7	93-0585	Washer	1

Ref. No.	Part No.	Description	No. Used
8	93-9993	Nut - Impeller	1
9	94-4496	Screw - PH Tap	9
10	93-0559	Choke - Air	1
11	93-0569	Cover - Inlet	1
12	93-0571	Tube - Blower	1
13	93-0589	Decal - Logo	1
14	100-2480	Decal - Warning	1