Form No. 3428-118 Rev A

TORO®

Count on it.

Parts Catalog

Rear Remote Hydraulic Kit

Sand Pro®/Infield Pro® 3040 and 5040 Traction Unit

Model No. 08781—Serial No. 403350001 and Up

Register at www.Toro.com.
Original Instructions (EN)

CE

3428-118 A

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1,6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.


For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Tank Assembly 4
Hydraulic Manifold Assembly No. 108-5479 5
Hydraulic Pump Assembly 6
Hydraulic Pump Assembly No. 114-0603 7
Quick Coupler Assembly 8
Attachments and Accessories 9

© 2018—The Toro® Company
8111 Lyndale Avenue South
Bloomington, MN 55420


Contact us at www.Toro.com.
Printed in the USA.
All Rights Reserved



Tank Assembly

Ref.	Part Number	Qty.	Description
1	340-157	1	Fitting-HYD, Tee
1:1	237-79	1	O-Ring
1:2	237-30	2	O-Ring
2	32144-11	2	Screw-Thd Roll, HWH
3	120-3445	1	Hose-Molded
4	321-11	2	Screw-HH
5	3296-42	2	Nut-Lock, NI
6	120-3409	1	Fitting-Tee
6:1	237-79	1	O-Ring
6:2	237-30	1	O-Ring
7	108-8460-01	1	Bracket-Valve
8	108-5479	1	Hydraulic Manifold ASM
9	2412-36	2	Clamp-Hose
10	87-3990	1	Strainer-Transaxle
10:1	237-123	1	O-Ring


Ref.	Part Number	Qty.	Description
11	112-7103	1	Hydraulic Tube ASM
11:1	237-30	1	O-Ring
11:2	340-152	1	Cap-HYD
12	340-142	1	Fitting-Elbow, 90 DEG
12:1	237-58	1	O-Ring
12:2	237-81	1	O-Ring
13	340-98	1	Fitting-Elbow, 90 DEG
13:1	237-79	1	O-Ring
13:2	237-30	1	O-Ring
14	112-1410	1	Hydraulic Tube ASM
17	340-104	1	Fitting-HYD, Tee
17:1	237-30	2	O-Ring
18	110-8162	1	Dipstick
19	99-7430	1	Relay-Mini
20	340-152	1	Cap-HYD



Hydraulic Manifold Assembly No. 108-5479

Ref.	*Part Number*	*Qty.*	*Description*
1		1	Housing-Aluminum ●
2	110-6344	1	Coil-12V, DC
3	110-6345	1	Valve-Relief, Solenoid
3:1	110-6316	1	Seal Kit
3:2	130-8181	1	Nut-Coil (1/2-20 Unf-2B)


● Not serviced separately



Hydraulic Pump Assembly

Ref.	Part Number	Qty.	Description
1	5-7280	1	Key
2	108-2825	1	Hub
3	3246-4	4	Screw-Set
4	112-1406	1	Bracket ASM
4:2	23-2270	1	Bushing-Rubber
5	3235-6	2	Screw-HH
7	99-3578	1	Hose ASM
9	112-6451-01	1	Torque Arm ASM
11	112-1407	1	Hose-Suction
12	104-8301	2	Nut-HF, NI
13	340-101	1	Fitting-HYD, 45 DEG
13:1	237-30	1	O-Ring


Ref.	Part Number	Qty.	Description
13:2	237-79	1	O-Ring
14	114-0603	1	HYD Pump ASM
15	323-7	2	Screw-HH
16	353-987	1	Fitting-Elbow, 90
16:1	237-81	1	O-Ring
17	2412-129	2	Clamp-Hose
18	122-1432	1	Harness-Wire
18:2	100-4918	1	Diode
19	93-9999	1	Switch-PTO
22	218-578	1	Fuse-Blade, 10 Amp
23	3256-23	2	Washer-Plain
24	98-4700	1	Key-Square



Hydraulic Pump Assembly No. 114-0603

Ref.	*Part Number*	*Qty.*	*Description*
1	114-0606	1	Seal Kit
1:1		1	Seal-Lip ●
1:2		2	Seal-Backup ●
1:3		2	Seal-Channel ●
1:4		2	Seal-Gasket ●

● Not serviced separately



Quick Coupler Assembly

Ref.	Part Number	Qty.	Description
1	108-8467	1	Tube-HYD
1:1	237-30	1	O-Ring
2	108-8466	1	Tube-HYD
2:1	237-30	1	O-Ring
3	121-2525-01	1	Bracket-Hose, Suction
4	2112-11	2	Clamp-Muffler
5	105-7962	1	Plug-Dust
6	105-7963	2	Cap-Dust
7	32151-29	2	Ring-Retaining
8	108-8464	2	Fitting-Straight
8:2	237-79	1	O-Ring
8:3	237-30	1	O-Ring
9	105-4170	2	Coupler-Male

Ref.	Part Number	Qty.	Description
10	105-4169	1	Coupler-Female
11	112-6457	1	Coupler Bracket ASM
11:2	110-1303	1	Decal-Coupler
12	32120-2	1	Ring-Retaining
13	340-4	1	Fitting-Straight
13:1	237-30	1	O-Ring
13:2	237-79	1	O-Ring
16	340-152	1	Cap-HYD
17	3296-29	1	Nut-Lock, NI
18	322-4	1	Screw-HH
19	2412-104	1	Clamp-R
20	3296-29	4	Nut-Lock, NI
22	80-7330	1	Hose ASM

Attachments and Accessories

For 08781 Rear Remote Hydraulic Kit Sand Pro/Infield Pro 3040 and 5040 Traction Unit

Product Name	Model/Part
Debris Blower	08759
QAS Bunker Pump	08765
Vibratory Edger	08766

Notes:

Notes:



Count on it.