FORM NO. 3322–666


TORO®

MODEL NO. 79350–9900001 & UP

PARTS CATALOG

48” DOZER BLADE

WHEEL HORSE® Garden Tractor



Sheet No.:3

BLADE ASSEMBLY


PROTOTYPE

Ref. No.	Part No.	Description	No. Used
9	3296–39	Nut – Lock	5
18	9335124	Hairpin	1
19	5120	Rod – Blade Pivot	2
20	88–2080	Lug – Spring	4
21	93–1611	Spring – Return	2
22	3272–11	Pin – Cotter	5

Ref. No.	Part No.	Description	No. Used
23	78–1330–01	Blade	1
24	93–1612–01	Plate – Blade Edge	1
25	3231–1	Screw – Carriage	5
26	92–8748	Decal – Attachment	1
27	78–8760	Quandrant	1
28	4564	Rod – Lower	1

*Not Illustrated

© The TORO Company –1999
All Rights Reserved



Sheet No.:2

FRAME ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	9231204	Pin − Clevis	2
2	104659	Bracket − Axle	1
3	3231−25	Screw − Carriage	2
4	105052	Link −Lift, Short	1
*	7706	Link − Lift, Long (Optional)	1
5	283−2	Pin − Clevis	2
6	98−1745	Rod − Upper Index	1
7	3218−18	Nut	1
8	92−7037	Plate − Index	1
9	323−6	Screw − HH	1
10	3771	Rod − Lower Index	1
11	4944	Button − Plug	2
12	3296−15	Nut − Lock	1
13	3216−7	Screw − HH	1
14	3272−11	Pin − Cotter	1
15	104338	Rod − Index Leveler	1
16	9335124	Hairpin	1
17	3256−24	Washer − Flat	3
18	9335054	Hairpin	2

Ref. No.	Part No.	Description	No. Used
21	325−4	Screw − HH	1
22	94−6687	Bolt − Eye	1
23	3296−12	Nut − Lock	3
24	108566	Bolt−Eye	1
25	94−6686	Lever − Index	1
26	108567	Frame Assembly	1
26:1	88−6520	Pin − Index	1
26:2	2354	Spring	1
26:3	3272−11	Pin − Cotter	1
27	321−6	Screw − HH	1
28	5359	Grip − Handle	1
29	32146−17	Nut − Lock	1
30	98−1743	Lever − Index	1
31	104657	Handle − Latch	2
32	3231−11	Screw− Carriage	4
34	3296−39	Nut − Lock	7
35	9335044	Hairpin	2
36	7713	Spacer − Bracket	2
37	3697	Link − Bracket	2

PROTOTYPE

* Not Illustrated