



Count on it.

Form No. 3429-313 Rev A

Parts Catalog

Bore Drive Attachment TRX Trencher

Model No. 22978—Serial No. 400000000 and Up



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.


Contents

Bore Drive Assembly 4

Hydraulic Motor Assembly No. 117-4037 6


Attachments and Accessories 7

Bore Drive Assembly



Bore Drive Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	117-4019-03	1	Bore ASM	18	104-6115	2	Coupler-Female
2	117-4037	1	Hydraulic Motor ASM	19	117-9935	2	Screw-HSH
3	340-6	2	Fitting-Straight	20	95-3209	2	Fitting-Thread, Straight
3:1	237-30	1	O-Ring	20:1	237-79	2	O-Ring
3:2	237-80	1	O-Ring	21	117-9936	1	HYD Hose ASM
5	121-4560	1	Joint-Universal	22	117-9937	1	HYD Hose ASM
6	115-3897	1	Coupler	23	117-9938	2	HYD Hose ASM
8	112-7161	1	Screw-HH	24	117-9939	2	HYD Hose ASM
9	3296-39	1	Nut-Lock, NI	24:4	237-79	1	O-Ring
10	3274-4	2	Screw-HSH	25	104-5988-03	1	Tool-Guide, Rod
11	3272-15	1	Pin-Cotter	26	32121-41	1	Pin-Roll
12	117-4017-03	1	Plate-Clamp	27	106-7740-03	1	Handle-Tool, Guide
13	107-1664	1	Lever ASM	28	340-4	4	Fitting-Straight
13:1	106-3239	1	Screw-Lock	28:1	237-30	1	O-Ring
13:2	107-1644	1	Cap-Lock	28:2	237-79	1	O-Ring
13:3	106-3241	1	Lever-Lock	29	117-9909	1	HYD Manifold ASM
13:4	3296-29	1	Nut-Lock, NI	30	117-9934	1	Handle-Manifold
14	117-4049-01	1	Plate-Manifold	31	3218-3	1	Nut-Jam
15	3230-2	1	Bolt-CARR	33	95-7896	1	Decal
16	3296-29	3	Nut-Lock, NI	34	117-9952	1	Decal-Danger
17	104-6114	2	Nipple-Connector	37	117-8855	1	Decal-Instructional
17:1	107-9301	1	Seal Kit	38	120-0981	2	Hose-HYD



Hydraulic Motor Assembly No. 117-4037

Ref.	Part Number	Qty.	Description
1	56-6890	1	Seal Kit
1:1		4	Seal ●
1:2		1	Exclusion Seal ●
1:3		1	Outer Face Seal ●
1:4		1	Inner Face Seal ●
1:5		1	Shaft Face Seal ●
1:6		1	Shaft Seal ●
1:7		1	Back-Up Washer ●
1:8		1	O-Ring ●
2	99-3139	1	Nut

● Not serviced separately

Attachments and Accessories

For 22978 Bore Drive Attachment TRX Trencher

Product Name	Model/Part
Rod and Reamer	22421



Count on it.