



Count on it.

Form No. 3426-282 Rev B

Parts Catalog

Hot Oil Shuttle Kit 2226 Directional Drill

Model No. 139-2475



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.


For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Hot Oil Shuttle Kit Assembly 4

Flush Manifold Assembly No. 139-2477..... 6

Hot Oil Shuttle Kit Assembly




Hot Oil Shuttle Kit Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|-------------------------|
| 1 | 139-2461-03 | 1 | Bracket-Mount, Manifold |
| 2 | 139-2477 | 1 | Manifold-Flush |
| 3 | 323-5 | 4 | Screw-HH |
| 4 | 321-14 | 2 | Screw-HH |
| 5 | 104-7201 | 2 | Nut-HF |
| 6 | 340-97 | 1 | Fitting-Elbow, 90 DEG |
| 6:1 | 237-22 | 1 | O-Ring |
| 6:2 | 237-78 | 1 | O-Ring |
| 7 | 340-18 | 1 | Fitting-HYD, 90 DEG |
| 7:1 | 237-79 | 1 | O-Ring |
| 7:2 | 237-22 | 1 | O-Ring |
| 8 | 340-98 | 1 | Fitting-Elbow, 90 DEG |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|-------------------------|
| 8:1 | 237-79 | 1 | O-Ring |
| 8:2 | 237-30 | 1 | O-Ring |
| 9 | 353-508 | 1 | Plug-HH |
| 9:1 | 237-42 | 1 | O-Ring |
| 10 | 340-115 | 2 | Fitting-Tee, Swivel Nut |
| 10:1 | 237-22 | 2 | O-Ring |
| 11 | 340-147 | 1 | Fitting-HYD, Tee |
| 11:1 | 237-65 | 2 | O-Ring |
| 12 | 139-2458 | 1 | Hose ASM-HYD |
| 13 | 139-2459 | 1 | Hose ASM-HYD |
| 14 | 139-2460 | 1 | Hose ASM-HYD |
| 15 | 3290-379 | 3 | Tie-Cable |

Flush Manifold Assembly No. 139-2477



Flush Manifold Assembly No. 139-2477 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1 | 139-2478 | 1 | Valve-Check |
| 1:1 | 110-8772 | 1 | Seal Kit |
| 2 | 106-1026 | 1 | Plug-HYD |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|------------------------|
| 3 | 120-9868 | 1 | Valve-Shuttle, Hot Oil |
| 3:1 | 120-7597 | 1 | Seal Kit |



Count on it.