
FORM NO. 3322–543 REV A

TORO®

MODEL NO. 53009–990001 & UP

PARTS CATALOG

TRIMMER



C–2798

CLUTCH AND HANDLE ASSEMBLY


Ref. No.	Part No.	Description	No. Used
*1	M221473	Clutch Case Asm (Incl. Ref. #2–4)	1
2	M221474	Case–Clutch	1
3	M016405	Bearing	1
4	M013825	Snap Ring	1
5	M096042	Bolt	1
6	M054677	Drum–Clutch	1
7	M817002	Bolt	4
8	M221434	Grip–Shaft	1
9	M222953	Trigger–Throttle	1
10	M214083	Guide–Outer	1
11	M223052	Tube–Plastic	1

Ref. No.	Part No.	Description	No. Used
12	M054691	Hanging Bracket Asm (Incl. Ref. #13)	1
13	M089738	Bolt	1
*14	M219046	Loop Handle Asm (Incl. Ref. #15–18)	1
15	M219032	Loop Handle	1
16	M213171	Packing	1
17	M092088	Screw	4
18	M081027	Nut	4
19	M223051	Cable–Throttle	1
*	95–6122	Glasses–Safety	1

* Not Illustrated

©The TORO Company – 1999 REV A
All Rights Reserved

TPS




HEAD, SHAFT AND SHIELD ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	M221524	Driveshaft	1
2	M222922	Driveshaft Tube Asm (Incl. Ref. #3,4)	1
3	M221501	Decal−Caution	1
4	M221502	Decal−Caution	1
5	M221500	Decal−Toro	1
7	M222880	Cover−Safety	1
8	M222899	Plate	1
9	M092579	Bolt	4
*10	M222898	String Cutter Asm (Incl. Ref. #11−13)	1
11	M222900	Cutter−String	1

Ref. No.	Part No.	Description	No. Used
12	M092548	Bolt	2
13	M081027	Nut	2
14	95−7468	Bolt	1
15	95−7451	Housing	1
16	95−7450	Eyelet	2
17	95−7455	Spool with Line	1
*	95−7452	Spool	1
18	95−7465	Spring	1
19	95−7453	Button	1
20	95−7454	Cover	1
*	95−4424	4” Head Asm (Incl. Ref. #14−20)	

* Not Illustrated



C−2800


GEARCASE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
2	M222888	Gearcase	1
3	M089884	Bolt	1
4	M219205	Bearing	1
5	M222121	Gear	1
6	M219430	Shaft−Blade	1
7	M212999	Bearing	1
8	M055185	Snap Ring	1
9	M222122	Gear−Pinion	1
10	M140268	Bearing	1

Ref. No.	Part No.	Description	No. Used
11	M140269	Snap Ring	1
12	M140270	Snap Ring	1
13	M092561	Bolt	1
14	M089737	Bolt	1
15	M222890	Adapter−Boss	1
*	M222887	Gearcase Asm (Incl. Ref. #2−13)	1

* Not Illustrated


ENGINE ASSEMBLY



ENGINE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
2	M266249	Cylinder	1
3	M267178	Gasket	1
4	M261250	Cap Screw	6
5	M265802	Insulator	1
6	M267049	Gasket	1
7	M265924	Cap Screw	2
8	M267051	Muffler Asm (Incl. Ref. # 9–12)	1
9	M267052	Muffler Comp.	1
10	M267056	Spark Arrester	1
11	M267053	Tail	1
12	M265107	Cap Screw	2
13	M266264	Cap Screw	2
14	M267189	Gasket Comp.	1
15	M261607	Cap Screw	1
16	M267270	Top Cover Asm	1
17	M267581	Decal–Caution	1
18	M264022	Knob	1
19	M267063	Crankcase	1
20	M261491	Bearing	2
21	M261492	Seal–Oil	1
22	M261386	Seal–Oil	1
23	M055185	Snap Ring	1
24	M261612	Cap Screw	3
25	M263569	Piston	1
26	M263789	Ring–Piston	1
27	M261036	Pin–Piston	1
28	M263957	Bearing–Needle	1
29	M261576	Clip–Piston	2
30	M267193	Crankshaft/Connecting Rod Asm	1
31	M264025	Clutch Asm (Incl. Ref. #32,33)	1
32	M264026	Shoe–Clutch	2
33	M264028	Spring–Clutch	1
34	M264505	Bolt	2
35	M261189	Washer	2
36	M261777	Washer–Wave	2
37	M267593	Cover–Fan (Incl. Ref.#17)	1
39	M265017	Rotor–Fan	1
40	M267173	Ignition Coil Asm	1
48	M261076	Key–Woodruff	1
49	M261417	Nut–Rotor	1
50	M261078	Spacer	2
51	M261256	Cap Screw	2
52	M264652	Spark Plug	1
53	M267093	Wire–Coil Ground	2
54	M261202	Grommet	1
55	M267096	Recoil Starter Asm (Incl. Ref. #56–65)	1
56	M267097	Recoil Asm. (Incl. Ref. #57–64)	1
57	M267217	Rope Asm (Incl. Ref. #58,59)	1
58	M267219	Grip–Starter	1
59	M267218	Rope–Starter	1
60	M267214	Spring–Spiral	1
61	M267212	Pulley	1
62	M267215	Collar	1
63	M267216	Arm–Swing	1
64	M267213	Screw	1
65	M267098	Pulley–Starter	1
66	M265726	Cap Screw	3
67	M261878	Nut	1
68	M265409	Adapter	1
69	M266201	Decal–Toro (Round)	1
70	M267177	Screw	1
71	M266323	Decal–Toro	1
72	M267307	Decal	
*	M850266	Engine	1

CARBURETOR ASSEMBLY



C–2802

CARBURETOR AND FUEL ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	M267100	Carburetor Assembly (Incl. Ref. #2−15)	1
2	M261871	O−Ring	1
3	M267358	Main Jet	1
4	M262995	Gasket	1
5	M262994	Diaphragm−Fuel Pump	1
6	M264155	Body−Pump	1
7	M262993	Gasket	1
8	M261873	Diaphragm−Metering	1
9	M262991	Body−Purge	1
10	M261874	Bulb−Primer	1
11	M262992	Plate−Cover	1
12	M262996	Screw	4
13	M261876	E−Ring	1
14	M261658	Swivel	1
15	M264682	Screw	2
16	M261864	Gasket	1
17	M264691	O−Ring	1
19	M266433	Housing	1
20	M264695	Filter	1
21	M264709	Cover	1
22	M264016	Cap Screw	2
24	M267103	Fuel Tank	1
25	M264784	Fuel Tank Cap Assembly (Incl. Ref. # 26)	1
26	M261105	Gasket	1
27	M261696	Breather Assembly	1
29	M266955	Fuel Pipe Assembly (Incl. Ref. # 30−32)	1
30	M261115	Grommet	1
31	M265469	Fuel Pipe	1
32	M263038	Return Pipe	1
33	M264653	Fuel Filter Assembly	1
34	M261117	Clip	2
35	M264318	Pad	2
36	M263824	Pad	1

* Not Illustrated

TORO PART NUMBER INDEX

Part No.	Description	Pg. No.	Ref. No.	Qty.
M013825	Snap Ring	1	4	1
M016405	Bearing	1	3	1
M054677	Drum−Clutch	1	6	1
M054691	Hanging Bracket Asm	1	12	1
M055185	Snap Ring	3	8	1
M055185	Snap Ring	5	23	1
M081027	Nut	2	13	2
M081027	Nut	1	18	4
M089737	Bolt	3	14	1
M089738	Bolt	1	13	1
M089884	Bolt	3	3	1
M092088	Screw	1	17	4
M092548	Bolt	2	12	2
M092561	Bolt	3	13	1
M092579	Bolt	2	9	4
M096042	Bolt	1	5	1
M140268	Bearing	3	10	1
M140269	Snap Ring	3	11	1
M140270	Snap Ring	3	12	1
M212999	Bearing	3	7	1
M213171	Packing	1	16	1
M214083	Guide−Outer	1	10	1
M219032	Loop Handle	1	15	1
M219046	Loop Handle Asm	1	*14	1
M219205	Bearing	3	4	1
M219430	Shaft−Blade	3	6	1
M221434	Grip−Shaft	1	8	1
M221473	Clutch Case Asm	1	*1	1
M221474	Case−Clutch	1	2	1
M221500	Decal−Toro	2	5	1
M221501	Decal−Caution	2	3	1
M221502	Decal−Caution	2	4	1
M221524	Driveshaft	2	1	1
M222121	Gear	3	5	1
M222122	Gear−Pinion	3	9	1
M222880	Cover−Safety	2	7	1
M222887	Gearcase Asm	3*		1
M222888	Gearcase	3	2	1
M222890	Adapter−Boss	3	15	1
M222898	String Cutter Asm	2	*10	1
M222899	Plate	2	8	1
M222900	Cutter−String	2	11	1
M222922	Driveshaft Tube Asm	2	2	1
M222953	Trigger−Throttle	1	9	1
M223051	Cable−Throttle	1	19	1
M223052	Tube−Plastic	1	11	1
M261036	Pin−Piston	5	27	1
M261076	Key−Woodruff	5	48	1
M261078	Spacer	5	50	2
M261105	Gasket	7	26	1
M261115	Grommet	7	30	1
M261117	Clip	7	34	2
M261189	Washer	5	35	2
M261202	Grommet	5	54	1
M261250	Cap Screw	5	4	6
M261256	Cap Screw	5	51	2
M261386	Seal−Oil	5	22	1
M261417	Nut−Rotor	5	49	1
M261491	Bearing	5	20	2
M261492	Seal−Oil	5	21	1
M261576	Clip−Piston	5	29	2
M261607	Cap Screw	5	15	1
M261612	Cap Screw	5	24	3
M261658	Swivel	7	14	1
M261696	Breather Assembly	7	27	1
M261777	Washer−Wave	5	36	2
M261864	Gasket	7	16	1
M261871	O−Ring	7	2	1
M261873	Diaphragm−Metering	7	8	1
M261874	Bulb−Primer	7	10	1
M261876	E−Ring	7	13	1
M261878	Nut	5	67	1
M262991	Body−Purge	7	9	1
M262992	Plate−Cover	7	11	1
M262993	Gasket	7	7	1
M262994	Diaphragm−Fuel Pump	7	5	1
M262995	Gasket	7	4	1
M262996	Screw	7	12	4
M263038	Return Pipe	7	32	1
M263569	Piston	5	25	1
M263789	Ring−Piston	5	26	1
M263824	Pad	7	36	1
M263957	Bearing−Needle	5	28	1
M264016	Cap Screw	7	22	2
M264022	Knob	5	18	1
M264025	Clutch Asm	5	31	1
M264026	Shoe−Clutch	5	32	2
M264028	Spring−Clutch	5	33	1
M264155	Body−Pump	7	6	1
M264318	Pad	7	35	2
M264505	Bolt	5	34	2
M264652	Spark Plug	5	52	1
M264653	Fuel Filter Assembly	7	33	1
M264682	Screw	7	15	2
M264691	O−Ring	7	17	1
M264695	Filter	7	20	1
M264709	Cover	7	21	1
M264784	Fuel Tank Cap Assembly	7	25	1
M265017	Rotor−Fan	5	39	1
M265107	Cap Screw	5	12	2
M265409	Adapter	5	68	1
M265469	Fuel Pipe	7	31	1
M265726	Cap Screw	5	66	3
M265802	Insulator	5	5	1
M265924	Cap Screw	5	7	2
M266201	Decal−Toro (Round)	5	69	1
M266249	Cylinder	5	2	1
M266264	Cap Screw	5	13	2
M266323	Decal−Toro	5	71	1
M266433	Housing	7	19	1
M266955	Fuel Pipe Assembly	7	29	1
M267049	Gasket	5	6	1
M267051	Muffler Asm	5	8	1
M267052	Muffler Comp.	5	9	1
M267053	Tail	5	11	1
M267056	Spark Arrester	5	10	1
M267063	Crankcase	5	19	1
M267093	Wire−Coil Ground	5	53	2
M267096	Recoil Starter Asm	5	55	1
M267097	Recoil Asm.	5	56	1
M267098	Pulley−Starter	5	65	1
M267100	Carburetor Assembly	7	1	1
M267103	Fuel Tank	7	24	1
M267173	Ignition Coil Asm	5	40	1
M267177	Screw	5	70	1
M267178	Gasket	5	3	1
M267189	Gasket Comp.	5	14	1
M267193	Crankshaft/Connecting	5	30	1
M267212	Pulley	5	61	1
M267213	Screw	5	64	1
M267214	Spring−Spiral	5	60	1
M267215	Collar	5	62	1
M267216	Arm−Swing	5	63	1
M267217	Rope Asm	5	57	1
M267218	Rope−Starter	5	59	1
M267219	Grip−Starter	5	58	1
M267270	Top Cover Asm	5	16	1
M267307	Decal	5	72	
M267358	Main Jet	7	3	1
M267581	Decal−Caution	5	17	1
M267593	Cover−Fan	5	37	1
M817002	Bolt	1	7	4
M850266	Engine	5	*	1
95−4424	4 Head Asm	2	*	
95−6122	Glasses−Safety	1	*	1
95−7450	Eyelet	2	16	2
95−7451	Housing	2	15	1
95−7452	Spool	2	*	1
95−7453	Button	2	19	1
95−7454	Cover	2	20	1
95−7455	Spool with Line	2	17	1
95−7465	Spring	2	18	1
95−7468	Bolt	2	14	1

*Not Illustrated