



Form No. 3429-696 Rev A

Count on it.

Parts Catalog

FP-3000

Forward Plate Compactor

Model No. 68026—Serial No. 404320000 and Up



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.


Contents

Handle and Base Assembly 4

Base Assembly No. 125-6236 5

Engine Assembly 6


Roll Cage and Water Tank Assembly 7



Handle and Base Assembly


Ref.	Part Number	Qty.	Description
1	125-6249-03	1	Deck-Engine
2	125-6236	1	Base ASM
3	132-3869	4	Mount-Shock
4	3256-26	4	Washer-Flat
5	325-2	4	Screw-HH
6	86-1990	4	Washer-Thrust
7	325-3	4	Screw-HH
8	ST50265	4	Spacer-Stop, Handle
9	ST81213	4	Screw-HSH

Ref.	Part Number	Qty.	Description
10	33003-00	4	Nut-HF
11	ST50263	2	Bushing-Handle, Main Plate
12	ST50264	2	Spacer-Handle, Pivot
13	ST50260-03	1	Handle-Main
14	ST80891	2	Washer-Flat
15	33116-080	2	Screw-HH
16	115-1115	2	Nut-Lock, HHF
19	125-4929	1	Decal
20	117-4979	1	Decal-Warning



Base Assembly No. 125-6236


Ref.	Part Number	Qty.	Description
1	127-2820	1	Base
2	ST22061	1	Plate Cap Bearing ASM
2:2	ST32033	1	O-Ring
3	ST50455	1	Shaft-Eccentric
4	ST22060	1	Plate Cap Bearing ASM
4:2	ST32033	1	O-Ring
4:3	ST32047	2	Seal-Shaft
5	ST81210	1	Washer-Sealing, Nyltite
6	ST47647	1	Fitting-HYD
7	43-0090	12	Screw-HH
8	ST80185	1	Screw-HH
9	ST81213	1	Screw-HSH



Engine Assembly

Ref.	Part Number	Qty.	Description
2	125-4813	1	Engine-Honda, Gx160
3	ST50257	1	Bracket-Adjuster, Engine
4	33004-00	2	Nut-HF
5	33014-00	1	Nut-Hex
6	ST81191	1	Screw
7	ST50506	1	Plate-Nut, Engine
8	33094-00	2	Washer-Plain
9	127-0517	2	Screw-HSH
10	ST32347	1	Clutch, S-Plate
11	ST80611	1	Key-Square
12	ST39233	1	Washer
13	3235-6	1	Screw-HH
14	67-7490	1	Key-Square
15	138-3106	1	Bushing-Locking

Ref.	Part Number	Qty.	Description
15:1	3245-42	1	Screw-Set
16	ST32797	1	Sheave
17	321-4	2	Screw-HH
18	ST50500	1	Belt-V
19	127-2819	1	Guard-Belt
19:1	125-4805	1	Guard-Belt
19:2	125-4943	1	Decal-Warning, Plate
20	33103-020	4	Screw-HHF
21	125-3866	1	Deflector
22	125-0519	2	Screw-Self Tapping
23	ST42790	1	Clip-Throttle
24	32128-17	1	Nut-Lock, Flange
26	133-8062	1	Decal-Arrestor, Spark
27	130-8322	1	Decal-Warning, Ethanol



Roll Cage and Water Tank Assembly

Ref.	Part Number	Qty.	Description
2	ST50215-03	1	Cage-Roll
3	125-4810	1	Tank-Water
4	ST47241	1	Cap-Plastic
5	125-8217	1	Sprinkler
6	ST50497	1	Valve-Ball
7	ST50498	1	Fitting-Quick, Female
8	ST50499	1	Fitting-Quick, Female, Nipple
9	ST34486	2	Fitting-HYD, 90 DEG
10	ST47182	1	Latch-Rubber
11	125-8733	1	Hose-Water
12	33104-020	6	Screw-HHF
13	ST81130	1	Screw-HSBH
14	33116-060	2	Screw-HH
15	115-1115	2	Nut-Lock, HHF
17	93-9084	1	Decal-Point, Lift



Count on it.