



Count on it.


Form No. 3430-931 Rev A

Parts Catalog

Trench Filler Compact Tool Carrier

Model No. 22472—Serial No. 404320000 and Up






Trench Filler Assembly

Ref.	Part Number	Qty.	Description
1	112-2604	1	Frame ASM
1:2	100-4708	1	Decal-Warning
1:3	93-7321	2	Decal-Danger
2	108-5595	1	Hydraulic Motor ASM
3	3274-89	2	Screw-HSH
4	340-6	2	Fitting-Straight
4:1	237-30	1	O-Ring
4:2	237-80	1	O-Ring
5	106-7702	2	Hose ASM
5:3	237-79	1	O-Ring
6	100-4617	2	Adapter-HYD
6:1	237-80	1	O-Ring
7	104-6134	1	Coupler-Face, Flush
8	100-4701	1	Nipple-Connect, Pressure
8:1	100-6120	1	Seal Kit ●
9	130-7590-03	1	Shaft-Filler
10	3245-41	1	Screw-HSH
11	99-0160	1	Bearing
11:1	251-249	1	Collar W/Set Screws

Ref.	Part Number	Qty.	Description
11:2	3245-35	1	Screw-Set, HSH
11:3	302-2	1	Fitting-Grease
12	324-5	2	Screw-HH
13	107-9393-01	2	Skid Plate ASM
14	3234-6	4	Screw-HHF
15	112-2619	1	Qtach ASM
15:2	100-4652	2	Decal-Warning
16	110-0237	4	Roller-Float
17	3256-24	8	Washer-Flat
20	107-9378	1	Decal-Center Trench
21	62-7400	1	Decal
23	110-0245	4	Spacer-Float
24	110-0179	4	Spacer-Wheel
25	323-25	4	Screw-HH
26	3296-39	20	Nut-Lock, NI
27	110-0175-01	4	Bracket-Cap, Float
28	110-0174-01	2	Bracket-Guide, Float
29	323-6	16	Screw-HH
32	133-8061	1	Decal-Warning

● Not illustrated



Hydraulic Motor Assembly No. 108-5595

Ref.	Part Number	Qty.	Description
1	94-8178	1	Seal Kit
2	95-6137	1	Coupling Shaft
3	76-0850	1	Bearing-Thrust
6	95-6136	1	Housing ASM
6:1		1	Housing ●
6:2		1	Bearing ●
6:3		2	Washer-Thrust ●
6:4		1	Bearing-Thrust ●
7	11-5790	1	Key-Square
8	76-0940	1	End Cover ASM

● Not serviced separately



Count on it.