




MODEL NO. 21070-9900001 & UP
MODEL NO. 21071-9900001 & UP
MODEL NO. 21072-9900001 & UP

PARTS CATALOG

40cm Electric Recycler[®] Mower




C-2782

CHASSIS ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	95-6749	Housing	1	13	95-6741	Spacer	1
2	95-6737	Axle - Rear	1	14	95-6565	Nut-Push	1
3	95-6736	Axle - Front	1	†15		Indicator - HOC	1
4	95-6665	Wheel Assembly (Incl. Ref. # 5 & 7)	3	†16		U-Clip - Indicator	1
5	95-6543	Cover - Wheel	3	17	95-6525	Balance Spring - HOC	1
6	95-6716	Cover - Wheel	1	18	95-6670	Plate - Axle Front	1
7	95-6544	Spring Clamp - Wheel	4	19	95-6667	Plate - Axle Rear	1
8	95-6563	Cover Knob	1	20	95-6560	Screw	5
9	95-6562	Knob - HOC	1	21	95-6527	Decal - Recycler 40cm	1
10	95-6526	Latch - HOC	1	22	95-6666	Smartwheel Assembly (Incl. Ref. 6 & 7)	1
11	95-6564	Spring - HOC	1	23	95-6709	Decal - HOC	1
12	95-6791	Rod - HOC (Incl. Ref. # 23)	1				

† Not Serviced Separately




C-2783

MOTOR AND BLADE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	95-6764	Motor	1
2	95-6663	Screw	4
3	95-6548	Fan	1
4	95-6754	Adapter - Motor	1
5	95-6624	Baffle - Motor	1
6	95-6633	Capacitor	1
7	95-6584	Clip - Capacitor	1
8	95-6598	Screw	1
9	95-6620	U-Clip	1
10	95-6715	Shroud - Motor (Incl. Ref. # 17)	1


Ref. No.	Part No.	Description	No. Used
11	95-6698	Screw	1
12	95-6583	Blade	1
13	95-6767	Retainer - Blade	1
14	95-6743	Screw - Blade	1
15	95-6619	Snap on Nut - Shroud	2
16	95-6623	Screw	2
17	92-2289	Plate - Logo	1
18	95-6532	Screw	2
19	95-6692	Release - Cable	1



C-2784

HANDLE ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	95-6514	Handle Lower	1	*	95-6631	Switch Assy. (Only on: 21071)	1
2	95-6516	Handle Upper	1	13	95-6598	Screw - Switch Assembly	2
3	95-6718	Bolt & Screw Set - Handle	2	14	95-6596	Mount - Bail	1
5	95-6713	Adjusting Knob - Handle (Incl. Ref. #11)	2	15	95-6598	Screw - Mount	1
6	95-6567	Adjusting Disk - Handle	2	16	95-6607	Rod	1
7	95-6568	Holding Disk - Handle	2	17	95-6606	Bail	1
8	95-6694	Bolt - LH	1	18	95-6602	Clamp - Bail	1
9	95-6740	Nut	2	19	95-6597	Cable Holder	1
10	95-6695	Bolt - RH	1	20	95-6630	Switch Assembly (Only on: 21072)	1
11	95-6569	Nut	2	*	95-6685	Cord - Power (Only on: 21072)	1
12	95-6605	Switch Assembly (Only on: 21070)	1				



C-2785

BAG AND RECYCLING ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	95-6711	Rear Door (Incl. Ref. # 13)	1
2	95-6796	Spring - Rear Door	1
3	95-6786	Handle	1
4	95-6698	Screw	2
5	95-6579	Recycler Plug	1
6	95-6575	Kicker - Middle	1

Ref. No.	Part No.	Description	No. Used
7	95-6753	Kicker - Front	1
8	95-6560	Screw	3
9	95-6552	Frame - Bag	1
10	95-6550	Bag	1
11	95-6554	Ramp - Bag	1
13	95-6572	Decal - Safety	1
*	95-6770	Bushing - Rear Door	1

* Not Illustrated