Form No. 3323–127

Roller Kit

for Greensmaster® 3000 Series

Model No. 04412
Model No. 04414
Model No. 04424
Model No. 04426

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply: the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form **a:b.** The **a** represents the reference number of the entire service assembly and the **b** represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number **6**, the tire by **6:1**, the valve by **6:2**, and the wheel by **6:3**. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually.


Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form **nX y.** The **n** represents the quantity of the part, the **X** is the multiplication symbol, and the **y** represents the reference number.

For example, in an illustration, the reference number **2X 37** means that two of the parts identified by reference number 37 are indicated.

© The TORO Company — 1999
All Rights Reserved



Sheet No.: 0
T–0956

Roller Assemblies

Ref. No.	Part No.	Qty.	Description
1	52–3170	3	Full Front Roller ASM (Only On: 04412)
1:2	52–3180	6	Bearing–Front Roller (Only On: 04412)
1:3	302–5	6	Fitting–Lube (Only On: 04412)
2	52–3590	3	Swaged Roller ASM (Only On: 04414)
2:2	52–3180	6	Bearing–Front Roller (Only On: 04414)
2:3	302–5	6	Fitting–Lube (Only On: 04414)
3	71–1550	3	Wiehle Roller ASM (Only On: 04424)
3	88–6790	3	Aluminum Wiehle Roller ASM (Only On: 04426)
3:2	302–5	6	Fitting–Lube (Only On: 04424, 04426)
3:3	52–3180	6	Bearing–Front Roller (Only On: 04424, 04426)

Ref. No.	Part No.	Qty.	Description