



BY APPOINTMENT TO
HER MAJESTY THE QUEEN
MANUFACTURERS OF HAYTER
HORTICULTURAL MACHINERY
TORD U.K. LIMITED, SPELLBROOK,
BISHOPS STORTFORD, HERTS

HAYTER

MAKERS OF THE FINEST MOWERS

Parts Catalogue

HARRIER 56 PRO AUTODRIVE FS BBC

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents


Handlebar and Controls 4

Engine and Blade 6

Deck and Grassbag 8

Traction, Suspension and HOC 10


Handlebar and Controls



Handlebar and Controls (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	111-9837-03	2	Handlebar Lower	31	134-2297	1	Cable BBC
2	300160	2	Plug-Tube	32	134-1714	1	Cable Clutch
3	340028	2	Plate-Clamp, Handlebar	33	134-2660	1	Anchor Plate Welded
4	134-2241-03	2	Brace Handlebar	34	134-2662	1	BBC Linkage Assembly
5	134-3571-03	1	Upper Handlebar	35	0201086	1	Washer-Starlock
7	134-2614-03	1	Clutch Lever	36	09379	2	Bolt-Coach
11	111-8716	1	"handle, Soft Grip"	37	04020	2	Grip-Fix
12	340182	1	Pin-Pivot	38	09441	4	Nut-Hex, NI
13	111-8990	1	Clamp-Bar	39	HY234051	2	Cap-Nut
14	09688	3	Washer-Nylon	40	09785	2	Bolt
15	09687	1	Screw	41	480088	2	Knob-Handlebar
16	134-3569	1	Guide-Rope	42	ZHS1H020U	2	Screw-HSBH
17	410037	2	Guide-Cable	43	09267	4	Washer-Plain
18	09544	1	Nut-Nyloc	47	134-3208	1	Starlock-Domed
20	134-2608	1	Arm-Bail	48	134-3328	1	Tape - Toffee
21	111-8903	1	Lever-Catch	49	111-8696	1	Clip-Conduit, Twin
22	134-2609	1	Bcc Latch Button	50	137-3088	1	Nut-Hex
23	111-8908	1	Latch-Pin	53	05010	1	Bolt
24	111-8906	1	Lever-Bail, Spring	54	09780	1	Setscrew
25	111-0718	1	Fastener-Starlock, Push-On	55	09438	1	Nut-Nyloc
26	134-2027	1	Clip-Tree	56	HY3966	1	Tie-Cable
27	134-2284	1	Lever-Bail Arm, Spring	57	134-1761	1	Bush, Igus
30	134-2246	1	Control Throttle				


Engine and Blade



Engine and Blade (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	134-2143	1	Engine B&s 850E Recoil	19	130-2377	2	Bushing-Flange
2	134-2671	1	Cutterbar	20	134-3773	1	BBC Anchor Plate Assy
3	410057W	1	Disc-Friction	21	137-3005	1	Nut-HF
5	134-2252	1	Spacer-Blade, BBC	22	134-0325	2	Bearing
6	134-2648	1	Nut-Retaining	23	111-8895	1	BBC Shaft Nut
7	134-4249	1	Pulley Half Drive BBC	24	108-3792	1	Spring-Tension, Brake
8	134-2590	1	Drum-BBC	25	111-8828	1	Spacer-Retaining
9	107-0759	1	Bolt-Shoulder	26	09349	3	Screw-Taptite, Unc
10	110-1790	1	Belt	27	134-3973	1	Spacer-Distance, Cutterbar
11	125-1063	1	Plate-Brake	28	134-3191	1	Washer-Lock
12	107-0758	1	Spacer-Bearing	29	134-1681	3	Bolt, Unf 3/8 X 1.3/4 (Grade 8. Rohs)
13	38-7820	1	Bearing-Ball	30	09575	3	Screw-Taptite
14	138-3217	1	Retainer-Belt	31	134-2714	1	Pulley-Engine
15	605256	1	Spacer	32	139-1706	2	Nut-Flange, Lock
16	111-8855	1	Plate-Tensioner	40	134-3305	1	Decal Engine
17	119-4162	1	Screw-CARR				
18	603773	2	Locknut				

Deck and Grassbag




Deck and Grassbag (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	134-0332-07	1	Harrier 56 Deck	14	134-2255	1	Rod-Support
2	134-2899	1	Fin-Front	15	111-8659	1	Washport Adapter Assembly
3	134-0334	1	Plate-Throw	16	134-2238	1	Top Trim Port Cover
4	134-0335	1	Trim-Top	17	111-8628-03	1	Grassbag-Frame
5	134-0336	1	Cover-Belt	18	134- 6403	1	Fabric Grassbag 80L
6	134-2208-03	1	Cover-Belt	22	09575	27	Screw-Taptite
7	111-8541	1	Mount-Deflector, Left	23	134-2137	1	Decal-Safety
8	111-8542	1	Deflector Mount Right	24	111-9937	1	Decal-Easy Wash
9	111-8647	1	Deflector-Rear	25	134-0051	1	Logo-Hayter
10	111-8648	1	Deflector-Seal, Rear	27	111-7722	1	Made In Britain Decal
11	111-8728	1	Rod-Deflector	30	134-0262	1	Rivet-Push, Plastic
12	111-8543	1	Spring-Deflector, Left	31	134-3554	1	Front Bumper Kit, Loose
13	111-8544	1	Spring-Deflector, Right				(56) ●

● Not illustrated

Traction, Suspension and HOC



Traction, Suspension and HOC (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	134-4647	1	Mv500 Gearbox	49	09263	1	Washer
4	09441	1	Nut-Hex, NI	50	134-2254	1	Spring Load Lever
5	134-2656	1	Pivot Plate Bracket	51	134-2287	1	Spring Counter Balance
6	134-2209	1	Gearbox Bracket Assembly	52	134-2299	5	Screw-HWH
7	111-8587	1	Spring-Mounting, Gearbox	53	480132	1	Spring-Torsion, HOC
8	134-5276-03	1	Rear Frame, 56 (Pro)	54	04020	1	Grip-Fix
10	134-5253	1	Shaft-Roller, Pro	56	09363	1	Screw-HH
11	134-2924	4	Cam-Drive	57	09472	1	Washer-Plain
12	134-2034	4	Key-Drive	58	09544	1	Nut-Nyloc
13	111-8602	2	Washer-Thrust	59	09575	16	Screw-Taptite
14	134-2635	2	Bush, Rear Roller	60	134-2631	2	Cap-Roller, End
15	340129	2	Bushing-Roller, Oilite	61	134-0315-03	2	Roller Shell Assembly
16	480097	2	Washer	62	134-2623	1	Washer-Thrust
17	134-0314	1	Spacer-Roller	64	134-0254	3	Circlip-External, HD
18	134-3806	1	Sprocket	66	111-8216	1	Washer-Thrust
20	134-5261	1	Chain(46 Pitches 3/8	67	0201086	2	Washer-Starlock
21	134-4620	1	Chain Cover ASM	68	09365	2	Screw-Taptite
22	134-0393	2	Mount-Bearing, Frame (Rear)	72	134-1734	2	Bearing Support Plate
23	134-3805	1	Sprocket, 10T	73	09545	4	Screw-Taptite
24	111-8705	1	Lever-HOC	75	134-2889	2	Bearing-Ball
25	480134	1	Knob-HOC	76	134-2290	1	Welded Jack Shaft ASM
26	134-2232	1	HOC Tower Assembly	77	134-2292	1	Split Pulley Upper
30	134-2236	1	56 Front Axle Assembly	78	134-3284	1	Spacer Tube, Bearing
31	111-9270	2	Wheel ASM-8Inch Semi-Pneu	79	ZWP1H000U	1	Washer-Plain
32	09447	2	Nut	80	110-4068	1	Washer-Plastic
33	09479	2	Washer-Plain	81	134-4514	1	Pin, Roll, 3MM X 16MM
34	134-0365	1	Connecting Rod Assembly	82	134-6225-03	1	Back Plate, Tensioner
35	410069	2	Bearing-Axle, Front	83	134-6226	1	Pulley, Tensioner
37	111-5115	1	Belt-Variator	84	111-0118	1	Screw-HSH
38	134-0377	1	Jack Shaft Bracket	85	09438	1	Nut-Nyloc
39	134-2889	2	"bearing, Ball 12Mm"	86	111-7679	1	Washer-Plain
45	111-8670	1	Axle- Support, Rear	87	09474	1	Washer-Spring
48	134-2295	1	V-Belt	88	134-6999	1	Screw-HH Lock[m6-1.0X20,Ci8.8, Patch,Cz]

