



Form No. 3431-258 Rev A

Count on it.

Parts Catalog

Powervac Gas-Powered Blower

Model No. 51988—Serial No. 318000001 and Up



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents


Main Blower Assembly 4

Engine and Housing Assembly 6

Engine Component Assembly 8

Attachments and Accessories 10


Main Blower Assembly



Main Blower Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	580955001	1	Tube-Vacuum, Lower	4	580956001	1	Tube-Adaptor, Vacuum Bag
2	660621001	2	Screw-Tube, Vacuum	5	360015001	1	Blower Tube ASM
3	311954001	1	Tube-Vacuum, Upper	6	970694003	1	Bag-Vacuum

Engine and Housing Assembly




Engine and Housing Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	694143002	1	Hinge-Spring, Vacuum Door	25	941727005	1	Decal-Warning Strip Icon
2	527987001	1	Door-Vacuum	26	527985001	1	Lever-Control, Cruise
3	941727006	1	Decal-Warning Icon	27	940908003	1	Decal-Starting Instructions
4	940907028	1	Decal-Logo, Right	28	203385001	1	Air Box Cover ASM
5	660629005	17	Screw	29	560873001	1	Element-Filter, Air
6	203383001	1	Outer Volute ASM	30		1	Power Head ASM Not Serviced Separately, For Replacement Parts See Engine Component Assembly ●
7	678018001	1	Nut-Lock, Flange				
8	678114004	1	Blade-Mulching				
9	527982001	1	Fan-Blower				
10	638125008	1	Washer	31	203381001	1	Fuel Tank ASM
11	660351001	4	Screw-PH	32	940991054	1	Decal-E85
12	203657001	1	Engine Shroud ASM	33	310816015	1	Cap-Fuel
13	940654088	1	Label-Combustion	34	662274001	1	Screw
14	940907027	1	Decal-Rear Logo	35	310000001	1	Starter Housing ASM
15	941727009	1	Decal-Tube Removal	36	525485008	1	Grip-Starter
16	760961005	1	Switch-On/Off	37	638088002	1	Eyelet
17	527926001	1	Lever-Throttle	38	660344001	4	Screw-PH
18	308209004	1	Throttle Cable ASM	39	940907029	1	Decal-Logo Left
19	290469001	1	Wire-Ground	40	527925001	1	Cover-Muffler
20	660629002	1	Screw	41	638033001	1	Spring Housing ASM
21	527986001	1	Trigger-Activator, Throttle	42	527983001	1	Pulley-Starter
22	632423001	1	Washer-Wave	43	900849012	1	Rope-Starter
23	631049004	1	Washer				
24	678587001	1	Washer				

● Not serviced separately

Engine Component Assembly



Engine Component Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	690689001	1	Nut-Rotor	13	642368002	1	Cylinder
2	307201002	1	Flywheel ASM	14	310997003	1	Air Box Cover ASM
3	307366001	1	Crankcase/Piston ASM	15	660347003	2	Screw
4	900709007	1	Gasket	16	660342001	2	Screw-Socket Head
5	291388002	1	Harness-Wire	17	870174001	1	Sparkplug
6	660968004	2	Screw And Washer	18	562927008	1	Gasket-Cylinder
7	290178029	1	Module-Ignition	19	528049001	1	Plate-Heat Sink
8	690969001	2	Washer	20	T662210002	2	Screw
9	590462001	2	Spacer	21	900711015	1	Gasket-Carburetor
10	639243002	1	Gasket-Muffler	22	308480002	1	Carburetor ASM
11	300748042	1	Muffler ASM	23	561635002	1	Purge Bulb
12	662169001	2	Screw				

Attachments and Accessories

For 51988 Powervac Gas-Powered Blower

Product Name	Model/Part
High Altitude Kit	120900226

Notes:



Count on it.