Form No. 3323–174

Tri–Roller Kit

For Greensmaster® 3000 Series

Model No. 04495—200000001 and Up

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply: the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form **a:b.** The **a** represents the reference number of the entire service assembly and the **b** represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number **6**, the tire by **6:1**, the valve by **6:2**, and the wheel by **6:3**. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually.


Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form **nX y.** The **n** represents the quantity of the part, the **X** is the multiplication symbol, and the **y** represents the reference number.

For example, in an illustration, the reference number **2X 37** means that two of the parts identified by reference number 37 are indicated.

© The TORO Company — 1999
All Rights Reserved




Sheet No.:0
T–3464

Tri–Roller Mounting Assembly (3200 Shown)

Ref. No.	Part No.	Qty.	Description
*1	99–1603	3	Tri–Roller ASM
2	94–2958	6	Stud–Ball (Greensmaster 3050 & 3100)
3	3254–6	6	Washer–Lock, Internal
4	94–4548	6	Bumper–Recessed
5	32144–44	6	Screw
6	61–2370	1	Spacer (Greensmaster 3050 & 3100)
7	32144–102	1	Screw–HWH (Greensmaster 3050 & 3100)
*8	3256–24	2	Washer–Flat (Greensmaster 3050 & 3100)
*9	95–1642–01	1	Weight – Counter (Greenmaster 3050 & 3100)
17	54–7460	6	Ball Joint
18	54–7430	6	Stud – Ball
19	3220–5	6	Nut–Hex Jam
20	18–3049	6	Pull Link ASM
20:1	95–0532	1	Bushing ASM – Rubber
21	256–292	6	Bushing–Flange, NI
22	75–5270	6	Spacer–Seat Knob
23	3256–4	6	Washer–Flat
24	3211–6	6	Screw–HH

* Not illustrated



Sheet No.:A1

Tri–Roller Assembly No. 99–1603

Ref. No.	Part No.	Qty.	Description
1	99–1605–01	1	Frame ASM
2	94–3405	2	Bearing–Ball
2:1	3245–35	6	Screw – Set
2:2	251–77	6	Collar – Lock
3	95–7148	2	Housing – Bearing
4	95–1642–01	1	Weight – Counter
5	93–2569	4	Screw–HHF
6	3256–24	2	Washer–Flat
7	302–5	2	Fitting–Lube
10	33025–00	1	Nut–Lock, NI
11	33026–00	6	Nut–Lock, NI
12	93–2463	1	Roller – Lift
13	93–2464	1	Spacer – Roller
14	99–1615	1	Rear Roller ASM
14:1	93–2466	1	Shaft – Roller
14:2	99–1616	1	Tube ASM – Rear Roller
14:3	93–2559	2	Bearing – Ball
14:4	93–2525	2	Ring – Retaining
14:5	302–5	2	Fitting–Lube
14:6	98–2194	2	Sleeve – Grease
15	33115–080	1	Screw–HH
16	33024–00	4	Nut–Lock, NI
17	99–8168	2	Collar–HOC
18	2410–30	1	Cap–Plastic
19	33114–025	2	Screw–HH

Ref. No.	Part No.	Qty.	Description
20	67–1300	1	Decal – Toro
21	48–9590	4	Washer–Lock
22	33115–025	4	Screw–HH
23	99–1614	1	Roller ASM
24	33126–040	4	Screw–CARR
25	99–1637–01	1	Plate – Scraper
26	99–1620–01	9	Plate – Weight, Long
27	33116–070	2	Screw–HH
30	99–1638	2	Roller – Plastic
31	51–3640	2	Sleeve–Pivot, Idler
32	3256–3	2	Washer–Flat
33	33114–050	2	Screw–HH
34	3256–74	4	Washer–flat


TORO®