



**Count on it.**

# Parts Catalog

## **Workman® HD** **Utility Vehicle with Bed**

Model No. 07369—Serial No. 404950001 and Up



# Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

## Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

## Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.


## Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

# Contents


|                                                                     |    |
|---------------------------------------------------------------------|----|
| Front Frame Assembly .....                                          | 4  |
| Rear Frame and Suspension Assembly .....                            | 5  |
| Rear Axle Assembly .....                                            | 6  |
| Brake Caliper Assembly No. 127-7424 .....                           | 8  |
| Driveshaft Assembly .....                                           | 9  |
| Front and Rear Brake Line Assembly .....                            | 10 |
| Front Suspension Assembly .....                                     | 11 |
| Steering and Front Wheel Assembly .....                             | 12 |
| Steering Linkage Assembly .....                                     | 13 |
| Hydraulic Cylinder Assembly No. 112-3217 .....                      | 14 |
| Front Control Arm Assembly .....                                    | 15 |
| Brake and Clutch Pedal Assembly .....                               | 16 |
| Master Cylinder Assembly No. 104-6782 .....                         | 17 |
| Accelerator Pedal Assembly .....                                    | 18 |
| Console Assembly .....                                              | 19 |
| Shift Assembly No. 106-7887 .....                                   | 21 |
| Bumper, Hood and Seat Base Assembly .....                           | 22 |
| Dash Assembly .....                                                 | 23 |
| Steering Hydraulic Assembly .....                                   | 24 |
| Steering Valve Assembly No. 120-4813 .....                          | 25 |
| Seat Assembly .....                                                 | 26 |
| Roll-Over Protection System Assembly .....                          | 27 |
| Full Bed and Side Panel Assembly .....                              | 28 |
| Engine Sub Frame Assembly .....                                     | 29 |
| Hydraulic Gear Pump Assembly No. 112-2983 .....                     | 30 |
| Engine Assembly .....                                               | 31 |
| Muffler Assembly .....                                              | 33 |
| Clutch Linkage Assembly .....                                       | 34 |
| Transaxle Assembly .....                                            | 35 |
| Case Assembly Transaxle Assembly No. 115-7783 .....                 | 36 |
| Center Plate Assembly Transaxle Assembly No. 115-7783 .....         | 37 |
| Main Shaft Assembly Transaxle Assembly No. 115-7783 .....           | 38 |
| Reduction Shaft Assembly Transaxle Assembly No. 115-7783 .....      | 39 |
| Reverse Shaft Assembly Transaxle Assembly No. 115-7783 .....        | 40 |
| Main Shift Assembly Transaxle Assembly No. 115-7783 .....           | 41 |
| Hi-Lo Shift Assembly Transaxle Assembly No. 115-7783 .....          | 42 |
| Countershaft Assembly Transaxle Assembly No. 115-7783 .....         | 43 |
| Differential Gear Assembly Transaxle Assembly No. 115-7783 .....    | 44 |
| Differential Carrier Assembly Transaxle Assembly No. 115-7783 ..... | 45 |
| Differential Lock Assembly Transaxle Assembly No. 115-7783 .....    | 46 |
| Axle Shaft Assembly Transaxle Assembly No. 115-7783 .....           | 47 |
| Battery Assembly .....                                              | 48 |
| Tail Light and Fender Assembly .....                                | 49 |
| Fuel System Assembly .....                                          | 50 |
| Hydraulic Lift Cylinder Assembly .....                              | 51 |
| Hydraulic Cylinder Assembly No. 133-0620 .....                      | 53 |
| Lift Valve Assembly .....                                           | 54 |
| Control Valve Assembly No. 43-1950 .....                            | 55 |
| Front and Rear Wire Harness Assembly .....                          | 56 |
| Attachments and Accessories .....                                   | 57 |



## Front Frame Assembly

| Ref. | Part Number | Qty. | Description            |
|------|-------------|------|------------------------|
| 1    | 138-9251    | 1    | Frame-Front            |
| 2    | 87-2440     | 2    | Bumper-Rubber          |
| 3    | 26-0071     | 2    | Snubber-Rubber         |
| 7    | 42862       | 1    | Block-Terminal, Ground |
| 8    | 32105-13    | 6    | Screw-HWH              |
| 9    | 3290-148    | 6    | Nut-HF                 |
| 12   | 106-2427-03 | 1    | Cover                  |
| 13   | 114-8272-03 | 1    | Bracket-Bumper         |
| 14   | 3234-5      | 4    | Screw-HHF              |
| 15   | 32144-70    | 4    | Screw-HWHTF            |


| Ref. | Part Number | Qty. | Description     |
|------|-------------|------|-----------------|
| 17   | 94-2413     | 7    | Nut-U           |
| 18   | 3231-21     | 4    | Screw-CARR      |
| 19   | 3290-357    | 6    | Nut-HHF, Whiz   |
| 21   | 114-8418    | 7    | Screw-HWH, Sems |
| 22   | 42863       | 1    | Strip-Jumper    |
| 23   | 107-8042    | 2    | Bumper-Rubber   |
| 25   | 3290-379    | 9    | Tie-Cable       |
| 26   | 115-7813    | 1    | Decal-Fuse      |
| 31   | 32180-030   | 2    | Clip-Tie        |



## Rear Frame and Suspension Assembly

| Ref. | Part Number | Qty. | Description       |
|------|-------------|------|-------------------|
| 1    | 115-2255-03 | 1    | Frame-Rear        |
| 2    | 131-3474    | 1    | Mount-Spring, LH  |
| 3    | 131-3472    | 1    | Mount-Spring, RH  |
| 4    | 104-8301    | 10   | Nut-HF, NI        |
| 5    | 87-4760     | 12   | Bushing-Rubber    |
| 6    | 87-1490     | 2    | Spring-Leaf, Rear |
| 7    | 131-3476    | 4    | Shackle           |
| 8    | 3234-38     | 18   | Screw-HHF         |
| 9    | 99-5107     | 18   | Nut-Lock          |
| 10   | 32148-9     | 4    | Nut-Clinch        |
| 11   | 87-5800-03  | 2    | Mount-Transaxle   |
| 12   | 106-7865    | 2    | Mount-Engine      |

| Ref. | Part Number | Qty. | Description        |
|------|-------------|------|--------------------|
| 13   | 87-5100     | 4    | Washer-Snubbing    |
| 14   | 3234-24     | 4    | Screw-HHF          |
| 15   | 108-3109    | 2    | Retainer-Cylinder  |
| 16   | 3229-1      | 2    | Bolt-CARR          |
| 17   | 104-7201    | 3    | Nut-HF             |
| 18   | 87-3470     | 2    | Bumper             |
| 19   | 103-9511    | 2    | Nut-Lock, NI       |
| 20   | 115-2047    | 2    | Decal-Surface, Hot |
| 21   | 33116-080   | 2    | Screw-HH           |
| 22   | 3255-8      | 1    | Washer-Lock        |
| 23   | 32105-15    | 1    | Screw-HWH          |



## Rear Axle Assembly

| Ref. | Part Number | Qty. | Description            |
|------|-------------|------|------------------------|
| 1    | 119-9515    | 1    | Axle-Rear              |
| 2    | 121-9751    | 2    | Hub-Bearing, Wheel     |
| 2:2  | 121-9752    | 5    | Stud-Wheel             |
| 3    | 3234-11     | 20   | Screw-HHF              |
| 4    | 127-7424    | 2    | Brake Caliper ASM      |
| 5    | 119-9509    | 2    | Screw-Bleed            |
| 6    | 115-2362-03 | 1    | Bracket-Caliper, LH    |
| 7    | 115-2359-03 | 1    | Bracket-Caliper, RH    |
| 8    | 115-7742    | 1    | Hitch ASM              |
| 8:1  | 92-5951-03  | 1    | Angle-Hitch            |
| 8:2  | 136-1163    | 1    | Decal-Load, Towing     |
| 9    | 114-8351    | 2    | Rotor-Brake            |
| 10   | 114-8365    | 1    | Caliper-Mechanical, LH |
| 10:1 | 115-7847    | 1    | Parking Brake Pad Kit  |
| 11   | 114-8366    | 1    | Caliper-Mechanical, RH |
| 11:1 | 115-7847    | 1    | Parking Brake Pad Kit  |
| 12   | 131-8428    | 2    | Tire/Wheel ASM         |
| 12:1 | 131-6673    | 1    | Tire-Rear              |


| Ref. | Part Number | Qty. | Description            |
|------|-------------|------|------------------------|
| 12:2 | 131-8429    | 1    | Wheel                  |
| 12:3 | 232-27      | 1    | Stem-Valve             |
| 13   | 87-7470-03  | 2    | Plate-Spring, Clamp    |
| 14   | 87-7480     | 8    | Washer                 |
| 15   | 87-3600     | 2    | Spacer-Absorber, Shock |
| 16   | 87-5330     | 2    | Washer                 |
| 17   | 87-3920     | 8    | Bushing                |
| 18   | 121-9774    | 2    | Absorber-Shock         |
| 19   | 242-50      | 10   | Nut-Lug                |
| 20   | 3256-27     | 2    | Washer-Flat            |
| 21   | 3256-6      | 2    | Washer-Flat            |
| 22   | 99-5107     | 2    | Nut-Lock               |
| 23   | 115-2398    | 8    | Bolt-HH                |
| 24   | 114-8417    | 2    | Nut-HF, NI             |
| 25   | 114-8424    | 2    | Screw-HH               |
| 26   | 283-85      | 2    | Pin-Clevis             |
| 27   |             | 2    | Driveshaft ASM ●       |
| 28   | 80-6990     | 4    | Washer-Hardened        |

● Not serviced separately



| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   |
|-------------|--------------------|-------------|----------------------|
| 31          | 115-2164           | 2           | Nut-Spindle          |
| 34          | 104-6415           | 2           | Spring-Return, Pedal |


3431-920A



## Brake Caliper Assembly No. 127-7424


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 119-9510           | 1           | Pads-Brake         |
| 2           | 119-9511           | 1           | Bracket Kit        |
| 3           | 133-0614           | 1           | Piston Kit         |






## Driveshaft Assembly

| Ref.  | Part Number | Qty. | Description               |
|-------|-------------|------|---------------------------|
| 1     | 114-8367    | 1    | Driveshaft ASM            |
| 1:1   | 98-2940     | 1    | Yoke                      |
| 1:2   | 92-4187     | 2    | Cross And Bearing Kit     |
| 1:2:1 | 302-58      | 4    | Fitting-Straight          |
| 1:2:2 | 92-4188     | 4    | Ring-Snap                 |
| 1:3   | 92-4179     | 1    | Yoke-Tube, Shaft And Seal |
| 1:3:1 | 302-5       | 1    | Fitting-Grease            |
| 1:4   | 92-4180     | 1    | Seal                      |
| 1:5   | 115-2351    | 1    | Yoke                      |
| 1:6   | 92-4182     | 1    | Yoke-Telescoping          |
| 2     | 115-7771    | 1    | Shaft-Splined             |
| 3     | 32128-53    | 1    | Nut-HF                    |



## Front and Rear Brake Line Assembly


| Ref. | Part Number | Qty. | Description          |
|------|-------------|------|----------------------|
| 1    | 119-9682    | 1    | Front Brake Line ASM |
| 2    | 119-9681    | 1    | Rear Brake Line ASM  |
| 3    | 32144-70    | 1    | Screw-HWHTF          |
| 4    | 321-6       | 3    | Screw-HH             |
| 5    | 104-7201    | 3    | Nut-HF               |
| 6    | 3234-21     | 3    | Screw-HHF            |
| 7    | 32128-33    | 3    | Nut-HF               |
| 8    | 115-2341    | 8    | Washer-Banjo         |
| 9    | 120-4875    | 4    | Bolt-Flange, Banjo   |



## Front Suspension Assembly

| Ref. | Part Number | Qty. | Description            |
|------|-------------|------|------------------------|
| 1    | 87-0160     | 1    | Tower-Control Arm, LH  |
| 2    | 87-0150     | 1    | Tower-Control Arm, RH  |
| 3    | 33-3090     | 4    | Bushing                |
| 4    | 3234-39     | 8    | Screw-HHF              |
| 5    | 87-2500     | 2    | Sleeve-Spring, Pivot   |
| 6    | 105-7958    | 2    | Spring Cradle ASM      |
| 6:2  | 93-9879     | 1    | Decal-Warning          |
| 7    | 325-13      | 2    | Screw-HH               |
| 8    | 99-5107     | 4    | Nut-Lock               |
| 9    | 87-3600     | 10   | Spacer-Absorber, Shock |
| 10   | 87-5330     | 12   | Washer                 |
| 11   | 119-6725    | 2    | Link, Anti-Sway Bar    |
| 12   | 87-3920     | 24   | Bushing                |
| 13   | 133-0633-03 | 1    | Bar-Anti-Sway, HD      |

| Ref. | Part Number | Qty. | Description          |
|------|-------------|------|----------------------|
| 14   | 302-11      | 2    | Fitting-Lube, 45 DEG |
| 15   | 87-3910     | 2    | Bushing-Rubber       |
| 16   | 87-4010-03  | 2    | Clamp-Bar, Sway      |
| 17   | 87-3890-03  | 2    | Bracket-Bar, Sway    |
| 18   | 3231-25     | 4    | Bolt-CARR            |
| 19   | 104-8301    | 12   | Nut-HF, NI           |
| 20   | 119-6724    | 2    | Link-Stabilizer      |
| 21   | 324-10      | 8    | Screw-HH             |
| 22   | 105-4183-01 | 2    | Spring-Compression   |
| 24   | 121-9774    | 2    | Absorber-Shock       |
| 25   | 324-13      | 2    | Screw-HH             |
| 26   | 3256-6      | 2    | Washer-Flat          |
| 27   | 3256-27     | 2    | Washer-Flat          |
| 28   | 114-8417    | 10   | Nut-HF, NI           |




## Steering and Front Wheel Assembly

| Ref. | Part Number | Qty. | Description            |
|------|-------------|------|------------------------|
| 1    | 104-8301    | 2    | Nut-HF, NI             |
| 2    | 324-10      | 2    | Screw-HH               |
| 3    |             | 1    | Steering Linkage ASM ● |
| 4    | 119-9548    | 2    | Bearing-Ball           |
| 5    | 114-8296    | 1    | Link-Center            |
| 6    | 32120-22    | 2    | Ring-Snap, Internal    |
| 7    | 112843      | 2    | Washer                 |
| 8    | 114-8417    | 2    | Nut-HF, NI             |
| 9    | 119-9513    | 1    | Knuckle-LH             |
| 10   | 119-9514    | 1    | Knuckle-RH             |
| 11   | 114-8356    | 2    | Tie Rod ASM            |
| 12   | 121-9751    | 2    | Hub-Bearing, Wheel     |
| 12:2 | 121-9752    | 5    | Stud-Wheel             |
| 13   | 3234-11     | 12   | Screw-HHF              |
| 14   | 114-8351    | 2    | Rotor-Brake            |
| 15   | 127-7424    | 2    | Brake Caliper ASM      |
| 16   | 112-3217    | 1    | HYD Cylinder ASM       |


| Ref. | Part Number | Qty. | Description              |
|------|-------------|------|--------------------------|
| 17   | 106-6774    | 2    | Joint-Ball               |
| 19   | 302-5       | 2    | Fitting-Grease           |
| 21   | 131-8430    | 2    | Tire/Wheel ASM           |
| 21:1 | 131-8431    | 1    | Wheel                    |
| 21:2 | 131-6670    | 1    | Tire                     |
| 21:3 | 232-27      | 1    | Stem-Valve               |
| 22   | 242-50      | 10   | Nut-Lug                  |
| 23   | 114-4681    | 2    | Screw-HHF                |
| 24   | 32151-104   | 2    | Ring-Retaining, External |
| 25   | 32136-14    | 2    | Nut-Hst                  |
| 26   | 32136-3     | 2    | Nut-SHH                  |
| 27   | 3272-12     | 4    | Pin-Cotter               |
| 28   | 104-0719    | 2    | Washer-Hardened          |
| 29   | 3256-62     | 2    | Washer-Flat              |
| 30   | 115-2173    | 2    | Screw-HH                 |
| 31   | 3296-49     | 2    | Nut-Lock, NI             |
| 32   | 119-9509    | 2    | Screw-Bleed              |

● Not serviced separately



## Steering Linkage Assembly


| Ref. | Part Number | Qty. | Description                      |
|------|-------------|------|----------------------------------|
| 1    | 132-6767    | 1    | Mount-Pivot, W/Bushings          |
| 7    | 115-2164    | 2    | Nut-Spindle                      |
| 9    | 302-60      | 2    | Fitting-Grease                   |
| 10   | 132-0794    | 1    | Idler Arm ASM                    |
| 10:1 | 132-0792    | 1    | Idler Arm And Thrust Washer ASM  |
| 10:2 | 93-7510     | 1    | Ring-Quad                        |
| 10:3 | 131-3499    | 1    | O-Ring                           |
| 11   | 132-0795    | 1    | Pitman Arm ASM                   |
| 11:1 | 132-0793    | 1    | Pitman Arm And Thrust Washer ASM |
| 11:2 | 93-7510     | 1    | Ring-Quad                        |
| 11:3 | 131-3499    | 1    | O-Ring                           |



## Hydraulic Cylinder Assembly No. 112-3217

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|---------------------|
| 1           |                    | 1           | Rod-Cylinder ●      |
| 2           |                    | 1           | Body-Cylinder ●     |
| 3           | 115-2160           | 1           | Cylinder Repair Kit |


● Not serviced separately



## Front Control Arm Assembly

| Ref.  | Part Number | Qty. | Description              |
|-------|-------------|------|--------------------------|
| 1     | 115-2405    | 1    | Lower LH Control Arm ASM |
| 1:2   | 87-1450     | 2    | Bushing-Flange           |
| 1:3   | 115-2165    | 1    | Ball Joint               |
| 1:3:1 | 302-5       | 1    | Fitting-Grease           |
| 1:4   | 87-2420     | 1    | Seal-Joint, Ball         |
| 1:5   | 32151-104   | 1    | Ring-Retaining, External |
| 2     | 115-2407    | 1    | Lower RH Control Arm ASM |
| 2:2   | 87-1450     | 2    | Bushing-Flange           |
| 2:3   | 115-2165    | 1    | Ball Joint               |
| 2:3:1 | 302-5       | 1    | Fitting-Grease           |
| 2:4   | 87-2420     | 1    | Seal-Joint, Ball         |
| 2:5   | 32151-104   | 1    | Ring-Retaining, External |
| 3     | 115-2404    | 1    | Upper LH Control Arm ASM |
| 3:2   | 87-1450     | 2    | Bushing-Flange           |
| 3:3   | 115-2165    | 1    | Ball Joint               |

| Ref.  | Part Number | Qty. | Description              |
|-------|-------------|------|--------------------------|
| 3:3:1 | 302-5       | 1    | Fitting-Grease           |
| 3:4   | 87-2420     | 1    | Seal-Joint, Ball         |
| 3:5   | 32151-104   | 1    | Ring-Retaining, External |
| 4     | 115-2406    | 1    | Upper RH Control Arm ASM |
| 4:2   | 87-1450     | 2    | Bushing-Flange           |
| 4:3   | 115-2165    | 1    | Ball Joint               |
| 4:3:1 | 302-5       | 1    | Fitting-Grease           |
| 4:4   | 87-2420     | 1    | Seal-Joint, Ball         |
| 4:5   | 32151-104   | 1    | Ring-Retaining, External |
| 5     | 99-5107     | 8    | Nut-Lock                 |
| 6     | 114-8419    | 6    | Screw-HHF                |
| 7     | 324-10      | 4    | Screw-HH                 |
| 8     | 325-17      | 2    | Screw-HH                 |
| 9     | 114-8417    | 4    | Nut-HF, NI               |




## Brake and Clutch Pedal Assembly

| Ref. | Part Number | Qty. | Description         |
|------|-------------|------|---------------------|
| 1    | 127-7357-03 | 1    | Pedal-Clutch        |
| 2    | 115-2269    | 1    | Pin-Pivot           |
| 3    | 120-5023-03 | 1    | Pedal-Brake         |
| 4    | 256-156     | 4    | Bushing-Flange      |
| 5    | 104-6782    | 1    | Master Cylinder ASM |
| 6    | 3234-11     | 2    | Screw-HHF           |
| 7    | 3290-357    | 2    | Nut-HHF, Whiz       |
| 8    | 283-2       | 1    | Pin-Clevis          |
| 9    | 3272-10     | 1    | Pin-Cotter          |
| 10   | 137-6729    | 1    | Shaft-Brake         |
| 11   | 63-3410     | 2    | Screw-Shoulder      |


| Ref. | Part Number | Qty. | Description         |
|------|-------------|------|---------------------|
| 12   | 32128-33    | 2    | Nut-HF              |
| 13   | 95-1653     | 1    | Switch-Pole, Single |
| 15   | 110-2554    | 1    | Rod End-Spherical   |
| 16   | 302-5       | 1    | Fitting-Grease      |
| 17   | 3256-21     | 4    | Washer-Flat         |
| 18   | 3269-25     | 4    | Rivet-Pop           |
| 19   | 105-0023    | 1    | Switch-Proximity    |
| 20   | 115-2284    | 1    | Cable-Clutch        |
| 21   | 3296-13     | 1    | Nut-Lock, NI        |
| 22   | 46-6811     | 4    | Screw-HWH           |
| 23   | 302-60      | 1    | Fitting-Grease      |





## Master Cylinder Assembly No. 104-6782


| Ref. | Part Number | Qty. | Description          |
|------|-------------|------|----------------------|
| 1    | 104-6845    | 1    | Reservoir ASM        |
| 1:1  | 92-4112     | 1    | Cap ASM              |
| 2    | 93-8971     | 2    | Seal-Port, Flange    |
| 3    | 92-4103     | 1    | Pin-Stop             |
| 4    | 92-4102     | 1    | Secondary Piston ASM |
| 5    | 92-4110     | 1    | Clevis               |
| 6    | 21-0360     | 1    | Nut-Hex              |
| 7    | 94-5209     | 1    | Cover-Dust           |
| 8    | 94-5210     | 1    | Rod-Push             |
| 9    | 92-4109     | 1    | Ring-Snap            |
| 10   | 92-4108     | 1    | Retainer-Washer      |
| 11   | 92-4101     | 1    | Primary Piston ASM   |



## Accelerator Pedal Assembly

| Ref. | Part Number | Qty. | Description              |
|------|-------------|------|--------------------------|
| 1    | 93-8969-03  | 1    | Pedal                    |
| 2    | 256-259     | 2    | Bushing-Flange           |
| 3    | 87-2880     | 1    | Shaft-Pedal, Accelerator |
| 4    | 32151-56    | 1    | Ring-Retaining, External |
| 5    | 119-4881    | 1    | Bolt-Shoulder            |
| 6    | 32128-33    | 1    | Nut-HF                   |
| 7    | 120-4982    | 1    | Bracket-Mount, Cable     |
| 8    | 3230-1      | 2    | Bolt-CARR                |
| 9    | 32128-20    | 2    | Nut-HF                   |


| Ref. | Part Number | Qty. | Description          |
|------|-------------|------|----------------------|
| 10   | 283-85      | 1    | Pin-Clevis           |
| 11   | 3272-6      | 1    | Pin-Cotter           |
| 12   | 67-1450     | 1    | Spring-Idler         |
| 13   | 321-6       | 1    | Screw-HH             |
| 14   | 3218-1      | 1    | Nut-Jam              |
| 15   | 127-8625-03 | 1    | Bracket-Mount, Pedal |
| 16   | 120-4983-03 | 1    | Pedal-Accelerator    |
| 17   | 302-5       | 1    | Fitting-Grease       |



## Console Assembly

| Ref. | Part Number | Qty. | Description               |
|------|-------------|------|---------------------------|
| 1    | 3231-21     | 2    | Screw-CARR                |
| 2    | 108-6914-03 | 1    | Support-Lever             |
| 3    | 114402      | 2    | Spacer                    |
| 4    | 127-8863    | 1    | Lever-Brake, Park         |
| 4:1  | 127-8864    | 1    | Grip-Handle               |
| 5    | 3290-477    | 1    | Washer-Curved             |
| 6    | 321-9       | 2    | Screw-HH                  |
| 7    | 104-8301    | 1    | Nut-HF, NI                |
| 8    | 3296-56     | 2    | Nut-Lock, NI              |
| 9    | 120-5037    | 1    | Spacer                    |
| 10   | 106-7887    | 1    | Shift ASM                 |
| 11   | 106-2376    | 1    | Boot-Shift, Lower         |
| 12   | 323-10      | 2    | Screw-HH                  |
| 13   | 3290-357    | 4    | Nut-HHF, Whiz             |
| 14   | 106-7814    | 2    | Bellcrank                 |
| 15   | 87-2310     | 2    | Clevis-Cable              |
| 16   | 87-4960     | 1    | Clamp-Cable               |
| 17   | 87-4340     | 1    | Clamp-Cable               |
| 18   | 65-5220     | 5    | Screw-HSH, Thread Forming |
| 19   | 87-3480     | 1    | Bracket-Equalizer, Cable  |


| Ref. | Part Number | Qty. | Description              |
|------|-------------|------|--------------------------|
| 20   | 94-3829     | 1    | Pin-Clevis               |
| 21   | 3256-23     | 1    | Washer-Plain             |
| 22   | 106-7828    | 1    | Lever                    |
| 23   | 33096-00    | 2    | Washer-Flat              |
| 24   | 131-3479    | 1    | Lever-Lock, Differential |
| 25   | 106-7960    | 1    | Lever-HYD                |
| 26   | 3290-221    | 4    | Washer-Spring            |
| 27   | 87-7160     | 1    | Clevis-Cable             |
| 28   | 283-62      | 6    | Pin-Clevis               |
| 29   | 3290-307    | 7    | Pin-Cotter               |
| 30   | 66-6501     | 1    | Spacer-Wheel             |
| 31   | 323-36      | 1    | Screw-HH                 |
| 32   | 87-6570     | 1    | Seal-Boot, Lower         |
| 33   | 3220-1      | 2    | Nut-Jam                  |
| 34   | 3218-18     | 1    | Nut-Jam                  |
| 35   | 32120-47    | 3    | Ring-Retaining, External |
| 36   | 106-7903    | 2    | Knob-Control             |
| 37   | 87-6720     | 1    | Knob-Shift               |
| 38   | 106-7952    | 1    | Knob                     |
| 39   | 115-2250    | 1    | Link                     |
| 40   | 106-7833    | 1    | Spacer                   |



## Console Assembly (continued)


| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 41   | 100-1270    | 1    | Switch-Proximity      |
| 42   | 3234-12     | 2    | Screw-HHF             |
| 43   | 100-4872    | 1    | Plate-Switch, Neutral |
| 44   | 3296-12     | 1    | Nut-Lock, NI          |
| 45   | 3229-34     | 1    | Screw-CARR            |
| 46   | 115-2283    | 2    | Cable-Brake, Park     |

| Ref. | Part Number | Qty. | Description              |
|------|-------------|------|--------------------------|
| 47   | 115-2350    | 1    | Pin-Retainer             |
| 48   | 115-7811    | 2    | Cable-Selector, Gear     |
| 49   | 115-7812    | 1    | Cable-Hi Low             |
| 50   | 115-2287    | 1    | Cable-Lock, Differential |
| 51   | 3290-379    | 5    | Tie-Cable                |



## Shift Assembly No. 106-7887


| Ref. | Part Number | Qty. | Description        |
|------|-------------|------|--------------------|
| 1    | 131-3469    | 1    | Lever-Shift        |
| 2    | 87-3650     | 1    | Pin-Shift          |
| 3    | 87-3540     | 2    | Link-Shift         |
| 4    | 87-2520     | 1    | Tube-Pivot         |
| 5    | 87-2900     | 1    | Spring-Compression |
| 6    | 87-8640     | 1    | Washer-Flat        |
| 7    | 322-12      | 1    | Screw-HH           |
| 8    | 87-3530     | 1    | Button-Shifter     |
| 9    | 87-3660     | 1    | Spring-Compression |
| 10   | 3290-507    | 1    | Pin-Dowel          |
| 11   | 87-3520     | 1    | Clevis             |
| 12   | 32121-48    | 1    | Pin-Spring         |
| 13   | 87-6040     | 1    | Bracket-Shifter    |
| 14   | 3290-456    | 2    | Washer-Belleville  |
| 15   | 104-8300    | 1    | Nut-HF, NI         |



## Bumper, Hood and Seat Base Assembly

| Ref. | Part Number | Qty. | Description            |
|------|-------------|------|------------------------|
| 1    | 112-3185    | 1    | Bumper                 |
| 2    | 139-3382    | 1    | Hood ASM               |
| 2:2  | 117-4950    | 1    | Decal                  |
| 4    | 106-7886    | 1    | Control Plate ASM      |
| 4:2  | 106-2377    | 1    | Decal-Console          |
| 5    | 136-6318    | 2    | Housing-Headlight, 12V |
| 6    | 114-8341    | 6    | Clip-Speed             |
| 7    | 3256-55     | 8    | Washer-Flat            |
| 8    | 3234-4      | 4    | Screw-HHF              |
| 9    | 104-7201    | 4    | Nut-HF                 |
| 11   | 98-1375     | 6    | Screw-HWH              |
| 12   | 106-7984    | 1    | Lever-Detent           |
| 13   | 3274-55     | 1    | Screw-HSBH             |

| Ref. | Part Number | Qty. | Description        |
|------|-------------|------|--------------------|
| 14   | 82-4240     | 1    | Spacer-Bearing     |
| 15   | 94-8196     | 1    | Washer-Nylon       |
| 16   | 3290-221    | 1    | Washer-Spring      |
| 17   | 3256-23     | 1    | Washer-Plain       |
| 18   | 104-8300    | 1    | Nut-HF, NI         |
| 22   | 133-0566    | 1    | Seatbase ASM       |
| 22:2 | 114-8407    | 1    | Fender-Front, RH   |
| 22:3 | 114-8408    | 1    | Fender-Front, LH   |
| 22:4 | 117-5036    | 14   | Screw-Plastic, HWH |
| 23   | 106-2378    | 2    | Mudflap            |
| 24   | 117-8063    | 1    | Boot-Shift         |
| 27   | 133-0574    | 2    | Bulb-LED           |
| 28   | 112-6957    | 6    | Washer-Hardened    |




## Dash Assembly

| Ref. | Part Number | Qty. | Description                |
|------|-------------|------|----------------------------|
| 1    | 104-7201    | 2    | Nut-HF                     |
| 2    | 115-7912    | 1    | Dash ASM                   |
| 2:2  | 138-3523    | 1    | Decal-Panel, Control       |
| 2:3  | 121-9776    | 1    | Decal-Danger, Vehicle (CE) |
| 2:4  | 115-2282    | 1    | Decal-Warning, Dash        |
| 2:5  | 106-2353    | 1    | Decal-Powerpoint           |
| 2:6  | 106-2355    | 1    | Decal-Switch, Supervisor   |
| 3    | 117-4948    | 1    | Handle-Grab                |
| 4    | 103995      | 2    | Washer                     |
| 5    | 110-2580    | 1    | Switch-Key, Supervisor     |
| 5:1  |             | 1    | Switch-Key ●               |
| 5:2  | 108-8660    | 1    | Nut-Mounting               |
| 5:3  | 110-5221    | 1    | Set-Key, Supervisor        |
| 5:4  | 108-8659    | 1    | Washer-Backup              |

| Ref. | Part Number | Qty. | Description          |
|------|-------------|------|----------------------|
| 6    | 95-8999     | 1    | Switch               |
| 7    | 99-7420     | 3    | Plug-Hole            |
| 8    | 33103-012   | 2    | Screw-HHF            |
| 9    | 3234-5      | 3    | Screw-HHF            |
| 10   | 106-5269    | 1    | Ignition Switch ASM  |
| 10:2 | 108-8660    | 1    | Nut-Mounting         |
| 10:3 | 106-5270    | 1    | Ignition Key Set     |
| 10:4 | 108-8659    | 1    | Washer-Backup        |
| 11   | 99-7411     | 1    | Point-Power          |
| 12   | 99-7416     | 1    | Cap                  |
| 14   | 106-7943    | 1    | Cable-Control, Choke |
| 17   | 138-9288    | 1    | Cluster-Instrument   |
| 18   | 94-5627     | 1    | Plug                 |
| 19   | 104-8300    | 3    | Nut-HF, NI           |

● Not serviced separately




## Steering Hydraulic Assembly

| Ref. | Part Number | Qty. | Description                |
|------|-------------|------|----------------------------|
| 1    | 120-4813    | 1    | Pump-Steering              |
| 2    | 98-1471     | 1    | Wheel-Steering             |
| 2:1  | 98-1468     | 1    | Cover-Wheel, Steering      |
| 3    | 94-1444     | 3    | Union-Bulkhead             |
| 3:1  | 237-21      | 2    | O-Ring                     |
| 4    | 106-7974    | 3    | Hose-HYD                   |
| 5    | 106-7975    | 2    | Hose-HYD                   |
| 6    | 340-71      | 2    | Fitting-Straight, Bulkhead |
| 6:1  | 237-22      | 2    | O-Ring                     |
| 8    | 340-70      | 4    | Nut-Lock                   |
| 9    | 106-7804    | 1    | Tube-HYD                   |
| 9:1  | 237-21      | 1    | O-Ring                     |
| 10   | 3219-10     | 6    | Nut-Hex                    |
| 11   | 106-7806    | 1    | Tube-HYD                   |
| 11:1 | 237-21      | 1    | O-Ring                     |
| 13   | 340-132     | 1    | Fitting-Elbow, 90 DEG      |
| 13:1 | 237-78      | 1    | O-Ring                     |
| 13:2 | 237-21      | 1    | O-Ring                     |
| 14   | 98-7977     | 4    | Screw-HHF                  |

| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 15   | 106-7839    | 2    | Clamp-Tube            |
| 16   | 3234-21     | 2    | Screw-HHF             |
| 18   | 104-7201    | 2    | Nut-HF                |
| 19   | 3256-27     | 1    | Washer-Flat           |
| 20   | 3296-33     | 1    | Nut-Lock, NI          |
| 21   | 106-6713    | 1    | Cover-Lines, Steering |
| 22   | 3290-379    | 4    | Tie-Cable             |
| 23   | 108-6505    | 1    | Hose-HYD              |
| 24   | 340-92      | 1    | Fitting-Straight      |
| 24:1 | 237-78      | 1    | O-Ring                |
| 24:2 | 237-21      | 1    | O-Ring                |
| 25   | 115-7701    | 1    | Tube-HYD              |
| 25:1 | 237-22      | 1    | O-Ring                |
| 26   | 115-7702    | 1    | Tube-HYD              |
| 26:1 | 237-22      | 1    | O-Ring                |
| 27   | 115-7703    | 1    | Tube-HYD              |
| 27:1 | 237-21      | 1    | O-Ring                |
| 28   | 56-7973     | 2    | Clamp-Tube            |
| 29   | 117-4861    | 1    | Hose-HYD              |






## Steering Valve Assembly No. 120-4813

| Ref. | Part Number | Qty. | Description       |
|------|-------------|------|-------------------|
| 1    | 106-6716    | 1    | Seal Kit          |
| 1:1  |             | 1    | Ring-Seal, Dust ● |
| 1:2  |             | 1    | Seal-Shaft ●      |
| 1:3  |             | 1    | O-Ring ●          |
| 1:4  |             | 2    | O-Ring ●          |
| 1:5  |             | 5    | O-Ring ●          |

● Not serviced separately




| <b>Ref.</b> | <b>Part Number</b> | <b>Qty.</b> | <b>Description</b>   |
|-------------|--------------------|-------------|----------------------|
| 9           | 119-0727-03        | 2           | Bracket-Belt, Seat   |
| 10          | 119-0731-03        | 1           | Armrest-LH           |
| 11          | 119-0732-03        | 1           | Armrest-RH           |
| 12          | 133-0577           | 2           | Seat ASM             |
| 13          | 33114-030          | 12          | Screw-HH             |
| 14          | 110-0413           | 2           | Seatbelt-Retractable |
| 15          | 3212-4             | 4           | Screw-HH             |
| 16          | 3296-7             | 4           | Nut-Lock             |



## Roll-Over Protection System Assembly


| Ref. | Part Number | Qty. | Description            |
|------|-------------|------|------------------------|
| 2    | 115-2213    | 1    | ROPS Cover ASM         |
| 2:2  | 105-4215    | 1    | Decal-Caution          |
| 3    | 3230-18     | 6    | Screw-CARR             |
| 5    | 32128-20    | 6    | Nut-HF                 |
| 6    | 105-7960    | 1    | Bed Support ASM        |
| 6:2  | 93-9852     | 1    | Decal-Warning          |
| 6:3  | 92-5972     | 4    | Grommet-Rubber         |
| 11   | 3234-38     | 6    | Screw-HHF              |
| 13   | 115-7910    | 1    | ROPS ASM               |
| 13:2 | 106-7767    | 2    | Decal-ROPS             |
| 13:3 | 93-9850     | 1    | Decal-ROPS, CE         |
| 13:4 | 117-4969    | 1    | Decal-ROPS, ISO        |
| 14   | 127-7382    | 2    | Seal-ROPS              |
| 15   | 115-7814    | 1    | Decal-Reference, Quick |



## Full Bed and Side Panel Assembly

| Ref. | Part Number | Qty. | Description              |
|------|-------------|------|--------------------------|
| 1    | 93-9724-03  | 1    | Flatbed-Full             |
| 2    | 133-0645    | 1    | Front Panel ASM          |
| 2:2  | 115-7739    | 1    | Decal-No Riders          |
| 3    | 133-0617    | 1    | Panel-Side, RH           |
| 4    | 133-0616    | 1    | Panel-Side, LH           |
| 5    | 92-1320-03  | 2    | Angle-Side               |
| 6    | 92-1265-03  | 2    | Bracket-Pivot            |
| 7    | 133-0644    | 1    | Tailgate                 |
| 7:2  | 105-4222    | 1    | Decal                    |
| 8    | 106-2423-03 | 1    | Bracket-Spacer, RH       |
| 9    | 106-2422-03 | 1    | Bracket-Spacer, LH       |
| 10   | 93-9720-03  | 2    | Bracket-Pivot, Long (LH) |
| 11   | 93-9721-03  | 2    | Bracket-Pivot, Long (RH) |
| 12   | 93-9575     | 2    | Tube-Pivot, Flatbed      |
| 13   | 99-1123     | 2    | Latch ASM                |
| 13:1 | 92-1271     | 1    | Pivot-Latch              |
| 13:2 | 99-1113     | 1    | Handle-Latch             |
| 13:3 | 99-1112     | 1    | Plate-Retainer           |
| 13:4 | 32121-78    | 1    | Pin-Roll                 |
| 13:5 | 32121-25    | 1    | Pin-Roll                 |


| Ref. | Part Number | Qty. | Description   |
|------|-------------|------|---------------|
| 15   | 93-9719     | 2    | Block-Wear    |
| 16   | 93-9595     | 2    | Lanyard       |
| 17   | 3256-57     | 4    | Washer-Flat   |
| 18   | 92-1233     | 4    | Pin-Clevis    |
| 19   | 92-1298     | 8    | Pin-Lynch     |
| 20   | 32148-7     | 4    | Nut-Clinch    |
| 21   | 32148-6     | 4    | Nut-Clinch    |
| 22   | 3230-18     | 6    | Screw-CARR    |
| 23   | 3234-7      | 21   | Screw-HHF     |
| 24   | 3234-29     | 6    | Screw-HHF     |
| 25   | 3250-45     | 4    | Screw-SPH     |
| 26   | 3296-42     | 4    | Nut-Lock, NI  |
| 27   | 323-42      | 8    | Screw-HH      |
| 28   | 3231-24     | 6    | Screw-CARR    |
| 31   | 3296-44     | 14   | Nut-Lock, NI  |
| 32   | 32128-20    | 27   | Nut-HF        |
| 33   | 115-7913    | 2    | Decal         |
| 35   | 93-9868     | 2    | Decal-Caution |
| 36   | 93-9899     | 2    | Decal-Warning |



## Engine Sub Frame Assembly

| Ref. | Part Number | Qty. | Description          |
|------|-------------|------|----------------------|
| 1    | 115-2257-03 | 1    | Engine Support ASM   |
| 2    | 106-7865    | 2    | Mount-Engine         |
| 3    | 115-2352-03 | 1    | Engine Mount ASM     |
| 4    | 112-2983    | 1    | Pump-Gear, Hydraulic |
| 5    | 87-7740     | 1    | Pulley               |
| 6    | 87-8170     | 1    | Fitting-90           |
| 6:1  | 237-80      | 1    | O-Ring               |
| 7    | 340-18      | 1    | Fitting-HYD, 90 DEG  |
| 7:1  | 237-79      | 1    | O-Ring               |
| 7:2  | 237-22      | 1    | O-Ring               |
| 8    | 87-4730-03  | 2    | Guard-Belly          |
| 9    | 76-9100     | 6    | Spacer               |
| 10   | 3290-413    | 12   | Washer-Belleville    |
| 11   | 3234-11     | 6    | Screw-HHF            |
| 12   | 104-8301    | 6    | Nut-HF, NI           |

| Ref. | Part Number | Qty. | Description     |
|------|-------------|------|-----------------|
| 13   | 3230-22     | 1    | Screw-CARR      |
| 14   | 3234-29     | 1    | Screw-HHF       |
| 15   | 104-8300    | 2    | Nut-HF, NI      |
| 16   | 3256-45     | 1    | Washer-Flat     |
| 17   | 3296-5      | 1    | Nut-Hex         |
| 18   | 2412-129    | 1    | Clamp-Hose      |
| 19   | 324-13      | 2    | Screw-HH        |
| 20   | 87-5100     | 2    | Washer-Snubbing |
| 21   | 114-8417    | 2    | Nut-HF, NI      |
| 22   | 87-8370     | 1    | V-Belt          |
| 23   | 3290-379    | 6    | Tie-Cable       |
| 24   | 3272-37     | 2    | Pin-Cotter      |
| 25   | 87-8030     | 1    | Hose-Suction    |
| 26   | 121-6283    | 1    | Hose-HYD        |




## Hydraulic Gear Pump Assembly No. 112-2983

| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 1    |             | 1    | Body ●                |
| 2    |             | 1    | Cover-Front ●         |
| 3    |             | 1    | Cover-Rear ●          |
| 4    |             | 1    | Plate-Thrust ●        |
| 5    |             | 1    | Plate-Thrust, Upper ● |
| 6    |             | 1    | Shaft-Drive ●         |
| 7    |             | 1    | Gear-Driven ●         |
| 8    |             | 4    | Screw-HH ●            |
| 9    |             | 4    | Washer ●              |
| 10   |             | 2    | O-Ring Seal ●         |

| Ref. | Part Number | Qty. | Description            |
|------|-------------|------|------------------------|
| 11   |             | 1    | Seal ●                 |
| 12   |             | 1    | Seal-Upper ●           |
| 13   |             | 1    | Seal-Shaft ●           |
| 14   |             | 1    | Ring-Clip ●            |
| 15   |             | 1    | Seal-Extrusion, Anti ● |
| 16   |             | 1    | Seal-Extrusion, Anti ● |
| 17   | 115-7856    | 1    | Key-Square             |
| 18   |             | 1    | Pin-Dowel ●            |
| 19   | 112-0199    | 1    | Seal Kit               |

● Not serviced separately




## Engine Assembly

| Ref. | Part Number | Qty. | Description               |
|------|-------------|------|---------------------------|
| 1    | 107-7991    | 1    | Adapter-Clutch            |
| 2    | 115-7819    | 1    | Engine-Kohler, Ch680-3025 |
| 2:1  | 108-3847    | 1    | Filter-Oil ●              |
| 3    | 3256-25     | 4    | Washer-Flat               |
| 4    | 3253-6      | 4    | Washer-Lock               |
| 5    | 324-4       | 4    | Screw-HH                  |
| 6    | 3257-5      | 1    | Key-Woodruff              |
| 7    | 120-4893    | 1    | Flywheel                  |
| 8    | 87-6080     | 1    | Washer                    |
| 9    | 3274-63     | 1    | Screw-HSBH                |
| 10   | 87-6460     | 1    | Bearing-Ball (W/Seal)     |
| 11   | 87-4700     | 1    | Disc-Clutch               |
| 12   | 87-4690     | 1    | Cover-Clutch              |
| 13   | 3253-4      | 6    | Washer-Lock               |
| 14   | 33114-016   | 6    | Screw-HH                  |
| 15   | 42-7160     | 3    | Pin                       |
| 16   | 87-7710     | 1    | Pulley ASM                |
| 17   | 3257-7      | 1    | Key-Woodruff              |

| Ref. | Part Number | Qty. | Description        |
|------|-------------|------|--------------------|
| 18   | 3256-28     | 1    | Washer-Flat        |
| 19   | 3296-15     | 1    | Nut-Lock, NI       |
| 20   | 121-9659-03 | 1    | Bracket-Throttle   |
| 21   | 32144-4     | 4    | Screw-HWH          |
| 22   | 32128-33    | 2    | Nut-HF             |
| 23   | 329-6       | 1    | Screw-HH           |
| 24   | 7-0030      | 1    | Screw-Shoulder, HH |
| 25   | 104-8300    | 1    | Nut-HF, NI         |
| 26   | 329-7       | 1    | Screw-HH           |
| 27   | 87-7790     | 1    | Lever-Choke        |
| 28   | 87-7800     | 1    | Lever-Throttle     |
| 29   | 119-4881    | 1    | Bolt-Shoulder      |
| 31   | 67-1450     | 1    | Spring-Idler       |
| 32   | 80-8040     | 1    | Decal-Warning      |
| 33   | 120-4980    | 1    | Cable-Throttle     |
| 34   | 3290-379    | 1    | Tie-Cable          |
| 35   | 3234-19     | 4    | Screw-HHF          |
| 36   | 104-8301    | 4    | Nut-HF, NI         |

● Not illustrated




## Engine Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|------|-------------|------|-------------|
| 37   | 3274-15     | 1    | Screw-HSH   |
| 39   | 3220-1      | 2    | Nut-Jam     |
| 40   | 3255-9      | 1    | Washer-Lock |

| Ref. | Part Number | Qty. | Description                |
|------|-------------|------|----------------------------|
| 41   | 99-3441     | 1    | Harness-Wire, Fusible Link |
| 42   | 117-5612    | 1    | Harness-Wire, Ground       |


● Not illustrated





## Muffler Assembly

| Ref. | Part Number | Qty. | Description          |
|------|-------------|------|----------------------|
| 1    | 106-7855    | 1    | Manifold-Cooled, Air |
| 2    | 110-6697    | 2    | Gasket-Exhaust       |
| 3    | 106-7880-03 | 1    | Mount-Angle          |
| 4    | 3234-5      | 3    | Screw-HHF            |
| 5    | 32128-20    | 9    | Nut-HF               |
| 6    | 133-0613    | 1    | Muffler              |
| 7    | 105-4209    | 1    | Gasket-Muffler       |
| 8    | 3234-17     | 4    | Screw-HHF            |
| 9    | 98-7977     | 1    | Screw-HHF            |
| 10   | 105-9472    | 1    | Plate-Mount, Muffler |
| 11   | 3230-1      | 2    | Bolt-CARR            |
| 12   | 33104-030   | 1    | Screw-HHF            |




## Clutch Linkage Assembly

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|-------------------------|
| 1           | 104-9249           | 1           | Housing-Bell            |
| 2           | 120-4886           | 1           | Guide-Release           |
| 3           | 33104-025          | 3           | Screw-HHF               |
| 4           | 115-2313           | 1           | Bracket-Cable, Clutch   |
| 5           | 98-7977            | 2           | Screw-HHF               |
| 6           | 110-2538           | 1           | Bearing-Release, Clutch |
| 7           | 87-5300            | 1           | Fork-Clutch             |
| 8           | 115-2311           | 1           | Lever-Clutch            |
| 9           | 87-1920            | 2           | Seal-Oil                |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       |
|-------------|--------------------|-------------|--------------------------|
| 10          | 87-3770            | 2           | Bushing-Housing, Bell    |
| 11          | 87-1910            | 4           | Pin-Dowel                |
| 12          | 33104-040          | 9           | Screw-HHF                |
| 13          | 115-2247           | 2           | Bracket-Harness          |
| 14          | 107-7983           | 6           | Screw-HH                 |
| 15          | 32121-7            | 1           | Pin-Roll, Slotted        |
| 16          | 32121-24           | 2           | Pin-Spring               |
| 17          | 2411-33            | 1           | Balljoint-RH (W/Grommet) |
| 18          | 3296-4             | 1           | Nut-Lock                 |




| <b>Ref.</b> | <b>Part Number</b> | <b>Qty.</b> | <b>Description</b>      |
|-------------|--------------------|-------------|-------------------------|
| 17          | 87-2310            | 2           | Clevis-Cable            |
| 18          | 283-62             | 3           | Pin-Clevis              |
| 19          | 3290-307           | 3           | Pin-Cotter              |
| 20          | 92-3735            | 1           | Seal-Sensor, Oil        |
| 21          | 115-7774           | 1           | Plug ASM                |
| 23          | 3290-357           | 1           | Nut-HHF, Whiz           |
| 24          | 87-6710            | 1           | Switch-Transmission     |
| 25          | 3220-1             | 2           | Nut-Jam                 |
| 26          | 115-2240-03        | 1           | Bracket-Fuel            |
| 27          | 115-7741           | 1           | Decal-Oil, Transmission |
| 28          | 3290-379           | 1           | Tie-Cable               |
| 29          | 33104-030          | 1           | Screw-HHF               |
| 30          | 87-3990            | 1           | Strainer-Transaxle      |
| 30:1        | 237-123            | 1           | O-Ring                  |
| 31          | 353-987            | 1           | Fitting-Elbow, 90       |
| 31:1        | 237-81             | 1           | O-Ring                  |



## Case Assembly Transaxle Assembly No. 115-7783


| Ref. | Part Number | Qty. | Description         |
|------|-------------|------|---------------------|
| 2    | 92-0651     | 1    | Case-Transmission   |
| 3    | 92-0810     | 1    | Cover-Upper, Sensor |
| 4    | 92-0653     | 1    | Cover-Side          |
| 5    | 92-0655     | 1    | Cover-Seal, Axle    |
| 6    | 92-0656     | 1    | Cover-Upper, PTO    |
| 7    | 92-0743     | 1    | Breather-Air        |
| 8    | 92-0662     | 1    | Cap-Oil             |
| 9    | 92-0762     | 1    | Washer-Spring       |
| 10   | 92-0765     | 4    | Pin-Parallel        |
| 11   | 92-0773     | 1    | Plug-Drain          |

| Ref. | Part Number | Qty. | Description             |
|------|-------------|------|-------------------------|
| 12   | 92-0787     | 1    | O-Ring                  |
| 13   | 92-0788     | 1    | O-Ring                  |
| 14   | 92-0790     | 1    | O-Ring                  |
| 15   | 92-0793     | 1    | Seal-Oil                |
| 16   | 92-0796     | 5    | Bolt                    |
| 17   | 33104-025   | 4    | Screw-HHF               |
| 18   | 33104-025   | 4    | Screw-HHF               |
| 19   | 33104-040   | 10   | Screw-HHF               |
| 20   | 92-0805     | 1    | Bolt 8X20               |
| 21   | 68-9400     | 1    | Nut-Flange [f/W Engine] |



## Center Plate Assembly Transaxle Assembly No. 115-7783


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 100-4461           | 1           | Plate-Center       |
| 2           | 100-4460           | 1           | Shim-Set           |
| 3           | 92-0706            | 1           | Shaft-Fork         |
| 4           | 92-0759            | 1           | Ring-Snap          |
| 5           | 92-0791            | 1           | Seal-Oil           |
| 6           | 33104-025          | 3           | Screw-HHF          |
| 7           | 33104-040          | 15          | Screw-HHF          |
| 8           | 33104-050          | 1           | Screw-HHF          |
| 9           | 92-0807            | 1           | Cap-Sealing        |
| 10          | 100-4465           | 1           | Shim (W/Tab)       |



## Main Shaft Assembly Transaxle Assembly No. 115-7783

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   |
|-------------|--------------------|-------------|----------------------|
| 1           | 92-0663            | 1           | Shaft-Main           |
| 2           | 92-0664            | 1           | Hub-Synchro          |
| 3           | 92-0665            | 3           | Key-Synchro          |
| 4           | 92-0666            | 2           | Spring-Synchro       |
| 5           | 92-0667            | 2           | Ring-Synchro         |
| 6           | 92-0668            | 1           | Shifter-Synchro      |
| 7           | 92-0672            | 1           | Gear-Main, 18 Tooth  |
| 8           | 92-0673            | 1           | Gear-Main, 14 Tooth  |
| 9           | 110-2521           | 1           | Gear-Main, 27 Tooth  |
| 10          | 110-2522           | 1           | Gear- Main, 24 Tooth |


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|---------------------|
| 11          | 92-0687            | 1           | Gear-Main, 16 Tooth |
| 12          | 92-0740            | 2           | Washer-Thrust       |
| 13          | 92-0650            | 1           | Bearing             |
| 14          | 92-0753            | 1           | Ring-Snap           |
| 15          | 92-0754            | 1           | Ring-Snap           |
| 16          | 92-0763            | 2           | Ring-Snap           |
| 17          | 92-0772            | 1           | Key                 |
| 18          | 251-8              | 1           | Bearing-Ball        |
| 19          | 92-0781            | 4           | Bearing-Needle      |



## Reduction Shaft Assembly Transaxle Assembly No. 115-7783

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>        |
|-------------|--------------------|-------------|---------------------------|
| 1           | 92-0664            | 1           | Hub-Synchro               |
| 2           | 92-0665            | 3           | Key-Synchro               |
| 3           | 92-0666            | 2           | Spring-Synchro            |
| 4           | 92-0667            | 1           | Ring-Synchro              |
| 5           | 92-0668            | 1           | Shifter-Synchro           |
| 6           | 92-0674            | 1           | Shaft-Reduction           |
| 7           | 110-2524           | 1           | Gear- Reduction, 49 Tooth |
| 8           | 92-0819            | 1           | Gear-Reduction, 40 Tooth  |
| 9           | 92-0679            | 1           | Gear-Reduction, H23 Tooth |
| 10          | 92-0680            | 1           | Collar                    |


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       |
|-------------|--------------------|-------------|--------------------------|
| 11          | 92-0681            | 2           | Bearing-Needle           |
| 12          | 92-0682            | 1           | Washer-Thrust            |
| 13          | 92-0822            | 1           | Gear-Reduction, 28 Tooth |
| 14          | 92-0823            | 1           | Gear-Reduction, 43 Tooth |
| 15          | 92-0740            | 1           | Washer-Thrust            |
| 16          | 92-0763            | 1           | Ring-Snap                |
| 17          | 92-0772            | 1           | Key                      |
| 18          | 105-7985           | 1           | Bearing                  |
| 19          | 92-0778            | 1           | Bearing                  |
| 20          | 92-0782            | 1           | Bearing-Needle           |



## Reverse Shaft Assembly Transaxle Assembly No. 115-7783


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     |
|-------------|--------------------|-------------|------------------------|
| 1           | 92-0684            | 1           | Gear-Reverse, 33 Tooth |
| 2           | 92-0824            | 1           | Shaft-Idler, Reverse   |
| 3           | 251-346            | 1           | Bearing-Ball           |
| 4           | 92-0778            | 1           | Bearing                |






## Main Shift Assembly Transaxle Assembly No. 115-7783

| Ref. | Part Number | Qty. | Description  |
|------|-------------|------|--------------|
| 1    | 92-0698     | 1    | Shaft-Fork   |
| 2    | 92-0699     | 1    | Shaft-Fork   |
| 3    | 92-0700     | 1    | Fork-Shift   |
| 4    | 92-0701     | 1    | Fork-Shift   |
| 5    | 92-0705     | 1    | Lock-Spindle |
| 6    | 92-0729     | 2    | Seal-Oil     |
| 7    | 92-0816     | 1    | Arm-Shift    |
| 8    | 92-0817     | 1    | Arm-Shift    |
| 9    | 92-0731     | 2    | Spring       |
| 10   | 92-0732     | 2    | Plate-Keeper |
| 11   | 92-0769     | 2    | Pin-Roll     |
| 12   | 92-0785     | 2    | Ball-Steel   |
| 13   | 33104-016   | 2    | Screw-HHF    |




## Hi-Lo Shift Assembly Transaxle Assembly No. 115-7783

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 92-0729            | 1           | Seal-Oil           |
| 2           | 92-0818            | 1           | Arm-Shift          |
| 3           | 92-0731            | 1           | Spring             |
| 4           | 92-0708            | 1           | Shaft-Fork         |
| 5           | 92-0709            | 1           | Fork-Shift         |
| 6           | 92-0732            | 1           | Plate-Keeper       |
| 7           | 92-0761            | 1           | Ring-E             |
| 8           | 92-0785            | 1           | Ball-Steel         |
| 9           | 33104-016          | 1           | Screw-HHF          |




## Countershaft Assembly Transaxle Assembly No. 115-7783

| Ref. | Part Number | Qty. | Description                    |
|------|-------------|------|--------------------------------|
| 1    | 92-0741     | 1    | Washer-Thrust                  |
| 2    | 105-7983    | 1    | Countershaft And Ring Gear ASM |
| 3    | 92-0711     | 2    | Washer-Thrust                  |
| 4    | 92-0713     | 1    | Collar                         |
| 5    | 92-0714     | 2    | Bearing                        |
| 6    | 92-0715     | 1    | Gear-Countershaft              |
| 7    | 92-0716     | 1    | Collar                         |
| 8    | 92-0717     | 1    | Gear-Countershaft              |
| 10   | 92-0718     | 1    | Shifter                        |
| 11   | 105-7986    | 1    | Collar-Spline                  |
| 12   | 92-0712     | 1    | Bearing-Ball                   |
| 13   | 105-7987    | 2    | Ring-Snap                      |
| 14   | 92-0755     | 1    | Ring-Snap                      |
| 15   | 92-0783     | 1    | Race-Inner                     |
| 16   | 92-0759     | 1    | Ring-Snap                      |




## Differential Gear Assembly Transaxle Assembly No. 115-7783

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    |
|-------------|--------------------|-------------|-----------------------|
| 1           | 92-0745            | 1           | Gear-Side, LH         |
| 2           | 92-0746            | 1           | Gear-Side, RH         |
| 3           | 92-0747            | 2           | Side-Gear, Left Inner |
| 4           | 92-0748            | 2           | Pinion-Differential   |
| 5           | 92-0749            | 1           | Shaft-Pinion          |
| 6           | 92-0750            | 2           | Washer                |
| 7           | 92-0720            | 1           | Case-Differential     |
| 8           | 92-0756            | 1           | Ring-Snap             |
| 9           | 92-0765            | 2           | Pin-Parallel          |
| 10          | 92-0768            | 1           | Pin-Roll, Spring      |
| 11          | 92-0775            | 1           | Bearing               |
| 12          | 92-0776            | 1           | Bearing               |
| 13          | 92-0803            | 12          | Bolt                  |




## Differential Carrier Assembly Transaxle Assembly No. 115-7783

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   |
|-------------|--------------------|-------------|----------------------|
| 1           | 92-0654            | 1           | Carrier-Differential |
| 2           | 92-0809            | 1           | Set-Shim             |
| 3           | 92-0760            | 1           | Ring-Snap            |
| 4           | 92-0789            | 1           | O-Ring               |
| 5           | 92-0793            | 1           | Seal-Oil             |
| 6           | 33104-030          | 5           | Screw-HHF            |




## Differential Lock Assembly Transaxle Assembly No. 115-7783

| Ref. | Part Number | Qty. | Description                   |
|------|-------------|------|-------------------------------|
| 1    | 92-0730     | 1    | Slider-Differential, Lock     |
| 2    | 92-0721     | 1    | Fork-Lock, Differential       |
| 3    | 92-0722     | 1    | Shaft-Fork, Lock Differential |
| 4    | 92-0723     | 1    | Spring-Lock, Differential     |
| 5    | 92-0744     | 1    | Washer                        |
| 6    | 92-0724     | 1    | Arm-Lock, Differential        |
| 7    | 92-0733     | 1    | Washer                        |
| 8    | 92-0753     | 1    | Ring-Snap                     |
| 9    | 92-0768     | 1    | Pin-Roll, Spring              |
| 10   | 92-0770     | 1    | Pin-Roll, Spring              |
| 11   | 92-0771     | 1    | Pin-Roll, Spring              |
| 12   | 92-0787     | 1    | O-Ring                        |



## Axle Shaft Assembly Transaxle Assembly No. 115-7783


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 92-0725            | 1           | Shaft-Axle, Left   |
| 2           | 92-0726            | 1           | Shaft-Axle, Right  |
| 3           | 92-0727            | 2           | Washer             |
| 4           | 92-0728            | 1           | Washer             |
| 5           | 92-0756            | 2           | Ring-Snap          |
| 6           | 92-0775            | 1           | Bearing            |
| 7           | 92-0780            | 1           | Bearing            |



## Battery Assembly

| Ref. | Part Number | Qty. | Description             |
|------|-------------|------|-------------------------|
| 1    | 115-2237-03 | 1    | Tray-Battery            |
| 2    | 3230-6      | 1    | Bolt-CARR               |
| 3    | 66-2490     | 1    | Retainer-Battery        |
| 4    | 104-8300    | 3    | Nut-HF, NI              |
| 5    | 94-5780     | 2    | Screw-HWH               |
| 7    | 119-9496    | 1    | Cover-Battery           |
| 8    | 122-0204    | 1    | Cable-Battery, Positive |
| 9    | 122-0120    | 1    | Cable-Battery, Negative |
| 10   | 106-5187    | 1    | Battery-Dry             |






## Tail Light and Fender Assembly

| Ref. | Part Number | Qty. | Description                |
|------|-------------|------|----------------------------|
| 1    | 132-6701    | 2    | Fender-Rear                |
| 2    | 93-8943-03  | 1    | Bracket-Fender, Rear (LH)  |
| 3    | 93-8944-03  | 1    | Bracket-Fender, Rear (RH)  |
| 4    | 93-8941-03  | 1    | Bracket-Fender, Front (LH) |
| 5    | 93-8942-03  | 1    | Bracket-Fender, Front (RH) |
| 6    | 121-6269-03 | 2    | Bracket-Light, Tail        |
| 7    | 120-4820    | 2    | Light-Tail, Brake          |
| 7:1  | 115-7858    | 1    | Bulb-7528                  |
| 7:2  | 121-6271    | 1    | Lens-Light, Tail           |


| Ref. | Part Number | Qty. | Description         |
|------|-------------|------|---------------------|
| 7:3  | 121-6272    | 2    | Screw-PPH           |
| 8    | 2412-93     | 2    | Clamp-R             |
| 10   | 3234-17     | 4    | Screw-HHF           |
| 11   | 104-8300    | 4    | Nut-HF, NI          |
| 12   | 32105-15    | 12   | Screw-HWH           |
| 13   | 105-6245    | 6    | Screw-Tapping       |
| 14   | 104-7201    | 12   | Nut-HF              |
| 15   | 43-5920     | 4    | Washer-Lock, Spring |
| 16   | 121-6320    | 4    | Screw-HH            |



## Fuel System Assembly

| Ref. | Part Number | Qty. | Description       |
|------|-------------|------|-------------------|
| 1    | 115-7767-03 | 1    | Tube-Support      |
| 2    | 94-5780     | 2    | Screw-HWH         |
| 3    | 104-8300    | 4    | Nut-HF, NI        |
| 4    | 115-7700    | 1    | Tank-Fuel         |
| 5    | 115-2163    | 1    | Gasket-Pump, Fuel |
| 6    | 114-8348    | 1    | Sender-Fuel       |
| 7    | 115-2162    | 1    | Cap-Pump, Fuel    |
| 8    | 114-0284    | 1    | Grommet           |
| 9    | 114-0285    | 1    | Valve-Rollover    |
| 10   | 114-8404    | 1    | Plate-Retainer    |
| 11   | 32144-70    | 2    | Screw-HWHTF       |
| 12   | 137-4127    | 1    | Cap-Fuel          |
| 13   | 127-8685    | 1    | Canister-Carbon   |
| 14   | 2412-148    | 1    | Clamp-R           |
| 15   | 108-3854    | 1    | Filter-Fuel       |
| 16   | 3234-4      | 1    | Screw-HHF         |


| Ref. | Part Number | Qty. | Description         |
|------|-------------|------|---------------------|
| 17   | 32128-33    | 1    | Nut-HF              |
| 18   | 92-2379     | 1    | Clamp-Hose          |
| 19   | 2412-98     | 3    | Clamp-Hose          |
| 20   | 115-2403    | 1    | Cap                 |
| 21   | 106-5317    | 1    | Hose-Fuel           |
| 22   | 115-7854    | 1    | Filter-Fuel, Inline |
| 23   | 133-8499    | 1    | Valve-Check, Vacuum |
| 24   | 2412-79     | 1    | Clamp-Hose          |
| 25   | 2412-146    | 1    | Clamp-Hose          |
| 26   | 110-3372    | 1    | Hose-Fuel           |
| 27   | 109-0281    | 1    | Hose-Fuel           |
| 28   | 115-7871    | 1    | Hose-Fuel           |
| 29   | 115-7872    | 1    | Hose-Fuel           |
| 30   | 110-3254    | 1    | Hose-Fuel           |
| 31   | 3290-379    | 1    | Tie-Cable           |



## Hydraulic Lift Cylinder Assembly

| Ref. | Part Number | Qty. | Description              |
|------|-------------|------|--------------------------|
| 1    | 24-7922     | 1    | Conduit-Convolved, Split |
| 2    | 24-7923     | 2    | Conduit-Convolved, Split |
| 3    | 54-0110     | 1    | Filter-Oil, Transmission |
| 4    | 56-7971     | 2    | Clamp-Tube               |
| 5    | 56-7976     | 6    | Clamp-Tube               |
| 6    | 87-8780     | 1    | Head-Filter              |
| 7    | 100-4887    | 1    | Fitting-Elbow, 90        |
| 7:1  | 237-42      | 1    | O-Ring                   |
| 8    | 104-7201    | 2    | Nut-HF                   |
| 9    | 104-8300    | 2    | Nut-HF, NI               |
| 10   | 106-7881    | 2    | Cap-Dust, HYD            |
| 11   | 106-7882    | 2    | Plug-Dust, HYD           |
| 12   | 133-0620    | 2    | HYD Cylinder ASM         |
| 13   | 106-7968    | 2    | Coupler-Quick, Female    |
| 14   | 106-7969    | 2    | Coupler-Quick, Male      |
| 15   | 115-2168-03 | 1    | Bracket-Filter           |
| 16   | 103-1807    | 1    | Fitting-Barbed, 45 DEG   |
| 16:1 | 237-42      | 1    | O-Ring                   |
| 17   | 115-7715    | 1    | Coupler Bracket ASM      |
| 17:2 | 115-7723    | 1    | Decal-Disconnect, Quick  |
| 18   | 340-132     | 4    | Fitting-Elbow, 90 DEG    |


| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 18:1 | 237-78      | 1    | O-Ring                |
| 18:2 | 237-21      | 1    | O-Ring                |
| 19   | 340-2       | 2    | Fitting-Straight      |
| 19:1 | 237-22      | 1    | O-Ring                |
| 19:2 | 237-42      | 1    | O-Ring                |
| 20   | 340-21      | 2    | Fitting               |
| 20:1 | 237-21      | 3    | O-Ring                |
| 21   | 340-82      | 2    | Fitting-Elbow, 90 DEG |
| 21:1 | 237-42      | 1    | O-Ring                |
| 21:2 | 237-21      | 1    | O-Ring                |
| 22   | 2412-36     | 2    | Clamp-Hose            |
| 23   | 3234-4      | 4    | Screw-HHF             |
| 24   | 3290-148    | 1    | Nut-HF                |
| 25   | 3290-379    | 6    | Tie-Cable             |
| 26   | 32105-13    | 1    | Screw-HWH             |
| 27   | 32144-57    | 4    | Screw                 |
| 28   | 32151-83    | 2    | Ring-Snap             |
| 29   | 115-7711    | 1    | Hose-HYD              |
| 30   | 108-6508    | 1    | Hose-HYD              |
| 31   | 104-3716    | 1    | Hose-HYD              |
| 32   | 115-2228    | 1    | Hose-HYD              |



## Hydraulic Lift Cylinder Assembly (continued)


| Ref. | Part Number | Qty. | Description |
|------|-------------|------|-------------|
| 33   | 110-0931    | 1    | Hose-HYD    |
| 34   | 106-3680    | 2    | Hose-HYD    |
| 35   | 3234-5      | 2    | Screw-HHF   |

| Ref. | Part Number | Qty. | Description     |
|------|-------------|------|-----------------|
| 40   | 353-397     | 1    | Reducer-Adapter |
| 40:1 | 237-79      | 1    | O-Ring          |



## Hydraulic Cylinder Assembly No. 133-0620


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 133-0618           | 1           | Cylinder Seal Kit  |
| 2           | 93-9852            | 1           | Decal-Warning      |



## Lift Valve Assembly

| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 1    | 43-1950     | 1    | HYD Control Valve ASM |
| 2    | 56-7973     | 4    | Clamp-Tube            |
| 3    | 94-5781     | 2    | Screw-HHF             |
| 4    | 104-7201    | 4    | Nut-HF                |
| 7    | 114-8410    | 2    | Screw-HHF             |
| 8    | 127-8605    | 1    | Tube-HYD              |
| 9    | 115-2217    | 1    | Tube-HYD              |
| 10   | 115-2218    | 1    | Tube-HYD              |
| 11   | 127-8604    | 1    | Tube-HYD              |
| 11:1 | 237-22      | 1    | O-Ring                |
| 11:2 | 340-117     | 1    | Cap                   |
| 12   | 127-8752    | 1    | Tube-HYD              |
| 12:1 | 237-22      | 1    | O-Ring                |
| 12:2 | 340-117     | 1    | Cap                   |
| 13   | 340-18      | 1    | Fitting-HYD, 90 DEG   |


| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 13:1 | 237-79      | 1    | O-Ring                |
| 13:2 | 237-22      | 1    | O-Ring                |
| 14   | 340-77      | 1    | Fitting-Elbow, 90 DEG |
| 14:1 | 237-22      | 1    | O-Ring                |
| 14:2 | 237-42      | 1    | O-Ring                |
| 15   | 340-88      | 1    | Fitting-Straight      |
| 15:1 | 237-22      | 1    | O-Ring                |
| 15:2 | 237-78      | 1    | O-Ring                |
| 16   | 340-94      | 1    | Adapter               |
| 16:1 | 237-22      | 2    | O-Ring                |
| 16:2 | 237-42      | 1    | O-Ring                |
| 17   | 340-97      | 1    | Fitting-Elbow, 90 DEG |
| 17:1 | 237-22      | 1    | O-Ring                |
| 17:2 | 237-78      | 1    | O-Ring                |



## Control Valve Assembly No. 43-1950

| Ref. | Part Number | Qty. | Description |
|------|-------------|------|-------------|
| 1    | 22-8330     | 2    | Plug        |
| 2    | 237-42      | 2    | O-Ring      |
| 3    | 22-8340     | 2    | Spring      |
| 4    | 22-8350     | 2    | Ball        |
| 5    | 22-8370     | 2    | Seat-Valve  |
| 6    | 22-8360     | 2    | Pin         |
| 7    |             | 1    | Body ●      |
| 8    | 22-8420     | 1    | Spool       |
| 9    | 22-8500     | 2    | O-Ring      |
| 10   | 22-8380     | 2    | Retainer    |
| 11   | 22-8410     | 1    | Spring      |
| 12   | 23-3030     | 1    | Spacer      |
| 13   | 22-8480     | 1    | Ring-Snap   |
| 14   | 22-8490     | 1    | Ring-Snap   |

● Not serviced separately



## Front and Rear Wire Harness Assembly

| Ref. | Part Number | Qty. | Description                       |
|------|-------------|------|-----------------------------------|
| 1    | 132-6714-03 | 1    | Bracket-Mount, Filter             |
| 2    | 107069      | 2    | Clip                              |
| 3    | 3234-4      | 2    | Screw-HHF                         |
| 4    | 99-7435     | 1    | Relay                             |
| 5    | 32144-112   | 3    | Screw-HWH                         |
| 6    | 99-7430     | 3    | Relay-Mini                        |
| 7    | 32144-10    | 1    | Screw-HWH                         |
| 8    | 122-1450    | 1    | Harness-Wire, Front               |
| 8:8  | 218-578     | 5    | Fuse-Blade, 10 Amp                |
| 8:9  | 109355      | 2    | Fuse-Blade, 15 Amp                |
| 8:11 | 100-4918    | 2    | Diode                             |
| 8:17 | 32180-156   | 1    | Cap-Plug, 6 Way                   |
| 9    | 114-8380    | 1    | Harness-Wire, Rear                |
| 9:1  | 100-4918    | 1    | Diode                             |
| 9:2  | 119-7787    | 1    | Harness-Wire, Vertical Lift Shunt |



# Attachments and Accessories

## For 07369 Workman HD Utility Vehicle with Bed

| Product Name                                           | Model/Part |
|--------------------------------------------------------|------------|
| Pro Sweep Turf Sweeper.....                            | 07068      |
| 2/3 Area Flatbed .....                                 | 07321      |
| 2/3 Area Flatbed Side Kit .....                        | 07322      |
| Bed Liner .....                                        | 07331      |
| Automatic Tailgate Release Kit .....                   | 92-1220    |
| Topdresser 1800 .....                                  | 44225      |
| Topdresser 1800 Lift Kit .....                         | 92-4452    |
| 1/3 Area Flatbed .....                                 | 07341      |
| 1/3 Area Platform Lift .....                           | 07347      |
| Hitch Asm .....                                        | 131-3462   |
| ProCore Processor .....                                | 09749      |
| Topdresser 2500 .....                                  | 44507      |
| Core Harvester Adapter Kit .....                       | 44242      |
| Synthetic Turf Conditioner, Tow-Behind Accessory ..... | 08791      |
| Rear PTO Kit .....                                     | 07419      |
| Multi Pro WM Turf Sprayer .....                        | 41240      |
| Cab Kit .....                                          | 07392      |
| Door Kit with Sliding Window .....                     | 07393      |
| Beacon Kit .....                                       | 130-5484   |
| 12 Inch Rear Wheel Weights .....                       | 81115      |
| Exterior Mirror Kit .....                              | 130-5448   |
| Worklight Kit .....                                    | 117-4827   |
| Backup Alarm Kit .....                                 | 107-8037   |
| Hand Throttle Kit .....                                | 07420      |
| Side Mirror Kit .....                                  | 115-7849   |
| Tailpipe Extension Kit .....                           | 127-7397   |
| Fold Down Side Kit .....                               | 07303      |
| Tire-Rear, 24x13-12 .....                              | 110-5132   |
| Tire-Rear, 23x8.50-12 .....                            | 98-2993    |
| Spark Arrestor Screen .....                            | 94-8157    |
| PTO Over Running Clutch Kit .....                      | 92-2655    |
| Fuse Block .....                                       | 92-2641    |
| 1/3 Area Cover Kit .....                               | 127-8739   |
| Remote Hydraulic Float Kit .....                       | 117-4828   |
| Canopy .....                                           | 07372      |
| Windshield .....                                       | 07373      |
| Full Area Flatbed .....                                | 07301      |
| Full Area Flatbed Side Kit .....                       | 07302      |
| Premium ATF (Drum) .....                               | 108-1185   |
| Premium ATF (Pail) .....                               | 108-1186   |
| Premium All Purpose Grease (Tube) .....                | 108-1190   |
| Horn Kit .....                                         | 115-7825   |
| Remote Hydraulics Manifold Kit .....                   | 110-2626   |
| Roll-Over Protection System Signal Kit .....           | 117-4825   |
| 4 Post Roll-Over Protection System .....               | 07378      |
| Receiver Hitch Kit .....                               | 117-4831   |

## Attachments and Accessories (continued)

|                                                                                        |          |
|----------------------------------------------------------------------------------------|----------|
| Trailer Signal Kit .....                                                               | 117-4836 |
| Trailer Brake Kit .....                                                                | 125-0123 |
| Tire and Wheel Asm .....                                                               | 131-8432 |
| Canopy for Four-Post Roll-Over Protection System Kit .....                             | 119-9457 |
| Tire-Rear, Industrial .....                                                            | 99-1091  |
| Wheel-12in x 8.0in .....                                                               | 114-8260 |
| Road Light and Homologation Kit .....                                                  | 120-5030 |
| Brake and Signal Light Kit .....                                                       | 120-5045 |
| ProPass 200 Top Dresser with Twin Spinner and Wireless Control .....                   | 44751    |
| ProPass 200 Top Dresser with Twin Spinner .....                                        | 44701    |
| Pro Force Debris Blower .....                                                          | 44553    |
| Pro Force Debris Blower .....                                                          | 44552    |
| Work Light Kit .....                                                                   | 130-5485 |
| Interior Mirror Kit .....                                                              | 130-5449 |
| Windshield Washer Fluid Kit, 2015 and after Workman MD/HD Series Utility Vehicle ..... | 130-5615 |
| Tachometer And Speedometer Kit .....                                                   | 115-7786 |
| LED Worklight Kit .....                                                                | 133-0554 |
| ROPS Beacon Kit .....                                                                  | 133-0609 |
| Aggressive Tire Kit .....                                                              | 07422    |
| Bracket-light, Canopy .....                                                            | 133-0627 |
| Pro Force Debris Blower .....                                                          | 44554    |
| Wheel/Tire ASM, A404 (20X9-12)Smooth .....                                             | 136-6334 |
| Wheel/Tire ASM, A404 (24X12-12)Smooth .....                                            | 136-6335 |
| Wheel/Tire ASM, A502 (20X9-12)Semi-Aggressive .....                                    | 136-6308 |
| Wheel/Tire ASM, K502 (24X12-12)Semi-Aggressive .....                                   | 136-6309 |
| Wireless Hourmeter .....                                                               | 115-4754 |
| Wireless Hourmeter Kit .....                                                           | 138-5655 |

**Notes:**



**Count on it.**