


TORO®

PART NO. 94-5286

PARTS CATALOG

FRAME UPDATE KIT For Workman® Vehicles




T-2756-1

FRAME & BRAKE PEDAL ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	94-3814	Tube Asm - Brake, Front	1
2	94-3815	Tube Asm - Brake, Rear	1
3	94-3800	Master Cylinder Assembly	1
4	283-2	Pin - Clevis	1
5	87-3570	Union - Brake Line	2
6	302-5	Fitting - Grease	2
7	3272-10	Pin - Cotter	1
8	323-7	Screw - Cap Hex. Hd.	2
9	256-247	Bushing - Flange	2
10	94-5223	Bell Crank Assembly	1
11	3296-6	Nut - Lock	2
12	3256-26	Washer - Flat	1
13	3296-23	Nut - Hex. Lock	1
14	68-3840	Ball Joint Assembly	1
15	3220-3	Nut - Hex. Jam	1

Ref. No.	Part No.	Description	No. Used
16	94-5299	Rod - Link	1
17	256-155	Bushing - Flange	2
18	93-8965	Brake Pedal Arm Assembly	1
19	21-1830	Spring - Tension	1
20	32128-20	Nut - Lock Flange	2
21	94-3821	Center Plate - Frame	1
22	87-2590	Brake Shaft Assembly	1
23	322-5	Screw - Cap Hex. Hd.	2
24	3290-357	Nut - Flange	2
25	321-9	Screw - Cap Hex. Hd.	1
26	3256-22	Washer - Flat	1
27	87-7660	Clamp - Tube	2
28	3296-42	Nut - Hex. Lock	1
29	68-3841	Ball Joint LH	1
30	3220-16	Nut - Hex. Jam LH	1




T-2339-1

MASTER BRAKE CYLINDER NO. 94-3800

Ref. No.	Part No.	Description	No. Used
1	87-3040	Reservoir - Master Cylinder (Incl. Ref. #12)	1
2	93-8971	Seal - Port, Flanger	2
3	92-4103	Pin - Stop	1
4	92-4102	Secondary Piston Assembly	1
5	92-4110	Clevis	1
6	21-0360	Nut - Hex.	1

Ref. No.	Part No.	Description	No. Used
7	94-5209	Cover - Dust	1
8	94-5210	Rod - Push	1
9	92-4109	Circlip	1
10	92-4108	Washer - Retainer	1
11	92-4101	Primary Piston Assembly	1
12	92-4112	Cap Assembly	1




T-3309

OPERATOR FRAME ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	94-5240-03	Operator Platform Asm	1
2	32148-7	Nut-Clinch	8
3	80-8040	Caution Decal	1
4	87-8710	Tab-Clutch Up-Stop	1

Ref. No.	Part No.	Description	No. Used
5	3256-22	Washer-Flat	4
6	87-6620	Screw-Torx Pan HD	4
7	87-9420	Decal Caution	1
8	94-5221	Flap- Cylinder, Master	1




T-2759-1

STEERING LINE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	321-9	Screw - Cap Hex. Hd.	2
2	56-7973	Clamp - Tube	4
3	3256-22	Washer - Flat	3
4	3296-42	Nut - Hex. Lock	2

Ref. No.	Part No.	Description	No. Used
5	87-9350	Tube Asm. - Steering Press	1
6	87-4540	Tube Asm. - Steering Return	1
7	322-2	Screw - Cap Hex. Hd.	1
8	32128-20	Nut - Lock Flange	1



T-2758-1

HYDRAULIC BRAKE LINE ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	94-3844	Tube Asm. - Rear Brake LH	1	11	93-7082	Tube Asm. - Brake Front LH	1
*2	94-3846	Tube Asm. - Rear Brake RH	1	12	93-7081	Tube Asm. - Brake Front	1
3	87-3570	Union - Brake Line	4	13	87-7660	Clamp - Tube	8
4	94-3845	Tube Asm. - Rear Brake RH	1	14	3296-42	Nut - Hex. Lock	4
5	94-3842	Tube Asm. - Brake	1	15	3256-22	Washer - Flat	5
6	94-3843	Tube Asm. - Brake LH	1	16	94-3819	Tube Asm. - Brake	1
7	87-3560	Tee - Brake Line	2	17	94-3820	Tube Asm. - Brake Front	1
8	87-3580	Retainer	2	18	321-9	Screw - Cap Hex. Hd.	4
9	93-7123	Hose - Brake Front	2	19	93-7085	Tube Asm. - Brake Front	1
10	32128-20	Nut - Lock Flange	1	20	322-2	Screw - Cap Hex. Hd.	1

*Not Illustrated

Maintenance Record

[illegible]

[illegible]

