

SEAT KIT

PART NO. 100-6097

INSTALLATION INSTRUCTIONS

Loose Parts

Note: Use the chart below to identify parts for assembly.

DESCRIPTION	QTY.	USE
Seat (includes switch)	1	Install seat
Adapter wire	1	iristali seat
Installation instructions	1	Read before installing

This seat is designed to replace seats on older model tractors utilizing a different version of a seat interlock switch. Some modification, using the adapter wire, is necessary to update to this assembly.

4. Install the wire harness adapter by sliding the wire connectors onto the stripped ends and crimping with a pair of wire crimpers (Fig. 1).

Assembling Seat to Tractor

Remove Old Seat

- 1. Disconnect the seat switch wire at the connector under the seat. Remove the seat. If seat adjusters were installed, remove them and install on the new seat.
- 2. Remove the connector from the tractor wiring harness by cutting the wires at the connector (Fig.1).
- **3.** Strip the insulation back on each wire approximately 1/4" (Fig.1).




Figure 1

- 1. Seat switch lead
- 2. Adapter wire
- 3. Tractor wire harness (end connector removed)
- 4. Stripped ends
- 5. Crimp connectors

Install New Seat

- **1.** Install the new seat using the hardware from the old seat.
- 2. Connect the seat switch to the adapter, added to the tractor wire harness.
- **3.** Check the seat for proper function as described in the tractor Operators Manual.