

LAWN-BOY®

Gold Series™ Walk-Behind Mower Model No. 10528–200000001 and Up

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply: the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form **a:b**. The **a** represents the reference number of the entire service assembly and the **b** represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number **6**, the tire by **6:1**, the valve by **6:2**, and the wheel by **6:3**. When you order the assembly identified by reference number **6**, you receive all parts identified by reference numbers **6:1**, **6:2**, and **6:3**. However, you may also order any part individually.

Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form **nX y**. The **n** represents the quantity of the part, the **X** is the multiplication symbol, and the **y** represents the reference number.

For example, in an illustration, the reference number **2X 37** means that two of the parts identified by reference number **37** are indicated.

Contents

Description	Page	Description	Page
Housing Assembly	3	Engine–OVRM105–21038F	9
Gear Case Assembly No. 92–7869	4	Engine–OVRM105–21038F	10
Engine And Blade Assembly	5	Engine–OVRM105–21038F	11
Rear Axle Assembly	6	Recoil Starter No. 590737	12
Handle And Controls Assembly	7	Recoil Starter No. 590694 (Optional)	13
Carburetor No. 640281	8		


Accessories

Description	Model / Part No.	Description	Model / Part No.
Side Bagging Kit	Model No. 89817		
Rear Bagging Kit	Model No. 89906		

Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

Abbreviation	Meaning	Abbreviation	Meaning
AR	as required	INC	incorporated
ASM	assembly	LH	left hand
CARR	carriage	NI	nylon insert
DEG	degrees	PPH	Phillips pan head
FH	flat head	PTH	Phillips truss head
GA	gauge	PTO	power take off
HF	hex flange	RH	right hand
HH	hex head	SFH	slotted fillister head
HHF	hex head flange	SHH	slotted hex head
HLH	hex lag head	SQH	square head
HJ	hex jam	SHWH	slotted hex washer head
HOC	height-of-cut	SPH	slotted pan head
HS	hex socket	SRH	slotted round head
HSBH	hex socket button head	STD	standard
HSFH	hex socket flat head	TAP	self tapping
HSH	hex socket head	TTH	Torx truss head
HWH	hex washer head	WH	wing head
HWHTF	hex washer head thread forming		




Sheet No.:2

Housing Assembly

Ref. No.	Part No.	Qty.	Description	Ref. No.	Part No.	Qty.	Description
1	92-7869	1	Gear Case ASM	25	92-1008	4	Knob-Lever, Height Adjustment
2	46-5551	2	Spacer	26	92-1099	2	Bolt-Shoulder
3	92-7699-03	1	Bracket-Actuator	28	92-4856	2	Bolt-Shoulder
4	32144-110	2	Screw-HWH	29	92-8630	1	Plate-Mulch
5	12-5450	2	Screw	30	92-9673	2	Screw-Torx
6	98-4493	1	Cover - Drive	*99	614249	1	Tie Strap
7	95-7421	1	Decal - Deck	*99	95-7052	1	Plate - Chute Opening
12	100-8760	1	Housing ASM				
12:2	43-8480	1	Decal-Danger				
12:3	608175	1	Toe Bar				
12:4	46-6811	2	Screw-HWH				
12:5	94-1610	3	Grommet - Plastic				
12:6	93-7250	1	Decal-Warning				
14	92-7736	1	Shield - Trailing				
16	3290-413	2	Washer-Belleville				
17	3296-39	2	Nut-Lock, NI				
18	40-1940	6	Washer				
19	603773	2	Nut				
20	95-7403-03	2	Bracket-Wheel Height Adjustment				
21	614677	2	Screw- Sems				
22	98-8332	1	Knob				
23	684776	2	Wheel & Tire ASM				
24	92-1006	2	Spring Arm ASM - Front				

* Not illustrated




Sheet No.:A1
C-2957

Gear Case Assembly No. 92-7869

Ref. No.	Part No.	Qty.	Description
1	60-8770	1	Bushing- Output
2	76-0760	2	Key-Shift
3	65-5250	1	Clip-Spring
4	76-0770	1	Collar-Shift
5	60-8750	2	Bushing
6	36-4791	2	Washer-Thrust
7	55-3760	1	Gear-Bevel
8	55-3780	1	20 T Pinion
9	55-3800	1	25 T Pinion
10	60-8800	1	Shaft-Intermediate
11	60-8850	1	Bushing-Output
12	65-4770	1	Shaft-Output
13	3285-19	1	Pin-Groove
14	60-8790	1	Sleeve - Gear
15	55-3810	1	39 T Gear
16	55-3790	1	44 T Gear
17	55-3770	1	49 T Gear
18	76-0780	1	Sleeve-Key, Shift
19	36-4780	1	Washer
20	38-7820	1	Bearing-Ball
21	3256-24	1	Washer-Flat
22	3296-5	1	Nut-Lock, NI
23	92-5790	1	Pinion
24	100-1176	2	Pulley-Half
25	92-5791	1	Spacer
26	60-8810	1	Retainer- Shift Fork


Ref. No.	Part No.	Qty.	Description
27	29-9570	1	Bushing-Yoke
28	60-8870	1	Yoke-Shift
29	60-8710	1	Case-Gear, Upper
30	60-8730-03	1	Cover-Gear Case
31	49-2040	6	Screw-Taptite



Sheet No.:3
C-2960

Engine And Blade Assembly

Ref. No.	Part No.	Qty.	Description	Ref. No.	Part No.	Qty.	Description
1		1	Engine-6.5HP (Tecumseh OVRM105-21038f)				
2	92-1701	1	Rope - Stop				
3	100-8758	1	Decal-Recoil,6.5 HP Ohv				
4	98-1593	1	Applique				
6	65-2690	1	Decal-Surface, Hot				
8	95-1878	1	Pulley				
9	104-0214	1	Screw-Set,Cone Point				
10	95-1727	3	Screw-Taprite w/Patch				
11	92-4877	3	Push Nut				
12	100-4382	1	Shield-Grass				
13	100-2899	1	Plate & Collar ASM				
14	612543	1	Blade				
15	99-6351-03	1	Fan - Mulching				
16	95-1712	1	Spacer - Blade				
17	3253-22	1	Washer-Lock/Sp				
18	100-5019	1	Bolt-Blade				




Rear Axle Assembly

Ref. No.	Part No.	Qty.	Description
1	92-1057	2	Bolt-Shoulder
2	92-1042	2	Wheel & Tire ASM
2:1	27-6250	2	Bushing
3	65-2720	4	Ring-Klip
4	65-4740	4	Washer-Thrust, Keyed
5	66-6050	1	Key-Rocking, LH
*6	66-6040	1	Key-Rocking, RH
7	65-4710	2	Ring-Friction
8	92-7746	2	Arm ASM-Rear Height Adjustment
8:1	302-56	1	Fitting-Zerk
8:2	47-2900	1	Bushing
8:3	70-9760	1	Bushing
9	32144-70	1	Screw-HH
10	60-8821	1	Lever-Shift
11	3272-10	1	Pin-Cotter
12	82-8780	1	Clamp-Cable
13	24-7920	1	Cover-Shaft, Drive
14	303259	1	Washer
15	605255	1	Washer
16	614426	2	Washer-Stepped
17	92-6535	2	Ring - Isolator
18	32144-85	2	Screw-HH
19	92-6540	1	Rear Spring Arm

Ref. No.	Part No.	Qty.	Description
*20	92-6539	1	ASM-LH Rear Spring Arm ASM-RH
21	603773	2	Nut
22	65-4730	2	Washer-Arm, Pivot
23	65-4760	2	Washer-Clutch
24	65-4750	2	Gear-Pinion
25	65-4720	2	Spring-Compression
26	94-1609	2	Cover-Wheel
27	92-1043	1	V-Belt


* Not illustrated



Sheet No.:5

Handle And Controls Assembly

Ref. No.	Part No.	Qty.	Description	Ref. No.	Part No.	Qty.	Description
1	3230-29	2	Screw-CARR	30	92-2268	1	Screw-Handle
2	100-2890-05	1	Handle-Lower	31	92-2928	1	Bracket-Anchor, Cable
3	614249	2	Tie Strap	32	3296-73	3	Nut-Lock, NI
4	3296-56	1	Nut-Lock, NI	33	100-2892-05	1	Handle-Upper
5	614697	2	Screw	34	32103-29	2	Nut-wing
6	98-7134	2	Knob-Handle				
7	92-9665	4	Screw				
9	92-1094	1	Bracket-Stop, Bail				
10	321-51	1	Screw-HH				
12	92-5412	1	Stop-Pivot				
13	92-1001-03	1	Bail-Control				
14	321-4	1	Screw-HH				
15	613050	1	Bolt				
16	100-6369	1	Control ASM-Throttle				
18	100-5981	1	Cable-Traction				
19	92-7899-03	1	Bracket-Traction Cable				
20	100-5984	1	Control ASM-Ground Speed				
21	16-8929	1	Panel w/Decal				
21:2	95-1701	1	Decal - Control Panel				
22	3253-33	2	Washer-Lock				
23	92-1093	1	Bail-Engine Control				
24	100-6391	1	Decal-Panel Sp				
26	100-6368	1	Cable ASM-Brake				
29	93-7383	1	Rope - Guide				




Carburetor No. 640281

Ref. No.	Part No.	Qty.	Description
0	640281	1	Carburetor (Incl. #184 of Engine Parts List)
1	631615	1	Throttle Shaft & Lever Assembly
2	631767	1	Throttle Return Spring
4	631184	1	Dust Seal Washer
5	631183	1	Dust Seal (Throttle)
6	640070	1	Throttle Shutter
7	650506	1	Shutter Screw
16	631807	1	Fuel Fitting
17	651025	1	Throttle Crack Screw/Idle Speed Screw
18	630766	1	Tension Spring
20	640027	1	Idle Restrictor Screw
20A	640200	1	Idle Restrictor Screw Cap
25	631867	1	Float Bowl
27	631024	1	Float Shaft
28	632019	1	Float
29	631028	1	Float Bowl "O" Ring
30	631021	1	Inlet Needle, Seat, & Clip (Incl. 31)
31	631022	1	Spring Clip
35	640259	1	Primer Bulb/Retainer Ring

Ref. No.	Part No.	Qty.	Description
36	640080	1	Main Nozzle Tube
36A	632766	1	Bowl Vent Tube Extension
37	632547	2	O-Ring, Main Nozzle Tube
40	640074	1	High Speed Bowl Nut
44	27110A	1	Bowl Nut Washer
47	630748	1	Welch Plug, Idle Mixture Well
48	631027	1	Welch Plug, Atmospheric Vent
60	632760B	1	Repair Kit

Obtain parts from local Tecumseh dealer

Engine-OVRM105-21038F



Engine–OVRM105–21038F


Ref. No.	Part No.	Qty.	Description
1	36835A	1	Cylinder (Incl. 2 & 20)
2	26727	2	Dowel Pin
6	33734	1	Breather Element
7	36557	1	Breather Body ASM (Incl. 6 & 12A)
12A	36558	1	Breather Cover & Tube
14	28277	1	Washer
15	30589	1	Governor Rod (Incl. 14)
16	34839A	1	Governor Lever
17	31335	1	Governor Lever Clamp
18	651018	1	Screw, Torx T–15
19	36796	1	Extension Spring
20	32600	1	Oil Seal
30	37510	1	Crankshaft
40	35544A	1	Piston, Pin & Ring Set (Std.)
40	35545A	1	Piston, Pin & Ring Set (.010" OS)
40	35546	1	Piston, Pin & Ring Set (.020" OS)
41	35541	1	Piston & Pin ASM (Std.)
41	35542	1	Piston & Pin ASM (.010" OS) (Incl. 43)
41	35543	1	Piston & Pin ASM (.020" OS) (Incl. 43)
42	35547A	1	Ring Set (Std.)
42	35548A	1	Ring Set (.010" OS)
42	35549	1	Ring Set (.020" OS)
43	20381	2	Piston Pin Retaining Ring
45	32875A	1	Connecting Rod ASM (Incl. 46)
46	32610A	2	Connecting Rod Bolt
48	35616	2	Valve Lifter
50	37473	1	Camshaft Exhaust(MCR)(Incl. Ref #104)
52	29914	1	Oil Pump ASM
69	35261	1	Mounting Flange Gasket
70	34311E	1	Mounting Flange (Incl. 72 thru 83)
72	36083	1	Oil Drain Plug
75	27897	1	Oil Seal
80	30574A	1	Governor Shaft
81	30590A	1	Washer
82	30591	1	Governor Gear ASM (Incl. 81)
83	30588A	1	Governor Spool
86	650488	6	Screw
89	611004	1	Flywheel Key
90	611112	1	Flywheel
92	650815	1	Belleville Washer
93	650816	1	Flywheel Nut
100	34443B	1	Solid State Ignition
101	610118	1	Spark Plug Cover
103	651007	2	Screw, Torx T–15
104	37480	1	Cam Bushing

Ref. No.	Part No.	Qty.	Description
110	37047	1	Ground Wire
119	36738	1	Cylinder Head Gasket
120	37474	1	Cylinder Head
125	36471	1	Exhaust Valve (Std.) (Incl. 151)
125	36472	1	Exhaust Valve (1/32 OS)(Incl. 151)
126	29314C	1	Intake Valve (Std.) (Incl. 151)
130	650912	4	Screw
130A	650999	1	Screw
135	34645	1	Resistor Spark Plug (RN4C)
150	31672	2	Valve Spring
151	31673	2	Valve Spring Cap
151A	40016A	1	Intake Valve Seal
153	36649	1	Push Rod Guide
154	650913	1	Rocker Arm Stud
155	35624A	1	Rocker Arm
157	650914	1	Lock Nut
158	36629	2	Push Rod
159	35626	1	Rocker Arm Cover Gasket
160A	37512	1	Heat Shield
161	30063	4	Screw, Torx T–30
178	29752	2	Nut & Lock Washer
182	30088A	2	Screw
184	26756	1	Carburetor To Intake Pipe Gasket
185	36579	1	Intake Pipe
186	36255	1	Governor Link
187	37203	1	Spacer
189	650839	2	Screw
191	36559A	1	S.E. Brake Bracket
200	37134	1	Control Bracket (Incl. 202 Thru 206)
202	36482	1	Compression Spring
203	31342	1	Compression Spring
204	651029	1	Screw, Torx T–10
205	651019	1	Screw, Torx T–10
206	610973	1	Terminal
207	36200B	1	Throttle Link
209	30200	2	Screw
223	651044	1	Screw
224	36581	2	Intake Pipe Gasket
238	650806	2	Screw
239	34338	1	Air Cleaner Gasket
240	36743	1	Air Cleaner Body
245	36745	1	Air Cleaner Filter
250	36744	1	Air Cleaner Cover
260	37513	1	Blower Housing
261	650853	1	Screw, Torx T–30
262	650831	2	Screw
263A	36758	1	Starter Grill
266	651040	1	Screw
266A	650852	1	Lockwasher
275	37275A	1	Muffler(Incl. 276 & 277)
276	36949	1	Locking Plate
277	651039	2	Screw

Obtain parts from local Tecumseh dealer

Ref. No.	Part No.	Qty.	Description

* Not illustrated




Recoil Starter No. 590737

Ref. No.	Part No.	Qty.	Description
0	590737	1	Rewind Starter
3	590740	1	Retainer
6	590616	2	Starter Dog
7	590617	2	Dog Spring
8	590618A		Pulley & Rewind
		1	Spring ASM
11	590687A		Starter Housing ASM
		1	(40 degree grommet)
12	590535		Starter Rope
		1	(Length 98" x 9/64"
			dia.)
13	590701	1	Starter Handle
14	590760	1	Spring Clip

Ref. No.	Part No.	Qty.	Description

Obtain parts from local Tecumseh dealer



Recoil Starter No. 590694 (Optional)

Ref. No.	Part No.	Qty.	Description
0	590694	1	Recoil Starter
1	590599A	1	Spring Pin (Incl. 4)
2	590600	1	Washer
3	590696	1	Retainer
4	590601	2	Washer
5	590697	1	Brake Spring
6	590698	2	Starter Dog
7	590699	2	Dog Spring
8	590700		Pulley & Rewind Spring
		1	ASM
11	590695		Starter Housing ASM
		1	(40 degree grommet)
12	590535		Starter Rope
		1	(98" X 9/64" dia.)
13	590701	1	Starter Handle

Obtain parts from local Tecumseh dealer

Maintenance Record

[illegible]

LAWN-BOY®