



Count on it.

Parts Catalog

Cargo Bed

Outcross 9060 Series Traction Unit

Model No. 07530



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity


In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

- Cargo Box Topside Assembly 4
- Cargo Box Underside Assembly 6
- Cargo Box Mounting Assembly 8
- Hydraulic Cylinder Assembly No. 131-5440 10


Cargo Box Topside Assembly



Cargo Box Topside Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	138-3857	1	Tailgate ASM	9	92-1242	2	Decal
1:2	138-4107	2	Decal-Hazard, Pinch	10	3230-8	4	Screw-CARR
2	99-1123	2	Latch ASM	11	3230-19	4	Bolt-CARR
2:1	92-1271	1	Pivot-Latch	12	104-8300	20	Nut-HF, NI
2:2	99-1113	1	Handle-Latch	13	138-4134-03	1	Base-Bed
2:3	99-1112	1	Plate-Retainer	14	138-3851	1	Panel ASM
2:4	32121-78	1	Pin-Roll	14:2	115-7739	1	Decal-No Riders
2:5	32121-25	1	Pin-Roll	15	3230-9	8	Screw-CARR
3	32128-20	4	Nut-HF	16	138-4130-03	1	Panel-RH
4	130-5726	2	Lanyard	17	138-8166	1	Decal-Instructions, Removal (Bed)
5	37-8771	4	Bolt-Shoulder, HF	18	93-9899	2	Decal-Warning
6	138-4110-03	2	Hinge ASM	19	105-4215	1	Decal-Caution
7	3230-26	8	Screw-CARR				
8	138-4122-03	1	Panel-LH				


Cargo Box Underside Assembly



Cargo Box Underside Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	138-8176-03	1	Leg-Rear	16	104-7201	4	Nut-HF
2	T0000-3423	1	Jack-Sidewind	17	93-9719	2	Block-Wear
3	115-7721	28	Nut-Clip, U	18	3274-65	4	Screw-HSBH
4	138-8184-03	1	Leg-RH	19	136-9999	4	Mudflap-Box
5	138-1980	2	Lock-Leg	20	322-5	16	Screw-HH
6	3234-29	12	Screw-HHF	21	3256-68	16	Washer-Flat
7	3269-23	5	Rivet-Pop	22	138-8183-03	1	Leg-LH
8	138-8179	5	Pin-Release, Quick	23	138-8148	1	Rod-Push
9	138-8180-03	1	Receiver-RH	24	3218-5	1	Nut-Jam
10	132-7924-01	1	Support-Cylinder	25	3256-6	1	Washer-Flat
11	237-136	4	Grommet	26	138-8147	1	Pin
12	130-5726	1	Lanyard	27	1-513959	1	Wingnut-Nylock
13	104-8300	1	Nut-HF, NI	28	3290-467	1	Pin-Hair
14	116-1297	2	Screw-Shoulder	29	283-52	1	Pin-Clevis
15	138-8170-03	1	Receiver ASM				

Cargo Box Mounting Assembly




Cargo Box Mounting Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	138-1951-03	1	Arm-Support, LH	13:1:1	237-79	1	O-Ring
2	99-5107	10	Nut-Lock	14	131-5440	1	Cylinder-HYD
3	325-7	8	Screw-HH	15	132-8169	1	Spring-Torsion
4	3234-38	2	Screw-HHF	16	138-8153	1	Spacer
5	92-1298	2	Pin-Lynch	17	283-52	1	Pin-Clevis
6	138-3817	1	Pin-Cylinder	18	137-9142	1	Screw-CARR
7	104-7201	2	Nut-HF	19	138-8150	1	Hinge ASM
8	3290-307	1	Pin-Cotter	20	133-7828	2	Coupler-Connect, Quick
9	122-0528	1	Harness-Wire	21	138-1950-03	1	Arm-Support, RH
10	138-8149-03	1	Lift-Cylinder	22	130-6481	2	Screw-HHF
11	120-9699	1	Screw-CARR	23	138-8165	1	Bracket-Lanyard
12	340-77	2	Fitting-Elbow, 90 DEG	24	3290-378	1	Tie-Cable
12:1	237-22	1	O-Ring	25	93-9852	1	Decal-Warning
12:2	237-42	1	O-Ring	26	T56152152	1	Cap-Connect, Quick
13	136-9716	2	Hose ASM	27	138-3066	1	Cap-Dust, Red
13:1		1	Fitting-Straight, Rgd ●				

● Not serviced separately

Hydraulic Cylinder Assembly No. 131-5440



Hydraulic Cylinder Assembly No. 131-5440 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	138-7867	1	Repair Kit



Count on it.