Form No. 3424-217 Rev B

TORO®

Count on it.

Parts Catalog

Cargo Bed

Outcross 9060 Series Traction Unit

Model No. 07530

Register at www.Toro.com.
Original Instructions (EN)

CE

3424-217 B

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1,6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.


Contents

Cargo Box Topside Assembly. 4
Cargo Box Underside Assembly 6
Cargo Box Mounting Assembly 8
Hydraulic Cylinder Assembly No. 131-5440 10

© 2019—The Toro® Company
**8111 Lyndale Avenue South
Bloomington, MN 55420**

**Contact us at www.Toro.com.
Printed in the USA.
All Rights Reserved**


Cargo Box Topside Assembly



Cargo Box Topside Assembly (continued)

Ref.	Part Number	Qty.	Description
1	138-3857	1	Tailgate ASM
1:2	138-4107	2	Decal-Hazard, Pinch
2	99-1123	2	Latch ASM
2:1	92-1271	1	Pivot-Latch
2:2	99-1113	1	Handle-Latch
2:3	99-1112	1	Plate-Retainer
2:4	32121-78	1	Pin-Roll
2:5	32121-25	1	Pin-Roll
3	32128-20	4	Nut-HF
4	130-5726	2	Lanyard
5	37-8771	4	Bolt-Shoulder, HF
6	138-4110-03	2	Hinge ASM
7	3230-26	8	Screw-CARR
8	138-4122-03	1	Panel-LH
9	92-1242	2	Decal
10	3230-8	4	Screw-CARR
11	3230-19	4	Bolt-CARR
12	104-8300	20	Nut-HF, NI
13	138-4134-03	1	Base-Bed
14	138-3851	1	Panel ASM
14:2	115-7739	1	Decal-No Riders
15	3230-9	8	Screw-CARR
16	138-4130-03	1	Panel-RH
17	138-8166	1	Decal-Instructions, Removal (Bed)
18	93-9899	2	Decal-Warning
19	105-4215	1	Decal-Caution


Cargo Box Underside Assembly



Cargo Box Underside Assembly (continued)

Ref.	Part Number	Qty.	Description
1	138-8176-03	1	Leg-Rear
2	T0000-3423	1	Jack-Sidewind
3	115-7721	28	Nut-Clip, U
4	138-8184-03	1	Leg-RH
5	138-1980	2	Lock-Leg
6	3234-29	12	Screw-HHF
7	3269-23	5	Rivet-Pop
8	138-8179	5	Pin-Release, Quick
9	138-8180-03	1	Receiver-RH
10	132-7924-01	1	Support-Cylinder
11	237-136	4	Grommet
12	130-5726	1	Lanyard
13	104-8300	1	Nut-HF, NI
14	116-1297	2	Screw-Shoulder
15	138-8170-03	1	Receiver ASM
16	104-7201	4	Nut-HF
17	93-9719	2	Block-Wear
18	3274-65	4	Screw-HSBH
19	136-9999	4	Mudflap-Box
20	322-5	16	Screw-HH
21	3256-68	16	Washer-Flat
22	138-8183-03	1	Leg-LH
23	138-8148	1	Rod-Push
24	3218-5	1	Nut-Jam
25	3256-6	1	Washer-Flat
26	138-8147	1	Pin
27	1-513959	1	Wingnut-Nylock
28	3290-467	1	Pin-Hair
29	283-52	1	Pin-Clevis

Cargo Box Mounting Assembly




Cargo Box Mounting Assembly (continued)

Ref.	Part Number	Qty.	Description
1	138-1951-03	1	Arm-Support, LH
2	99-5107	10	Nut-Lock
3	325-7	8	Screw-HH
4	3234-38	2	Screw-HHF
5	92-1298	2	Pin-Lynch
6	138-3817	1	Pin-Cylinder
7	104-7201	2	Nut-HF
8	3290-307	1	Pin-Cotter
9	122-0528	1	Harness-Wire
10	138-8149-03	1	Lift-Cylinder
11	120-9699	1	Screw-CARR
12	340-77	2	Fitting-Elbow, 90 DEG
12:1	237-22	1	O-Ring
12:2	237-42	1	O-Ring
13	136-9716	2	Hose ASM
13:1		1	Fitting-Straight, Rgd ●
13:1:1	237-79	1	O-Ring
14	131-5440	1	Cylinder-HYD
15	132-8169	1	Spring-Torsion
16	138-8153	1	Spacer
17	283-52	1	Pin-Clevis
18	137-9142	1	Screw-CARR
19	138-8150	1	Hinge ASM
20	133-7828	2	Coupler-Connect, Quick
21	138-1950-03	1	Arm-Support, RH
22	130-6481	2	Screw-HHF
23	138-8165	1	Bracket-Lanyard
24	3290-378	1	Tie-Cable
25	93-9852	1	Decal-Warning
26	T56152152	1	Cap-Connect, Quick
27	138-3066	1	Cap-Dust, Red

● Not serviced separately

Hydraulic Cylinder Assembly No. 131-5440



Hydraulic Cylinder Assembly No. 131-5440 (continued)

Ref.	*Part Number*	*Qty.*	*Description*
1	138-7867	1	Repair Kit



Count on it.