Form No. 3323–394

14.4 Volt – 18” Cordless Hedge Trimmer

Model No. 51596–9900001 and Up

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply: the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form **a:b.** The **a** represents the reference number of the entire service assembly and the **b** represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number **6**, the tire by **6:1**, the valve by **6:2**, and the wheel by **6:3**. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually.


Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form **nX y.** The **n** represents the quantity of the part, the **X** is the multiplication symbol, and the **y** represents the reference number.

For example, in an illustration, the reference number **2X 37** means that two of the parts identified by reference number 37 are indicated.

© The TORO Company — 1999
All Rights Reserved



Sheet No.:1

C–2842

Hedge Trimmer Assembly

Ref. No.	Part No.	Qty.	Description
1	99–9854	1	Protector – Blade, 18”
2	99–9855	1	Blade ASM
2:1	99–8835	1	Decal – Safety, Blade
3	99–9866	4	Screw – PPH
4	99–8803	8	Nut – Square
5	99–8804	6	Screw – PPH
6	99–9856	1	Housing – Cover
7	99–9857	1	Decal – Housing, Cover
8	99–8807	1	Spring – Button, Safety
9	99–8808	1	Button – Safety
10	99–8809	2	Screw – PPH
11	99–8811	1	Safety Handle ASM
11:1	99–8810	1	Screw – PPH
12	99–8812	1	Decal – Cover, Battery
13	99–9858	1	Cover – Battery
14	99–9859	1	Battery ASM
15	99–8815	1	Button – On/Off
16	99–9860	1	Harness – Wire ASM
16:1	99–8816	1	Switch – On/Off
17	99–8818	1	Spring – Button, On/Off
18	99–9861	1	Motor And Gear Train ASM
18:1	99–9862	1	Motor ASM

Ref. No.	Part No.	Qty.	Description
18:2	99–8821	1	Housing – Gear ASM
18:3	99–8822	2	Screw – PPH
18:4	99–8823	4	Washer – Flat
18:5	99–8824	1	Gear – Center
18:6	99–8825	1	Gear – Final
18:7	99–8826	1	Cam
18:8	99–8827	2	Ring – Retaining, External
19	99–9863	1	Housing – Support
20	99–9864	1	Decal – Housing, Support
21	99–8830	1	Guard – Hand
22	99–8831	1	Cover – Bottom
23	99–8822	8	Screw – PPH
24	99–9865	1	Decal–Model/Warning
25	99–8802	1	Charger ASM
25:1	99–9868	1	Decal – Warning
25:2	99–9867	1	Decal – Nameplate, Charger