Form No. 3423-535 Rev B

TORO®

Count on it.

Parts Catalog

# 21in Recycler®/Rear Bagging

## Lawn Mower

**Model No. 21320—Serial No. 404320000 and Up**

Register at www.Toro.com.
Original Instructions (EN)

*3423-535* B

# Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

**Understanding Reference Numbers**

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

**Service Assembly Reference Numbers**

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1,6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

**Reference Numbers Indicating Quantity**

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

# Contents


Housing Assembly . . . . . 4
Bag Assembly . . . . . 6
Engine and Blade Assembly . . . . . 8
Front Wheel Assembly . . . . . 10
Rear Wheel Assembly . . . . . 12
Handle Assembly . . . . . 14
Attachments and Accessories . . . . . 16

© 2019—The Toro® Company
8111 Lyndale Avenue South
Bloomington, MN 55420



Contact us at www.Toro.com.
Printed in the USA.
All Rights Reserved


# Housing Assembly



# Housing Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 136-5906 | 1 | Housing ASM |
| 1:2 | 94-8072 | 1 | Decal-Danger |
| 2 | 130-6657 | 1 | Chute ASM |
| 5 | 130-2368 | 1 | Rear Deflector ASM |
| 5:2 | 117-4143 | 1 | Decal-Warning |
| 6 | 127-6807 | 1 | Spring-Torsion |
| 7 | 138-5378 | 1 | Spring-Torsion |
| 8 | 127-0698 | 1 | Rod-Door |
| 9 | 127-0724 | 1 | Shield-Trailing |
| 14 | 132-4518 | 1 | Cover-Belt |
| 15 | 32144-1 | 1 | Screw-Taptite |
| 16 | 127-0677 | 1 | Bumper |
| 17 | 130-2355 | 6 | Stud |
| 18 | 130-6658 | 9 | Screw-Flange, Plastic |
| 31 | 136-5905 | 1 | Decal-Deck |


# Bag Assembly



# Bag Assembly (continued)

| *Ref.* | *Part Number* | *Qty.* | *Description* |
|---|---|---|---|
| 1 | 131-9697-03 | 1 | Frame-Bag |
| 2 | 130-6744 | 1 | Bag-Grass |

# Engine and Blade Assembly




# Engine and Blade Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 8 | | 1 | Engine-Briggs, 103M020083F1 ●■ |
| 9 | 95-1726 | 3 | Screw-Taptite |
| 12 | 104-1007 | 1 | Retainer-Blade |
| 13 | 133-8182-03 | 1 | Blade-21In |
| 14 | 108-3766-03 | 1 | Support-Blade |
| 15 | 125-2466 | 1 | Bolt-Blade |
| 20 | 133-8062 | 1 | Decal-Arrestor, Spark |
| 28 | 137-9136 | 1 | Decal-Engine |

● Not serviced separately

■ Obtain parts from www.briggsandstratton.com


# Front Wheel Assembly



# Front Wheel Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 127-0668-03 | 1 | Axle-Front |
| 2 | 127-6800 | 1 | Stop-Axle |
| 3 | 127-6831 | 1 | Screw-HWH |
| 5 | 105-3042 | 1 | Knob-Lever, HOC |
| 6 | 40-1940 | 2 | Washer |
| 7 | 92-1057 | 2 | Bolt-Shoulder |
| 8 | 127-0683 | 2 | 7 Inch Wheel ASM |
| 9 | 125-5069 | 2 | Nut-Hex |
| 11 | 133-8154 | 1 | Arm-Spring |


# Rear Wheel Assembly



# Rear Wheel Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 127-0669-03 | 1 | Axle-Rear |
| 2 | 127-6800 | 1 | Stop-Axle |
| 3 | 127-6831 | 1 | Screw-HWH |
| 4 | 127-0697 | 1 | Arm-Spring, Rear |
| 5 | 105-3042 | 1 | Knob-Lever, HOC |
| 6 | 40-1940 | 4 | Washer |
| 7 | 92-1057 | 2 | Bolt-Shoulder |
| 8 | 127-0686 | 2 | 11 Inch Wheel ASM |
| 9 | 125-5069 | 2 | Nut-Hex |

# Handle Assembly



# Handle Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 136-5923-05 | 1 | Handle-Lower, LH |
| 2 | 136-5924-05 | 1 | Handle-Lower, RH |
| 3 | 130-6654 | 4 | Bolt-CARR |
| 4 | 130-6655 | 4 | Nut-Flange, NI |
| 5 | 127-0699 | 2 | Bracket-Chute |
| 6 | 130-6659 | 2 | Screw-Flange, Serrated |
| 7 | 92-2260 | 2 | Screw-Handle |
| 8 | 117-5976 | 2 | Knob-Handle |
| 9 | 137-4826-05 | 1 | Handle-Upper |
| 10 | 86-9671 | 1 | Guide-Rope |
| 11 | 138-3270-03 | 1 | Bail-Brake |
| 14 | 127-0713 | 1 | Cable-Brake, Engine |
| 15 | 3296-73 | 1 | Nut-Lock, NI |
| 19 | 114-7988 | 1 | Guide-Cable |
| 22 | 137-4797 | 1 | Cover-Bail |

# Attachments and Accessories

## For 21320 21in Recycler/Rear Bagging Lawn Mower

| Product Name | Model/Part |
|---|---|
| All Season Synthetic Oil (10W30, QT) | 117-0066 |
| Fuel Stabilizer .05 oz | 130-2393 |
| Briggs Maint Kit | 130-8148 |
| 4-Cycle Fuel, Snow And Lawn 32oz Can | 131-3823 |
| Toro Premium Fuel Treatment 12 Oz Bottle | 131-6572 |
| Side-Discharge Deflector, 2013 and After 21in Steel Deck Mower | 136-7060 |
| Lawn Striping Kit with 22in Roller | 20601 |
| Toro 4-Cycle SAE 30 Oil (32oz Bottle) | 38903 |
| Summer Oil-Case of 24 (20oz Bottles) | 38916 |
| Bag-Walk Behind (Toro) | 490-7318 |
| Lawnmower Cover | 490-7462 |

## Notes:

## Notes:

## Notes:




**Count on it.**