



1/3 Industrial Flatbed

For Workman[®] Industrial 3000/4000

Model No. 07272—200000001 and Up

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply: the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form **a:b**. The **a** represents the reference number of the entire service assembly and the **b** represents a sequential number unique to each part within the service assembly.


For example, a wheel assembly might be identified by reference number **6**, the tire by **6:1**, the valve by **6:2**, and the wheel by **6:3**. When you order the assembly identified by reference number **6**, you receive all parts identified by reference numbers **6:1**, **6:2**, and **6:3**. However, you may also order any part individually.

Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form **nX y**. The **n** represents the quantity of the part, the **X** is the multiplication symbol, and the **y** represents the reference number.

For example, in an illustration, the reference number **2X 37** means that two of the parts identified by reference number **37** are indicated.



Sheet No.: 1

1/3 Area Industrial Flatbed Assembly

Ref. No.	Part No.	Qty.	Description
3	92-9028	1	Cover Assembly
3:5	32115-15	2	Pushnut-Bolt Retainer
3:6	3274-31	2	Screw-HSBH
4	3234-1	7	Screw-HHF
7	32148-6	2	Nut-Insert
8	32148-10	8	Nut-Insert
9	100-4512	1	Restraint-Cover Assembly
9:2	32148-10	1	Nut-Insert
10	100-4513	1	Restraint-Bottle Assembly
10:2	32148-10	1	Nut-Insert
10:3	99-0547	1	Strip - Foam
15	99-0547	3	Strip - Foam

Ref. No.	Part No.	Qty.	Description