



Form No. 3434-958 Rev A

Count on it.

Parts Catalog

Rear Quick-Attach System

**2013 and After Groundsmaster® 7200 Series
Mower with Yanmar Engine**

Model No. 30810—Serial No. 400000000 and Up



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Cylinder Support, Lift-Arm and Adapter Assembly 4


Hydraulic Cylinder Assembly No. 125-2650 6

Hydraulic Manifold Assembly No. 112-1493 8

Hydraulic Hose and Fitting Assembly 10

Wire Harness and Switch Assembly 12


Cylinder Support, Lift-Arm and Adapter Assembly



Cylinder Support, Lift-Arm and Adapter Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	121-3300-03	1	Support-Cylinder	19	3220-5	1	Nut-Jam
2	112-6320-03	1	Adapter	20	3296-45	2	Nut-Hex
3	121-3310-03	1	Lift Arm ASM	21	325-6	2	Screw-HH
3:1:2:2	95-3577	2	Bushing	22	125-2650	1	Cylinder-HYD
3:1:8	1481	2	Fitting-Grease	23	112-1493	1	HYD Manifold ASM
4	110-5362	1	Pin	24	340-137	2	Fitting
5	3234-42	3	Screw-HHF	24:1	237-21	1	O-Ring
6	104-8301	5	Nut-HF, NI	24:2	237-42	1	O-Ring
7	323-13	2	Screw-HH	25	3253-4	2	Washer-Lock
8	3234-24	3	Screw-HHF	26	322-3	2	Screw-HH
9	98-9062	2	Screw	27	112-9546	1	Hose-HYD
10	1-303352	8	Washer-Spindle	28	112-9547	1	Hose-HYD
11	3253-28	2	Washer-Lock/Sp	29	130-8761-03	1	Bracket-Relay
12	103-8496	2	Nut-Jam	30	99-7430	6	Relay-Mini
13	121-3369	1	Pin-Flag	31	321-2	6	Screw-HH
14	131-3390	1	Pin-Flag	32	104-7201	7	Nut-HF
15	61-3540	1	Bearing-Rod End, LH	33	3234-4	1	Screw-HHF
16	61-3530	1	Bearing-Rod End, RH	34	302-60	2	Fitting-Grease
17	110-5367	1	Tube-Hex	38	302-5	1	Fitting-Grease
18	3220-12	1	Nut-Hex Jam LH	39	133-8061	1	Decal-Warning


Hydraulic Cylinder Assembly No. 125-2650



Hydraulic Cylinder Assembly No. 125-2650 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	125-1681	1	Cylinder Repair Kit

Hydraulic Manifold Assembly No. 112-1493




Hydraulic Manifold Assembly No. 112-1493 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
2	106-1025	2	Plug-HYD
3	106-1026	4	Plug-HYD
4	107-7516	2	Solenoid Valve ASM
4:1	105-9156	1	Seal Kit
4:2	110-2634	1	Nut-Coil
5	107-7517	1	Valve-Solenoid
5:1	105-9156	1	Seal Kit
5:2	107-7812	1	Nut-Solenoid
6	353-551	1	Plug-HH
6:1	237-80	1	O-Ring
7	110-8904	2	Orifice-Control, Flow (0.028)
8	340-92	2	Fitting-Straight

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
8:1	237-78	1	O-Ring
8:2	237-21	1	O-Ring
9	105-9333	5	Coil-12Vdc
10	110-8898	2	Valve-Solenoid
10:1	107-7527	1	Seal Kit
10:2	110-2634	1	Nut-Coil
10:3	110-8909	1	Spacer-Coil
12	353-989	1	Plug-Hex, Hollow
12:1	237-42	1	O-Ring
13	353-988	2	Plug-Hex
13:1	237-79	1	O-Ring

Hydraulic Hose and Fitting Assembly




Hydraulic Hose and Fitting Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	340-138	1	Fitting-HYD, 45 DEG
1:1	237-79	1	O-Ring
1:2	237-22	1	O-Ring
2	340-101	1	Fitting-HYD, 45 DEG
2:1	237-30	1	O-Ring
2:2	237-79	1	O-Ring

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
3	340-2	1	Fitting-Straight
3:1	237-22	1	O-Ring
3:2	237-42	1	O-Ring
4	131-3384	1	Hose-HYD
5	131-3383	1	Hose-HYD
6	3290-378	4	Tie-Cable

Wire Harness and Switch Assembly



Wire Harness and Switch Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	125-2711	1	Decal-Switch, Auxiliary	4	122-0418	1	Harness-Wire, Blower (Rear Lift)
2	95-8999	1	Switch	4:6	100-4918	7	Diode
3	100-1535	1	Switch-Rocker, (On)-Off-(On)				

Notes:

Notes:



Count on it.