



Form No. 3434-975 Rev A

Count on it.

Parts Catalog

Slope Sensor Kit

**LT-F3000 Heavy-Duty Triple Turf Flail Mower
Fitted With Cab**

Model No. 02947



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity


In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Slope Sensor Kit LT-F3000 Fitted with Cab 4

Slope Sensor Kit LT-F3000 Fitted with Cab



Slope Sensor Kit

LT-F3000 Fitted with Cab (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	134-3953-03	1	Mount, Slope-Sensor [black]	9	80-9330	1	Audio Alarm ASM
3	134-3743	2	Screw-HHF	9:1	104-5107	1	Nut-Plastic, Knurled ●
4	134-3741	2	Screw-HHF	10	122-1652	1	Harness-Wire, Slope Snsr
5	134-3761	4	Nut-Flange, NI	10:3	32180-101	1	Cover-Fuse, Single
8	122-0630	1	Red LED Indicator Lamp ASM	10:4	121-8861	1	Fuse-Mini Blade, 2 Amp
8:1	122-0634	1	Gasket-LED	10:5	32180-416	1	Cap-Tethered ●
8:2	122-0633	1	Washer-Locking	11	140-2710	1	Decal-Slope Sensor
8:3	122-0632	1	Nut-Fixing	20	134-1863	1	Controller-Slope, Lt-F+c
				99	HY3966	6	Tie-Cable ●

● Not illustrated

Notes:

Notes:



Count on it.