



Gearbox Kit

Out Front Z Series

Model No. 100-5842

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply: the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form **a:b**. The **a** represents the reference number of the entire service assembly and the **b** represents a sequential number unique to each part within the service assembly.


For example, a wheel assembly might be identified by reference number **6**, the tire by **6:1**, the valve by **6:2**, and the wheel by **6:3**. When you order the assembly identified by reference number **6**, you receive all parts identified by reference numbers **6:1**, **6:2**, and **6:3**. However, you may also order any part individually.

Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form **nX y**. The **n** represents the quantity of the part, the **X** is the multiplication symbol, and the **y** represents the reference number.

For example, in an illustration, the reference number **2X 37** means that two of the parts identified by reference number **37** are indicated.




Sheet No.:1

Gearbox Assembly

Ref. No.	Part No.	Qty.	Description
1	99-0299	1	Gearbox – PTO
2	2811-7	1	Elbow

Ref. No.	Part No.	Qty.	Description



c-2886

Sheet No.:A1

Gearbox Assembly No. 99-0299

Ref. No.	Part No.	Qty.	Description
1	100-5812	3	Plug
2	100-5828	1	Shaft – Cross
3	100-4571	2	Bearing – Cup
4	100-4572	2	Bearing – Cone
5	100-5814	1	Gear – Spiral, RH
6	100-5815	1	Gear – Spiral, LH
7	100-4575	1	Seal
8	100-5816	2	Cone – Bearing
9	100-5817	2	Cup – Bearing
10	100-5818	12	Screw
11	100-5819	1	Seal
12	100-5820	1	Cap – End
13	100-5821	1	End Cap w/ Drain Plugs
13:1	100-4583	2	Plug
14	100-5822	2	Key
15	100-5823	1	Nut – Lock
16	100-5824	1	Washer
17	100-5825	1	Housing – Pinion
18	100-5826	1	Case
19	100-5827	1	Shaft – Pinion
21	100-5847	2	O-Ring
22	100-5848	1	O-Ring
23	100-7757	A/R	Shim–Green (.003)
24	100-7758	A/R	Shim–Blue (.005)

Ref. No.	Part No.	Qty.	Description
25	100-7759	A/R	Shim–Brown (.010)
26	100-7760	A/R	Shim–Yellow (.020)

