



## Rear Roller Brush

for Reelmaster<sup>®</sup> 5000D

Model No. 03526

### Parts Catalog

---

#### Ordering Replacement Parts

To order replacement parts, please supply: the part number, the quantity, and the description of each part desired.

#### Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

#### Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form **a:b**. The **a** represents the reference number of the entire service assembly and the **b** represents a sequential number unique to each part within the service assembly.


For example, a wheel assembly might be identified by reference number **6**, the tire by **6:1**, the valve by **6:2**, and the wheel by **6:3**. When you order the assembly identified by reference number **6**, you receive all parts identified by reference numbers **6:1**, **6:2**, and **6:3**. However, you may also order any part individually.

Reference numbers of this type appear in illustrations and in part lists.

#### Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form **nX y**. The **n** represents the quantity of the part, the **X** is the multiplication symbol, and the **y** represents the reference number.

For example, in an illustration, the reference number **2X 37** means that two of the parts identified by reference number **37** are indicated.



Sheet No.: 2  
T-3307

## Brush Assembly

Ref. No.	Part No.	Qty.	Description
1	98-5208	2	Bearing – Roller w/Collar
2	98-5205	2	Housing–Bearing, Roller Brush
3	302-5	2	Fitting–Lube
4	99-8489	1	Adjustment–HOC, RH
5	87-8640	7	Washer – Flat, Hardened
6	3255-8	6	Washer–Lock/Ext
7	33114-020	4	Screw–HH
8	99-8488	1	Adjustment–HOC, LH
9	3274-7	1	Screw–HSH
10	80-6990	1	Washer–Hardened
11	99-8456	1	Spacer–Hex
12	99-8462	1	Housing–Roller Brush
13	99-8466	1	Shaft–Drive, Tang
14	100-5045	1	Bearing Tang ASM
14:2	251-336	2	Bearing
15	95-9619	2	Key–Square
16	48-9510	2	Nut
17	100-4965	1	O–Ring
18	98-5217	2	Bolt–Shoulder
19	99-8468	1	Pulley–Drive
20	99-8461	1	Belt–Drive
21	99-8457	1	Cover–Plastic
22	323-6	2	Screw–HH

Ref. No.	Part No.	Qty.	Description
23	323-50	2	Bolt–TAP
24	3234-30	1	Screw–HHF
25	322-3	2	Screw–HH
26	98-5231	1	Pulley – Driven
27	99-8460	1	Pivot Plate ASM
28	99-8465	1	Magnet–40 Pole
29	100-7119	1	Roller Brush Shaft ASM
30	99-8496	1	Rubber–Plug
31	64-7720	3	Screw
32	98-5237	1	Washer – Retaining
33	94-4548	1	Bumper–Recessed
34	32144-44	1	Screw
35	100-4963	1	Tab
36	3234-33	1	Screw–HHF
37	100-4962	1	Washer–Offset
38	3242-2	2	Screw–SQH
39	3296-39	2	Nut–lock, NI