Form No. 3323–817

Rear Roller Brush

for Reelmaster® 5000D

Model No. 03526

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply: the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form **a:b.** The **a** represents the reference number of the entire service assembly and the **b** represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number **6**, the tire by **6:1**, the valve by **6:2**, and the wheel by **6:3**. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually.


Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form **nX y.** The **n** represents the quantity of the part, the **X** is the multiplication symbol, and the **y** represents the reference number.

For example, in an illustration, the reference number **2X 37** means that two of the parts identified by reference number 37 are indicated.

© The TORO Company — 1999
All Rights Reserved



Sheet No.: 2

T–3307

Brush Assembly

Ref. No.	Part No.	Qty.	Description
1	98–5208	2	Bearing – Roller w/Collar
2	98–5205	2	Housing–Bearing, Roller Brush
3	302–5	2	Fitting–Lube
4	99–8489	1	Adjustment–HOC, RH
5	87–8640	7	Washer – Flat, Hardened
6	3255–8	6	Washer–Lock/Ext
7	33114–020	4	Screw–HH
8	99–8488	1	Adjustment–HOC, LH
9	3274–7	1	Screw–HSH
10	80–6990	1	Washer–Hardened
11	99–8456	1	Spacer–Hex
12	99–8462	1	Housing–Roller Brush
13	99–8466	1	Shaft–Drive, Tang
14	100–5045	1	Bearing Tang ASM
14:2	251–336	2	Bearing
15	95–9619	2	Key–Square
16	48–9510	2	Nut
17	100–4965	1	O–Ring
18	98–5217	2	Bolt–Shoulder
19	99–8468	1	Pulley–Drive
20	99–8461	1	Belt–Drive
21	99–8457	1	Cover–Plastic
22	323–6	2	Screw–HH

Ref. No.	Part No.	Qty.	Description
23	323–50	2	Bolt–TAP
24	3234–30	1	Screw–HHF
25	322–3	2	Screw–HH
26	98–5231	1	Pulley – Driven
27	99–8460	1	Pivot Plate ASM
28	99–8465	1	Magnet–40 Pole
29	100–7119	1	Roller Brush Shaft ASM
30	99–8496	1	Rubber–Plug
31	64–7720	3	Screw
32	98–5237	1	Washer – Retaining
33	94–4548	1	Bumper–Recessed
34	32144–44	1	Screw
35	100–4963	1	Tab
36	3234–33	1	Screw–HHF
37	100–4962	1	Washer–Offset
38	3242–2	2	Screw–SQH
39	3296–39	2	Nut–lock, NI