Form No. 3436-899 Rev A

TORO®

Count on it.

Parts Catalog

18in 14-Blade EdgeSeries™ Cutting Unit

Greensmaster® Flex™ 1018 Traction Unit

Model No. 04854—Serial No. 400000000 and Up

Register at www.Toro.com.
Original Instructions (EN)

CE

3436-899 A

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1,6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.


For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Frame Assembly 4
Reel Assembly 5
Roller Assembly 6
Drive Assembly 7

© 2020—The Toro® Company
8111 Lyndale Avenue South
Bloomington, MN 55420


Contact us at www.Toro.com.
Printed in the USA.
All Rights Reserved



Frame Assembly

Ref.	Part Number	Qty.	Description
1	119-4009	1	Crossmember
2	119-4005	1	LH Sideplate ASM
2:2	117-6619	1	Bushing
3	119-4007	1	RH Sideplate ASM
3:2	117-6619	1	Bushing
4	115-7042	4	Bolt-Shoulder, Flange
5	119-4054	4	Nut-Square
6	119-4066-03	1	Bar-Cutoff
7	119-4012	3	Screw-HWHTF
8	140-3384	1	Grass Shield ASM, 18 Inch
8:2	137-9706	1	Decal-Warning
23	131-6150	4	Screw-HWHTF
24	121-2637	1	DPA Rebuild Kit
24:1	106-5363	2	Shaft-Adjuster
24:2	106-5344	4	Bushing-Flange, Keyed

Ref.	Part Number	Qty.	Description
24:3	119-4164	2	Washer-Wave
24:4	32120-93	2	Ring-Retaining
24:5	137-6130	2	Screw-Adjuster, Bedbar
24:6	119-4155	2	Washer-Hardened
24:7	119-4156	2	Spring-Compression
24:8	119-4039	2	Nut-Hex, NI
24:9	99-2097	2	Detent
24:10	119-4067	2	Screw-HH
25	139-7433-01	2	Arm-Pitch
26	139-7377	2	Pin-Mount
27	133-7570	2	Nut-Flange, NI
28	140-3396	1	Gasket-Weight
29	140-3395-03	1	Weight-Reel, Flex [black]
30	115-1794	2	Screw-HHF
31	119-4038	2	Nut-Hex




Reel Assembly

Ref.	Part Number	Qty.	Description
4	115-5258	1	Spring-Wire, Flat
5	115-7263	1	Screw-Lock, Bearing
6	110-2281-0P	1	Bedbar-Aggressive ●
6	110-2282-01	1	Bedbar
7	119-4150	2	Washer-Flat
8	52-2900	4	Washer-Plastic
9	117-9493	2	Bolt-Bedbar
10	119-4154	2	Nut-Lock, NI
11	137-8523	1	ES Reel+,Low Drag (18), 14 Bld
11:2	115-3299	2	Seal-Flocked
11:3	115-3296	2	Bearing-Sealed
12	119-4153	2	Rubber Bushing ASM

Ref.	Part Number	Qty.	Description
13	52-2890	2	Bushing-Nylon
14	119-4151	11	Screw-Bedknife
15	110-2300	1	Bedknife-Microcut, Extended ●
15	110-2301	1	Bedknife-Low Cut ●
15	117-1530	1	Bedknife-Edgemax, Microcut
15	117-1532	1	Bedknife-Edgemax, Tournament ●
15	98-7260	1	Bedknife-Tournament Cut ●
15	98-7261	1	Bedknife-Microcut ●
16	115-7164	1	Spline-Drive
17	139-7383	1	Nut-Reel, LH


● Optional Equipment



Roller Assembly

Ref.	Part Number	Qty.	Description
1	140-3354	1	Rear Roller ASM, 18 Inch
1:1	140-3355	1	Rear Full Roller , 18"
1:2	138-1548	1	Shaft-Roller
1:3	117-6831	2	Bearing-Ball, Stainless
1:4	115-5604	2	Washer-Sealing, Flocked
1:5	117-9080	2	Nut-Lock, Bearing
2	119-4166	2	Spacer-Height, Roller
3	119-4157	2	Retainer-Shaft

Ref.	Part Number	Qty.	Description
4	119-4165	2	Shim-Height, Roller
5	119-4035	4	Screw-HSH
6	119-4040	4	Nut-Flange, NI
7	115-7041	2	Arm-HOC
8	110-7352	2	Screw-HOC
9	99-3773	2	Bolt-Plow
11	133-7570	2	Nut-Flange, NI
12	119-4067	2	Screw-HH



Drive Assembly

Ref.	Part Number	Qty.	Description
1	140-3393	1	Reel Drive Housing ASM, Flex
1:2	120-9570	1	Decal-Warning
2	139-7414	1	Gasket-Reel Drive, Flex
3	115-6923	1	Shield-Bearing, Flocked
6	119-4038	2	Nut-Hex
7	3256-23	1	Washer-Plain
8	119-4041	1	Nut-HF
10	133-9155	2	Spacer-Pulley, Reel
11	139-7384	1	Shaft-Driver
12	937218	2	Key-Hipro
13	121-4722	1	Pulley-Reel, 22 Tooth
14	3296-45	2	Nut-Hex
15	133-9154	1	Shaft-Reel, Driven
16	121-4724	1	Pulley-Reel, 24 Tooth
17	138-1549	1	Seal
18	133-9124	1	Belt-Reel, 75T
19	139-7351	1	Idler ASM

Ref.	Part Number	Qty.	Description
19:1	133-9152	1	Idler Arm
19:2	115-6869	2	Bearing-Ball, Stainless
19:3	115-6755	1	Ring-Retaining
20	3230-2	1	Bolt-CARR
21	131-1847	1	Bushing-Idler
22	3274-22	1	Screw-HSH
23	3296-47	1	Nut-Lock, NI
24	131-6150	1	Screw-HWHTF
25	3274-83	2	Screw-HSH
26	139-7404	1	Cover-Drive, Reel
27	3274-8	4	Screw-HSH
28	137-0325	1	Plug-Expansion
29	133-2341	1	Coupling-Helical
30	125-3542	2	Pin-Spring
31	360-0398	1	O-Ring
32	139-7399	1	Shaft-Coupler
33	32151-48	1	E-Ring



Count on it.