



Count on it.

Form No. 3436-989 Rev A

Parts Catalog

36in Sprayer Spray Master

Model No. 34231—Serial No. 400000000 and Up



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Main Frame Assembly 4

Engine Assembly 6

Hydraulic Assembly 8

Park Brake Assembly 10

Electrical Assembly 12

Motion Control Assembly 14

Wheel Assembly 16

Fuel Assembly 18

Fuel Tank Assembly No. 140-4343 20

Spray System Assembly 22

Left Tank Assembly 24

Right Tank Assembly 26


Manifold Assembly 28

Liquid Valve Assembly 30

Boom Assembly 32

Spreader Assembly 34


Main Frame Assembly



Main Frame Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	135-7823	1	Frame-Rear	25	135-6110	15	Nut-Hex Flg 3/8-16 SS
1:2	138-2758	2	Nut-Clinch,Hex				W/Patch SS
2	142-0778	1	Wld, Front Frame, Jr36 24 Gallon Unit	26	135-6278	2	Screw-HHF 3/8-16 X 1 1/2 Serrated SS
3	142-3038	1	Box-Battery	27	126-3875	2	Washer
4	142-1748	1	Strap, Tarp	28	135-6111	8	Nut-Hex Flg 3/8-16 SS
5	135-5494	1	Bracket-Cable, Lower				W/Patch SS
6	135-5195	1	Wing-Capture, Rt	29	135-6207	8	Screw-HHF 5/16-18 X 1 1/4 SS
7	135-5194	1	Wing-Capture, Lt	30	135-6217	1	Screw-HH 5/16-18 X 3 1/2 SS
8	142-0806	1	Wld, Capture, T-Bar, Jr36	31	135-6218	1	Screw-HH 5/16-18 X 4 SS
9	135-5654	3	Spring-Compression	32	135-6222	2	Screw-HHF 5/16-18 X 3 Serrated SS
10	135-7508	1	Wld, Foot Plate, Jr36	33	HDW05856	2	Nut-Hex Nyl Ins #10-32 Unf
11	142-1923	1	Wld, Foot Pedal, Lcs	34	142-0775	1	Wld, Mount, Fert Box, L, Jr36
12	135-5652	4	Spring-Extension	35	142-0777	1	Wld, Mount, Fert Box, R, Jr36,
13	302-63	2	Zerk	36	126-0980	8	Bolt-Carriage 3/8-16 X 1 SS
14	135-5644	1	Cable-Caster, Locking	37	135-6728	1	Decal-Button, Foot (Spray)
15	1126	3	Washer-Flat	38	135-6430	1	Decal-Lock, Caster
16	107-0279	2	Washer	39	520-0019	2	Nut-Hex Jam #10-32 Unf
17	HDW17294	2	Bolt-Carriage 5/16-18 X 1 SS	40	142-0744	1	Guard, Muffler, Jr36
18	126-0710	1	Screw-HHF 3/8-16 X 1.75 SS	41	126-2712	2	Screw-HHF 5/16-18 X 3/4 Serrated SS
19	126-0759	2	Washer-Flat	42	135-8653-05	1	Shield, Heat, HYD Pump, Jr36
20	135-6208	4	Screw-HHF 3/8-16 X 1 Serrated SS	43	135-6280	2	Screw-HHF 1/4-20 X 1/2 Serrated SS
21	135-6806	3	Nut-Hex Flange 3/8-16 Serrated SS				
22	135-5682	2	Ball Joint-SS				
24	135-6109	8	Nut-Hex Flg 5/16-18 Nyloc SS				


Engine Assembly



Engine Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
2	135-5657	1	Pulley-Drive	17	3234-46	1	Screw-HHF 1/2-13 X 2 1/4
3	135-6833	1	ASM, Arm-Tension	18	104-8300	1	Nut-Nyloc 5/16-18 Flg
3:2	256-132	2	Bushing-Flange	19	142-0559	4	Screw-HHF
3:3	302-63	1	Zerk	20	116-2959	1	Spacer
4	135-5382	1	Collar	21	3246-17	5	Screw-Set 5/16-24 X 1/2
5	135-9068	2	Pulley ASM	22	135-6374	2	Screw-Button Head #10-24 X 1/2 SS
6	142-0418	1	Bolt, Eye - 5/8 X 5/16-18 X 5	23	135-6342	2	Nut-Hex Flg #10-24 Nyloc SS
7	103-4177	1	Key	24	135-9078	1	Belt-V, A48
8	1-807272	2	Key-5Mm X 5Mm X 25Mm	25	120-1996	1	Fitting-STR
9	135-5662	1	Pulley-Idler, Flat	26	135-6687	1	Filter-Fuel
10	135-9245	1	Briggs 16/18 HP Muffler	27	135-5365	1	Oil Drain Hose ASM (W/Plug)
11	135-5260	1	Cable-Throttle	27:2	AU218-774	1	Plug
12	135-5707	1	Cable-Choke	28	135-6273	2	Washer
13	135-5780	1	Spring-Extension	29	81-1280	2	Screw-HHF M6-1 X 10Mm
14	135-5677	2	Tube-Shrink, Heat				
15	135-6109	4	Nut-Hex Flg 5/16-18 Nyloc SS				
16	99-5107	1	Nut-Lock 1/2-13				

Hydraulic Assembly




Hydraulic Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	135-5250	1	Pump-Hydro, Pg With Aux	29	135-5692	2	Clamp-Oetiker, 167
2	135-5251	1	Pump-Hydro, Pg	30	135-5757	2	Clamp-Oetiker, 167
3	135-6110	4	Nut-Hex Flange	31	135-8846	2	Extension, Hydro-Pump, Jr36
4	135-6211	4	Screw-HHF	32	126-2712	4	Screw-HHF
5	103-1802	5	Fitting-Elbow, 90 DEG	33	135-6109	9	Nut-Hex Flange
5:1	237-42	1	O-Ring	34	135-6398	1	Decal-Oil
6	131-1308	4	Fitting	35	135-7525	2	Hub-Wheel
6:1	237-79	1	O-Ring	35:1	135-7526	4	Stud-1/2-20 X 1.55
7	353-545	1	Fitting-Straight	36	116-1399	2	Locknut
10	142-0709	2	Backplate, Wheel, Jr36	37	135-5256	1	Manifold-Hopper, W/Out Relief
11	135-6689	1	Motor-Wheel,Lt	37:2	353-212	1	Fitting-Elbow, 45 DEG
11:1	3257-42	1	Key-Woodruff	37:2:1	237-42	1	O-Ring
11:2	135-7497	1	Kit-Seal, Tj Motor	38	135-5243	1	Motor-Hydraulic, Spreader
12	135-6688	1	Motor-Wheel,Rt	39	135-6272	2	Screw-HHF
12:1	3257-42	1	Key-Woodruff	40	135-6385	4	Screw-HSBH
12:2	135-7497	1	Kit-Seal, Tj Motor	41	126-0695	3	Screw-CARR
13	AU218-5281	4	Fitting-Elbow, 90 DEG	42	109-5577	1	Hose-Hydraulic
13:1	237-80	1	O-Ring	43	135-9977	1	Hose ASM, HYD LP
14	135-5574	1	Bracket-Hopper, Speedometer Sensor	44	135-7822	1	Hose ASM, HYD LP
15	99-5107	8	Nut-Lock	45	142-3121	2	Hose ASM-HYD HP
16	126-0095	8	Screw-CARR	46	142-3122	2	Hose ASM-HYD HP
18	135-9773	1	Mount, Hydraulic Filter, Jr36	47	135-9978	2	Hose ASM, HYD LP
19	135-9056	1	2 Qt Flambeau Hydro Tank	48	142-3119	1	Hose ASM-HYD HP
20	135-5713	1	Cap-Vented	49	135-7821	1	Hose ASM, HYD LP
21	135-7080	4	Screw-Hsbhf	50	142-3110	2	Hose ASM-HYD HP
22	135-6108	8	Nut-Hex Flange	50:3		1	Fitting-Straight, Rigid ●
23	104-7836	1	Head-Filter	50:3:1	237-42	1	O-Ring
24	135-6280	2	Screw-HHF, 1/4-20 X 1/2, Ser Flg, SS	51	3290-378	3	Tie-Cable
25	109-3278	1	Adapter-Straight	53	135-7494	1	Strip-Trim, 17.88"
25:1	237-42	1	O-Ring	54	AU218-5352	1	Adapter-Straight
26	AU218-980	1	Fitting-Swivel, 90 DEG	54:1	237-78	1	O-Ring
27	353-877	1	Fitting-HYD, Tee	55	135-7911	1	Decal-Hydro Level
28	114-3494	1	Element-Filter, 25 Micron	56	135-7948	4	Strip-Trim, 2.0"

● Not serviced separately


Park Brake Assembly



Park Brake Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	142-0703-03	1	Chock, L, Brake, Jr36	11	3233-7	2	Screw-CARR
2	142-0704-03	1	Chock, L, Brake, Jr36, Ms, 0.375	12	HDW14535	4	Washer-Flat 5/16 SS
3	3218-5	4	Nut-Jam 1/2-13	13	135-9812	2	Balljoint-SS
4	142-0732	2	Backplate, Brake Mount, Jr36	14	142-3043	2	Linkage-Brake, Park
5	3233-2	2	Screw-CARR	15	135-5257	2	Balljoint-SS
6	3296-45	4	Nut-Nyloc 1/2-13 Thin	16	107-0380	4	Nut-Hex Flg 5/16-24 Unf W/Patch
7	142-0733	2	Backplate, Brake Pedal, Jr36	17	107-0282	2	Nut-Hex 5/16-24 Jam SS
8	142-0730	1	Stop, Foot Pedal, Brake, Jr36	18	135-6512	2	Nut-Hex 5/16-24 Jam SS LH
9	142-0731	1	Stop, Jr36 Foot Pedal Brake	19	3233-1	2	Screw-CARR
10	142-0794	2	Wld, Foot Pedal, Brake, Jr36	20	135-6111	2	Nut-Hex Flg 3/8-16 SS W/Patch SS
				21	126-2127	2	Spring-Extension
				22	115-9625	2	Decal-Brake, Parking


Electrical Assembly



Electrical Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	104-4657	1	Battery (340 CCA, Wet)	20	135-6443	1	Harness-Striker
2	135-5259	1	Meter-Tach/Hour	21	126-0759	2	Washer-Flat
3	135-5715	1	Nut-Switch, Key	22	135-6357	2	Screw-HSH M4-0.7 X 10Mm
4	1-603511	1	Key-Ignition	23	126-0695	2	Screw-Carriage 5/16-18 X 3/4 SS
4	135-5708	1	Key-Umbrella	24	135-6109	2	Nut-Hex Flg 5/16-18 Nyloc SS
5	135-8900	1	Striker-Head Only	25	104-7201	2	Nut-Nyloc 1/4-20 Flg
6	100-8469	1	Switch-Rocker	26	135-6356	1	Screw-HH #10-24 X 3/4 SS
7	135-6052	1	Switch-Ignition	27	135-6342	1	Nut-Hex Flg #10-24 Nyloc SS
8	32160-008	1	Connector-Carling, 8F	28	1-543393	3	Insulator-Solenoid
9	135-6054	1	Switch-Push Button	29	3290-378	9	Tie-Cable
10	32160-072	1	Connector-Wp,2M	30	135-7273	1	Stud-Engine
11	135-6189	1	Solenoid-Starter	31	135-6108	1	Nut-Hex Flg 1/4-20 Nyloc SS
12	135-6113	1	Harness-Main	32	135-8898	1	Cable-Sensor, Trail Tech
12:1	135-6270	1	Relay-Mini ISO Pwr, 5M	33	135-8903	1	Magnet-Speedometer
13	138-3132	1	Cable-Battery, Positive	34	135-3998	1	Harness-Wire, Jumper
14	135-6115	1	Wire-Solenoid				
15	135-6116	1	Cable-Ground				
16	135-6117	1	Cable-Positive				
18	135-6121	1	Switch-Op				
19	135-2304	1	Insulator-Battery				


Motion Control Assembly



Motion Control Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	142-0688-05	1	Upright-LH, Jr36 [blk-Txt]	18	135-7884	1	Pad-Knee
2	142-0689-05	1	Upright-RH, Jr36 [blk-Txt]	19	142-3313	1	Decal-Chart, Spray
3	142-3239	1	ASM-Panel, Control	20	126-2712	2	Screw-HHF
3:2	135-7811	1	Decal-Control	21	135-5718	2	Ball Joint-Quick Disconnect, SS
3:3	138-2760	5	Nut-Clinch, Hex	22	135-5257	2	Balljoint-SS
4	135-5430	1	Rod-Pivot, Joy Stick	23	135-7481	2	Linkage-Control, SS
5	135-5427-05	1	Bar-Speed [blk-Txt]	24	107-0282	2	Nut-Hex
6	135-5779	2	Screw-HHF	25	107-0380	4	Nut-HHF
7	135-6286	2	Washer-Lock	26	135-6110	4	Nut-Hex Flange
8	HDW14535	8	Flat Washer, 5/16 Nom,ST/ST,18-8	27	HDW17294	2	Bolt,Carriage,5/16-18X1,ST/ST 18-8
9	135-5689	2	Knob-Fluted	28	135-7080	6	Screw-Hsbhf
10	135-6192	1	Collar	29	135-6108	8	Nut-Hex Flange
11	118-1722	2	Nut-Hex Flange	30	93-9155	2	Velcro
12	135-6272	2	Screw-HHF	31	126-0980	4	Screw-CARR
13	135-6109	4	Nut-Hex Flange	32	142-0745-05	1	Mount, Gun, Jr36
14	135-7000	2	Strip-Trim, 9.0"	33	135-5661	1	Holder-Tool, Clip
15	135-7002	1	Stick-Joy, Lt	34	135-6374	1	Screw-HSBH
15:2	1-633257	1	Grip-Control, Motion	35	135-6342	1	Nut-Hex Flange
15:3	135-5694	2	Bushing-Flange	36	135-5586	3	Washer
16	135-7003	1	Stick-Joy, Rt	37	135-6512	6	Nut-Hex
16:2	1-633257	1	Grip-Control, Motion	39	135-7081	2	Screw-Hsbhf
16:3	135-5694	2	Bushing-Flange				
17	142-0727-05	1	Plate, Knee Pad, Jr36				


Wheel Assembly



Wheel Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	142-0918-05	1	Wld, Caster, L, Jr36, 36R	10	135-8615	2	Wheel And Tire
2	142-0919-05	1	Wld, Caster, R, Jr36, 36R	10:1	135-6680	1	Rim-6 X 4.5
3	135-5683	4	Spacer-Axle	10:2	1-633585	2	Bearing-Cone, Taper
4	1-543511	2	Seal-Grease	10:3	103-0063	2	Seal-Caster
5	254-92	4	Cone-Bearing, Outer	10:4	5108	1	Valve
6	1-809082	2	Nut-SHH	10:5	135-6681	1	Tire-Rib
7	135-5756	2	Cap-Dust, Rubber	11	135-6292	2	Pin-Cotter
8	135-8621	2	Tire/Rim ASM, K500-4H-Blk	12	3256-28	4	Washer-Flat
8:1	135-6679	1	Rim-8X5.375, Centered	13	135-6300	2	Screw-HH
8:2	126-1618	1	Tire	14	3296-51	2	Nut-Lock, NI
8:3	232-27	1	Stem-Valve	15	126-2055	2	Decal-Torque, Wheel Hub
9	242-50	8	Nut-Lug				Lug


Fuel Assembly



Fuel Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	142-0756	1	Panel, Platform, Fuel Tank, Jr36	7	135-6109	10	Nut-Hex Flg 5/16-18 Nyloc SS
2	142-3034	1	Support-Fuel Tank	8	109-1395	1	Hose-Fuel Line 27"
3	142-0755	1	Panel, Platform, Fuel Tank, Jr36, SS,.12	9	2412-98	2	Clamp-Hose
4	140-4343	1	Fuel Tank ASM, 5 Gal	10	117-9569	1	Hose-Fuel
5	107-4543	2	Clamp	11	135-5779	2	Screw-HHF 5/16-18 X 1 3/4 Serrated SS
6	126-0695	8	Screw-Carriage 5/16-18 X 3/4 SS				


Fuel Tank Assembly No. 140-4343



Fuel Tank Assembly No. 140-4343 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
2	137-4119	1	Cap-Fuel, Ratcheting	5	46-6560	1	Bushing
3	114-0284	1	Grommet	6	109-9364	1	Fitting-Fuel (W/Line And
4	119-3547	1	Valve-Vent, Fuel				Screen)

Spray System Assembly




Spray System Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	142-0722	1	Pin, Support, Jr36	21	135-5692	20	Clamp-Oetiker, 167
2	142-0723	1	Pin, Support, Jr36, SS, 0.188	22		1	ASM-Boom, Spray ●
3		1	ASM-Tank Lt ●	23	142-2446	2	Box-Fert
4		1	ASM-Tank Rt ●	25	126-0980	8	Screw-CARR
5		1	ASM-Manifold ●	26	142-0749	1	Tray, Gun, Jr36
6	135-6109	10	Nut-Hex Flange	30	142-0042	1	Hose-Spray, Wrapped
7	135-6110	16	Nut-Hex Flange	31	142-0039	1	Hose-Spray, Wrapped
8	135-6208	8	Screw-HHF	32	142-0014	1	Hose-Spray, Wrapped
9	135-6111	2	Nut-Hex Flange	33	142-0041	2	Hose-Spray, Wrapped
10	135-6207	2	Screw-HHF	34	142-0036	1	Hose-Spray, Wrapped
11	126-0695	10	Screw-CARR	35	142-0037	2	Hose-Spray, Wrapped
12	135-6221	7	Screw-HHF	36	135-6612	1	Hose-Coiled, 15 Ft
13		1	ASM, Liquid Valve ●	37	135-5773	1	Gun-Spray, Spot
14	135-6108	2	Nut-Hex Flange	38	135-5778	1	Tip-Spray, #12 Spot
15	132-7706	1	Elbow-90 DEG ■	39	142-0013	1	Hose-Spray, Wrapped
16	135-5765	1	Strainer-Inline	40	135-5294	1	Hose-Spray, Wrapped
16:1	126-7195	1	Bowl-Strainer	41	32180-030	2	Clip-Tie
16:2	126-2272	1	Gasket-Head, Line Strainer	42	3290-378	11	Tie-Cable
16:3	135-5766	1	Screen-Strainer, 50 Mesh	43	3290-379	2	Tie-Cable
17	135-5744	1	Fitting-Elbow, 90 ■	44	135-6484	2	Guard-Mesh
18	135-6424	1	Decal-Cap, Strainer	45	142-3437	1	Gauge-Plain
19	135-5570-05	1	Bracket-Manifold	46	125-9088	1	Fitting-Elbow, 90
20	135-6285	1	Decal-Valve, Boom				

● Not serviced separately

■ Apply pipe sealant to all pipe threads.


Left Tank Assembly



Left Tank Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	135-7876	1	ASM-Tank, Lt	4	135-9063	2	Bushing-Flange
1:2	135-5916	1	Cap-Tank, Spray	5	135-6274	6	Screw-HHF
1:3	126-4393	2	Fitting-Bulkhead	6	142-0724	1	Plate, Pivot Lock, Tank, Jr36
2	135-5744	2	Fitting-Elbow, 90	7	142-0791	1	Wld, Wing, Tank, Bottom, L, Jr36
3	142-0789	1	Wld, Wing, Tank, Bottom, L, Jr36	8	142-1443	1	5/8 Shaft Collar


Right Tank Assembly



Right Tank Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	135-7878	1	ASM-Tank, Rt	5	142-0724	1	Plate, Pivot Lock, Tank, Jr36
1:2	135-5916	1	Cap-Tank, Spray	6	142-0792	1	Wld, Wing, Tank, Bottom, R, Jr36
1:3	126-4393	2	Fitting-Bulkhead	7	142-1443	1	5/8 Shaft Collar
2	135-5744	2	Fitting-Elbow, 90	8	135-7096	4	Screw-HHF
3	142-0790	1	Wld, Wing, Tank, Bottom, R, Jr36	9	135-6904	1	Platform-Valve, Liquid
4	135-9063	2	Bushing-Flange	10	135-6274	6	Screw-HHF

Manifold Assembly




Manifold Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	135-5721	3	Valve-Directo	8	135-5736	1	Valve-Throttle ●
2	135-5741	2	Fitting-Nipple ●	9	132-7706	1	Elbow-90 DEG ●
3	135-5742	1	Fitting-Nipple ●	10	135-5737	1	Valve-Chrome, 1/4 ●
4	94-7100	1	Tee	11	135-5744	1	Fitting-Elbow, 90 ●
5	120-8673	1	Fitting-Elbow, Hosebarb ●	12	135-5735	2	Plug-Valve ●
6	135-5743	1	Fitting-Reducer ●	13	120-8671	3	Fitting-Hosebarb ●

● Apply pipe sealant to all pipe threads.

Liquid Valve Assembly




Liquid Valve Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	135-5491	1	Mount-Plate, Liquid Valve	10	135-6312	4	Screw-HHF 1/4-20 X 1 1/4 Serrated SS
2	142-3321	1	Pump-5.3 GPM	11	135-6109	1	Nut-Hex Flg 5/16-18 Nyloc SS
3	135-5504	1	Plate-Clamp, Liquid Valve Fittings	12	126-2711	1	Screw-HHF 5/16-18 X 2 Serrated SS
4	94-7100	2	Tee	13	135-6420	1	Decal-Valve, Tank
5	135-5760	4	Valve-Chrome, 1/2 ●	14	142-3322	1	Heatsink-3.0"
6	135-5742	1	Fitting-Nipple ●				
7	120-8673	5	Fitting-Elbow, Hosebarb ●				
8	126-0961	2	Fitting-Elbow, Barbed				
9	135-6108	4	Nut-Hex Flg 1/4-20 Nyloc SS				

● Apply pipe sealant to all pipe threads.


Boom Assembly



Boom Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	135-6798	1	Boom-Center	11	1126	6	Washer-Flat
2	135-6800	1	Boom-Wing, Rt	12	135-6310	2	Screw-HH 3/8-16 X 4 SS
3	135-6799	1	Boom-Wing, Lt	13	135-6110	4	Nut-Hex Flg 3/8-16 SS
4	135-5790	2	Body-Nozzle, Right				W/Patch SS
5	135-5788	2	Body-Nozzle, Left	14	126-0702	2	Bolt-Carriage 3/8-16 X 2 1/2
6	138-2751	1	Fitting-Tee, Barb				SS
7	135-5781	4	Cap-Nozzle	15	135-6806	2	Nut-Hex Flange 3/8-16
7:1	40998	1	Seat-Gasket				Serrated SS
8	142-3308	4	Tip-Spray, 025	16	135-6298	1	Hose-Spray
9	135-5780	2	Spring-Extension	17	135-7129	1	Hose-Spray
10	126-3943	4	Strainer-Nozzle, 50M 5PSI	18	135-5692	4	Clamp-Oetiker, 167
			Check				

Spreader Assembly



Spreader Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	142-0784	1	Wld, Frame, Hopper, L, 120	26	135-5573	1	Slide-Door, Hopper
2	142-0785	1	Wld, Frame, Hopper, R, 120	27	126-0990	4	Guide-Rate, Gate
3	142-0708	1	Backshield, Hopper, Jr36	28	126-0991	1	Diffuser
4	142-0698	1	Bumper, Front, Hopper, 120	29	135-5961	2	Retainer-Cable, Wire
5	135-7080	10	Screw-Hsbhf	30	135-5569	2	Retainer, Cable
6	135-6272	4	Screw-HHF	31	135-5682	1	Ball Joint-SS
7	126-2712	4	Screw-HHF	32	HDW05856	1	Nut-NYL
8	135-6108	14	Nut-Hex Flange				Lock,#10-32,ST/ST 18-8
9	135-6109	9	Nut-Hex Flange	33	135-6725	1	Decal-Dismemberment
10	142-1987	1	Pan-Hopper, 120				Hazard
11	135-8519	1	Hopper-120Lb	34	135-5388	1	Mount-Deflector, Side
12	135-5937	1	Coupler-SS	35	135-5589	1	Deflector-Side, Spreader
13	135-8504	1	Shaft-Hopper, 120	36	135-6280	8	Screw-HHF, 1/4-20 X 1/2,
14	3241-7	2	Screw-SQH				Ser Flg, SS
15	135-5954	1	Spinner-Spreader	37	135-6341	8	Washer
16	135-6340	1	Pin-Cotter	38	135-7081	5	Screw-Hsbhf
17	135-5957	1	Wire-Agitator	39	142-1995	2	Screen-Hopper, 120
18	142-1990	1	Base-Hopper, 120	40	142-3283-05	1	Mount-Speedometer
19	135-5943	1	Bearing-Flange	41	142-3351	1	Decal-Hopper Control
20	135-6356	4	Screw-HH	42	135-5931	2	Cable-Push/Pull
21	135-6342	4	Nut-Hex Flange	43	135-7980	1	Cover-Hopper, Small
22	126-0985	1	Mount-Dial	44	135-8492	1	120Lb Hopper Cable
23	126-0988	1	Dial	45	520-0019	1	Nut-Hex, Jam
24	126-0986	1	Clip	46	3290-378	1	Tie-Cable
25	135-5965	1	Linkage-Gate, Rate				



Count on it.