



Count on it.

Form No. 3377-596 Rev D

Parts Catalog

RT600 Traction Unit

Model No. 25430—Serial No. 313000001 and Up



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity


In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Frame Assembly	4
Axle and Driveshaft Assembly	6
Front Axle Assembly No. AU124914	8
Pinion Group Assembly No. 131-7040	10
Wheel Hub Group Assembly No. 131-7035	12
Wheel Hub Group Assembly No. 131-7036	14
Brake Group Assembly No. 131-6900	16
Rear Axle Assembly No. AU124920	18
Pinion Group Assembly No. 131-7037	20
Differential Group Assembly No. 131-7038	22
Gearbox Group Assembly No. 131-7039	24
Drive Shaft Assembly No. AU126653	26
Engine Assembly	28
Engine Service Parts	30
Radiator and Fan Assembly	32
Air Cleaner and Exhaust Assembly	34
Air Cleaner Assembly No. 112-7329	36
Steering Assembly	38
Priority Flow Divider Valve Assembly No. AUH672904	40
Hydraulic Steering Valve Assembly No. AU141535A1	42
Lockout Valve Assembly No. AUH672547	44
Hydraulic Tank and Tandem Pump Assembly	46
Front Pump Assembly Tandem Pump No. AU125034	48
Rear Pump Assembly Tandem Pump No. AU125034	50
Hydraulic Tank Assembly No. 127-1242	52
Bulkhead and Hose Mounting Assembly	54
Directional Valve and Hydraulic Hose Assembly	56
Oil Filter and 60 CC Hi Motor Assembly	58
Hydraulic Motor Assembly No. AU125010	60
Solenoid Valve and Hose Assembly	62
Fuel Tank Assembly	64
Ground Drive Control Assembly	66
Ground Drive Linkage Assembly	68
ROPS and Platform Assembly	70
Seat and Mounting Assembly	72
Hydraulic Control Valve Assembly No. AU125537	74
Dash and Trim Assembly	76
Main Electrical Assembly	78
Instrument Panel Electrical Assembly	80
Instrument Panel Assembly No. AU125255	82
Battery and Cable Assembly	84
Parking Brake Assembly	86
Hydraulic Release Cylinder Assembly No. AU126603	88
Backfill Blade Assembly	90
Hydraulic Cylinder Assembly No. AU103989A1	92
Hydraulic Cylinder Assembly No. AUH674312	94
Hydraulic Cylinder Assembly No. AU125681	96
Backfill Blade Hose Assembly	98
Attachments and Accessories	100


Frame Assembly



Frame Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	127-1240	1	Chassis Frame ASM	9:2	125-6689	2	Decal-Warning, Fan
1:2	125-8481	1	Decal-Fluid, Hydraulic (Out)	9:3	125-8479	1	Decal-Warning, Radiator
1:3	125-8482	1	Decal-Fluid, Hydraulic (In)	9:4	67-1300	1	Decal
2	AU232-41120	4	Nut-Hex	10	125-6749	1	Hood Support ASM
3	AU125441-03	1	Support-Hood	10:2	125-4963	1	Decal-Surface, Hot
4	AU125499	1	Hood-RH	12	AUH672204	2	Latch-Draw, Flexible
5	33105-030	8	Screw-HHF	13	103-0138	4	Rivet-Pop
6	103-9511	4	Nut-Lock, NI	14	107-0386	4	Rivet-Blind
7	33106-030	2	Screw-HHF	15	3269-26	4	Washer-Plain
8	AU125500	1	Hood-LH	17	127-1284	2	Trim-Edge
9	127-1230	1	Nose Clip ASM				


Axle and Driveshaft Assembly



Axle and Driveshaft Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	AU125288-03	2	Spacer-Axle	14	AU126653	1	Front Axle Drive Shaft ASM
2	AUH426833	8	Washer	15	127-1263	2	RH Wheel And Tire ASM
3	AU125289-03	2	Bar-Clamp	15:1	127-1260	1	Wheel
4	AU413-16128	4	Screw-Cap	15:2	127-1261	1	Tire-31 Inch
5	AU124914-03	1	Front Axle ASM	15:3	232-24	1	Stem-Valve
6	AU124920-03	1	Rear Axle ASM	16	127-1262	2	LH Wheel And Tire ASM
7	AU426-1640	4	Bolt	16:1	127-1260	1	Wheel
8	AU125429	1	Pin	16:2	127-1261	1	Tire-31 Inch
9	302-5	1	Fitting-Grease	16:3	232-24	1	Stem-Valve
10	33106-030	1	Screw-HHF	17	127-1286-03	1	Plate-Spacer
11	AU125432-03	2	Plate-Stop, Pivot	18	AU125582-03	1	Plate-Spacer
12	AU100878	4	Screw-HHF	19	285-17	2	Plug-Pipe
13	108-1531	8	Screw-HHF				


Front Axle Assembly No. AU124914



Front Axle Assembly No. AU124914 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	131-6901	32	Screw-Soc HD	17	131-6917	2	Bearing
2	131-6902	4	Joint-Ball	18	131-7040	1	Pinion Group
3	131-6903	10	Shim-Joint, Articulated (0.2)	19	131-6918	2	Housing-Side
4	131-6904	4	Greaser	20	131-6927	2	O-Ring
5	131-6905	4	Seal-Oil	21	131-6919	2	Ring-Snap
6	131-6906	2	Shim-Joint, Articulated (0.1)	22	131-6920	1	Plug-Breather
7	131-6907	4	V-Ring	23	131-6921	2	Shim (1.0)
8	131-6908	2	Bushing	24	131-6922	2	Shim (0.2)
9	131-6909	2	Rod-Tie	25	131-6923	2	Shim (0.3)
10	131-6910	1	Cylinder-Steering	26	131-6924	2	Shim (0.35)
11	131-6911	4	Pin-Flanged	27	131-6925	2	Shim (0.5)
12	131-6912	24	Bolt	28	131-6926	1	Plug
13	131-6913	4	Washer-Copper	29	131-7035	1	Wheel Hub Group
14	131-6914	4	Plug-Magnetic	30	131-7036	1	Wheel Hub Group
15	131-6915	24	Washer-Schnorr	31	131-6900	1	Brake Group
16	131-6916	2	Flange-Differential				


Pinion Group Assembly No. 131-7040



Pinion Group Assembly No. 131-7040 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	131-7007	1	Nut-Lock	7	131-7013	1	Shim (0.35)
2	131-7008	2	Bearing-Roller, Taper	8	131-7014	1	Shim (0.3)
3	131-7009	1	Pinion-Bevel	9	131-7015	1	Shim (0.4)
4	131-7010	1	Washer-Rotation, Anti	10	131-7017	1	Housing-Central, Upper
5	131-7011	1	Shim (0.5)				Pivot
6	131-7012	1	Spacer-Deformable	11	131-7018	2	Bushing


Wheel Hub Group Assembly No. 131-7035



Wheel Hub Group Assembly No. 131-7035 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	131-6933	1	Hub-Wheel	17	131-6948	8	Nut
2	131-6934	1	Hub-Planetary	18	131-6949	4	Screw
3	131-6935	1	Flange-Crown	19	131-6950	2	Shim (0.2)
4	131-6936	1	Ring-Crown	20	131-6951	1	Shim (0.1)
5	131-6937	1	Shim-Crown, Wheel	21	131-6952	1	Shim (0.35)
6	131-6938	1	Wheel-Crown	22	131-6953	8	Nut
7	131-6939	3	Gear-Planetary	23	131-6954	8	Bolt-Stud
8	131-6940	3	Ring-Snap	24	131-6905	2	Seal-Oil
9	131-6941	8	Bolt-Stud	25	131-6955	2	Nut
10	131-6942	1	Cap	26	131-6956	1	Ring-Snap
11	131-6943	2	Bearing	27	131-6957	2	Screw-End, Steering
12	131-6944	1	Washer-Copper	28	131-6958	1	Shim-Crown
13	131-6945	1	Ring-Retaining	29	131-6908	1	Bushing
14	131-6946	1	Seal-Oil	30	131-6960	8	Washer-Elastic
15	131-6927	1	O-Ring	31	131-6961	1	Joint-LH, Articulated
16	131-6947	3	Bearing-Roller	32	131-6962	1	Shaft-Drive


Wheel Hub Group Assembly No. 131-7036



Wheel Hub Group Assembly No. 131-7036 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	131-6933	1	Hub-Wheel	17	131-6948	8	Nut
2	131-6934	1	Hub-Planetary	18	131-6949	4	Screw
3	131-6935	1	Flange-Crown	19	131-6950	2	Shim (0.2)
4	131-6936	1	Ring-Crown	20	131-6951	1	Shim (0.1)
5	131-6937	1	Shim-Crown, Wheel	21	131-6952	1	Shim (0.35)
6	131-6938	1	Wheel-Crown	22	131-6953	8	Nut
7	131-6939	3	Gear-Planetary	23	131-6960	8	Washer-Elastic
8	131-6940	3	Ring-Snap	24	131-6954	8	Bolt-Stud
9	131-6941	8	Bolt-Stud	25	131-6905	2	Seal-Oil
10	131-6942	1	Cap	26	131-6955	2	Nut
11	131-6943	2	Bearing	27	131-6956	1	Ring-Snap
12	131-6944	1	Washer-Copper	28	131-6962	1	Shaft-Drive
13	131-6945	1	Ring-Retaining	29	131-6957	2	Screw-End, Steering
14	131-6946	1	Seal-Oil	30	131-6958	1	Shim-Crown
15	131-6927	1	O-Ring	31	131-6908	1	Bushing
16	131-6947	3	Bearing-Roller	32	131-6963	1	Joint-RH, Articulated


Brake Group Assembly No. 131-6900



Brake Group Assembly No. 131-6900 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	131-7019	4	Screw	12	131-7026	1	Washer-Axial
2	131-6915	4	Washer-Schnorr	13	131-7027	1	Shaft-Pivot, Brake
3	131-6999	1	Screw-Flanged	14	131-7028	1	O-Ring
4	131-7000	1	Washer-Pinion	15	131-7029	1	Seal-Oil
5	131-7004	1	O-Ring	16	131-7030	2	Spring-Brake
6	131-7020	1	O-Ring	17	131-7031	1	Lever-Brake
7	131-7021	1	Seal-Housing	18	131-7032	1	Washer-Lever, Brake
8	131-7022	1	Drum-Brake	19	131-7033	1	Ring-Snap
9	131-7023	1	Flange-Brake	20	131-7034	2	Shoe-Brake
11	131-7025	1	Pivot-Lever, Brake				


Rear Axle Assembly No. AU124920



Rear Axle Assembly No. AU124920 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	131-6901	32	Screw-Soc HD	17	131-6917	2	Bearing
2	131-6902	4	Joint-Ball	18	131-6918	2	Housing-Side
3	131-6903	10	Shim-Joint, Articulated (0.2)	19	131-6919	2	Ring-Snap
4	131-6904	4	Greaser	20	131-6920	1	Plug-Breather
5	131-6905	4	Seal-Oil	21	131-6921	2	Shim (1.0)
6	131-6906	2	Shim-Joint, Articulated (0.1)	22	131-6922	2	Shim (0.2)
7	131-6907	4	V-Ring	23	131-6923	2	Shim (0.3)
8	131-6908	2	Bushing	24	131-6924	2	Shim (0.35)
9	131-6909	2	Rod-Tie	25	131-6925	2	Shim (0.5)
10	131-6910	1	Cylinder-Steering	26	131-6926	1	Plug
11	131-6911	4	Pin-Flanged	27	131-6927	2	O-Ring
12	131-6912	24	Bolt	28	131-7035	1	Wheel Hub Group
13	131-6913	4	Washer-Copper	29	131-7036	1	Wheel Hub Group
14	131-6914	4	Plug-Magnetic	30	131-7037	1	Pinion Group
15	131-6915	24	Washer-Schnorr	31	131-7038	1	Differential Group
16	131-6916	2	Flange-Differential	32	131-7039	1	Gearbox Group

Pinion Group Assembly No. 131-7037




Pinion Group Assembly No. 131-7037 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	131-7007	1	Nut-Lock
2	131-7008	2	Bearing-Roller, Taper
3	131-7009	1	Pinion-Bevel
4	131-7010	1	Washer-Rotation, Anti
5	131-7011	1	Shim (0.5)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
6	131-7012	1	Spacer-Deformable
7	131-7013	1	Shim (0.35)
8	131-7014	1	Shim (0.3)
9	131-7015	1	Shim (0.4)
10	131-7016	1	Housing-Central


Differential Group Assembly No. 131-7038



Differential Group Assembly No. 131-7038 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	131-6928	2	Package-Disc	6	131-6964	2	Washer-Pinion
2	131-6929	2	Wheel-Crown	7	131-6965	8	Screw-Socket
3	131-6930	1	Gear-Spider	8	131-6966	1	Crown-Bevel
4	131-6931	4	Pinion-Side	9	131-6967	2	Shim (0.2)
5	131-6932	4	Shim-Pinion, Side	10	131-6968	1	Housing-Differential


Gearbox Group Assembly No. 131-7039



Gearbox Group Assembly No. 131-7039 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	131-6914	3	Plug-Magnetic	24	131-6985	2	Bearing
2	131-6920	1	Plug-Breather	25	131-6986	10	Screw-HSH
3	131-6969	1	O-Ring	26	131-6987	3	Spring-Selector
4	131-7013	1	Shim (0.35)	27	131-6988	1	Shim
5	131-7011	1	Shim (0.5)	28	131-6989	1	Ring-Snap
6	131-7015	1	Shim (0.4)	29	131-6990	1	Bearing-Needle
7	131-7014	1	Shim (0.3)	30	131-6991	3	Sphere
8	131-6915	4	Washer-Schnorr	31	131-6992	1	Seal-Oil
9	131-6970	2	Pin-Parallel	32	131-6993	2	Sensor-Selector, Gear
10	131-6971	1	Ring-Retaining	33	131-6994	2	Nut
11	131-6972	1	Ring-Snap	34	131-6995	3	Key
12	131-6973	4	Screw	35	131-6996	1	O-Ring
13	131-6974	2	Screw-HSH	36	131-6997	1	Elbow-90 DEG
14	131-6975	1	Fork-Gearbox	37	131-6998	1	Seal-Oil
15	131-6976	1	Cylinder-Gearbox	38	131-6999	1	Screw-Flanged
16	131-6977	1	Gear-Driven	39	131-7000	1	Washer-Pinion
17	131-6978	1	Gear-Drive	40	131-7001	1	Flange-PTO
18	131-6979	1	Gear-Driven	41	131-7002	1	Housing-Gear
19	131-6980	1	Shaft-Driven	42	131-7003	1	Shim-Gear
20	131-6981	2	Bearing-Ball	43	131-7004	1	O-Ring
21	131-6982	2	Cage-Bearing, Needle	44	131-7005	1	Sleeve-Motor
22	131-6983	1	Hub-Selector	45	131-7006	1	Cover-Gear
23	131-6984	1	Collar-Shift				


Drive Shaft Assembly No. AU126653



Drive Shaft Assembly No. AU126653 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	127-6233	2	Flange-Yoke	3	127-6235	1	Slip-Yoke
2	127-6234	2	Joint-Universal	4	127-6236	1	Yoke, Tube And Stub ASM








Engine Assembly



Engine Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	AU124870	1	Engine-Cummins	16	2412-147	4	Clamp-R
2	AU125037	1	Flange-Pump	17	AU862-10030	12	Screw-HSH
3	AU125036	1	Hub-Pump	18	AU112937A1	1	Cable-Throttle
4	AU125035-03	1	Plate-Mounting, Pump	19	AUH327494	1	Swivel
5	AU125213-03	1	Plate-Front Engine Mount, LH	20	AU495-11028	1	Washer-Flat
6	AU8NG28121	4	Isolator-Mounting, Universal	21	3272-2	1	Pin-Cotter
7	33105-030	8	Screw-HHF	22	AU91-GG308-NP12-22	1	Adapter
8	AU126014-03	1	Plate-Rear Engine Mount, LH	23	125-6797	1	Hose ASM
9	AU113262	4	Spacer-Isolator	24	AU218-675	1	Union-Bulkhead
10	86-1990	8	Washer-Thrust	25	AU218-1251	1	Nut-Lock, Bulkhead
11	33106-090	4	Screw-HHF	26	AU218-756	1	Fitting-Cap
12	115-1115	2	Nut-Lock, HHF	27	AU116960-03	1	Bracket-Throttle
13	AU125224-03	1	Plate-Front Engine Mount, RH	28	AU8NG10019-51-03	1	Bracket-Alternator
14	AU126015-03	1	Plate-Rear Engine Mount, RH	29	AU126606	1	Belt-Fan
15	33106-030	8	Screw-HHF	30	AU100869	1	Screw-HHF
				31	33093-00	1	Washer-Flat
				32	AU100877	8	Screw-HH
				33	122-0218	1	Sender-Temperature


Engine Service Parts



Engine Service Parts (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	131-7059	1	Alternator	5	131-7061	1	Starter
2	131-7060	1	Belt	6	131-7062	1	Thermostat
3	AU8NG10019-23	1	Filter-Fuel	7	131-7063	1	Water Pump
4	130-8860	1	Filter-Oil, Engine				


Radiator and Fan Assembly



Radiator and Fan Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	AU124915	1	Fan-Cooling	16	AU109352	1	Tank-Overflow
2	AU217-380	1	Stem-Straight, Bead	17	33104-020	2	Screw-HHF
3	114-0832	1	Hose-Fuel	18	AU100526	2	Nut-Torque, Prevailing
4	AU217-151	1	Stem-Straight, Bead	19	116-4344	1	Hose-Fuel
5	AU217-1101	1	Coupling-Pipe (NPTF)	20	127-1287	1	Seal-Foam
6	AUH434809	2	Valve-Shutoff	21	127-1288	2	Seal-Foam
7	2412-4	1	Clamp-R	22	127-1289	1	Seal-Foam
8	2412-32	5	R-Clamp	23	115-9469	1	Clamp-R
9	AU126607	1	Hose-Radiator, Upper	24	3256-23	4	Washer-Plain
10	125-6747	1	Hose-Radiator, Lower (Molded)	25	322-5	4	Screw-HH
11	2412-3	2	Clamp-Hose	26	3256-26	2	Washer-Flat
12	AU100323	4	Screw-Flange	27	325-6	2	Screw-HH
13	AU125209	1	Cooling ASM	28	2412-92	2	Clamp-Hose
14	AU8HX30005-2	1	Guard-Fan	29	108-3284	1	Hose-Fuel
15	AU125515-03	1	Mount-Tank, Overflow	30	AU112950	3	Protector-Hose
				31	3290-379	6	Tie-Cable


Air Cleaner and Exhaust Assembly



Air Cleaner and Exhaust Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	AU217-1050	1	Fitting-Elbow, 90	15	AU125498	1	Intake-Air
2	108-1531	2	Screw-HHF	16	AU214-3180	1	Clamp-Hose, Worm Gear (Heavy Duty)
3	112-7340	2	Band-Mounting, Air Cleaner	17	AU125250	1	Connector-Intake, Air
4	112-7329	1	Air Cleaner ASM	18	AU125248	1	Tube-Intake, Air
5	AU125242	1	Tube-Exhaust	19	3273-41	3	Screw-HSH
6	AU111840	1	Bolt-U, Clamp	20	127-1239	1	Muffler Support Mount ASM
7	AU129272A1	1	Muffler-Vertical, Oval	20:2	125-8470	1	Decal-Disconnect, Battery
8	AU115334	1	Exhaust-Stack	21	125-6741-03	1	Shield-Exhaust
9	AU125249	1	Connector-Air Intake	22	33105-030	4	Screw-HHF
10	AU102427	1	Clamp-Torque, Constant	23	103-9511	4	Nut-Lock, NI
11	AU102431	2	Clamp-Torque, Constant	24	AU119330	1	Screw-HSH
12	33104-030	4	Screw-HHF	25	114-0031	1	Clamp, T-Bolt
13	104-3082	4	Nut-Lock, HHF				
14	AU106185	1	Clamp-Muffler				

Air Cleaner Assembly No. 112-7329




Air Cleaner Assembly No. 112-7329 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
4	115-8877	1	Filter-Air, Engine (Safety)
5	115-8887	1	Filter-Air, Engine (Primary)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
6	114-5624	1	Valve-Vacuator
7	114-5625	1	Cover ASM


Steering Assembly



Steering Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	AUH672904	1	HYD Priority Flow Divider ASM	18	125-6715	2	Hose ASM
2	AU141535A1	1	HYD Steering Control Valve ASM	19	125-6777	1	Hose ASM
3	AUH672220	1	Steering Column ASM	20	125-6778	1	Hose ASM
3:1	120-2593	1	Boot-Rubber, Bearing	21	125-6789	2	HYD Hose ASM
4	AU496-21041	4	Washer-Flat	22	125-6782	2	Hose ASM
5	323-43	4	Screw-HH	23	353-537	5	Fitting-Elbow, 90 DEG
6	AUF19646	1	Nut	23:1	237-79	1	O-Ring
7	AUA65544	1	Wheel-Steering	24	353-371	1	Fitting-Elbow, 90
8	AU114882A2	1	Cap-Steering Wheel	24:1	237-79	1	O-Ring
9	AU238-5227	1	O-Ring	25	353-375	2	Fitting-Elbow, 90
10	AUH672547	1	HYD Lockout Valve ASM	25:1	237-78	1	O-Ring
11	AU106457	1	Manifold-Return, Hydraulic	27	AU218-5058	1	Connector
12	AU700701358	1	Elbow	27:1	237-79	1	O-Ring
13	AU111865A1	1	Elbow	28	AU218-980	1	Fitting-Swivel, 90 DEG
13:1	237-79	1	O-Ring	29	353-620	1	Fitting-Straight
14	AUL104449	1	Valve-Check	29:1	237-81	1	O-Ring
15	125-6712	1	Hose ASM	30	AU127172	2	Fitting-Straight
16	125-6713	1	Hose ASM	31	AU127173	2	Fitting-Elbow, 90
17	125-6714	1	Hose ASM	32	AU112950	1	Protector-Hose
				33	3290-379	3	Tie-Cable
				34	AUH270603	1	Plate-Orifice

Priority Flow Divider Valve Assembly No. AUH672904




Priority Flow Divider Valve Assembly

No. AUH672904 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	AUH436407	1	Body-Valve
2	AUH436366	1	Spool-Valve
3	AUH436367	1	Plug ASM
4	AUH436365	1	Spring-Spool

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
5	AUH436408	1	Plug-Retaining, Spool Spring
6	AU237-6008	1	O-Ring
7	AUN7163	1	Cartridge-Valve, Relief

Hydraulic Steering Valve Assembly No. AU141535A1




1 = Items Included in Seal Kit

Hydraulic Steering Valve Assembly No. AU141535A1 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	92-9749	1	Seal Kit	1:4		3	O-Ring ●
1:1		1	Seal-Dust ●	1:5		1	O-Ring ●
1:2		1	O-Ring ●	1:6		1	O-Ring ●
1:3		1	Ring-Quad ●				

● Not serviced separately

Lockout Valve Assembly No. AUH672547




Lockout Valve Assembly No. AUH672547 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	AUH270603	1	Plate-Orifice
2	AUA43525	2	Plug ASM
3	AUF88777	2	Poppet
4	AUN13488	2	Eyelet-Poppet

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
5	AU85069C1	2	Spring
6	AUN13369	2	Seat ASM
6:1	AUL33213	1	O-Ring
7	AUN13489	1	Plunger

Hydraulic Tank and Tandem Pump Assembly



Hydraulic Tank and Tandem Pump Assembly (continued)


<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	AU125034	1	Tandem Pump ASM
2	AU105969A1	1	HYD Gear Pump ASM
2:1	550LG31619002	1	Overhaul Service Seal Kit - Purchase From Dynamics Limited Dealer ●■
3	127-1242	1	HYD Tank ASM
4	AU111774A1	1	Bracket-Mounting, Filter
5	AUD121629	1	Oil Filter ASM
5:1	110-4146	1	Filter-HYD
6	AU496-21041	5	Washer-Flat
7	323-5	3	Screw-HH
8	AU100877	2	Screw-HH
9	103-9511	2	Nut-Lock, NI
10	AUH439363	2	Adapter-Special
11	125-6708	1	Hose ASM
12	125-6719	1	HYD Hose ASM
13	125-6723	1	Hose ASM

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
14	125-6727	2	Hose ASM
15	AU218-492	1	Elbow-90
16	285-17	2	Plug-Pipe
17	353-370	3	Fitting-Elbow, 90 DEG
17:1	237-80	1	O-Ring
18	AU218-5112	1	Elbow-90
19	353-385	1	Fitting-Straight
19:1	237-80	1	O-Ring
20	112-3282	1	Fitting-Straight
21	AU238-5152	1	O-Ring
22	AU218-5140	1	Fitting-Elbow, 45
23	127-0519	1	Fitting-Elbow, 45 DEG
24	100-6116	2	Screw-HHF
25	3256-24	2	Washer-Flat
26	323-44	2	Screw-HH
27	127-0518	1	Clamp-R

● Not illustrated

■ Obtain locally.

Front Pump Assembly Tandem Pump No. AU125034




Front Pump Assembly Tandem Pump No. AU125034 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	130-8806	1	Switch-Neutral
2	4510018	1	Overhaul Service Seal Kit - Purchase From Sauer-Danfoss Dealer ●
3	69-3920	1	Piston Ring And O-Ring Kit

● Obtain locally.

Rear Pump Assembly Tandem Pump No. AU125034




Rear Pump Assembly Tandem Pump No. AU125034 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	130-8806	1	Switch-Neutral
2	4510018	1	Overhaul Service Seal Kit - Purchase From Sauer-Danfoss Dealer ●
3	69-3920	1	Piston Ring And O-Ring Kit

● Obtain locally.


Hydraulic Tank Assembly No. 127-1242



Hydraulic Tank Assembly No. 127-1242 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	127-1231	1	HYD Tank And Decal ASM	10	AU637-63153	1	O-Ring
1:2	125-8483	1	Decal-HYD Fluid	11	AU91-202713-16-1	2	Adapter
2	AU105820	1	Cap-HYD Fluid (W/ Lock)	11:1	237-146	1	O-Ring
3	AU8PG00005	1	Gauge-Level, Fluid (W/Thermometer)	12	AU118209	2	Strainer-Mounted, Tank
4	AU119908	1	Plug-Hex, Magnetic	13	AU218-5072	1	Fitting-Straight
5	AU8NG28121	4	Isolator-Mounting, Universal	13:1	237-101	1	O-Ring
6	AU496-81018	4	Washer-Flat	14	AU105912	1	Tape-Anti Skid, Lower Step
7	115-1115	4	Nut-Lock, HHF	15	AUH433994	1	Strip-Anti Skid
8	33106-080	4	Screw-HHF	16	127-1273	1	Strip-Seal
9	AU119493	1	Sensor-Sender, Oil/Water Temp	17	AU218-5086	1	Adapter-Straight
				17:1	237-101	1	O-Ring
				18	AU31543	1	Breather


Bulkhead and Hose Mounting Assembly



Bulkhead and Hose Mounting Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	127-1241	1	Bulkhead Mount Plate ASM	23	125-6784	1	Hose ASM
1:2	125-8482	1	Decal-Fluid, Hydraulic (In)	24	125-6722	1	Hose ASM
1:3	125-8481	1	Decal-Fluid, Hydraulic (Out)	25	125-6728	1	Hose ASM
2	AU218-673	2	Union-Bulkhead	26	125-6769	1	Hose ASM
3	AU218-675	1	Union-Bulkhead	27	125-6775	1	Hose ASM
4	AU201-366	2	Elbow-Bulkhead, 45	28	353-370	1	Fitting-Elbow, 90 DEG
4:1	340-65	2	O-Ring	28:1	237-80	1	O-Ring
5	AU218-717	5	Elbow-Bulkhead, 45	29	340-129	2	Fitting-Elbow, 90 DEG
6	AU218-1251	1	Nut-Lock, Bulkhead	29:1	237-146	1	O-Ring
7	AU218-1256	5	Nut-Lock, Bulkhead	29:2	340-65	1	O-Ring
8	AU218-1254	2	Nut-Lock, Bulkhead	30	AU218-5294	1	Fitting-Tee
10	AUH673212	2	Fitting-Special	31	353-877	2	Fitting-HYD, Tee
11	AU100877	3	Screw-HH	32	AU218-335	1	Cap
12	103-9511	3	Nut-Lock, NI	33	AU218-980	2	Fitting-Swivel, 90 DEG
13	AU126562-03	1	Plate-Cover	34	AU218-5585	1	Fitting-Tee
14	AU100861	3	Nut-U	34:1	237-146	1	O-Ring
15	AU100869	3	Screw-HHF	35	AU218-5063	1	Fitting-Straight
16	125-6717	1	Hose ASM	36	01-201-4520	2	Cap
17	125-6768	1	Hose ASM	37	AU201-901	2	Fitting-Cap
18	125-6720	1	Hose ASM	38	AU218-756	1	Fitting-Cap
19	125-6721	2	Hose ASM	39	AU218-767	2	Fitting-Straight
20	125-6771	1	Hose ASM	40	127-0519	1	Fitting-Elbow, 45 DEG
21	125-6774	1	Hose ASM	41	127-1063	1	Sleeve-Protective
22	125-6783	1	Hose ASM				


Directional Valve and Hydraulic Hose Assembly



Directional Valve and Hydraulic Hose Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	26-4840	4	Spacer-Pin, Mounting	22	T0000-5536	2	Fitting-Swivel, 45
2	AU8HV80164	2	Directional Valve ASM	23	3290-379	17	Tie-Cable
3	AU218-696	2	Fitting-Elbow, 90	24	127-0516	1	Clamp-R, Double
4	AUH673212	1	Fitting-Special	25	95-0581	1	Fitting-Elbow, 90 DEG
5	AU100327	4	Screw-Flange	26	AU218-5241	1	Fitting-Tee
6	104-3082	4	Nut-Lock, HHF	27	353-426	2	Fitting-90 DEG
7	125-6705	1	Hose ASM	27:1	237-80	1	O-Ring
8	125-6706	1	Hose ASM	29	353-385	1	Fitting-Straight
9	125-6707	1	Hose ASM	29:1	237-80	1	O-Ring
10	125-6785	6	Hose ASM	31	AU218-673	6	Union-Bulkhead
11	125-6772	1	Hose ASM	33	AU218-1254	6	Nut-Lock, Bulkhead
12	125-6773	1	HYD Hose ASM	34	01-201-4520	2	Cap
13	125-6774	2	Hose ASM	35	3234-9	1	Screw-HHF
14	125-6776	1	Hose ASM	36	AU112950	4	Protector-Hose
15	125-6779	1	HYD Hose ASM	37	127-1063	1	Sleeve-Protective
17	125-6781	2	Hose ASM	38	AU218-1256	2	Nut-Lock, Bulkhead
18	125-6766	1	Hose ASM	39	AU224-2206	1	Nut-Square
19	125-6786	1	Hose ASM	40	94-7023	1	Adaptor
20	125-6787	1	Hose ASM	41	3256-23	4	Washer-Plain
21	353-433	2	Fitting-Straight				

Oil Filter and 60 CC Hi Motor Assembly




Oil Filter and 60 CC Hi Motor Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	AUD125507	1	Oil Filter ASM
2	AU496-21041	5	Washer-Flat
3	323-5	4	Screw-HH
4	AU125010	1	HYD Motor ASM
5	AU120043	1	Spacer
6	AU218-5044	1	Adapter-Straight
6:1	237-81	1	O-Ring
7	AU100328	2	Screw-HHF
8	104-3082	7	Nut-Lock, HHF
9	114-9566	2	Clamp-R
10	AU218-582	1	Fitting-Tee
11	AUH627513	1	Valve-Check
12	AU218-459	1	Adapter
13	AU91-203101-16-1	1	Fitting-Tee
14	125-6701	1	Hose ASM
15	125-6702	1	Hose ASM
16	125-6703	1	Hose ASM
17	125-6709	1	Hose ASM
18	125-6710	1	Hose ASM
19	125-6711	1	Hose ASM
20	125-6724	1	Hose ASM
21	125-6770	1	Hose ASM
22	125-6791	1	Hose ASM

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
23	127-9663	1	Fitting-Elbow, 90
23:1	237-81	1	O-Ring
24	3290-379	14	Tie-Cable
25	AU218-5176	1	Fitting-Elbow, 45
26	AU218-5234	1	Fitting-Elbow, 90
27	353-545	1	Fitting-Straight
28	AU218-5110	2	Elbow-90 DEG
28:1	237-146	1	O-Ring
29	353-877	1	Fitting-HYD, Tee
30	AU218-5069	2	Fitting-Straight
31	AU100325	3	Screw-Flange
32	127-0518	2	Clamp-R
33	AU218-980	1	Fitting-Swivel, 90 DEG
34	353-370	1	Fitting-Elbow, 90 DEG
34:1	237-80	1	O-Ring
35	AU218-5140	1	Fitting-Elbow, 45
36	353-620	1	Fitting-Straight
36:1	237-81	1	O-Ring
37	AU112950	2	Protector-Hose
38	33104-080	2	Screw-HHF
39	3256-23	7	Washer-Plain

Hydraulic Motor Assembly No. AU125010




Hydraulic Motor Assembly No. AU125010 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	11044525	1	Overhaul Service Seal Kit - Purchase From Sauer-Danfoss Dealer ●

● Obtain locally.


Solenoid Valve and Hose Assembly



Solenoid Valve and Hose Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
2	AU8TS06212	2	3/4 Inch Split Flange Kit	14	125-6767	1	Hose ASM
3	98-4799	4	Spacer	16	125-6790	1	Hose ASM
4	AU187505C91	1	Solenoid Valve ASM	17	125-6718	1	Hose ASM
5	321-24	2	Screw-HH	18	AU218-5118	2	Elbow
6	AUH426767	2	Washer-Flat	19	353-374	1	Fitting-Elbow, 90 DEG
7	353-384	1	Fitting-Straight	19:1	237-42	1	O-Ring
7:1	237-42	1	O-Ring	20	AU218-5243	2	Fitting-Tee
8	AU218-980	1	Fitting-Swivel, 90 DEG	20:1	237-42	1	O-Ring
9	104-7201	2	Nut-HF	21	127-1618	1	Fitting-Straight
10	125-6704	1	Hose ASM	22	AU864-14040	4	Screw-HSH
11	125-6725	1	Hose ASM	23	AU127171	2	Adapter
12	125-6726	1	Hose ASM	24	AU112950	2	Protector-Hose
13	125-6729	2	Hose ASM	25	3290-379	6	Tie-Cable


Fuel Tank Assembly



Fuel Tank Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	127-1232	1	Fuel Tank ASM	12	127-6618	1	Strip-Seal
1:2	125-8478	1	Decal-Diesel	13	127-1292	1	Cap-Diesel Fuel, Non-Vented
2	AU8TA60006	2	Fitting-Straight	14	AU31543	1	Breather
3	AU8NG28121	4	Isolator-Mounting, Universal	15	125-4529	1	Hose-Fuel
4	AU496-81018	12	Washer-Flat	16	127-0946	1	Hose-Fuel
5	33106-080	2	Screw-HHF	17	127-1245	1	Hose-Fuel
7	AU119908	1	Plug-Hex, Magnetic	18	AU105912	1	Tape-Anti Skid, Lower Step
8	2412-108	6	Clamp-Worm	19	33106-090	2	Screw-HHF
9	AU8NG10019-24	1	Filter-Inline Fuel	20	127-6619	1	Strip-Seal
10	AUH433994	1	Strip-Anti Skid				
11	AU125245	1	Sender-Fuel Level				


Ground Drive Control Assembly



Ground Drive Control Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	AU125532-03	1	Plate-Floor	19	AUH358374	2	Rod End-Female
2	AU125349-03	1	Plate-Gusset	20	3296-3	2	Nut-Lock
3	AUH674569	1	Mount	21	3220-1	2	Nut-Jam
4	AU136779A1	1	Shaft	22	AU102691A1	2	Ground Drive Control Cable ASM
5	AUS5625	2	O-Ring	23	33104-025	6	Screw-HHF
6	AUH438122	1	Spring-Locking	24	AUH675066	1	On/Off Toggle Switch ASM
7	AU125311	1	Handle	24:1	AUH438667	1	Switch-Toggle
8	AUH438152	2	Screw-Set	25	3256-24	1	Washer-Flat
9	3256-14	3	Washer-Flat	26	AU116400A1	1	Boot-Switch, Toggle
10	3290-321	6	Screw-HWH	27	AU126572	4	Washer
11	AUH438119	1	Plug-Friction	28	AUH166421	1	Bolt-U
12	AUH438151	1	Screw-HSH	33	127-1297	2	Strip-Anti Skid
13	AU125310-03	1	Plate-Control	34	127-1298	1	Strip-Anti Skid
14	AUD128268	1	Grip-Handle	35	AUH373779	1	Spacer
15	AU107152A1-03	1	Pedal-Toe	36	AU100861	4	Nut-U
16	AU107153A1-03	1	Pedal-Heel	37	104-7201	2	Nut-HF
17	AU107156A1	1	Pin-Pedal	38	AUH439229	1	Bushing
18	65-2720	2	Ring-Retaining, Clip				


Ground Drive Linkage Assembly



Ground Drive Linkage Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	AUD128616	6	Bushing-Insert, Plastic	19	AUH437601-03	2	Lever-Control, Pump
2	AU125307-03	1	Shaft-Control	20	146375	2	Nut-Lock, Cone
3	AU495-11081	2	Washer-Flat	21	AU125576	1	Rod-Linkage
4	AUD38296	6	Joint-Ball	22	AUH436588	1	Rod-Linkage
5	AU232-4616	5	Nut-Hex	23	AU125321	1	Rod-Control
6	3272-12	2	Pin-Cotter	24	3256-3	8	Washer-Flat
7	3220-3	6	Nut-HJ	25	323-32	1	Screw-HH
8	AU106411A1-03	1	Channel-Mounting, Bellcrank	26	97-1204	3	Nut-Hex
9	97-1206	1	Locknut	27	AU125908-03	1	Plate-Mount
10	AU126576-03	1	Stop-Lever, Pump	28	AUH166421	1	Bolt-U
11	AU326-424	3	Screw-HH	29	3296-5	1	Nut-Hex
12	AU125320	1	Pivot-Bellcrank	30	323-7	2	Screw-HH
13	AUH435694	1	Spacer	31	3234-1	4	Screw-HHF
14	AUH436215	1	Washer-Special	32	32128-36	4	Nut-HF
15	AUH436303	1	Spring	33	AUH373779	1	Spacer
16	325-10	1	Screw-HH	34	3296-3	2	Nut-Lock
17	AUH439075	1	Spacer-Pivot, Bellcrank	35	127-1226	1	Sleeve-Protective
18	AU125318	1	Link-Mounting, Cable	36	AUH358374	2	Rod End-Female


ROPS and Platform Assembly



ROPS and Platform Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	125-6730-03	1	Platform-Operator	13	108-1531	4	Screw-HHF
2	125-6737	1	Seat ASM	14	AUA141451	4	Mount-Rear
3	3256-27	20	Washer-Flat	15	AUA141470	4	Washer-Snubbing
4	AU232-41110	12	Nut-Lock, Hex	16	AUD89007	4	Washer
5	127-1235	1	Battery Cover ASM	17	AU113-2649	4	Screw-HH
5:2	125-6699	1	Decal-Safety	18	AUH437165	1	Pointer-Indicator, Position
5:3	125-6691	1	Decal-Safety	19	32149-8	2	Nut-Keps
5:4	125-8473	1	Decal-Warning, Battery	20	AUH673996	1	Position Indicator Cable ASM
6	AU125419-01	1	Fender-LH	21	125-6692	2	Decal
7	127-1237	1	RH Fender ASM	22	62-7400	2	Decal
7:2	125-6697	1	Decal-Rear Steering Indicator	23	AU103216	1	Holder-Manual, Operator
7:3	125-8471	1	Decal-Warning, Steering	24	1-803035	4	Rivet-Pop
8	33104-025	14	Screw-HHF	25	AUR46465	1	Lanyard
9	104-3082	14	Nut-Lock, HHF	26	AUR46463	1	Post-Manual
11	127-1884	1	ROPS ASM	27	AUR40745	1	Strap-Tie, Nylon
12	327-26	8	Screw-HH				


Seat and Mounting Assembly



Seat and Mounting Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	127-1233	1	Seat Plate ASM	34	AU126022-03	1	Plate-Bulkhead, Seat
1:2	125-8480	1	Decal-Warning, No Riders	35	AU218-693	5	Elbow
1:3	125-6698	1	Decal-Control, LH	36	AU218-673	5	Union-Bulkhead
1:4	125-6695	1	Decal-Control, RH	36:1	AU218-1254	1	Nut-Lock, Bulkhead
2	AU100526	10	Nut-Torque, Prevailing	37	AU218-1254	10	Nut-Lock, Bulkhead
3	AU495-21050	4	Washer-Flat	38	AU218-694	2	Elbow
4	AU249116A1	1	Seat Belt ASM	39	AU218-1255	2	Nut-Lock
5	AU428-716	1	Screw-HH	40	AU126291	1	Ring-Retaining
6	100-4368	1	Bolt-Blade	41	AU100873	6	Screw-HH
7	130-8820	2	Pivot-Bearing Seat	42	AU126427-03	1	Plate-Mount
8	AU125352	1	Mount-Seat	43	240-3	1	Grommet-Rubber
9	AU109011	1	Spring-Pivot Lock, Seat	44	33103-025	2	Screw-HHF
10	AU495-81163	2	Washer-Flat	45	81-0130	2	Nut-Flange, NI
11	AU432-816	1	Pin-Cotter	46	AU126597	1	Seat ASM
12	32128-23	1	Nut-HF	48	AU218-786	5	Reducer-Tube
13	AU100878	1	Screw-HHF	49	AU218-980	10	Fitting-Swivel, 90 DEG
14	103-9511	1	Nut-Lock, NI	50	AU218-5058	5	Connector
15	AU125537	1	HYD Control Valve ASM	50:1	237-79	1	O-Ring
16	AU8EO24121	1	Cup-Holder	52	AU124119-03	1	Bracket-Seat
17	AUH428284	2	Spacer-Gearbox	53	AU108909	1	Rod-Swing, Seat
18	AUH256305	2	Washer-Friction	54	353-388	5	Fitting-Straight
19	127-1285	1	Lever-Control, Speed	54:1	237-79	1	O-Ring
20	3256-24	2	Washer-Flat	55	94-7146	2	Adapter
21	3217-7	1	Nut-Hex	56	94-7023	2	Adaptor
22	AU125544-03	1	Plate-Mounting, Cable	57	3218-5	3	Nut-Jam
23	3218-3	1	Nut-Jam	58	3256-23	19	Washer-Plain
24	AU114524A1	1	Rod-Linkage	59	106-9888	1	Washer-Flat
25	AUA14051	1	Knob-Control	60	117-1350	4	Nut-HF, Lock
26	60-9870	1	Screw-HH	61	AU100874	4	Screw-HHF
27	322-3	5	Screw-HH	62	127-1293	1	Trim-Battery
28	104-8300	2	Nut-HF, NI	63	127-1295	1	Trim-Base, Control
29	106-0327	2	Nut-Hex	64	127-1296	1	Trim-Base, Control
32	AU126446-03	1	Mount-Seat	65	302-5	1	Fitting-Grease
33	AU515-23159	2	Clamp-R				

Hydraulic Control Valve Assembly No. AU125537




8 = Items Included in Seal Kit

Hydraulic Control Valve Assembly No. AU125537 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	130-8866	3	Spool-Control	4:10	33023-00	3	Nut-Lock
1:7	130-8867	1	Boot-Rubber	4:11	110-7192	2	Pin-Roll
2	130-8868	1	Spool-Control	4:12	130-8876	1	Joint-Joystick, RH
2:2	130-8869	1	Cap-Spool, Control	4:13	131-2640	1	Boot-Joystick
3	130-8871	1	Spool-Control	5	136-7652	1	Lever-Long
4	130-8872	1	Joystick-Mechanism, RH	6	136-7653	3	Lever-Short
4:7	130-8873	1	Pin-Foundation, Joint	7	137-4409	1	Valve-Relief
4:8	130-8874	3	Ball-Joystick	8	139-8878	1	Seal Kit
4:9	09472	3	Washer-Plain				


Dash and Trim Assembly



Dash and Trim Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	AU100861	8	Nut-U	10	127-1222	2	Trim-Edge
2	127-1234	1	Dash Panel ASM	11	127-1223	2	Trim-Edge
2:2	125-8475	1	Decal-Brake, Parking	12	127-1224	1	Trim-Edge
2:3	125-6683	1	Decal-Throttle	13	3234-42	1	Screw-HHF
2:4	125-8472	1	Decal-Ignition	14	104-8301	1	Nut-HF, NI
2:5	125-8484	1	Decal-Aux Power	15	2412-113	1	Clamp-R
3	33103-025	8	Screw-HHF	16	AU105912	5	Tape-Anti Skid, Lower Step
4	125-6765-03	1	Plate-Kick	17	127-1842	1	Plug-Dome
5	32149-8	1	Nut-Keps	18	119-5329	2	Plug-Hole
6	AU125581-03	1	Plate	19	567001	2	Plug-Hole
7	AUL12437	1	Joint-Ball	20	104-9368	1	Plug-Dome
9	127-1221	1	Trim-Edge	21	127-1843	1	Plug-Dome


Main Electrical Assembly



Main Electrical Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	122-0151	1	Wire Harness ASM	6	99-3441	1	Harness-Wire, Fusible Link
1:10	100-4918	1	Diode	7	363-3205	4	Screw-PPH
1:11	94-6710	1	Fuse-2 Amp	8	3296-1	4	Nut-Lock
1:12	218-578	3	Fuse-Blade, 10 Amp	9	AU217-1050	1	Fitting-Elbow, 90
1:13	109355	1	Fuse-Blade, 15 Amp	10	98-5845	1	Nut-Hex
2	108-0344	4	Spacer	11	122-0124	1	Harness-Wire (HYD Drive Extension)
3	AU443897A1	1	Switch-Pressure	12	122-0123	1	Harness-Wire (HYD Temp Extension)
4	AU127738	1	Sender-Water Temp				
5	AU293797A1	1	Switch ASM				


Instrument Panel Electrical Assembly



Instrument Panel Electrical Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	AU125255	1	Instrument Panel ASM	8	AU22000121	1	Receptical-12V DC
2	99-7430	6	Relay-Mini	9	AU463-11012	4	Screw-HH
3	106-9277	1	Module-Control, Standard	10	42863	1	Strip-Jumper
4	42862	1	Block-Terminal, Ground	11	321-13	3	Screw-HH
5	99-7435	1	Relay	12	104-7201	3	Nut-HF
6	121-5159	1	Ignition Switch ASM	13	32105-12	9	Screw
6:2	121-5160	1	Nut-Hex	14	3296-2	9	Nut-Lock, NI
6:3	121-5161	1	Nut-Face	15	3256-14	7	Washer-Flat
6:4	121-5162	1	Set-Key, Ignition				
7	AU113662	2	Switch-Rocker, 2 Pole (On/Off)				

Instrument Panel Assembly No. AU125255




Instrument Panel Assembly No. AU125255 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
3	AU126881	1	Gauge-Fuel
4	AU126878	1	Gauge-Volt
5	AU126879	1	Gauge-Temp
6	AU127902	1	Gauge-HYD Oil Temp
7	AU126983	1	Gauge-Tachometer
8	AU126984	8	Bulb-12 Volt

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
9	AU8EO21402	2	Lens-Dome, Fluted Red (Type T-2)
10	AU8EO21406	5	Lens-Dome, Fluted Amber (Type T2)
11	AU8EO21403	1	Lens-Dome, Fluted Green (Type T2)

Battery and Cable Assembly




Battery and Cable Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	122-0154	1	Cable-Negative	12	104-3082	2	Nut-Lock, HHF
2	122-0157	1	Cable-Battery, Positive	13	AUD127018	2	Strap-Grounding
3		1	Battery (1000CCA) ●■	14	119-4061	2	Screw-HHF
4	AU117616-03	1	Plate-Hold Down, Battery	15	32128-36	2	Nut-HF
5	AUH436311	2	Bolt-Holddown, Battery	16	AU108132	1	Cable-Positive
6	AUR52278	1	Switch-Disconnect, Master	17	104-8301	4	Nut-HF, NI
8	AU105186	1	Post-Battery, Remote	18	2412-4	1	Clamp-R
9	AU114443	1	Cable-Battery, Positive	19	108-1531	2	Screw-HHF
10	2412-71	2	Clamp-R	20	127-1293	1	Trim-Battery
11	33104-030	2	Screw-HHF				

● Obtain locally.

■ Not serviced separately


Parking Brake Assembly



Parking Brake Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	AU126600-03	1	Bracket-Cable, Parking Brake	20	AU127784-03	1	Mount-Brake, Parking
2	AUD129747	1	Spacer	21	353-374	1	Fitting-Elbow, 90 DEG
3	AU126601-03	1	Plate-Mount, Parking Brake	21:1	237-42	1	O-Ring
4	AUD121608	1	Clamp-Cable	22	353-384	1	Fitting-Straight
5	AU100873	6	Screw-HH	22:1	237-42	1	O-Ring
6	AU100526	6	Nut-Torque, Prevailing	23	353-508	1	Plug-HH
7	AU87405607	1	Brake Cable ASM	23:1	237-42	1	O-Ring
8	AUH44206	1	Pin-Clevis	24	340-77	1	Fitting-Elbow, 90 DEG
9	AU432-816	1	Pin-Cotter	24:1	237-22	1	O-Ring
10	3234-42	2	Screw-HHF	24:2	237-42	1	O-Ring
11	104-8301	2	Nut-HF, NI	25	340-159	1	Elbow-90
12	AU100772-03	1	Clamp-Muffler	25:1	237-22	2	O-Ring
13	AU126603	1	HYD Release Cylinder ASM	26	99-7149	1	Pin-Clevis
15	127-1227	1	Solenoid Valve ASM	27	3272-6	1	Pin-Cotter
19	AU126904	1	Link-Cable, Parking Brake	28	125-6788	1	Hose ASM

Hydraulic Release Cylinder Assembly No. AU126603




Hydraulic Release Cylinder Assembly No. AU126603 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	237-22	1	O-Ring
2	33016-00	2	Nut-Hex
3	127-6218	1	Pin-Clevis
4	127-6219	1	Clevis

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
5	3272-10	1	Pin-Cotter
6	33035-00	1	Nut-Hex
7	127-6217	1	Boot-Dust


Backfill Blade Assembly



Backfill Blade Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	AU125298-03	1	Pivot-Backfill	17	AUH674649-03	2	Shoe-Skid
2	AU103984A1-03	1	Frame	18	AU496-21053	24	Washer-Flat
3	AUH673758-03	1	Blade	19	325-7	4	Screw-HH
4	AU103989A1	2	HYD Cylinder ASM	20	325-5	4	Screw-HH
5	AU125503	2	Pin-Link	21	AUH438472	1	Bracket-Hose
6	AU125502	2	Pin-Link	22	AU125681	1	HYD Cylinder ASM
7	32151-36	12	Ring-Retaining	23	AU439-11648	2	Pin-Headed
8	AU125547	1	Pin-Pivot	24	3272-33	2	Pin-Cotter
9	AU103993A1	1	Pin-Frame	25	AUH438314	3	Clamp
10	AUD25279	2	Ring	26	AU224-2206	3	Nut-Square
11	AUH437684	2	Pin-Cylinder	27	AU496-21041	5	Washer-Flat
12	AUH674312	1	HYD Cylinder ASM	28	323-7	2	Screw-HH
13	AUH438278-03	8	Shim-Retainer	30	32128-43	2	Nut-Flange
14	AUH438273-03	2	Retainer-Blade	31	AU103-16125	2	Ring-Retaining
15	3256-27	6	Washer-Flat	32	323-8	3	Screw-HH
16	327-4	6	Screw-HH				

Hydraulic Cylinder Assembly No. AU103989A1




Hydraulic Cylinder Assembly No. AU103989A1 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	AU117269A1	1	Rod
2	AU117271A1	1	Bushing
3	3211-42	1	Screw-HH
4	AU117268A1	1	Case-A
5	AU117267A1	1	Piston
6	AU117270A1	1	Head
7	AU117272A1	1	Seal Kit
7:1		1	Wiper-Piston Rod ●

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
7:2		1	Seal-U Cup ●
7:3		1	O-Ring, Gland ●
7:4		1	Ring-Back Up ●
7:5		1	O-Ring, Piston Rod ●
7:6		1	Seal-Piston ●
7:7		1	O-Ring, Piston ●
7:8		2	Ring-Wear ●

● Not serviced separately

Hydraulic Cylinder Assembly No. AUH674312




Hydraulic Cylinder Assembly No. AUH674312 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	AUH674937	1	Case ASM
2	AU85260C1	1	Head
3	AUH674938	1	Rod-Piston
4	AUH439025	1	Piston
5	AU232-46314	1	Nut-Lock
6	127-6196	1	Seal Kit
6:1		1	Wire-Locking, Gland ●
6:2		1	O-Ring, Gland ●

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
6:3		1	Ring-Back Up ●
6:4		1	Wiper-Piston Rod ●
6:5		1	Seal-U Cup ●
6:6		1	O-Ring, Piston Rod ●
6:7		1	O-Ring, Piston ●
6:8		1	Ring-Back Up ●
6:9		2	Ring-Wear, Piston ●

● Not serviced separately


Hydraulic Cylinder Assembly No. AU125681



Hydraulic Cylinder Assembly No. AU125681 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	131-0167	1	Piston Seal Kit
2	131-0168	1	Gland Seal Kit

Backfill Blade Hose Assembly



Backfill Blade Hose Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	AUL104616	2	Fitting	4	125-6796	2	Hose ASM
2	353-212	1	Fitting-Elbow, 45 DEG	5	125-6795	1	Hose ASM
2:1	237-42	1	O-Ring	6	125-6794	1	Hose ASM
3	353-374	5	Fitting-Elbow, 90 DEG	7	125-6793	2	Hose ASM
3:1	237-42	1	O-Ring				

Attachments and Accessories

For 25430 RT600 Traction Unit

Product Name	Model/Part
Standard Pulling Blade, VST-24E 18/24 Plow Depth	131-6284
Standard Pulling Blade, VST-24F 18/24 Plow Depth.....	131-6285
Standard Pulling Blade, 24/30 Plow Depth	131-6286
Standard Pulling Blade, 30/36 Plow Depth	131-6287
Standard Pulling Blade, 36/42 Plow Depth	131-6288
Standard Pulling Blade, 42/48 Plow Depth	131-6289
Plow Blade, 18/24 Plow Depth.....	132-4950
Plow Blade, .75 W, 18/24 G-C, 10.0 R	132-4951
Plow Blade, .75 W, 24/30 G-C, 8.0 R	132-4952
Plow Blade, .75 W, 24/30 G-C, 10.0 R	132-4953
Plow Blade, .75 W, 30/36 G-C, 8.0 R	132-4954
Plow Blade, .75 W, 30/36 G-C, 10.0 R	132-4955
Plow Blade, 1.00 W, 18/24 G-C, 8.0 R	132-4956
Plow Blade, 1.00 W, 24/30 G-C, 8.0 R	132-4957
Plow Blade, 1.00 W, 24/30 G-C, 8.0 R	132-4958
Plow Blade, 1.00 W, 24/30 G-C, 10.0 R	132-4959
Plow Blade, 1.00 W, 30/36 G-C, 8.0 R	132-4960
Plow Blade, 1.00 W, 30/36 G-C, 10.0 R	132-4961
Plow Blade, 1.50 W, 18/24 G-C, 8.0 R	132-4962
Plow Blade, 1.50 W, 18/24 G-C, 8.0 R	132-4963
Plow Blade, 1.50 W, 18/24 G-C, 10.0 R	132-4964
Plow Blade, 1.50 W, 18/24 G-C, 13.0 R	132-4965
Plow Blade, 1.50 W, 18/24 G-C, 13.0 R	132-4966
Plow Blade, 1.50 W, 24/30 G-C, 10.0 R	132-4967
Plow Blade, 1.50 W, 24/30 G-C, 13.0 R	132-4968
Plow Blade, 1.50 W, 30/36 G-C, 8.0 R	132-4969
Plow Blade, 1.50 W, 30/36 G-C, 10.0 R	132-4970
Plow Blade, 1.50 W, 30/36 G-C, 13.0 R	132-4971
Plow Blade, 1.50 W, 36/42 G-C, 8.0 R	132-4972
Plow Blade, 1.50 W, 36/42 G-C, 10.0 R	132-4973
Plow Blade, 1.50 W, 36/42 G-C, 13.0 R	132-4974
Plow Blade, 2.00 W, 18/24 G-C, 10.0 R	132-4975
Plow Blade, 2.00 W, 18/24 G-C, 13.0 R	132-4976
Plow Blade, 2.00 W, 24/30 G-C, 10.0 R	132-4977
Plow Blade, 2.00 W, 24/30 G-C, 13.0 R	132-4978
Plow Blade, 2.00 W, 30/36 G-C, 10.0 R	132-4979
Plow Blade, 2.00 W, 30/36 G-C, 13.0 R	132-4980
Plow Blade, 2.00 W, 36/42 G-C, 10.0 R	132-4981
Plow Blade, 2.00 W, 36/42 G-C, 13.0 R	132-4982
Plow Blade, 2.50 W, 24/30 G-C, 13.0 R	132-4983
Plow Blade, 2.50 W, 24/30 G-C, 20.0 R	132-4984
Plow Blade, 2.50 W, 30/36 G-C, 13.0 R	132-4985
Plow Blade, 2.50 W, 30/36 G-C, 20.0 R	132-4986
Plow Blade, 2.50 W, 36/42 G-C, 13.0 R	132-4987
Plow Blade, 2.50 W, 36/42 G-C, 20.0 R	132-4988
Plow Blade, 3.00 W, 30/36 G-C, 13.0 R	132-4989

Attachments and Accessories (continued)

Plow Blade, 3.00 W, 30/36 G-C, 20.0 R	132-4990
Plow Blade, 3.00 W, 36/42 G-C, 13.0 R	132-4991
Plow Blade, 3.00 W, 36/42 G-C, 20.0 R	132-4992
Additional Depth Setting	132-4993
Tape Tube	132-4994
Blade, MAXI-TRAC 18/24 Depth, E	132-4995
Blade, MAXI-TRAC 18/24 Depth, F	132-4996
Blade, MAXI-TRAC 24/30 Depth, F	132-4997
Blade, MAXI-TRAC 30/36 Depth, F	132-4998
Blade, MAXI-TRAC 36/42 Depth, F	132-4999
Blade, MAXI-TRAC 42/48 Depth, H	132-5000
Bullet, 2.00	132-5001
Bullet, 3.00	132-5002
Bullet, 4.00	132-5003
Bullet, 5.00	132-5004
Bullet, 6.00	132-5005
Plow Blade, .75 CW, 18/24 GC, 8 RAD	132-5006
Plow Blade, .75 CW, 18/24 GC, 10 RAD	132-5007
Plow Blade, .75 CW, 24/30 GC, 8 RAD	132-5008
Plow Blade, .75 CW, 24/30 GC, 10 RAD	132-5009
Plow Blade, 1.00 CW, 18/24 GC, 8 RAD	132-5010
Plow Blade, 1.00 CW, 18/24 GC, 10 RAD	132-5011
Plow Blade, 1.00 CW, 24/30 GC, 8 RAD	132-5012
Plow Blade, 1.00 CW, 24/30 GC, 10 RAD	132-5013
Plow Blade, 1.00 CW, 30/36 GC, 8 RAD	132-5014
Plow Blade, 1.00 CW, 30/36 GC, 10 RAD	132-5015
Plow Blade, 1.00 CW, 30/36 GC, 13 RAD	132-5016
Plow Blade, 1.50 CW, 18/24 GC, 8 RAD	132-5017
Plow Blade, 1.50 CW, 18/24 GC, 10 RAD	132-5018
Plow Blade, 1.50 CW, 18/24 GC, 13 RAD	132-5019
Plow Blade, 1.50 CW, 24/30 GC, 8 RAD	132-5020
Plow Blade, 1.50 CW, 24/30 GC, 10 RAD	132-5021
Plow Blade, 1.50 CW, 24/30 GC, 13 RAD	132-5022
Plow Blade, 1.50 CW, 30/36 GC, 8 RAD	132-5023
Plow Blade, 1.50 CW, 30/36 GC, 10 RAD	132-5024
Plow Blade, 1.50 CW, 30/36 GC, 13 RAD	132-5025
Plow Blade, 1.50 CW, 36/42 GC, 8 RAD	132-5026
Plow Blade, 1.50 CW, 36/42 GC, 10 RAD	132-5027
Plow Blade, 1.50 CW, 36/42 GC, 13 RAD	132-5028
Plow Blade, 2.00 CW, 18/24 GC, 10 RAD	132-5029
Plow Blade, 2.00 CW, 18/24 GC, 13 RAD	132-5030
Plow Blade, 2.00 CW, 24/30 GC, 10 RAD	132-5031
Plow Blade, 2.00 CW, 24/30 GC, 13 RAD	132-5032
Plow Blade, 2.00 CW, 30/36 GC, 10 RAD	132-5033
Plow Blade, 2.00 CW, 30/36 GC, 13 RAD	132-5034
Plow Blade, 2.00 CW, 36/42 GC, 10 RAD	132-5035
Plow Blade, 2.00 CW, 36/42 GC, 13 RAD	132-5036
Plow Blade, 2.50 CW, 24/30 GC, 13 RAD	132-5037
Plow Blade, 2.50 CW, 24/30 GC, 20 RAD	132-5038

Attachments and Accessories (continued)

Plow Blade, 2.50 CW, 30/36 GC, 13 RAD	132-5039
Plow Blade, 2.50 CW, 30/36 GC, 20 RAD	132-5040
Plow Blade, 2.50 CW, 36/42 GC, 13 RAD	132-5041
Plow Blade, 2.50 CW, 36/42 GC, 20 RAD	132-5042
Plow Blade, 3.00 CW, 30/36 GC, 13 RAD	132-5043
Plow Blade, 3.00 CW, 30/36 GC, 20 RAD	132-5044
Plow Blade, 3.00 CW, 36/42 GC, 13 RAD	132-5045
Plow Blade, 3.00 CW, 36/42 GC, 20 RAD	132-5046
Direct Drive Trencher.....	25200
Direct Drive Trencher.....	25200E
Combo for Direct Drive Trencher and P85 Plow	25201
Combo for Direct Drive Trencher and P85 Plow	25201E
48in Direct Drive Boom.....	25202
48in Direct Drive Boom.....	25202E
60in Direct Drive Boom.....	25203
60in Direct Drive Boom.....	25203E
Sliding Offset Kit, Centerline Trencher.....	25204
Sliding Offset Kit, Centerline Trencher.....	25204E
P85 Vibratory Plow	25401
P85 Vibratory Plow	25401E
Horn Kit, RT600 or RT1200 Trencher	25409
Horn Kit, RT600 or RT1200 Trencher	25409E
Beacon Kit, RT600 or RT1200 Trencher	25415
Beacon Kit, RT600 or RT1200 Trencher	25415E
Back-Up Alarm Kit	25428
Back-Up Alarm Kit	25428E
Heavy Duty Center Line Trencher.....	25431
Heavy-Duty Centerline Trencher	25431E
Heavy Duty Backhoe 125	25432
Heavy Duty Backhoe 125	25432E
Backhoe Drive Release Kit (Tow Valve Kit)	25433
Backhoe Drive Release Kit (Tow Valve Kit)	25433E
48in Heavy Duty Crumber.....	25435
48in Heavy Duty Crumber.....	25435E
60in Heavy Duty Crumber.....	25436
60in Heavy Duty Crumber.....	25436E
48in Heavy Duty Rock Boom	25437
48in Heavy Duty Rock Boom with Restraint Bar	25437E
60in Heavy Duty Rock Boom With Rest Bar.....	25438
60in Heavy Duty Rock Boom with Restraint Bar	25438E
Counterweight Kit	25439
Counterweight Kit	25439E
Auxiliary Valve Kit	25445
Auxiliary Valve Kit	25445E
Rear Steering Indicator Kit.....	25520
Rear Steering Indicator Kit.....	25520E
6in x 48in 2 Pitch Cup Chain, Utility Trencher	TR26506235
6in x 60in 2 Pitch Cup Chain, Utility Trencher.....	TR26506240
6in x 48in Terminator and Cup Combo Chain, Utility Trencher.....	TR26506C35

Attachments and Accessories (continued)

6in x 60in Terminator and Cup Combo Chain, Utility Trencher.....	TR26506C40
6in x 48in H-Plate, Rock and Frost Chain, Utility Trencher	TR26506H35
6in x 60in H-Plate, Rock and Frost Chain, Utility Trencher	TR26506H40
6in x 48in Mixed Rock and Frost Chain, Utility Trencher.....	TR26506M35
6in x 60in Mixed Rock and Frost Chain, Utility Trencher.....	TR26506M40
6in x 48in Rock and Frost Chain, Utility Trencher	TR26506R35
6in x 60in Rock and Frost Chain, Utility Trencher	TR26506R40
6in x 48in Solid Weld Terminator Chain, Utility Trencher	TR26506S35
6in x 60in Solid Weld Terminator Chain, Utility Trencher	TR26506S40
6in x 48in Bolt-On Terminator Chain, Utility Trencher	TR26506T35
6in x 60in Bolt-On Terminator Chain, Utility Trencher	TR26506T40
8in x 48in 2 Pitch Cup Chain, Utility Trencher.....	TR26508235
8in x 60in 2 Pitch Cup Chain, Utility Trencher.....	TR26508240
8in x 48in Terminator and Cup Combo Chain, Utility Trencher.....	TR26508C35
8in x 60in Terminator and Cup Combo Chain, Utility Trencher.....	TR26508C40
8in x 48in H-Plate, Rock and Frost Chain, Utility Trencher	TR26508H35
8in x 60in H-Plate, Rock and Frost Chain, Utility Trencher	TR26508H40
8in x 48in Mixed Rock and Frost Chain, Utility Trencher.....	TR26508M35
8in x 60in Mixed Rock and Frost Chain, Utility Trencher.....	TR26508M40
8in x 48in Rock and Frost Chain, Utility Trencher	TR26508R35
8in x 60in Rock and Frost Chain, Utility Trencher	TR26508R40
8in x 48in Solid Weld Terminator Chain, Utility Trencher	TR26508S35
8in x 60in Solid Weld Terminator Chain, Utility Trencher	TR26508S40
8in x 48in Bolt-On Terminator Chain, Utility Trencher	TR26508T35
8in x 60in Bolt-On Terminator Chain, Utility Trencher	TR26508T40



Count on it.