



Z-Master

Compact Series Z153

with 52" Side Discharge Mower

Model No. 74175—200000001 and Up

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply: the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form **a:b**. The **a** represents the reference number of the entire service assembly and the **b** represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number **6**, the tire by **6:1**, the valve by **6:2**, and the wheel by **6:3**. When you order the assembly identified by reference number **6**, you receive all parts identified by reference numbers **6:1**, **6:2**, and **6:3**. However, you may also order any part individually.

Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form **nX y**. The **n** represents the quantity of the part, the **X** is the multiplication symbol, and the **y** represents the reference number.

For example, in an illustration, the reference number **2X 37** means that two of the parts identified by reference number **37** are indicated.

Contents

Description	Page	Description	Page
Front Frame Assembly	3	Idle, Pulley/Lift Strut, Chains Assembly	16
Height of Cut Handle and Plates	4	Piston/Crankshaft Assembly	17
Main Frame	5	Cylinder/Crankcase Assembly	18
Fuel System Assembly	7	Valve/Camshaft Assembly	19
Parking Brake System Assembly	8	Cooling–Equipment Assembly	20
Motion Control System Assembly	9	Electric–Equipment Assembly	21
Hydraulic System Assembly	10	Control–Equipment Assembly	22
Pump, Idler and Belt Assembly	11	Carburetor Assembly	23
Engine and Clutch Assembly	12	Lubrication–Equipment Assembly	24
Electrical System Assembly	13	Air Filter/Muffler Assembly	25
52" Deck Assembly	14	Fuel–Tank/Fuel Valve Assembly	26
52" Deck Spindle Assembly	15	Starter/Decals Assembly	27


Accessories

Description	Model / Part No.	Description	Model / Part No.
Recycler Kit	59225	Grass Gobbler	30131
Bahaia Mulch Kit	59227	Striping Kit	30121
High Sail Blades (3 required for improved bagging)	56–2390	High Suspension Seat	74210
Bagging System	79460	Hitch Kit	99–8924

Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

Abbreviation	Meaning	Abbreviation	Meaning
AR	as required	INC	incorporated
ASM	assembly	LH	left hand
CARR	carriage	NI	nylon insert
DEG	degrees	PPH	Phillips pan head
FH	flat head	PTH	Phillips truss head
GA	gauge	PTO	power take off
HF	hex flange	RH	right hand
HH	hex head	SFH	slotted fillister head
HHF	hex head flange	SHH	slotted hex head
HLH	hex lag head	SQH	square head
HJ	hex jam	SHWH	slotted hex washer head
HOC	height-of-cut	SPH	slotted pan head
HS	hex socket	SRH	slotted round head
HSBH	hex socket button head	STD	standard
HSFH	hex socket flat head	TAP	self tapping
HSH	hex socket head	TTH	Torx truss head
HWH	hex washer head	WH	wing head
HWHTF	hex washer head thread forming		




Sheet No.:2

Front Frame Assembly

Ref. No.	Part No.	Qty.	Description
1	E632586	2	Caster Wheel ASM
1:1	E633582	1	Wheel & Tire ASM
1:1:1	E633002	1	Tire
1:1:2	E633583	1	Wheel
1:1:3	254-79	2	Bearing-Roller, Cup
1:2	E633581	2	Spacer-Bearing
1:3	E633580	2	Seal-Bearing
1:4	254-78	2	Cone-Bearing
1:5	E633579	1	Spacer-Caster, Front
2	3296-45	2	Nut-Lock, NI
3	E632511	2	Caster
4	E543511	2	Seal-Grease
5	254-94	4	Bearing-Taper/Cone
6	E633508	6	Washer-Bellevue
7	3296-51	2	Nut-Lock NI
8	E543513	2	Cap-Grease
9	322-3	6	Screw-HH
10	3256-23	4	Washer- Flat
11	99-3940	1	Floorpan-Front
11:1	E633553	1	Pad-Antiskid
11:2	E633737	1	Decal- Z-Master
11:3	E633737	1	Decal- Z-Master
12	E653049	1	Hinge-Floorpan
13	99-3930	1	Footrest ASM
13:2	99-3924	1	Decal-Service
13:3	98-5954	1	Decal-Missing, Cover
13:4	E633553	1	Pad-Antiskid

Ref. No.	Part No.	Qty.	Description
14	3229-10	10	Screw-CARR
15	32128-33	10	Nut-HF
16	3230-1	2	Screw-CARR
17	99-3870-01	2	Bracket-Floorpan
18	32128-20	8	Nut-HF
19	88-1270	1	Decal-Safety STD
20	99-3931	1	Front Frame ASM
20:2	E633818	1	Decal
21	32151-103	6	Ring-Snap
22	3256-29	6	Washer-Flat
23	3290-357	12	Nut-Flange, Lock
24	E303327	12	Washer-Spring, Disc
25	323-7	12	Screw-HH
26	3217-11	8	Nut-Hex
27	E633441	4	Swivel-Mount, Deck
28	3218-6	4	Nut-Jam
29	3256-7	2	Washer-Flat
30	E653011	2	Rod-Deck Lift
31	E653009	2	Spring-Assist, Lift
32	3256-27	2	Washer-Flat
33	99-3871-01	1	LH Lift Arm ASM
34	99-3872-01	1	RH Lift Arm ASM
35	302-58	4	Fitting-Grease
36	E811010	2	Plug-Swivel, Caster
37	E800339	2	Screw-HH
38	254-72	4	Bearing-Taper/Cup




Sheet No.:3

Height of Cut Handle and Plates

Ref. No.	Part No.	Qty.	Description
1	323-9	2	Screw-HH
2	32151-103	1	Ring-Snap
3	3290-357	3	Nut-Flange, Lock
4	3296-39	3	Nut-Lock, NI
5	E652235	1	Plate-Lift, Deck
6	E633080	1	Bushing-Lever, Lift
7	E653230	1	Plate
8	E806005	1	Hairpin
9	323-6	1	Screw-HH
10	323-13	1	Screw-HH
11	E633082	1	Bushing-Lever, Lift
12	E652023	1	Lever-Lift
13	E633295	1	Grip-Lever, Lift
14	E633097	1	Pin-Hitch w/Lanyard
15	302-58	1	Fitting-Grease
16	E806003	2	Pin-Cotter, Hair
17	99-3922-03	1	Arm-Lift
18	E633325	1	Spring-Compression
19	3256-24	1	Washer-Flat
20	E633068	2	Arm-Lift, Deck
21	283-2	2	Pin-Clevis
22	E653140	1	Decal-Height, Deck
23	E653147	1	Decal-Height, Deck


Ref. No.	Part No.	Qty.	Description



Sheet No.:4

Main Frame

Ref. No.	Part No.	Qty.	Description	Ref. No.	Part No.	Qty.	Description
1	E513658	2	Bumper-Catcher, Grass	18:3	E633710	1	Armrest-RH
2	99-3932	1	Control Panel ASM	18:4	E633711	1	Armrest-LH
2:2	99-3942	1	Decal-Panel, Control	18:5	E543401	4	Spacer-Track
2:3	E633346	1	Decal-Valve, Fuel	18:6	E643255	1	Track-Locking, 4"
2:4	98-4387	1	Decal-Protection, Ear	18:7	E633859	1	Frame-Seat
3	E603336	1	Control-Choke, Push-Pull	19	93-7340	1	Decal-Toro
4	E807513	2	Bolt-CARR	20	2412-120	2	R-Clamp
5	322-5	3	Screw-HH	21	3256-14	2	Washer-Flat
6	3256-23	2	Washer- Flat	22	32144-34	2	Screw-Forming, Thread
7	E513592	1	Knob-Ball, Red	23	74-0720	1	Tube-Manual
8	322-3	3	Screw-HH	24	E523420	2	Bumper
9	E653089	1	Bracket-Panel, Instrument	25	E652470	1	Frame-Main
10	32128-20	12	Nut-HF	26	32128-33	2	Nut-HF
11	E633696	1	Cable-Throttle	27	65-2690	2	Decal-Surface, Hot
12	3296-2	2	Nut-Lock	28	E653159	2	Wheel And Tire ASM
13	99-3933	1	Console ASM	28:1	E653160	1	Tire
13:2	E633354	2	Decal-Control, Motion	28:2	E653161	1	Wheel
13:3	E513747	1	Decal-Battery	29	E513011	8	Nut-Wheel
14	E632187	1	Frame-Seat	30	322-2	6	Screw-HH
15	321-21	2	Screw-HH	31	100-3969	1	Decal-Z153
16	3296-29	1	Nut-Lock,NI	32	3256-3	2	Washer-Flat
17	E653495	1	Rod-Hold Up, Seat	33	3296-39	2	Nut-Lock, NI
18	E633705	1	Seat ASM				




Sheet No.:4

Main Frame

Ref. No.	Part No.	Qty.	Description
36	E603845	1	Decal-Release, Drive Wheel
38	E643372	1	Decal-Hazardous Mat.

Ref. No.	Part No.	Qty.	Description




Sheet No.:5

Fuel System Assembly

Ref. No.	Part No.	Qty.	Description
1	99-4606	1	Tank-Fuel, LH
2	99-4605	1	Tank-Fuel, RH
3	3256-23	8	Washer- Flat
4	3253-4	4	Washer
5	322-3	4	Screw-HH
6	E543277	2	Elbow-Tank, Fuel
7	E303007	6	Clamp
8	E513645	2	Bushing-Valve, Fuel
9	E543296	2	Grommet-Line, Fuel
10	E543526	2	Line-Fuel
11	E633347	1	Valve-Line, Fuel
12	E633348	1	Line-Fuel
16	E303335	1	Tie-Plastic
17	49019-7001	1	Filter-Fuel (Kawasaki)
20	93-3101	2	Cap-Fuel
21	E633023	4	Stud
22	E633349	4	Spring-Tank, Fuel
23	3296-47	4	Nut-Lock, NI

Ref. No.	Part No.	Qty.	Description




Sheet No.:6

Parking Brake System Assembly

Ref. No.	Part No.	Qty.	Description
1	E806800	2	Pin-Cotter
2	E652134	1	Bracket-Brake, LH
3	E523157	2	Spacer-14 GA
4	E808514	3	Ring-Retaining
5	3256-28	3	Washer-Flat
6	E808283	2	Pin-Clevis
7	3272-10	6	Pin-Cotter
8	E652135	1	Bracket-Brake, RH
9	E811007	2	Fitting-Grease
10	E633454	2	Spring-Brake
11	3219-3	8	Nut-Hex
12	3256-4	4	Washer-Flat
13	E653069	4	Spacer
14	E633144	2	Pin-Trunion
15	323-4	9	Screw-HH
16	E303327	1	Washer-Spring, Disc
17	E653074	1	Handle-Brake, Park
18	E633268	1	Grip-Lever, Brake
19	3253-7	8	Washer-Lock/Sp
20	3217-9	8	Nut-Hex
21	E633102	4	Bearing-Flange, Side
22	3290-357	8	Nut-Flange, Lock
23	E652085	1	Shaft-Brake
24	E808285	4	Pin-Clevis
25	E633131	4	Yoke-Linkage, Brake


Ref. No.	Part No.	Qty.	Description
26	E653061	1	Linkage-Handle, Brake
27	E652073	1	Crank-Brake
28	E653068	4	Spacer
29	E523328	2	Motor-Wheel
29:1	E809036	1	Nut-Castle
29:2	3257-42	1	Key-Woodruff
30	E633477	2	Rod-Brake
32	325-13	8	Screw-HH
33	E633693	2	Band-Brake
34	E634927	2	Hub And Drum ASM
34:2	E633926	4	Stud-Wheel



Sheet No.:7

Motion Control System Assembly

Ref. No.	Part No.	Qty.	Description	Ref. No.	Part No.	Qty.	Description
1	322-17	2	Screw-HH	29	E633257	2	Grip-Control, Motion
2	E653316	2	Pin-Dampner	30	323-9	6	Screw-HH
3	3256-23	6	Washer- Flat	31	E603737	2	Bolt-Return, Neutral
4	E808512	2	E-Ring	32	E603807	2	Spring-Return, Neutral
5	E523027	2	Damper-Control	33	E603735	2	Bushing-Flanged, Nylon
7	E633102	4	Bearing-Flange, Side	36	3256-2	2	Washer-Flat
8	E652467	1	Motion Control, LH	37	3220-2	2	Nut-Jam
9	32128-20	12	Nut-HF	38	E303105	2	Yoke-Adjustable
11	3256-3	4	Washer-Flat	39	E808280	2	Pin-Clevis
12	E543017	2	Joint-Ball	40	3272-5	2	Pin-Cotter
13	322-6	4	Screw-HH				
14	3290-357	8	Nut-Flange, Lock				
15	E632191	1	Lever-LH				
16	3219-2	10	Nut-Hex				
17	E653046	2	Link-Control, Pump				
18	E633152	2	Joint-Ball, LH Thread				
19	323-4	8	Screw-HH				
20	E653092	2	Arm-Control, Pump				
21	E803022	2	Screw				
22	E804524	2	Nut				
23	E652466	1	Motion Control, RH				
24	3296-39	6	Nut-Lock, NI				
25	E633177	2	Arm				
26	E303327	4	Washer-Spring, Disc				
27	323-6	4	Screw-HH				
28	E632193	1	Lever-RH				




Hydraulic System Assembly

Ref. No.	Part No.	Qty.	Description
1	E603841	2	Pump-Hydro
2	E632285	1	Hose-Pressure, Low
3	E513840	2	Elbow-90°
4	E603721	1	Fitting
5	E603827	5	Clamp-Hose
6	E413273	2	Hose-Pressure, Low
7	E413010	2	Sheave w/Hub
8	3242-4	4	Screw-Set, SQH
9	E807272	2	Key
10	323-7	4	Screw-HH
11	3290-357	4	Nut-Flange, Lock
12	E613073	2	Grip
13	3296-42	2	Nut-Lock
14	E801063	4	Screw-PPH
15	E632286	1	Hose-Pressure, Low
16	E603989	2	Elbow
17	E603990	4	Adapter
18	E633605	2	Elbow 90°
19	E653186	1	Hose
20	E653187	1	Hose
21	E654144	1	Hose
22	E603987	1	Elbow
23	E603988	1	Elbow
24	99-4625	1	Hydraulic Tank ASM
24:2	E523552	1	Decal-Hydraulic Tank, Hot Surface

Ref. No.	Part No.	Qty.	Description
25	E523103	1	Gasket-Tank/Cap
26	E513167	1	Cap-Reservior, Hydraulic
27	321-15	2	Screw-HH
28	32128-33	2	Nut-HF
29	E654320	1	Hose
30	E654509	1	Hose ASM
31	E513510	1	Connector-Male
32	E603720	1	Head-Filter
33	32128-20	2	Nut-HF
34	E633750	1	Filter-Hydro
34	E633752	1	Filter-Hydro, Winter
35	322-5	2	Screw-HH
36	E603722	1	Fitting
37	E603826	3	Clamp-Hose
38	E653409	1	Hose-Hyd
39	E653410	1	Hose-Hyd
40	E633786	2	Elbow 90°


Sheet No.:8



Sheet No.:9

Pump, Idler and Belt Assembly

Ref. No.	Part No.	Qty.	Description
1	323-13	1	Screw-HH
2	3256-4	1	Washer-Flat
3	E603044	1	Bushing
4	E811008	1	Fitting-Grease
5	3290-357	3	Nut-Flange, Lock
6	E603414	1	Spring-Extension
7	323-9	1	Screw-HH
8	E213069	1	Washer
9	E303327	1	Washer-Spring, Disc
10	3296-39	1	Nut-Lock, NI
11	3256-24	1	Washer-Flat
12	E603843	1	Pulley-Idler
13	E603496	1	Bushing-Idler
14	E653580	1	Belt-Pump Drive
15	E654143	1	Idler Arm w/Bushings, Zerk
15:2	E513034	2	Bearing-Pivot




Sheet No.:10

Engine and Clutch Assembly

Ref. No.	Part No.	Qty.	Description
1	E800820	1	Screw-HH
2	E603610	2	Washer-Spring, Disc
3	E653048	1	Clutch
4	E653035	1	Sheave-Pump Drive
5	E807259	1	Key
6	E543214	1	Spacer-Crankshaft
7	322-9	4	Screw-HH
8	32128-20	16	Nut-HF
9	322-3	14	Screw-HH
10	3296-29	4	Nut-Lock,NI
11	E652146	1	Strap-Guard, Engine
12	E653095	1	Shield-Guard, Engine
13	E653093	1	Strap-Guard, Engine
14	E653260	1	Muffler
19	E633630	2	Grommet
20	E633545	2	Spacer-Grommet
21	E613235	4	Washer
22	322-6	1	Screw-HH
23	E303335	2	Tie-Plastic
24	E523406	1	Bushing-Mount, Seat
25	E633543	1	Strap-Clutch/Brake
26	322-22	1	Screw-HH
27	3256-3	3	Washer-Flat
28	E653196	1	Bracket-Support, Muffler
30	E653539	1	Shield-Heat

Ref. No.	Part No.	Qty.	Description
31	3230-1	3	Screw-CARR
32	3256-23	3	Washer- Flat
33	3296-29	3	Nut-Lock,NI
*	E653537	1	Engine-23hp Kawasaki (FH680V-AS10)

* Not Illustrated.




Sheet No.:11

Electrical System Assembly

Ref. No.	Part No.	Qty.	Description
1	E303335	7	Tie-Plastic
2	E543316	1	Module-Safety
3	E807533	2	Bolt-CARR
4	E543070	1	Switch-Ignition
5	63-8360	2	Key-Ignition
6	E633673	1	Switch-PTO
7	E513374	1	Meter-Hours, Engine
8	E633181	4	Plate-Tapped
9	E633110	1	Switch-Brake
10	32104-81	10	Screw-Head, Pan
11	32128-33	8	Nut-HF
12	E323229	3	Clip-Loom
13	321-4	7	Screw-HH
14	E633111	2	Switch-Lever, Drive
15	E603479	1	Battery-12v
16	E543391	1	Insulator-Battery
17	E633651	2	Bolt-Hold Down, Battery
18	E543792	2	Wingnut-Nyloc
19	E633652	1	Strap-Hold Down, Battery
20	3256-2	2	Washer-Flat
21	E523282	1	Cable-Ground
22	E523281	1	Cable-Battery
23	E800279	1	Bolt-TAP
24	32128-20	6	Nut-HF


Ref. No.	Part No.	Qty.	Description
25	E804256	1	Nut-Hex, Nyloc
26	E633396	2	Clip-Loom
27	E543393	3	Insulator-Solenoid
29	E633306	1	Wire-Starter
30	E513075	1	Switch-Solenoid, 12v
31	E543286	1	Grommet
32	E303287	2	Tie-Plastic
33	E653154	1	Harness-Wiring
34	322-3	3	Screw-HH
35	E816001	2	Fuse
36	E653036	1	Washer
37	E652072	1	Bracket-Switch, Seat
38	E523415	1	Spring-Switch, Seat
39	E800282	1	Screw-HH
40	E513152	1	Switch-Seat
41	3296-2	2	Nut-Lock
42	E633082	1	Bushing-Lever, Lift
43	E613262	1	Harness-Wire
44	E644427	1	Switch-Tilt
44:2	E643401	1	Decal-Mercury Switch
45	3296-2	2	Nut-Lock



52" Deck Assembly

Ref. No.	Part No.	Qty.	Description
1	3290-357	9	Nut-Flange, Lock
2	68-2730	6	Wheel-Gage
3	98-5967	1	Spacer-Wheel
4	323-28	1	Screw-HH
5	3230-18	4	Screw-CARR
6	29-5590-01	2	Bracket-Pivot
7	40-6230	2	Spring
8	3211-15	2	Screw-HH
9	98-5984	1	Deflector ASM
9:2	54-9220	1	Decal-Danger
10	3296-5	2	Nut-Lock, NI
11	32152-1	4	Nut-Lock, NI
12	32128-17	4	Nut-Flange, Lock
13	249-21	2	Clamp-Slotted
14	99-3896	1	LH Cover ASM
14:2	67-5360	1	Decal-Danger
15	99-3895	1	RH Cover ASM
15:2	67-5360	1	Decal-Danger
16	99-2842	4	Spacer-Wheel
17	E303327	4	Washer-Spring, Disc
20	99-3875	1	52" Deck ASM
20:2	66-6380	1	Decal-Danger
20:3	98-5954	3	Decal-Missing, Cover
20:4	99-3943	1	Decal-Routing, Belt
20:5	43-8480	1	Decal-Danger

Ref. No.	Part No.	Qty.	Description
20:6	93-7818	1	Decal-Torque, Blade Bolt (Int'l)
20:7	98-3798	1	Decal-Wheel, Gage
20:8	98-5953	1	Decal-Sfs
20:10	66-1340	1	Decal-Danger
22	3290-321	4	Screw-HWH
24	321-1	6	Screw-HH
25	32128-33	6	Nut-HF
26	E373034	4	Washer-Swivel




Sheet No.:15

52" Deck Spindle Assembly

Ref. No.	Part No.	Qty.	Description
1	92-5816	3	Bolt-Blade
2	E513435	3	Washer-Spring
3	56-2390	3	Blade
4	100-3976	3	Spindle Housing ASM
4:1	100-3972	1	Spindle Shaft ASM
4:2	302-2	1	Fitting-Grease
4:3	46-8530	1	Bearing ASM
4:4	27-0950	1	Spacer-Bearing, Spindle
4:5	253-139	2	Seal-Oil
4:6	61-4160	1	Spindle
4:7	100-3970	1	Pulley And Hub ASM
4:8	32146-20	1	Nut-Jam
4:9	7-4150	1	Washer-Pinion
5	32128-21	18	Nut-HF
6	3256-24	6	Washer-Flat
7	3231-22	18	Screw-CARR
8	99-3904	1	Belt-Deck


Ref. No.	Part No.	Qty.	Description



Idler, Pulley/Lift Strut, Chains Assembly


Ref. No.	Part No.	Qty.	Description
1	3217-7	1	Nut-Hex
3	3256-24	3	Washer-Flat
4	E613098	2	Pulley-Idler
5	E303327	3	Washer-Spring, Disc
6	323-6	3	Screw-HH
8	E633151	1	Spring-Extension
9	E811008	1	Fitting-Grease
10	E413099	1	Pulley-Idler
11	99-3879	1	Idler Arm ASM w/Bushings
11:2	E513034	2	Bearing-Pivot
12	E603384	1	Bushing-Pivot, Idler
13	3296-41	2	Nut-Lock NI
14	3217-11	2	Nut-Hex
15	3253-8	2	Washer-Lock, Sp
16	E800344	2	Screw-HH
17	E634726	2	Strut ASM
17:1	E632690	1	Strut
17:2	3219-6	1	Nut-Hex
17:3	E633029	1	End-Rod, Spherical
18	302-58	4	Fitting-Grease
19	E632199	2	Pin-Strut, Deck
20	322-3	2	Screw-HH
21	324-6	8	Screw-HH
22	32128-37	16	Nut-Hex Flange
23	E633447	4	Chain-Lift, Deck

Ref. No.	Part No.	Qty.	Description
24	99-3946-01	1	Plate-Retainer, Bolt
25	E800805	1	Screw-HH
26	94-2547	1	Eyebolt
27	3296-39	2	Nut-Lock, NI
28	E809107	2	Washer-hardened



Piston/Crankshaft Assembly Kawasaki FH680V-AS10


Ref. No.	Part No.	Qty.	Description
13001	13001-7007	2	Piston-Engine
13002	13002-7001	2	Pin-Piston
13008	13008-6058	2	Ring-Set-Piston
13025	13025-7002	A/R	Ring-Set, Piston L,0.50
13029	13029-7003	A/R	Piston-Engine L,0.50
13031	13031-7002	1	Crankshaft-Comp
13251	13251-7002	2	Rod-Assy-Connecting
92002	92002-2053	4	Bolt
92033	92033-7005	4	Ring-Snap



Cylinder/Crankcase Assembly Kawasaki FH680V-AS10

Ref. No.	Part No.	Qty.	Description
11004	11004-7004	2	Gasket-Head
11008	11008-7003	1	Head-Comp-Cylinder
11008A	11008-7004	1	Head-Comp-Cylinder No. 2
11022	11022-7002	2	Case-Rocker
11060	11060-7012	1	Gasket, CrankCase Cover
11060A	11060-7013	2	Gasket, Rocker Case
11060B	11060-7014	1	Gasket, Breather
13271	13271-7006	1	Plate
14091	14091-7004	1	Cover
16126	16126-7001	1	Valve
49015	49015-6225	1	Cover-Crankcase
49109	49109-7003	1	Element-Breather
49120	49120-6122	1	Crankcase-Comp
92033	92033-7004	2	Ring-Snap
92043	92043-7001	6	Pin
92049	92049-7001	4	Seal-Oil
92049A	92049-7002	1	Seal-Oil
92049B	92049-7004	1	Seal-Oil
92049C	92049-7005	1	Seal-Oil
130	130B0612	4	Bolt-Flanged
130A	130B0640	4	Bolt-Flanged
130B	130T0850	18	Bolt-Flanged
130C	130T0875	2	Bolt-Flanged

Ref. No.	Part No.	Qty.	Description
172	172G0818	4	Bolt-Stud
214	214B0408	1	Screw-Pan




Valve/Camshaft Assembly Kawasaki FH680V-AS10

Ref. No.	Part No.	Qty.	Description	Ref. No.	Part No.	Qty.	Description
12004	12004-7002	2	Valve-Intake				
12005	12005-7002	2	Valve-Exhaust				
12009	12009-7001	4	Retainer-Valve Spring				
12011	12011-2056	8	Collet				
12016	12016-7006	4	Arm-Rocker				
12032	12032-7001	4	Tappet				
13070	13070-7003	2	Guide				
13070A	13070-7004	1	Guide				
13116	13116-7001	4	Rod-Push				
13270	13270-7002	1	Plate				
13271	13271-7007	1	Plate				
42036	42036-7001	1	Sleeve				
49078	49078-7002	4	Spring-Engine Valve				
49118	49118-7003	1	Camshaft-Comp				
92009	92009-2341	4	Screw				
92015	92015-2253	4	Nut				
92033	92033-7001	2	Ring-Snap				
92140	92140-7002	6	Ball				
92145	92145-7001	1	Spring				
92151	92151-7001	4	Bolt				
92200	92200-7001	1	Washer				

Cooling-Equipment Assembly Kawasaki FH680V-AS10


Ref. No.	Part No.	Qty.	Description
13270	13270-7007	1	Plate
14037	14037-7008-9H	1	Screen
14091	14091-7002	1	Cover
23062	23062-7005	1	Bracket-Comp
49089	49089-7004	1	Shroud-Engine
49089A	49089-7005	1	Shroud-Engine
49089B	49089-7006	1	Shroud-Engine
55020	55020-7002	1	Guard
59041	59041-7003	1	Fan
59066	59066-7004	1	Housing-Fan
92004	92004-2148	2	Stud
92009	92009-7008	3	Screw, 6x10
92015	92015-1170	4	Nut
92026	92026-7001	3	Spacer, 6.2x7.9x5
92026A	92026-7003	1	Spacer, 6.5x7.9x10.5
92026B	92026-7007	1	Spacer
130	130B0612	9	Bolt-Flanged
130A	130B0620	2	Bolt-Flanged
130B	130B0816	1	Bolt-Flanged

Ref. No.	Part No.	Qty.	Description




Electric-Equipment Assembly Kawasaki FH680V-AS10

Ref. No.	Part No.	Qty.	Description	Ref. No.	Part No.	Qty.	Description
21066	21066-7003	1	Regulator-Voltage				
21171	21171-7001	2	Coil-Assy-Ignition				
21193	21193-7002	1	Flywheel-Assy				
26011	26011-7008	1	Wire-Lead				
26030	26030-7002	1	Harness				
27010	27010-7001	1	Switch				
59031	59031-7001	1	Coil-Charging				
92004	92004-2147	2	Stud				
92009	92009-2308	1	Screw				
92070	92070-7004	2	Plug-Spark,BPR4ES (NGK), Solid				
92072	92072-7003	2	Band				
92151	92151-2097	1	Bolt, 12x30				
92200	92200-7002	1	Washer				
130	130B0620	2	Bolt-Flanged				
224	224B0520	4	Screw-Pan-WP-Cros				
510	510A5100	1	Key-Woodruff				




Control-Equipment Assembly Kawasaki FH680V-AS10

Ref. No.	Part No.	Qty.	Description	Ref. No.	Part No.	Qty.	Description
13107	13107-7011	1	Shaft				
13271	13271-7018	1	Plate				
16169	16169-7005	1	Link-Choke				
16171	16171-7004	1	Link				
39129	39129-7004	1	Spring-Governor				
49103	49103-7002	1	Arm-Governor				
49113	49113-7007	1	Panel-Comp-Control				
92145	92145-7004	1	Spring				
92145A	92145-7005	1	Spring				
92145B	92145-7009	1	Spring				
92150	92150-2182	2	Bolt, 5x18				
92151	92151-7006	1	Bolt, 6x30				
92151A	92151-7014	1	Bolt, 5x30				
92170	92170-7001	2	Clamp				
130	130B0612	2	Bolt-Flanged				
214	214B0408	2	Screw-Pan				
214A	214B0412	1	Screw-Pan				
311	311B0600	1	Nut-Hex				
411	411B0600	1	Washer-Plain				



Carburetor Assembly Kawasaki FH680V-AS10


Ref. No.	Part No.	Qty.	Description	Ref. No.	Part No.	Qty.	Description
11060	11060-7009	1	Gasket, Air Filter	92063	92063-7001	1	Jet—Main, #104
11060A	11060-7010	2	Gasket, Carburetor	92063A	92063-7002	1	Jet—Main, #106
11060B	11060-7011	2	Gasket	92066	92066-7008	2	Plug, Main Jet
11060C	11060-7018	1	Gasket, Float Chamber	92066A	92066-7009	2	Plug, Extension
11060D	11060-7019	2	Gasket, Main Plug	92093	92093-7001	1	Seal
11060E	11060-7020	1	Gasket, Solenoid	92093A	92093-7002	1	Seal
15003	15003-7022	1	Carburetor—Assy	92145	92145-7010	1	Spring
16025	16025-7001	2	Valve—Throttle	92145A	92145-7011	1	Spring
16030	16030-7002	1	Valve—Float	92152	92152-7001	1	Collar
16031	16031-7001	1	Float	92171	92171-7001	1	Clamp
16041	16041-7001	1	Shaft—Carburetor, Choke	92191	92191-7010	1	Tube
16041A	16041-7004	1	Shaft—Carburetor Throttle	130	130B0620	4	Bolt—Flanged
16073	16073-7003	1	Insulator	172	172G0105	2	Bolt—Stud
16126	16126-7004	1	Valve, Choke				
16158	16158-7003	2	Jet—Slow, #56				
16184	16184-7001	1	Chamber—Assy—Float				
16187	16187-7002	2	Needle—Jet				
21188	21188-7001	1	Solenoid				
59076	59076-7002	1	Manifold—Intake				
92009	92009-7003	6	Screw				
92009A	92009-7004	1	Screw				
92009B	92009-7005	4	Screw				
92009C	92009-7006	1	Screw, Drain				
92043	92043-7004	1	Pin—Float				



Lubrication-Equipment Assembly
Kawasaki FH680V-AS10


Ref. No.	Part No.	Qty.	Description
13107	13107-7009	1	Shaft, Oil Pump
13271	13271-7005	1	Plate
14075	14075-7002	1	Cap-Assy
16154	16154-2053	1	Rotor-Pump, In
16154A	16154-2054	1	Rotor-Pump, Out
49065	49065-2078	1	Filter-Oil
49065A	49065-7003	1	Filter-Oil
49116	49116-7001	1	Valve ASM
59051	59051-7004	1	Gear-Spur
59071	59071-7005	1	Joint
59231	59231-7002	1	Filler
92043	92043-7003	1	Pin
92055	92055-7002	1	O-Ring, 6mm
92066	92066-7003	1	Plug
92066A	92066-7007	1	Plug
92140	92140-7003	1	Ball
92145	92145-7002	1	Spring
92210	92210-7005	1	Nut-Nylon, 22mm
130	130B0612	3	Bolt-Flanged
670	670D2016	3	O-Ring

Ref. No.	Part No.	Qty.	Description



Air Filter/Muffler Assembly Kawasaki FH680V-AS10




Ref. No.	Part No.	Qty.	Description	Ref. No.	Part No.	Qty.	Description
11011	11011-7003	1	Case-Air Filter				
11013	11013-7009	1	Element-Air Filter				
11013A	11013-7010	1	Element-Air Filter				
11029	11029-7002	1	Element-Assy-Air Filter				
11060	11060-7016	2	Gasket, Muffler				
16060	16060-7001	1	Pipe-Intake				
42036	42036-7002	1	Sleeve				
92015	92015-1193	2	Nut				
92037	92037-2079	2	Clamp				
92191	92191-7006	1	Tube				
92210	92210-7004	2	Nut				
92210A	92210-7008	2	Nut				
130	130B06105	2	Bolt-Flanged				
172	172G0690	2	Bolt-Stud				
317	317R0800	4	Nut-Hex-Small				
411	411B0600	1	Washer-Plain				
461	461F0800	4	Washer-Spring				



Fuel-Tank/Fuel Valve Assembly Kawasaki FH680V-AS10

Ref. No.	Part No.	Qty.	Description
23062	23062-7004-9H	1	Bracket-Comp
49019	49019-7001	1	Filter-Fuel
49040	49040-2075	1	Pump-Fuel
92170	92170-2088	4	Clamp
92170A	92170-7003	1	Clamp
92191	92191-7003	1	Tube
92191A	92191-7005	1	Tube,6.35x12.7x160
92191B	92191-7007	1	Tube
130	130B0616	2	Bolt-Flanged
130A	130B0620	2	Bolt-Flanged

Ref. No.	Part No.	Qty.	Description



Starter/Decals Assembly Kawasaki FH680V-AS10

Ref. No.	Part No.	Qty.	Description
13101	13101-7001	1	Gear-Assy
21039	21039-7001	1	Brush
21080	21080-7001	1	Armature
21163	21163-7001	1	Starter-Electric
39184	39184-7001	1	Bracket-Assy
92151	92151-7013	1	Bolt
130	130B0816	1	Bolt-Flanged
56033	56033-7001	1	Decal-Manual
56080	56080-7009	1	Decal-Brand

Ref. No.	Part No.	Qty.	Description

