



1. FLOWS SHOWN ARE CALCULATED AT 100% EFFICIENCY UNLESS OTHERWISE NOTED

OPTIONAL FLOW-DIVIDER KIT COMES WITH CHECK VALVES INSTALLED IN PORTS V1 AND V2 FOR FULL-TIME FLOW-DIVIDER. INSTALL SOLENOID VALVES IN V1 AND V2 FOR MANUALLY CONTROLLED FLOW-DIVIDER.