

LAWN-BOY®

48cm

Walk–Behind Mower

Model No. 10925–200000001 and Up

Model No. 10926–200000001 and Up

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply: the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form **a:b**. The **a** represents the reference number of the entire service assembly and the **b** represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number **6**, the tire by **6:1**, the valve by **6:2**, and the wheel by **6:3**. When you order the assembly identified by reference number **6**, you receive all parts identified by reference numbers **6:1**, **6:2**, and **6:3**. However, you may also order any part individually.

Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form **nX y**. The **n** represents the quantity of the part, the **X** is the multiplication symbol, and the **y** represents the reference number.

For example, in an illustration, the reference number **2X 37** means that two of the parts identified by reference number **37** are indicated.

Contents

Description	Page	Description	Page
Deck, Door & Ramp Assembly	3	Gear Case Assembly No. 99–6466	9
Engine & Blade Assembly	4	Shroud, Crankcase, & Carburetor Assembly . . .	10
HOC & Wheel Assembly	5	Short Block Assembly	11
Handle Assembly	6	Carburetor Assembly	12
Rear Bagger Assembly	7	Muffler & Brake Assembly	13
Clutch Assembly	8	Maintenance	14–15


Accessories

Description	Model / Part No.	Description	Model / Part No.
-------------	------------------	-------------	------------------

Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.


Abbreviation	Meaning	Abbreviation	Meaning
AR	as required	INC	incorporated
ASM	assembly	LH	left hand
CARR	carriage	NI	nylon insert
DEG	degrees	PPH	Phillips pan head
FH	flat head	PTH	Phillips truss head
GA	gauge	PTO	power take off
HF	hex flange	RH	right hand
HH	hex head	SFH	slotted fillister head
HHF	hex head flange	SHH	slotted hex head
HLH	hex lag head	SQH	square head
HJ	hex jam	SHWH	slotted hex washer head
HOC	height-of-cut	SPH	slotted pan head
HS	hex socket	SRH	slotted round head
HSBH	hex socket button head	STD	standard
HSFH	hex socket flat head	TAP	self tapping
HSH	hex socket head	TTH	Torx truss head
HWH	hex washer head	WH	wing head
HWHTF	hex washer head thread forming		



Sheet No.:2

Deck, Door & Ramp Assembly


Ref. No.	Part No.	Qty.	Description
1	100-9115	1	Door-Decal ASM
1:2	93-4105	1	Decal - Danger
2	100-1509	1	Rod-Pivot, Door
4	3256-22	4	Washer-Flat
5	2412-87	2	Clamp-Cable
6	100-4367	1	Shield-Trailing
7	49-2040	2	Screw-Taptite
8	32144-1	7	Screw-Taptite
9	99-6486	1	Kicker-Cover, Rear
10	100-1506	1	Ramp-Discharge
11	100-4352	2	Screw-HWH
12	100-9144	1	Deck-48cm
13	100-4388	1	Decal-Deck
14	100-3932	1	Boot-HOC
15	99-6479	1	Belt Cover
16	100-9137	1	Spring-Torsion, Door
17	98-2256	2	Clamp
18	100-9123-03	1	Bracket - Deck



Sheet No.:3

Engine & Blade Assembly


Ref. No.	Part No.	Qty.	Description	Ref. No.	Part No.	Qty.	Description
1	612825	1	Handle–Start				
2	612824	1	Starter–Clip				
3	92–1701	1	Rope – Stop				
4	55–3578	1	Gas Cap Assembly				
5	93–1200	1	Strap – Tank				
6	92–6396	1	Tank/Shroud				
7	68–3632	1	Fuel Line				
9	92–8808	1	Stud – Ball Bearing				
			(only on: 10926)				
10	3296–29	1	Nut–Lock, NI (only on: 10926)				
11	100–9140	1	V–Belt (only on: 10926)				
12	612079	1	Blade				
13	603164	1	Nut–Blade				
14	677525	1	Plate & Collar ASM				
15	95–1727	3	Screw–Taptite w/Patch				
16	92–6542	1	Pulley (only on: 10926)				
17	613227	1	Screw–Set (only on: 10926)				
18	93–4306	1	Spring – Compression				
19	93–4302	3	Screw				
20	100–8782	1	Decal–Recoil				
21	32104–118	2	Screw–Philps Pan Hd				



Sheet No.:4

HOC & Wheel Assembly

Ref. No.	Part No.	Qty.	Description
1	100-4352	4	Screw-HWH
2	99-6487	1	Handle-Deck
3	100-4383-03	1	Cover-Handle
4	100-9138	1	Button-HOC
5	88-7540	1	Washer - Backup
6	99-6481	1	Spring-Compression, HOC
7	99-6483	1	Bushing-HOC (only on: 10926)
8	100-1525	1	Bracket-Traction Cable (only on: 10926)
9	32144-1	6	Screw-Taptite (only on: 10926)
9	32144-1	5	Screw-Taptite (only on: 10925)
11	99-6458	1	Pipe - HOC
12	3296-73	1	Nut-Lock, NI
13	99-6459	1	Bolt-Shoulder
14	99-6460	1	Plate-Support, HOC
15	99-6478	1	Axle-Rear ASM
16	92-9590	2	Wheel ASM (only on: 10926)
16	92-9592	2	Assembly - 8" Wheel (only on: 10925)
16:1	27-6250	2	Bushing




Sheet No.:5

Handle Assembly

Ref. No.	Part No.	Qty.	Description
1	99-1569-05	1	Handle-Upper
2	94-6097	1	Stop
3	99-1570-03	1	Bail-Brake
4	99-1571-03	1	Bail-Traction (only on: 10926)
5	92-5412	1	Stop-Pivot (only on: 10926)
6	94-6096	1	Anchor - Cable
7	92-2269	1	Screw-Handle
8	3296-73	2	Nut-Lock, NI
9	3256-1	1	Washer-Flat
10	3290-378	1	Tie-Cable
11	98-3248	1	Decal - Operation (only on: 10926)
12	92-2260	2	Screw-Handle
13	100-4396	2	Adjusting Knob-Handle
14	100-1510	2	Disk Adjusting-Handle
16	100-1517	2	Disk Holding-Handle
17	60-6690	2	Capscrew
18	100-9119-05	1	Handle-Lower 7/8"
19	100-4393	1	Cable-Brake
20	95-4457	1	Guide - Rope
21	100-4394	1	Cable-Traction (only on: 10926)
22	98-7134	2	Knob-Handle

Ref. No.	Part No.	Qty.	Description




Sheet No.:6

Rear Bagger Assembly

Ref. No.	Part No.	Qty.	Description
1	100-4391	1	Bag-Grass, ASM
2	100-1518-03	1	Bag Frame ASM


Ref. No.	Part No.	Qty.	Description



Clutch Assembly

Ref. No.	Part No.	Qty.	Description
1	65-4730	2	Washer-Arm, Pivot (only on: 10926)
2	65-4740	4	Washer-Thrust, Keyed (only on: 10926)
3	65-2720	2	Ring-Klip (only on: 10925)
3	65-2720	4	Ring-Klip (only on: 10926)
4	65-4710	2	Ring-Friction (only on: 10926)
5	65-4760	2	Washer-Clutch (only on: 10926)
6	66-6040	1	Key-Rocking, RH (only on: 10926)
7	66-6050	1	Key-Rocking, LH (only on: 10926)
8	65-4750	2	Gear-Pinion (only on: 10926)
9	65-4720	2	Spring-Compression (only on: 10926)
10	100-1513	2	Cover-Gear
12	100-9118	2	Bushing-Zerk ASM
12:2	302-56	1	Fitting-Zerk
13	99-6466	1	Transmission ASM (only on: 10926)

Ref. No.	Part No.	Qty.	Description
14	100-1512	1	Shaft-Pivot (only on: 10925)
15	614673	1	Bushing-Plate, Actuator (only on: 10926)
16	100-1524-03	1	Guide-Transmission (only on: 10926)
17	49-2040	1	Screw-Taptite (only on: 10926)
18	92-1616	1	Screw-HWHTF (only on: 10926)
19	100-1511	2	Retainer-Ring (only on: 10926)
20	100-1515	2	Washer-Wave (only on: 10926)
21	32144-1	4	Screw-Taptite




Sheet No.:A4

Gear Case Assembly No. 99-6466

Ref. No.	Part No.	Qty.	Description
1	100-1514	1	Shaft-Output (only on: 10926)
2	614668-03	1	Cover-Gear Case (only on: 10926)
3	92-7727	1	Gearcase (only on: 10926)
4	60-8850	2	Bushing-Output (only on: 10926)
5	3285-19	2	Pin-Groove (only on: 10926)
6	614596	1	Gear (only on: 10926)
7	36-4780	2	Washer (only on: 10926)
8	614696	1	Shaft-Intermediate (only on: 10926)
9	49-2040	4	Screw-Taptite (only on: 10926)
10	55-3760	1	Gear-Bevel (only on: 10926)
11	36-4791	2	Washer-Thrust (only on: 10926)
12	60-8750	2	Bushing (only on: 10926)
13	38-7820	1	Bearing-Ball (only on: 10926)

Ref. No.	Part No.	Qty.	Description
14	3256-24	1	Washer-Flat (only on: 10926)
15	60-8890	1	Gear-Bevel, Pinion (only on: 10926)
16	3296-5	1	Nut-Lock, NI (only on: 10926)
17	100-1176	2	Pulley-Half (only on: 10926)
18	62-6660	1	Spacer (only on: 10926)




Sheet No.:2

Shroud, Crankcase, & Carburetor Assembly

Ref. No.	Part No.	Qty.	Description
1	93-1248	1	Shroud/Start Ay
1:1	95-1781	1	Recoil
1:1:1	613773	1	Rope
2	614702	5	Screw
3	130743	1	Nut
4	316959	1	Washer-Lock
5	614640	1	Hub Starter
6	684743	1	Flywheel, Mach.
7	93-4320	1	Shield - Fuel
8	93-1216-03	1	Shroud Base
9	607199	1	Key
10	93-4349	1	Short Block Asy.
11	92-4948	2	Gasket, Carb.
14	100-9541	1	Carburetor ASM {Service}
15	609493	1	Element Air/F
17	614699	3	Screw
18	609482	2	Screw
20	44-3172	1	Hose-Primer
22	93-4316	1	Shield - Gov.
23	613269	2	Screw
25	100-9510	1	Shield Primer Mounting
26	44-2750	1	Body-Primer
27	66-7460	1	Bulb-Primer
28	100-9127	1	Cover-Air Filter
29	100-9111	1	Hook Cover


Ref. No.	Part No.	Qty.	Description
30	100-9110	1	Retainer Cover
31	100-9135	1	O-Ring Cover



Sheet No.:A1

Short Block Assembly

Ref. No.	Part No.	Qty.	Description
1	252-76	1	Bearing-Thrust
2	252-80	1	Bearing-Thrust
3	603954	2	Liner-Split
4	609754	1	Roller-Strip
5	611393	2	Screw-HSH
6	611396	2	Seal-Oil
7	614636	3	Screw,H.w.hd.
8	681830	1	Bearing
9	681831	1	Bearing
10	92-4937	1	Piston&conn Rod
11	94-5713	1	Crankshaft




Sheet No.:A2

Carburetor Assembly

Ref. No.	Part No.	Qty.	Description
1	92-6376	1	Air Vane & Shaft
2	610834	1	Collar-Adjust, Airvane
3	610833	1	Spring,Throttle
4	92-6373	1	Disc-Thro.
8	612383	1	Washer
9	92-6371	1	Nozzle
10	92-6370	1	Main Jet
11	611071	1	Filter-Fuel
12	678113	1	Float & Arm Ay
14	92-9697	1	Valve/Seat-Float
16	92-6389	1	Pin-Straight
17	98-1362	1	Gasket
18	92-9691	1	Chamber-Float
19	608850	4	Screw-HH
21	613269	2	Screw
22	306531	2	Nut-Hex

Ref. No.	Part No.	Qty.	Description



Sheet No.:3

Muffler & Brake Assembly

Ref. No.	Part No.	Qty.	Description
1	93-4312	1	Brake Plate ASM
2	614702	1	Screw
3	84-7820	1	Plate-Brake
4	613208	2	Screw
5	99-2911	1	Module-Ignition
*5:1	99-6721	1	Clip-High Tension Lead
5:2	99-6719	1	Lead-High Tension
6	614009	1	Spark Plug (Service)
7	93-1233	1	Gasket-Exh
8	93-1108-03	1	Muffler Cover
9	609471	3	Screw
10	93-1217	1	Baffle-Muffler
11	607601	4	Screw
12	614654	1	Plate-Muffler
13	100-2929	1	Stop-Ground Strap
14	12-5450	1	Screw
15	92-1156	1	Elec Lead Ay
16	60-9010	1	Strap-Ground
17	92-2925	1	Strap-Insulation
18	3290-459	2	Rivet-Plastic
19	92-9698	1	Screw-shoulder

* Not illustrated

Maintenance Record

[illegible]

LAWN-BOY®