



2/3 Area Flat Bed Kit

Workman[®] 3000/4000 Series

Model No. 07321

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply: the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form **a:b**. The **a** represents the reference number of the entire service assembly and the **b** represents a sequential number unique to each part within the service assembly.


For example, a wheel assembly might be identified by reference number **6**, the tire by **6:1**, the valve by **6:2**, and the wheel by **6:3**. When you order the assembly identified by reference number **6**, you receive all parts identified by reference numbers **6:1**, **6:2**, and **6:3**. However, you may also order any part individually.

Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form **nX y**. The **n** represents the quantity of the part, the **X** is the multiplication symbol, and the **y** represents the reference number.

For example, in an illustration, the reference number **2X 37** means that two of the parts identified by reference number **37** are indicated.



Sheet No.:1

2/3 Area Flat Bed Assembly

Ref. No.	Part No.	Qty.	Description
2	32148-6	4	Nut-Insert
3	92-1298	8	Pin - Lynch
4	92-1233	4	Pin-Clevis
5	32148-7	18	Nut-Insert
6	93-9723-03	1	Spacer Bracket, RH
7	3296-42	4	Nut-Lock
8	3296-44	14	Nut-Lock NI
9	93-9722-03	1	Spacer Bracket, LH
10	93-9719	2	Block - Wear
11	3250-45	4	Screw-SPH
12	323-42	14	Screw-HH
13	92-1312	2	Decal - Warning
15	93-9721-03	2	Bracket-Pivot, RH
16	93-9575	2	Tube-Flatbed Pivot
17	93-9720-03	2	Bracket-Pivot, LH
18	32148-6	2	Nut-insert

Ref. No.	Part No.	Qty.	Description