



Count on it.

Parts Catalog

72in E-Z Vac™ DFS Collection System

Z Master® G3 Mower

Model No. 78556—Serial No. 40000000 and Up



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.


Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.


Contents

- Bagger Frame Mount and Handle Assembly 4
- Hood Assembly 5
- Tube and Weight Assembly 6
- Bagger Assembly 7




Bagger Frame Mount and Handle Assembly

Ref.	Part Number	Qty.	Description	Ref.	Part Number	Qty.	Description
1	3233-34	2	Screw-CARR	22	109-6869	1	Pin-Handle
2	116-0473-03	1	Mount-Bagger, Upper	23	32151-48	1	E-Ring
3	323-12	4	Screw-HH	24	115-3604-03	1	Bagger Handle ASM
4	3256-4	7	Washer-Flat	25	109-8712-03	1	Mount-Pivot
5	103-2409	4	Half-Block, Bearing	26	3231-28	10	Screw-CARR
6	103-2412-03	1	Link-Intermediate	27	109-9248	1	Mount-Bagger, Lower
7	323-53	2	Screw-HH	28	1-513658	2	Bumper
8	3290-357	8	Nut-HHF, Whiz	29	321-6	2	Screw-HH
9	116-0458	2	Pin-Mount, Bagger	30	3256-55	2	Washer-Flat
10	109-8709-03	1	Frame	31	103-3191-03	2	Latch
11	103-3201	2	Cap	32	1-633545	2	Spacer
12	103-3202	4	Cap	33	3296-42	2	Nut-Lock, NI
13	116-2804	1	Exhaust Diverter ASM	34	103-7115	1	Handle-Grip
15	1-633131	3	Yoke-Linkage, Brake	36	116-0057-03	1	Bumper-RH
16	103-2399	3	Pin-Spring, Clevis	37	116-0180	1	LH Bumper ASM
17	3219-3	3	Nut-Hex	37:2	106-5517	1	Decal-Warning
18	103-2413	3	Link-Handle	38	99-5107	2	Nut-Lock
20	3272-10	3	Pin-Cotter	40	104-8301	2	Nut-HF, NI
21	109-6658	14	Nut-Flange, NI				




Hood Assembly



<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	103-0378	2	Clamp-Seal	11	103-0379	2	Bracket-Mount
2	103-0439	1	Seal-Tube	12	103-0376	2	Plate-Latch, Reinforcement
3	114-8246	1	Hood ASM	13	103-2360	1	Seal-Door Hinge
4	3256-61	23	Washer-Flat	14	103-3010-03	1	Strap-Hold Down
5	3250-27	8	Screw-PPH	15	103-2710	1	Rear Crossmember ASM
6	3256-22	13	Washer-Flat	15:2	32148-6	6	Nut-Clinch
7	321-4	18	Screw-HH	16	103-2662-03	1	Support-Screen
8	67-7310	1	Decal	17	32128-33	12	Nut-HF
9	103-0440	1	Screen-Bagger	18	3296-2	8	Nut-Lock, NI
10	114439	39	Rivet-Blind				



78567 AND 78556 (2020 AND NEWER)




78556 (2019 AND OLDER)



Tube and Weight Assembly

Ref.	Part Number	Qty.	Description	Ref.	Part Number	Qty.	Description
1	109-1973	1	Lower Tube ASM	10:2	106-0871	1	Decal-Warning, Counterweight
1:1	1-353005-03	1	Handle	11	120-7883	2	Weight ASM
1:2	103-2897	2	Latch-Catch ●	11:1	120-7882	1	Weight
1:3	103-3079	2	Plate-Backing	11:1:2	106-0871	1	Decal-Warning, Counterweight
1:4	109-1974	1	Tube-Lower	11:2	115-3616-01	1	Tab-Support, Weight
1:5	321-6	2	Screw-HH	11:3	323-4	2	Screw-HH
1:6	3256-55	2	Washer-Flat	11:4	3253-5	2	Washer-Lock
1:7	3296-2	4	Nut-Lock, NI	12	3230-23	2	Screw-CARR
1:8	3296-42	2	Nut-Lock, NI	13	3256-4	4	Washer-Flat
1:9	32105-13	4	Screw-HWH	14	323-6	4	Screw-HH
2	109-1968	1	Tube-Upper	15	115-3615-01	1	Bracket-Mount, Weight
3	32105-13	3	Screw-HWH	16	104-8300	2	Nut-HF, NI
4	3256-61	3	Washer-Flat	17	3253-5	4	Washer-Lock
5	3296-2	3	Nut-Lock, NI	18	104-8301	2	Nut-HF, NI
6	1-806003	2	Pin-Cotter	19	104-2442	2	Bumper-Rubber
7	323-53	2	Screw-HH	20	104-7658	2	Spacer
8	3217-7	2	Nut-Hex	21	3296-47	2	Nut-Lock, NI
9	100-1413	2	Pin-Clevis				
10	115-3636	2	63 Lbs Weight ASM				

● Kit No. 103-4143 - Contains catch, rubber latch, and mounting hardware



Bagger Assembly

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	103-7827	1	Panel-Bagger, RH	17	323-6	4	Screw-HH
2	3256-2	32	Washer-Flat	18	32128-33	24	Nut-HF
3	321-3	32	Screw-HH	19	103-2383	1	Bag And Bottom Panel ASM
4	3256-24	12	Washer-Flat	20	103-2414-03	1	Support
5	322-3	6	Screw-HH	21	3272-10	2	Pin-Cotter
6	103-2404-03	1	Sheet, Wall	22	103-2365	2	Link-Hinge
7	103-7826	1	Panel, Bagger LH	23	3219-3	2	Nut-Hex
8	32128-20	6	Nut-HF	24	1-633131	2	Yoke-Linkage, Brake
9	3256-22	4	Washer-Flat	25	1-808285	2	Pin-Clevis
10	321-4	4	Screw-HH	26	1-806003	2	Pin-Cotter
11	103-2737	1	Door ASM	27	103-3331-03	1	Arm-Hinge, RH
11:2	32148-6	12	Nut-Clinch	28	103-2361	2	Pin-Pivot, Hinge
12	103-8018	2	Plug-Dome	29	103-2377	2	Bushing
13	3290-357	4	Nut-HHF, Whiz	30	114439	21	Rivet-Blind
14	103-3332-03	1	Arm, Hinge LH	32	3296-39	2	Nut-Lock, NI
16	323-9	2	Screw-HH				



Count on it.