



Grass Collection System

Reelmaster[®] 2300/3100-D Attachment

Model No. 03223

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply: the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form **a:b**. The **a** represents the reference number of the entire service assembly and the **b** represents a sequential number unique to each part within the service assembly.


For example, a wheel assembly might be identified by reference number **6**, the tire by **6:1**, the valve by **6:2**, and the wheel by **6:3**. When you order the assembly identified by reference number **6**, you receive all parts identified by reference numbers **6:1**, **6:2**, and **6:3**. However, you may also order any part individually.

Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form **nX y**. The **n** represents the quantity of the part, the **X** is the multiplication symbol, and the **y** represents the reference number.

For example, in an illustration, the reference number **2X 37** means that two of the parts identified by reference number **37** are indicated.




Sheet No.:2

Front Basket Assembly

Ref. No.	Part No.	Qty.	Description
1	99-3569	2	Front Grass Basket ASM
1:2	61-3170	1	Baffle-Grass
1:5	61-1190	1	Tube-Basket, Front
1:6	5-2893	2	Basket Wheel ASM
1:6:1	256-90	2	Bushing-Flange
1:6:2	3-9274	2	Spacer
1:6:3	32120-64	2	Ring-Snap, External
1:6:4	5-2891	1	Wheel Shaft
1:7	3256-49	4	Washer-Flat
1:8	3269-18	10	Rivet-Pop, Steel
1:12	3269-7	4	Rivet-Pop, Steel
1:13	321-8	4	Screw-HH
1:14	32153-4	4	Locknut
1:15	3256-2	4	Washer-Flat
2	104-1352-03	2	Bracket-RH
3	104-1353-03	2	Bracket-LH
4	322-5	8	Screw-HH
5	3296-29	14	Nut-Lock, NI
6	3230-5	2	Screw-CARR
7	61-3160	2	Hanger-Basket, Front
8	3256-23	6	Washer-Flat
9	3230-2	4	Screw-CARR
10	95-8970	2	Bracket-Hanger
11	104-1351	2	Bracket-Hanger

Ref. No.	Part No.	Qty.	Description



Sheet No.:3

Rear Basket Assembly

Ref. No.	Part No.	Qty.	Description	Ref. No.	Part No.	Qty.	Description
1	95-8996	1	Rear Grass Basket ASM	16	33104-016	3	Screw-HHF
1:2	99-3571	1	Support-Rear Basket	17	61-3160	1	Hanger-Basket, Front
1:4	99-3572	1	Baffle-Grass	18	104-1350	1	Bracket-Hanger, Adj
1:5	3269-18	8	Rivet-Pop, Steel	19	3230-5	1	Screw-CARR
1:6	3269-7	4	Rivet-Pop, Steel	20	3230-2	2	Screw-CARR
1:7	3256-49	8	Washer-Flat	21	3256-23	3	Washer-Flat
1:8	63-8740	1	Strap-Basket	22	94-5128-03	1	Bracket - Rear
1:9	3290-282	4	Rivet-Pop, Steel	23	67-5910-03	1	Plate-Rear
1:10	62-5130	1	Flap-Plastic	24	3230-8	1	Screw-CARR
2	99-3573	1	Flap-Basket,Rear	25	3230-13	1	Screw-CARR
3	322-11	2	Screw-HH	26	322-7	1	Screw-HH
4	32128-43	2	Nut - Flange	27	92-2402-03	1	Hanger-Basket, Rear
5	94-3683-01	1	Bracket-Basket, LH	28	63-4220	1	Spring-compression
6	3256-24	2	Washer-Flat				
7	323-6	2	Screw-HH				
8	104-1357-03	1	Bracket LH				
9	3296-29	5	Nut-Lock, NI				
10	104-1356-03	1	Bracket-RH				
11	94-3679-01	1	Bracket-Basket, RH				
12	3269-23	8	Rivet-Pop				
13	340-89	1	Fitting-45°				
13:1	237-30	1	O-Ring				
13:2	237-80	1	O-Ring				
14	33024-00	1	Nut-Lock, NI				
15	100-4915-03	1	Guard - Flywheel				

