



Form No. 3425-440 Rev C

**Count on it.**

# Parts Catalog

## TimeCutter® MX 5000

### Riding Mower

Model No. 74773—Serial No. 404314000 and Up



# Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

## Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

## Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

## Reference Numbers Indicating Quantity


In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

# Contents

|                                                   |    |
|---------------------------------------------------|----|
| Frame and Front Axle Assembly .....               | 4  |
| Deck Lift Assembly.....                           | 6  |
| Caster, Wheel and Tire Assembly .....             | 8  |
| Hydro Transaxle Drive Assembly.....               | 10 |
| LH Hydro Transmission Assembly No. 139-2370 ..... | 12 |
| RH Hydro Transmission Assembly No. 139-2371.....  | 14 |
| Brake Assembly .....                              | 16 |
| Tire Assembly No. 131-3671 .....                  | 18 |
| Seat Assembly .....                               | 20 |
| Motion Control Assembly .....                     | 22 |
| Engine and Muffler Assembly.....                  | 24 |
| Body Styling and Fuel Tank Assembly .....         | 26 |
| Battery and Electrical Assembly.....              | 28 |
| 50 Inch Deck Assembly.....                        | 30 |
| 50 Inch Deck and Decal Assembly No. 131-3614..... | 32 |
| Model Specific Decal Assembly.....                | 34 |
| HOC and Service Decal Assembly .....              | 36 |
| Clutch Assembly.....                              | 38 |
| Attachments and Accessories .....                 | 40 |


# Frame and Front Axle Assembly



## Frame and Front Axle Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>             | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         |
|-------------|--------------------|-------------|--------------------------------|-------------|--------------------|-------------|----------------------------|
| 1           | 135-0508-01        | 1           | Riveted Frame ASM (Wide Lever) | 16          | 130-0701-03        | 1           | Guard-Engine, Wide         |
| 2           | 135-0687-03        | 1           | Brace-Seat, Rear (Wide)        | 18          | 137-7020-01        | 1           | Mount-Hydro, Front (Right) |
| 3           | 133-7063-03        | 1           | Support-Pod                    | 19          | 137-7021-01        | 1           | Mount-Hydro, Front (Left)  |
| 4           | 119-3431-03        | 2           | Support-Tank, Rear             | 20          | 130-6946-01        | 1           | Crossmember-Rear, Wide     |
| 5           | 135-0507-03        | 1           | Bracket-Battery                | 21          | 117-1232-03        | 1           | Bracket-Hitch              |
| 6           | 137-7029-01        | 1           | Axle-Wide                      | 25          | 121-2989           | 2           | Decal-Bypass               |
| 10          | 116-4348           | 2           | Cap-Grease                     | 27          | 32144-70           | 18          | Screw-HWHTF                |
| 11          | 109-3678           | 4           | Bearing-Ball                   | 28          | 3234-29            | 4           | Screw-HHF                  |
| 13          | 132-0892           | 1           | Footrest ASM                   | 29          | 3234-42            | 6           | Screw-HHF                  |
| 13:2        | 99-4693            | 1           | Decal                          | 30          | 3234-47            | 8           | Screw-HHF                  |
| 13:3        | 132-0869           | 1           | Decal-Danger                   | 34          | 104-8300           | 12          | Nut-HF, NI                 |
|             |                    |             |                                | 35          | 104-8301           | 6           | Nut-HF, NI                 |


# Deck Lift Assembly



## Deck Lift Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|-----------------------|-------------|--------------------|-------------|--------------------|
| 1           | 132-6878-03        | 1           | Lift-Deck (Wide)      | 14          | 108-7845           | 2           | Block-Pivot        |
| 2           | 119-8875           | 2           | Bracket-Lift          | 15          | 120-5499           | 2           | Screw-HSBH         |
| 3           | 32144-70           | 4           | Screw-HWHTF           | 16          | 3296-29            | 2           | Nut-Lock, NI       |
| 4           | 119-3427-03        | 1           | Lever-Lift            | 23          | 3256-26            | 3           | Washer-Flat        |
| 5           | 1-633268           | 1           | Grip-Lever            | 24          | 119-8810           | 1           | Pin-Pivot          |
| 7           | 3234-29            | 2           | Screw-HHF             | 25          | 133-4319           | 1           | Rod-Mount, Deck    |
| 8           | 104-8300           | 2           | Nut-HF, NI            | 26          | 3296-19            | 1           | Nut-Hex            |
| 12          | 119-3347           | 1           | Arm-Lift, Rear (Wide) | 27          | 3272-11            | 2           | Pin-Cotter         |
| 13          | 108-7840           | 2           | Link-Lift             | 28          | 1-806005           | 1           | Pin-Cotter         |


# Caster, Wheel and Tire Assembly



## Caster, Wheel and Tire Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|--------------------|
| 1           | 138-9833-01        | 2           | Fork ASM           | 3           | 138-9803           | 2           | Spacer-Spanner     |
| 2           | 138-7554           | 2           | Tire And Wheel ASM | 4           | 325-37             | 2           | Screw-HH           |
| 2:2         | 138-7553           | 1           | Tire               | 5           | 3296-45            | 2           | Nut-Hex            |
| 2:3         | 114-1640           | 2           | Bushing-Flange     | 6           | 117-7394           | 2           | Washer-Thrust      |
| 2:4         | 302-5              | 1           | Fitting-Grease     | 7           | 3256-68            | 2           | Washer-Flat        |
| 2:5         | 232-27             | 1           | Stem-Valve         | 8           | 3234-47            | 2           | Screw-HHF          |


# Hydro Transaxle Drive Assembly



## Hydro Transaxle Drive Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   |
|-------------|--------------------|-------------|------------------------|-------------|--------------------|-------------|----------------------|
| 1           | 119-3353           | 1           | Spacer                 | 18          | 324-10             | 4           | Screw-HH             |
| 2           | 119-8822           | 1           | Pulley-Idler           | 19          | 324-8              | 2           | Screw-HH             |
| 3           | 119-3327           | 1           | Spacer-Arm, Idler      | 20          | 3256-25            | 6           | Washer-Flat          |
| 4           | 119-3326           | 1           | Arm-Idler              | 21          | 3296-48            | 6           | Nut-Hex              |
| 5           | 138-7597           | 1           | Pulley-Idler, Flat     | 22          | 137-7040           | 1           | Spring-Return, Pedal |
| 6           | 5-4460             | 1           | Washer-Pivot           | 24          | 3256-23            | 6           | Washer-Plain         |
| 7           | 3230-8             | 1           | Screw-CARR             | 25          | 322-11             | 4           | Screw-HH             |
| 8           | 3256-3             | 1           | Washer-Flat            | 26          | 322-13             | 4           | Screw-HH             |
| 9           | 322-7              | 1           | Screw-HH               | 27          | 3234-29            | 4           | Screw-HHF            |
| 10          | 104-8300           | 14          | Nut-HF, NI             | 29          | 131-0900           | 1           | *obs* Rod-Bypass, LH |
| 11          | 130-6976           | 1           | V-Belt                 | 30          | 130-7049           | 1           | Rod-Bypass, RH       |
| 13          | 117-7264-03        | 2           | Mount-Hydro            | 31          | 119-8952           | 2           | Washer               |
| 15          | 139-2370           | 1           | LH Hydro Transaxle ASM | 32          | 3290-307           | 2           | Pin-Cotter           |
| 16          | 139-2371           | 1           | RH Hydro Transaxle ASM | 37          | 242-50             | 8           | Nut-Lug              |
| 17          | 119-3342-03        | 1           | Plate-Cross, Hydro     |             |                    |             |                      |


LH Hydro Transmission Assembly No. 139-2370



# LH Hydro Transmission Assembly No. 139-2370 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>        |
|-------------|--------------------|-------------|--------------------------|-------------|--------------------|-------------|---------------------------|
| 1           | 120-5532           | 1           | Main Housing ASM         | 83          | 104-5329           | 1           | Pin-Jackshaft             |
| 2           | 120-5534           | 1           | Housing Side Kit         | 91          | 120-5539           | 1           | Gear-Bull                 |
| 5           | 104-2189           | 1           | Plug-Thread, Straight    | 92          | 104-2142           | 1           | Nut-HJ                    |
| 7           | 117-5359           | 16          | Screw-HHF                | 93          | 115-8314           | 1           | Bushing-Inboard           |
| 10          | 104-2147           | 1           | Sealant                  | 94          | 120-5540           | 1           | Shaft-Axle                |
| 31          | 106-8677           | 1           | Ring-Retaining, External | 95          | 120-5541           | 1           | Bearing-Sleeve            |
| 32          | 106-8678           | 1           | Rod-Bypass               | 100         | 106-8694           | 1           | Disc-Brake, Cog           |
| 33          | 106-8679           | 1           | Ring-Retaining, Internal | 110         | 106-8677           | 1           | Ring-Retaining, External  |
| 40          | 104-5304           | 1           | Swashplate-Trunnion      | 130         | 103-2666           | 1           | Cylinder Block Kit        |
| 42          | 104-2116           | 1           | Stud                     | 131         | 110-8561           | 1           | Pump Block ASM            |
| 43          | 112-9853           | 1           | Puck-Friction            | 132         | 117-5362           | 1           | Control Arm Kit           |
| 50          | 133-1793           | 1           | Spring-Block             | 133         | 106-8688           | 1           | Brake Arm Kit             |
| 51          | 120-5538           | 1           | Washer                   | 134         | 112-9861           | 1           | Center Section Filter Kit |
| 52          | 104-5306           | 1           | Shaft-Input              | 135         | 114-1634           | 1           | Filter Kit                |
| 53          | 104-5311           | 1           | Bearing-Ball             | 136         | 121-5730           | 1           | RH Expansion Tank Kit     |
| 54          | 104-5307           | 1           | Ring-Retaining           | 137         | 120-5549           | 1           | Bypass Kit                |
| 55          | 104-5308           | 1           | Spacer                   | 138         | 121-5731           | 1           | Hub Kit                   |
| 56          | 104-5310           | 1           | Seal-Lip                 | 139         | 135-7349           | 1           | Fan And Pulley Kit        |
| 57          | 104-5309           | 1           | Ring-Retaining           | 139:1       | 116-9714           | 1           | Nut-HJ                    |
| 58          | 104-2147           | 1           | Sealant                  | 139:2       | 116-9708           | 1           | Washer-Slotted            |
| 60          | 94-6922            | 2           | Bearing-Thrust           | 139:4       | 135-7364           | 1           | Fan 7.0 X 10 Blade        |
| 70          | 104-5339           | 1           | Washer-Flat              | 150         | 104-5349           | 1           | Fitting-SAE               |
| 71          | 104-5340           | 1           | Ring-Retaining           | 151         | 115-8302           | 1           | Hose                      |
| 72          | 104-5316           | 1           | Gear-Pinnion, 13T        | 152         | 104-5361           | 1           | O-Ring                    |
| 73          | 106-8683           | 1           | Shaft-Motor              | 159         | 121-5728           | 1           | Case-Tube                 |
| 74          | 104-5360           | 1           | Washer                   | 160         | 125-0041           | 1           | Cap-Axle                  |
| 80          | 119-5541           | 1           | Washer                   | 162         | 139-3278           | 1           | Breather ASM Kit          |
| 81          | 104-5317           | 1           | Gear-10T/48T             | 163         | 120-7103           | 1           | Seal And Ring Kit         |
| 82          | 104-5318           | 1           | Gear-Jackshaft, 10T      |             |                    |             |                           |

# RH Hydro Transmission Assembly No. 139-2371




# RH Hydro Transmission Assembly No. 139-2371 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>        |
|-------------|--------------------|-------------|--------------------------|-------------|--------------------|-------------|---------------------------|
| 1           | 120-5531           | 1           | Main Housing ASM         | 83          | 104-5329           | 1           | Pin-Jackshaft             |
| 2           | 120-5533           | 1           | Housing Side Kit         | 91          | 120-5539           | 1           | Gear-Bull                 |
| 5           | 104-2189           | 1           | Plug-Thread, Straight    | 92          | 104-2142           | 1           | Nut-HJ                    |
| 7           | 117-5359           | 16          | Screw-HHF                | 93          | 115-8314           | 1           | Bushing-Inboard           |
| 10          | 104-2147           | 1           | Sealant ●                | 94          | 120-5540           | 1           | Shaft-Axle                |
| 31          | 106-8677           | 2           | Ring-Retaining, External | 95          | 120-5541           | 1           | Bearing-Sleeve            |
| 32          | 106-8678           | 1           | Rod-Bypass               | 100         | 106-8694           | 1           | Disc-Brake, Cog           |
| 33          | 106-8679           | 1           | Ring-Retaining, Internal | 110         | 106-8677           | 1           | Ring-Retaining, External  |
| 40          | 104-5304           | 1           | Swashplate-Trunnion      | 130         | 103-2666           | 1           | Cylinder Block Kit        |
| 42          | 104-2116           | 1           | Stud                     | 131         | 110-8561           | 1           | Pump Block ASM            |
| 43          | 112-9853           | 1           | Puck-Friction            | 132         | 117-5362           | 1           | Control Arm Kit           |
| 50          | 133-1793           | 1           | Spring-Block             | 133         | 106-8688           | 1           | Brake Arm Kit             |
| 51          | 120-5538           | 1           | Washer                   | 134         | 112-9862           | 1           | Center Section Filter Kit |
| 52          | 104-5306           | 1           | Shaft-Input              | 135         | 114-1634           | 1           | Filter Kit                |
| 53          | 104-5311           | 1           | Bearing-Ball             | 136         | 121-5735           | 1           | LH Expansion Tank Kit     |
| 54          | 104-5307           | 1           | Ring-Retaining           | 137         | 107-2489           | 1           | Bypass Arm Kit            |
| 55          | 104-5308           | 1           | Spacer                   | 138         | 121-5731           | 1           | Hub Kit                   |
| 56          | 104-5310           | 1           | Seal-Lip                 | 139         | 135-7349           | 1           | Fan And Pulley Kit        |
| 57          | 104-5309           | 1           | Ring-Retaining           | 139:1       | 116-9714           | 1           | Nut-HJ                    |
| 58          | 104-2147           | 1           | Sealant                  | 139:2       | 116-9708           | 1           | Washer-Slotted            |
| 60          | 94-6922            | 2           | Bearing-Thrust           | 139:4       | 135-7364           | 1           | Fan 7.0 X 10 Blade        |
| 70          | 104-5339           | 1           | Washer-Flat              | 150         | 104-5349           | 1           | Fitting-SAE               |
| 71          | 104-5340           | 1           | Ring-Retaining           | 151         | 115-8302           | 1           | Hose                      |
| 72          | 104-5316           | 1           | Gear-Pinnion, 13T        | 152         | 104-5361           | 1           | O-Ring                    |
| 73          | 106-8683           | 1           | Shaft-Motor              | 159         | 121-5728           | 1           | Case-Tube                 |
| 74          | 104-5360           | 1           | Washer                   | 160         | 125-0041           | 1           | Cap-Axle                  |
| 80          | 119-5541           | 1           | Washer                   | 162         | 139-3278           | 1           | Breather ASM Kit          |
| 81          | 104-5317           | 1           | Gear-10T/48T             | 163         | 120-7103           | 1           | Seal And Ring Kit         |
| 82          | 104-5318           | 1           | Gear-Jackshaft, 10T      |             |                    |             |                           |

● Not illustrated

# Brake Assembly



## Brake Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   |
|-------------|--------------------|-------------|----------------------|-------------|--------------------|-------------|----------------------|
| 1           | 130-0790-03        | 1           | Bracket-Mount, Brake | 7           | 121-2976           | 1           | Rod-Brake, Wide (RH) |
| 2           | 136-4213           | 1           | Brake Box ASM        | 8           | 121-2977           | 1           | Rod-Brake, Wide (LH) |
| 3           | 132-6949           | 1           | Cover-Connector      | 9           | 3296-42            | 2           | Nut-Lock, NI         |
| 4           | 32144-4            | 2           | Screw-HWH            | 10          | 119-8952           | 6           | Washer               |
| 5           | 32144-36           | 4           | Screw-PPH            | 11          | 117-1169           | 4           | Spring-Compression   |
| 6           | 94-4496            | 2           | Screw-PPH            | 13          | 3290-307           | 2           | Pin-Cotter           |

# Tire Assembly No. 131-3671




## Tire Assembly No. 131-3671 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       |
|-------------|--------------------|-------------|--------------------------|
| 1           | 131-3671           | 2           | 2 Ply Wheel And Tire ASM |
| 1:1         | 131-3678           | 1           | Tire-2 Ply               |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1:3         | 232-27             | 1           | Stem-Valve         |
| 1:99        | 107-2491           | 1           | Tube-Tire ●        |

● Not illustrated


Seat Assembly



## Seat Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|--------------------|
| 1           | 92-7054            | 3           | Spring-Compression | 9           | 1-603716           | 4           | Washer-Friction    |
| 2           | 3234-29            | 3           | Screw-HHF          | 10          | 322-5              | 4           | Screw-HH           |
| 3           | 104-8300           | 7           | Nut-HF, NI         | 12          | 132-9353           | 2           | Latch-Seat         |
| 4           | 139-2378-03        | 1           | Pan-Seat, Deluxe   | 19          | 3274-55            | 2           | Screw-HSBH         |
| 5           | 119-3433           | 1           | Rod-Pivot, Narrow  | 20          | 19-1470            | 2           | Screw-Shoulder     |
| 7           | 3290-250           | 2           | Pin-Cotter         | 80          | 139-2377           | 2           | Spacer-Stepped     |
| 8           | 139-2365           | 1           | Seat ASM           |             |                    |             |                    |


# Motion Control Assembly



## Motion Control Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|------------------------|
| 1           | 139-2368-03        | 1           | Control Box ASM    | 16          | 120-7950           | 2           | Screw-Torx             |
| 2           | 119-3470           | 2           | Actuator Arm ASM   | 17          | 131-4132           | 2           | Damper                 |
| 2:2         | 256-156            | 2           | Bushing-Flange     | 18          | 110-6810           | 2           | Stud-Damper            |
| 3           | 120-2273           | 2           | Washer-Nylon       | 19          | 3296-42            | 4           | Nut-Lock, NI           |
| 4           | 133-9299-05        | 2           | Arm-Control        | 20          | 3256-24            | 4           | Washer-Flat            |
| 5           | 133-7055           | 1           | Handle-Control, LH | 21          | 323-6              | 4           | Screw-HH               |
| 5:1         | 121-0726           | 1           | Grip               | 23          | 32144-70           | 4           | Screw-HWHTF            |
| 6           | 133-7057           | 1           | Handle-Control, RH | 24          | 32144-1            | 4           | Screw-Taptite          |
| 6:1         | 121-0726           | 1           | Grip               | 25          | 138-7217           | 2           | Rod-Hydro              |
| 8           | 115-5099           | 2           | Bolt-Pivot         | 26          | 138-7218           | 2           | Mount-Rod, Hydro       |
| 9           | 104-8301           | 4           | Nut-HF, NI         | 27          | 3256-23            | 2           | Washer-Plain           |
| 10          | 117-1240           | 2           | Washer             | 28          | 1-603807           | 2           | Spring-Return, Neutral |
| 11          | 119-8925           | 2           | Washer-Belleville  | 29          | 121-1753           | 2           | Pin-Rod, Hydro         |
| 12          | 117-1198           | 2           | Bolt-Pivot         | 31          | 321-3              | 2           | Screw-HH               |
| 13          | 3234-47            | 6           | Screw-HHF          | 32          | 3296-56            | 2           | Nut-Lock, NI           |
| 14          | 104-8300           | 10          | Nut-HF, NI         | 36          | 119-8876           | 2           | Spring-Return          |
| 15          | 119-8952           | 2           | Washer             | 37          | 119-8948           | 2           | Plate-Stop, Hydro      |

# Engine and Muffler Assembly




## Engine and Muffler Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>              | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|---------------------------------|-------------|--------------------|-------------|--------------------|
| 1           |                    | 1           | Engine-Kohler, Kt735-3084<br>●■ | 6           | 3256-24            | 3           | Washer-Flat        |
| 2           | 130-0676           | 1           | Muffler                         | 7           | 117-1261           | 1           | Hose-Drain, Oil    |
| 3           | 131-1071-03        | 1           | Shield-Heat                     | 8           | 614249             | 1           | Tie-Cable          |
| 4           | 46-8560            | 2           | Screw-HHFTF                     | 9           | 3274-10            | 4           | Screw-HSH          |
| 5           | 32144-109          | 4           | Screw-Thd                       | 10          | 3253-4             | 4           | Washer-Lock        |

● Not serviced separately

■ Obtain parts from [www.kohlerplus.com](http://www.kohlerplus.com)

# Body Styling and Fuel Tank Assembly




## Body Styling and Fuel Tank Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>        |
|-------------|--------------------|-------------|-------------------------|-------------|--------------------|-------------|---------------------------|
| 1           | 119-3335           | 1           | Pod-RH                  | 12          | 609830             | 2           | Spring                    |
| 2           | 137-7008           | 1           | Pod-LH                  | 13          | 131-1006           | 1           | Cable-Throttle            |
| 3           | 107069             | 3           | Clip                    | 14          | 112-9753           | 1           | Cable-Choke               |
| 4           | 119-3378-03        | 1           | Plate-Control           | 17          | 137-4119           | 1           | Cap-Fuel, Ratcheting      |
| 5           | 121-0772           | 1           | Decal-Panel, Control    | 19          | 119-8814           | 1           | Decal-Lever, Control (LH) |
| 7           | 119-3476-03        | 1           | Support-Tank, Front     | 20          | 119-8815           | 1           | Decal-Lever, Control (RH) |
| 8           | 32144-70           | 4           | Screw-HWHTF             | 25          | 109-0273           | 1           | Hose-Fuel                 |
| 9           | 119-3324           | 1           | Fuel Tank ASM           | 26          | 108-9698           | 1           | Hose-Fuel                 |
| 9:1         | 121-0793           | 1           | Connector-Elbow, 90 DEG | 27          | 2412-98            | 3           | Clamp-Hose                |
| 9:2         | 46-6560            | 2           | Bushing                 | 28          | 614249             | 3           | Tie-Cable ●               |
| 9:4         | 117-7400           | 1           | Fitting-Plastic         | 29          | 117-5399           | 1           | Adaptor-Orifice           |
| 10          | 3258-166           | 3           | Screw-PRH               | 30          | 110-1876           | 1           | Hose-Fuel                 |
| 11          | 120-7950           | 6           | Screw-Torx              | 31          | 3334-945           | 2           | Tie-Cable                 |

● Not illustrated

# Battery and Electrical Assembly




## Battery and Electrical Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 136-7482           | 1           | Harness-Wire       |
| 1:1:1       | 109103             | 1           | Fuse-Blade, 30 Amp |
| 1:1:2       | 109102             | 1           | Fuse-Blade, 25 Amp |
| 2           | 105-1692           | 1           | Battery            |
| 3           | 117-1197           | 1           | Solenoid           |
| 4           | 137-4100           | 1           | Switch-Ignition    |
| 5           | 63-8360            | 1           | Key-Ignition       |
| 6           | 103-5221           | 1           | Switch-PTO         |
| 7           | 110-6765           | 2           | Switch             |
| 9           | 32144-4            | 2           | Screw-HWH          |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|-------------------------|
| 10          | 3256-22            | 2           | Washer-Flat             |
| 11          | 321-3              | 1           | Screw-HH                |
| 12          | 3229-1             | 1           | Bolt-CARR               |
| 13          | 32128-33           | 2           | Nut-HF                  |
| 14          | 32103-22           | 1           | Nut-Wing                |
| 15          | 104-2466           | 1           | Holddown-Battery        |
| 16          | 3220-2             | 2           | Nut-Jam                 |
| 17          | 119-8897           | 1           | Cable-Battery, Red      |
| 18          | 121-0711           | 1           | Cable-Battery, Positive |
| 19          | 121-5726           | 1           | Cable-Battery, Black    |


# 50 Inch Deck Assembly



## 50 Inch Deck Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         |
|-------------|--------------------|-------------|---------------------|-------------|--------------------|-------------|----------------------------|
| 1           | 131-3614           | 1           | Deck And Decal ASM  | 31          | 32144-41           | 12          | Screw-Taptite              |
| 6           | 131-4138           | 1           | Bracket-Hanger, RH  | 32          | 117-7268           | 3           | Shaft-Spindle              |
| 7           | 131-1091           | 1           | Bracket-Hanger, LH  | 33          | 115-5059-03        | 3           | Blade-Hi Lift              |
| 8           | 3231-2             | 2           | Bolt-CARR           | 34          | 3290-465           | 3           | Washer-Belleville          |
| 9           | 120-7024           | 1           | Screw-Shoulder, HWH | 35          | 26-0671            | 3           | Screw-HH                   |
| 10          | 3230-22            | 5           | Screw-CARR          | 36          | 125-5575           | 3           | Pulley                     |
| 11          | 110-0618           | 1           | Pin-Clevis          | 37          | 3219-6             | 3           | Nut-Hex                    |
| 12          | 131-0955           | 1           | Rod-Level, Deck     | 38          | 110-9981           | 1           | Washer-Plain               |
| 13          | 104-8301           | 7           | Nut-HF, NI          | 39          | 120-2229           | 2           | Washer                     |
| 14          | 104-8300           | 8           | Nut-HF, NI          | 40          | 114-0463           | 2           | Washer-Friction, Composite |
| 15          | 3256-23            | 1           | Washer-Plain        | 41          | 115-4986           | 1           | Spacer                     |
| 16          | 1-806003           | 1           | Pin-Cotter          | 42          | 114-8540           | 1           | Arm-Idler                  |
| 17          | 108-7890           | 2           | Cover-Belt          | 43          | 132-9420           | 3           | Pulley-Idler, Flat         |
| 19          | 32144-4            | 4           | Screw-HWH           | 44          | 3256-24            | 2           | Washer-Flat                |
| 20          | 133-9289           | 2           | Fitting-Washout     | 45          | 323-9              | 4           | Screw-HH                   |
| 20:2        | 133-9290           | 1           | O-Ring              | 46          | 119-8820           | 1           | V-Belt                     |
| 23          | 95-3270            | 1           | Connector-Hose      | 47          | 1-603414           | 1           | Spring-Extension           |
| 24          | 131-3962           | 1           | Cover ASM W/Decal   | 48          | 112-3973           | 1           | Hook-Return, Spring        |
| 24:2        | 93-7009            | 1           | Decal-Danger        | 49          | 121-0739           | 1           | Deflector-Discharge        |
| 25          | 120-7951-03        | 1           | Baffle-Cutoff       | 50          | 121-2983           | 1           | Spring-Torsion             |
| 27          | 1-603299           | 3           | Roller-Scalp, Anti  | 52          | 112-3977           | 3           | Bolt-Shoulder              |
| 28          | 109-8854           | 1           | Pin-Chute           | 56          | 121-0792           | 1           | Decal-Deck                 |
| 30          | 121-0751           | 3           | Spindle ASM         | 57          | 32144-1            | 6           | Screw-Taptite              |
| 30:2        | 120-7935           | 2           | Spacer              | 68          | 322-2              | 2           | Screw-HH                   |
| 30:3        | 136-5441           | 2           | Bearing-Ball        |             |                    |             |                            |

# 50 Inch Deck and Decal Assembly No. 131-3614




## 50 Inch Deck and Decal Assembly No. 131-3614 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|---------------------|
| 3           | 93-7009            | 1           | Decal-Danger        |
| 4           | 132-0872           | 2           | Decal-Danger, Deck  |
| 5           | 99-3943            | 1           | Decal-Routing, Belt |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 7           | 112-9840           | 1           | Decal-Scalp, Anti  |
| 8           | 322-2              | 2           | Screw-HH           |
| 9           | 104-8300           | 2           | Nut-HF, NI         |


## Model Specific Decal Assembly



## Model Specific Decal Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 136-5578           | 1           | Decal-Timecutter   |


# HOC and Service Decal Assembly



## HOC and Service Decal Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 106-8717           | 1           | Decal-Service, CE  |
| 2           | 119-8871           | 1           | Decal-HOC          |

# Clutch Assembly



## Clutch Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|--------------------|
| 1           | 137-7000           | 1           | Stop-Clutch (Wide) | 5           | 104-8301           | 1           | Nut-HF, NI         |
| 2           | 130-6854           | 1           | Pulley-Engine      | 6           | 120-2217           | 1           | Isolator-Clutch    |
| 3           | 127-3408           | 1           | Clutch-PTO         | 7           | 3212-17            | 1           | Screw-HH           |
| 4           | 3234-42            | 1           | Screw-HHF          |             |                    |             |                    |

# Attachments and Accessories

## For 74773 TimeCutter MX 5000 Riding Mower

| Product Name                                   | Model/Part |
|------------------------------------------------|------------|
| Hourmeter Kit .....                            | 116-5461   |
| All Season Synthetic Oil (10W30, QT) .....     | 117-0066   |
| Bagging Enhancement Kit .....                  | 121-5692   |
| Striping Kit .....                             | 121-5706   |
| Jack Mount Kit .....                           | 126-5251   |
| Jack Kit .....                                 | 127-6666   |
| Fuel Stabilizer .05 oz .....                   | 130-2393   |
| 4-Cycle Fuel, Snow And Lawn 32oz Can .....     | 131-3823   |
| Attachment Mount Kit .....                     | 131-3966   |
| Toro Premium Fuel Treatment 12 Oz Bottle ..... | 131-6572   |
| Weight Kit .....                               | 131-7658   |
| 10w30 4-Cycle Engine Oil (32oz Bottle).....    | 38280      |
| Toro 4-Cycle SAE 30 Oil (32oz Bottle) .....    | 38903      |
| Storage Cover .....                            | 490-7516   |
| Blade Kit .....                                | 79016P     |
| 50in Recycler Kit.....                         | 79024      |
| 50in Bagger .....                              | 79395      |

**Notes:**

**Notes:**

**Notes:**



**Count on it.**