Form No. 3324–565

Dingo® Relief Valve Kit

Model No. 99–4360

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply: the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form **a:b.** The **a** represents the reference number of the entire service assembly and the **b** represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number **6**, the tire by **6:1**, the valve by **6:2**, and the wheel by **6:3**. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually.


Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form **nX y.** The **n** represents the quantity of the part, the **X** is the multiplication symbol, and the **y** represents the reference number.

For example, in an illustration, the reference number **2X 37** means that two of the parts identified by reference number 37 are indicated.

© The TORO Company — 2000
All Rights Reserved



Sheet No.:0
C–2815

Relief Valve Assembly

Ref. No.	Part No.	Qty.	Description
1	3296–29	2	Nut–Lock, NI
2	322–12	2	Screw–HH
*4	3290–379	2	Tie–Cable
7	340–82	2	Adapter
7:1	237–42	1	O–Ring
7:2	237–21	1	O–Ring
8	340–1	2	Adapter
8:1	237–35	1	O–Ring
8:2	237–42	1	O–Ring
10	100–4205	1	Valve–Relief, Crossover
10:1	100–4219	2	Kit–Seal, Buma
10:2	100–4220	1	Cartridge–Relief
10:3	100–4221	1	Cartridge–Relief
11	99–4361	1	Hose–ASM
15	99–4362	1	Hose–ASM

Ref. No.	Part No.	Qty.	Description

* Not Illustrated.